

---

## BOF Command Reference

---

### Command Hierarchies

#### Configuration Commands

```

bof
  — [no] address ip-prefix/ip-prefix-length [active | standby]
  — [no] autonegotiate
  — console-speed baud-rate
  — no console-speed
  — dns-domain dns-name
  — no dns-domain
  — duplex {full | half}
  — [no] li-local-save
  — [no] li-separate
  — persist {on | off}
  — primary-config file-url
  — no primary-config
  — primary-dns ip-address
  — no primary-dns
  — primary-image file-url
  — no primary-image
  — save [cflash-id ]
  — secondary-config file-url
  — no secondary-config
  — [no] secondary-dns ip-address
  — secondary-image file-url
  — no secondary-image
  — speed speed
  — [no] static-route ip-prefix/ip-prefix-length next-hop ip-address
  — tertiary-config file-url
  — no tertiary-config
  — [no] tertiary-dns ip-address
  — tertiary-image file-url
  — no tertiary-image
  — wait seconds

```

## Show Commands

- show**
- **bof** [*cf**flash-id* | *booted*]
- **boot-messages**