

Configuring Logging with CLI

This section provides information to configure logging using the command line interface.

Topics in this section include:

- [Basic Facility Alarm Configuration on page 606](#)
- [Common Configuration Tasks on page 607](#)

Basic Facility Alarm Configuration

The most facility alarm configuration must have the following:

- Log ID or accounting policy ID
- A log source
- A log destination

The following displays an alarm configuration example.

```
A:ALA-12>config>system# alarms
#-----
      no shutdown
      exit
-----
```

Common Configuration Tasks

The following sections are basic alarm tasks that can be performed.

- [Configuring the Maximum Number of Alarms To Clear on page 607](#)
-

Configuring the Maximum Number of Alarms To Clear

The number of alarms to clear can be configured using the command listed below.

Use the following CLI syntax to configure a log file:

CLI Syntax: `config>system
 alarms
 max-cleared max-alarms`

The following displays facility alarm configuration example:

```
ALA-12>config>system# alarms
-----
...
max-cleared 100
exit
...
-----
```

