
MLPPP Command Reference

Command Hierarchies

Configuration Commands

```

config
  — qos
    — mlppp-profile-egress profile-id [create]
    — no mlppp-profile-egress profile-id
      — class class-id
        — max-queue-size queue-size
        — no max-queue-size
        — mir mir-value
        — no mir
        — weight weight-value
        — no weight
      — description description-string
      — no description
      — fc-class mlppp-class class-id
      — no fc-class
    — mlppp-profile-ingress profile-id [create]
    — no mlppp-profile-ingress profile-id
      — class class-id
        — reassembly-timeout timeout-value
        — no reassembly-timeout
      — description description-string
      — no description

```

