
ATM QoS Policy Command Reference

Command Hierarchies

Configuration Commands

```

config
  — qos
    — [no] atm-td-profile traffic-desc-profile-id
      — [no] clp-tagging
      — description description-string
      — no description
      — descriptor-type type
      — [no] policing
      — service-category service-category
      — [no] shaping
      — traffic [sir sir-val] [pir pir-val] [mir mir-val] [mbs mbs-val] [cdvt cdvt-val]
      — no traffic
  
```

Operational Commands

```

config
  — qos
    — copy atm-td-profile src-prof dst-prof [overwrite]
  
```

Show Commands

```

show
  — qos
    — atm-td-profile [traffic-desc-profile-id] [detail]
  — service
    — sap-using [ingress | egress] atm-td-profile td-profile-id

show
  — port [port-id] atm [detail]
  — port [port-id] atm connections [detail]
  — port [port-id] atm interface-connections [detail]
  — port [port-id] atm pvc [vpi/vci] [detail]
  — port [port-id] atm pvp [vpi] [detail]
  — port [port-id] atm pvt [vpi-range] [detail]
  
```

