

Network Queue QoS Policy Command Reference

Command Hierarchies

- [Configuration Commands on page 141](#)
- [Operational Commands on page 142](#)
- [Show Commands on page 142](#)

Configuration Commands

```
config
  — qos
    — network-queue policy-name
      — description description-string
      — no description
      — egress-hsmda
        — [no] wrr-policy {add add-bytes | subtract sub-bytes}
        — [no] packet-byte-offset
        — [no] queue queue-id
          — [no] adaptation-rule [pir {min | max | closest}]
          — percent-rate percentage
          — wrr-weight value
          — mbs {size [bytes | kilobytes] | default}
          — slope-policy hsmda-slope-policy-name
        — [no] fc fc-name
          — multicast-queue queue-id
          — no multicast-queue
          — queue queue-id
          — no queue
          — egress-hsmda
            — [no] queue
      — queue queue-id [multipoint] [queue-type] [create]
      — no queue queue-id
        — adaptation-rule [pir adaptation-rule] [cir adaptation-rule]
        — no adaptation-rule
        — avg-frame-overhead percent
        — no avg-frame-overhead
        — cbs percent
        — no cbs
        — high-prio-only percent
        — no high-prio-only
        — mbs percent
        — no mbs
        — [no] pool pool-name [create]
        — pool-name
        — port-parent [weight weight] [level level] [cir-weight cir-weight] [cir-level cir-level] [cir-level level] [cir-weight weight]
        — no port-parent
        — rate percent [cir percent]
```

Command Hierarchies

— **no rate**

Operational Commands

config

— **qos**

— **copy network-queue** *src-name dst-name* [**overwrite**]

Show Commands

show

— **qos**

— **network-queue** [*network-queue-policy-name*] [**detail**]