

Network Queue QoS Policies

In This Section

This section provides information to configure network queue QoS policies using the command line interface.

Topics in this section include:

- [Overview on page 102](#)
- [Basic Configurations on page 103](#)
- [Default Network Queue Policy Values on page 109](#)
- [Service Management Tasks on page 115](#)

Overview

Network queue policies define the ingress network queuing at the XMAMDA network node level. Network queue policies are also used at the Ethernet port and SONET/SDH path level to define network egress queuing.

There is one default network queue policy. Each policy can have up to 16 queues (unicast and multicast). The default policies can be copied but they cannot be deleted or modified. The default policy is identified as **network-queue default**. Default network queue policies are applied to XMA/MDA network ingress ports. You must explicitly create and then associate other network queue QoS policies.

For information about the tasks and commands necessary to access the command line interface and to configure and maintain your devices, refer to CLI Usage chapter in the Basic System Configuration Guide.

Network Queue Parent Scheduler

Network queues support port scheduler parent priority-level associations. Using a port scheduler policy definition and mapping network queues to a port parent priority level, HQoS functionality is supported providing eight levels of strict priority and weights within the same priority. A network queue's bandwidth is allocated using the “within-cir” and “above-cir” scheme normal for port schedulers.

Queue CIR and PIR percentages when port-based schedulers are in effect will be based on frame-offered-load calculations.

A network queue with a port parent association exists on a port without a scheduler policy defined will be considered to be orphaned.

Refer to [QoS Scheduler Policies on page 541](#) for more information about queue parental association scope.

Basic Configurations

A basic network queue QoS policy must conform to the following:

- Each network queue QoS policy must have a unique policy name.
 - Queue parameters can be modified, but cannot be deleted.
-

Create a Network Queue QoS Policy

Configuring and applying QoS policies other than the default policy is optional. A default network queue policy is applied to MDA network ingress ports.

To create an network queue policy, define the following:

- Enter a network queue policy name. The system will not dynamically assign a name.
- Include a description. The description provides a brief overview of policy features.
- Forwarding class — You can assign a forwarding class to a specific queue.

Use the following CLI syntax to create a network queue QoS policy:

```
CLI Syntax: config>qos
    network-queue policy-name
        description description-string
        fc fc-name
            multicast-queue queue-id
            queue queue-id
        queue queue-id [multipoint] [queue-type]
            cbs percent
            high-prio-only percent
            mbs percent
            port-parent [weight weight] [level level] [cir-weight
                cir-weight] [cir-level cir-level]
            rate percent [cir percent]
```

```
A:ALA-1>config>qos# network-queue default
A:ALA-1>config>qos>network-queue# info detail
-----
        description "Default network queue QoS policy."
        queue 1 create
            mbs 50
            cbs 1
            high-prio-only 10
        exit
        queue 2 create
            rate 100 cir 25
            mbs 50
```

Basic Configurations

```
cbs 3
    high-prio-only 10
exit
queue 3 create
    rate 100 cir 25
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 4 create
    rate 100 cir 25
    mbs 25
    cbs 3
    high-prio-only 10
exit
queue 5 create
    rate 100 cir 100
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 6 create
    rate 100 cir 100
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 7 create
    rate 100 cir 10
    mbs 25
    cbs 3
    high-prio-only 10
exit
queue 8 create
    rate 100 cir 10
    mbs 25
    cbs 3
    high-prio-only 10
exit
queue 9 multipoint create
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 10 multipoint create
    rate 100 cir 5
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 11 multipoint create
    rate 100 cir 5
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 12 multipoint create
    rate 100 cir 5
    mbs 25
```

```
cbs 1
    high-prio-only 10
exit
queue 13 multipoint create
    rate 100 cir 100
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 14 multipoint create
    rate 100 cir 100
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 15 multipoint create
    rate 100 cir 10
    mbs 25
    cbs 1
    high-prio-only 10
exit
queue 16 multipoint create
    rate 100 cir 10
    mbs 25
    cbs 1
    high-prio-only 10
exit
fc af create
    multicast-queue 11
    queue 3
exit
fc be create
    multicast-queue 9
    queue 1
exit
fc ef create
    multicast-queue 14
    queue 6
exit
fc h1 create
    multicast-queue 15
    queue 7
exit
fc h2 create
    multicast-queue 13
    queue 5
exit
fc l1 create
    multicast-queue 12
    queue 4
exit
fc l2 create
    multicast-queue 10
    queue 2
exit
fc nc create
    multicast-queue 16
    queue 8
exit
```

Applying Network Queue Policies

Apply network queue policies to the following entities:

- MDAs
 - Ethernet Ports
 - SONET/SDH Ports
-

MDAs

Use the following CLI syntax to apply a network queue policy to an MDA network ingress port:

CLI Syntax: config>card
 mda *mda-slot*
 network
 ingress
 queue-policy *name*

The following output displays MDA network ingress queue policy reverted to the default policy.

```
A:ALA-7>config>card>mda# info
-----
      mda-type m60-10/100eth-tx
      network
          ingress
              pool default
                  resv-cbs sum
                  slope-policy "default"
              exit
              queue-policy "default"
          exit
          egress
              pool default
                  resv-cbs sum
                  slope-policy "default"
              exit
          exit
      access
          ingress
              pool default
                  resv-cbs sum
                  slope-policy "default"
              exit
          exit
          egress
              pool default
                  resv-cbs sum
```

```
        slope-policy "default"
    exit
exit
exit
no shutdown
-----
A:ALA-7>config>card>mda#
```

Ethernet Ports

Use the following CLI syntax to apply a network queue policy to an Ethernet port.

CLI Syntax: config>port#
 ethernet
 network
 queue-policy *name*
A:ALA-49>config>port# info

 ethernet
 network
 queue-policy "nql1"
 exit
 exit
 no shutdown

A:ALA-49>config>port#

SONET/SDH Ports

Use the following CLI syntax to apply a network queue policy to a SONET/SDH port:

CLI Syntax: config>port#
 sonet-sdh
 path *path*
 network
 queue-policy *name*

The following output displays the port configuration.

```
A:ALA-48>config>port# info
-----
description "OC-12 SONET/SDH"
sonet-sdh
path sts3
network
queue-policy "nql"
exit
no shutdown
exit
exit
no shutdown
-----
A:ALA-48>config>port#
```

Default Network Queue Policy Values

The default network queue policies are identified as policy-id **default**. The default policies cannot be modified or deleted. The following displays default policy parameters:

Table 23: Network Queue Policy Defaults

Field	Default
description	"Default network queue QoS policy."
queue 1	
pir	100
cir	0
mbs	50
cbs	1
high-prio-only	10
queue 2	
pir	100
cir	25
mbs	50
cbs	3
high-prio-only	10
queue 3	
pir	100
cir	25
mbs	50
cbs	1
high-prio-only	10
queue 4	
pir	100
cir	25

Default Network Queue Policy Values

Table 23: Network Queue Policy Defaults (Continued)

Field	Default
mbs	25
cbs	3
high-prio-only	10
queue 5	
pir	100
cir	100
mbs	50
cbs	1
high-prio-only	10
queue 6	
pir	100
cir	100
mbs	50
cbs	1
high-prio-only	10
queue 7	
pir	100
cir	10
mbs	25
cbs	3
high-prio-only	10
queue 8	
pir	100
cir	10
mbs	50
cbs	3

Table 23: Network Queue Policy Defaults (Continued)

Field	Default
high-prio-only	10
fc af	queue 3 multicast-queue 11
fc be	queue 1 multicast-queue 9
fc ef	queue 6 multicast-queue 14
fc h1	queue 67 multicast-queue 15
fc h2	queue 5 multicast-queue 13
fc l1	queue 7 multicast-queue 12
fc l2	queue 2 multicast-queue 10
fc nc	queue 8 multicast-queue 16

Default Network Queue Policy Values

```
A:ALA-7>config>qos>network-queue# info detail
-----
description "Default network queue QoS policy."
queue 1 auto-expedite create
    rate 100 cir 0
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 2 auto-expedite create
    rate 100 cir 25
    mbs 50
    cbs 3
    high-prio-only 10
exit
queue 3 auto-expedite create
    rate 100 cir 25
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 4 auto-expedite create
    rate 100 cir 25
    mbs 25
    cbs 3
    high-prio-only 10
exit
queue 5 auto-expedite create
    rate 100 cir 100
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 6 auto-expedite create
    rate 100 cir 100
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 7 auto-expedite create
    rate 100 cir 10
    mbs 25
    cbs 3
    high-prio-only 10
exit
queue 8 auto-expedite create
    rate 100 cir 10
    mbs 25
    cbs 3
    high-prio-only 10
exit
queue 9 multipoint auto-expedite create
    rate 100 cir 0
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 10 multipoint auto-expedite create
    rate 100 cir 5
```

```
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 11 multipoint auto-expedite create
    rate 100 cir 5
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 12 multipoint auto-expedite create
    rate 100 cir 5
    mbs 25
    cbs 1
    high-prio-only 10
exit
queue 13 multipoint auto-expedite create
    rate 100 cir 100
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 14 multipoint auto-expedite create
    rate 100 cir 100
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 15 multipoint auto-expedite create
    rate 100 cir 10
    mbs 25
    cbs 1
    high-prio-only 10
exit
queue 16 multipoint auto-expedite create
    rate 100 cir 10
    mbs 25
    cbs 1
    high-prio-only 10
exit
fc af create
    multicast-queue 11
    queue 3
exit
fc be create
    multicast-queue 9
    queue 1
exit
fc ef create
    multicast-queue 14
    queue 6
exit
fc h1 create
    multicast-queue 15
    queue 7
exit
fc h2 create
    multicast-queue 13
    queue 5
```

Default Network Queue Policy Values

```
exit
fc 11 create
    multicast-queue 12
    queue 4
exit
fc 12 create
    multicast-queue 10
    queue 2
exit
fc nc create
    multicast-queue 16
    queue 8
exit
-----
A:ALA-7>config>qos>network-queue#
exit
```

Service Management Tasks

This section discusses the following service management tasks:

- [Deleting QoS Policies on page 115](#)
- [Remove a Policy from the QoS Configuration on page 115](#)
- [Copying and Overwriting QoS Policies on page 116](#)
- [Editing QoS Policies on page 121](#)

Deleting QoS Policies

A network queue policy is associated by default with MDA network ingress ports. You can replace the default policy with a customer-configured policy, but you cannot entirely remove a QoS policy. When you remove a QoS policy, the policy association reverts to the default network-queue policy **default**.

To delete a user-created network queue policy, enter the following commands:

CLI Syntax: config>qos# no network-queue *policy-name*

Example: config>qos# no network-queue *nq1*

Remove a Policy from the QoS Configuration

To delete a network policy, enter the following commands:

CLI Syntax: config>qos# no network-queue *policy-name*

Example: config>qos# no network-queue *test*

Copying and Overwriting QoS Policies

You can copy an existing network queue policy, rename it with a new policy ID name, or overwrite an existing network queue policy. The `overwrite` option must be specified or an error occurs if the destination policy ID exists.

CLI Syntax: config>qos# copy network-queue *source-policy-id* *dest-policy-id* [overwrite]

Example: config>qos# copy network-queue **nq1 nq2**

The following output displays the copied policies:

```
A:ALA-12>config>qos# info
-----
echo "QoS Slope/Queue Policies Configuration"
-----
...
    network-queue "nq1" create
        description "Default network queue QoS policy."
        queue 1 create
            mbs 50
            cbs 1
            high-prio-only 10
        exit
        queue 2 create
            rate 100 cir 25
            mbs 50
            cbs 3
            high-prio-only 10
        exit
        queue 3 create
            rate 100 cir 25
            mbs 50
            cbs 1
            high-prio-only 10
        exit
        queue 4 create
            rate 100 cir 25
            mbs 25
            cbs 3
            high-prio-only 10
        exit
        queue 5 create
            rate 100 cir 100
            mbs 50
            cbs 1
            high-prio-only 10
        exit
        queue 6 create
            rate 100 cir 100
            mbs 50
            cbs 1
            high-prio-only 10
    exit
```

```
queue 7 create
    rate 100 cir 10
    mbs 25
    cbs 3
    high-prio-only 10
exit
queue 8 create
    rate 100 cir 10
    mbs 25
    cbs 3
    high-prio-only 10
exit
queue 9 multipoint create
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 10 multipoint create
    rate 100 cir 5
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 11 multipoint create
    rate 100 cir 5
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 12 multipoint create
    rate 100 cir 5
    mbs 25
    cbs 1
    high-prio-only 10
exit
queue 13 multipoint create
    rate 100 cir 100
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 14 multipoint create
    rate 100 cir 100
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 15 multipoint create
    rate 100 cir 10
    mbs 25
    cbs 1
    high-prio-only 10
exit
queue 16 multipoint create
    rate 100 cir 10
    mbs 25
    cbs 1
    high-prio-only 10
exit
```

Copying and Overwriting QoS Policies

```
fc af create
    multicast-queue 11
        queue 3
exit
fc be create
    multicast-queue 9
        queue 1
exit
fc ef create
    multicast-queue 14
        queue 6
exit
fc h1 create
    multicast-queue 15
        queue 7
exit
fc h2 create
    multicast-queue 13
        queue 5
exit
fc l1 create
    multicast-queue 12
        queue 4
exit
fc l2 create
    multicast-queue 10
        queue 2
exit
fc nc create
    multicast-queue 16
        queue 8
exit
exit
network-queue "nq2" create
    description "Default network queue QoS policy."
    queue 1 create
        mbs 50
        cbs 1
        high-prio-only 10
exit
    queue 2 create
        rate 100 cir 25
        mbs 50
        cbs 3
        high-prio-only 10
exit
    queue 3 create
        rate 100 cir 25
        mbs 50
        cbs 1
        high-prio-only 10
exit
    queue 4 create
        rate 100 cir 25
        mbs 25
        cbs 3
        high-prio-only 10
exit
    queue 5 create
```

```
rate 100 cir 100
mbs 50
cbs 1
high-prio-only 10
exit
queue 6 create
    rate 100 cir 100
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 7 create
    rate 100 cir 10
    mbs 25
    cbs 3
    high-prio-only 10
exit
queue 8 create
    rate 100 cir 10
    mbs 25
    cbs 5
    high-prio-only 10
exit
queue 9 multipoint create
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 10 multipoint create
    rate 100 cir 5
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 11 multipoint create
    rate 100 cir 5
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 12 multipoint create
    rate 100 cir 5
    mbs 25
    cbs 1
    high-prio-only 10
exit
queue 13 multipoint create
    rate 100 cir 100
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 14 multipoint create
    rate 100 cir 100
    mbs 50
    cbs 1
    high-prio-only 10
exit
queue 15 multipoint create
```

Copying and Overwriting QoS Policies

```
rate 100 cir 10
mbs 25
cbs 1
high-prio-only 10
exit
queue 16 multipoint create
    rate 100 cir 10
    mbs 25
    cbs 1
    high-prio-only 10
exit
fc af create
    multicast-queue 11
    queue 3
exit
fc be create
    multicast-queue 9
    queue 1
exit
fc ef create
    multicast-queue 14
    queue 6
exit
fc h1 create
    multicast-queue 15
    queue 7
exit
fc h2 create
    multicast-queue 13
    queue 5
exit
fc l1 create
    multicast-queue 12
    queue 4
exit
fc l2 create
    multicast-queue 10
    queue 2
exit
fc nc create
    multicast-queue 16
    queue 8
exit
exit
...
-----
A:ALA-12>config>qos#
```

Editing QoS Policies

You can change existing policies, except the default policies, and entries in the CLI. The changes are applied immediately to all interfaces where the policy is applied. To prevent configuration errors use the copy command to make a duplicate of the original policy to a work area, make the edits, and then overwrite the original policy.

