

7750 SR OS Router Configuration Guide

Software Version: 7750 SR OS 8.0 Rev. 01 February 2010 Document Part Number: 93-0073-07-01

his document is protected by copyright. Except as specifically permitted herein, no portion of the provided information can be reproduced in any form, or by any means, without prior written permission from Alcatel-Lucent.

Alcatel, Lucent, Alcatel-Lucent and the Alcatel-Lucent logo are trademarks of Alcatel-Lucent. All other trademarks are the property of their respective owners.

The information presented is subject to change without notice.

Alcatel-Lucent assumes no responsibility for inaccuracies contained herein.

Copyright 2010 Alcatel-Lucentt. All rights reserved.

G	etting Started	
	Alcatel-Lucent 7750 SR-Series Router Configuration Process1	7
IP	Router Configuration	
	Configuring IP Router Parameters	0
	Interfaces	
	Network Interface	0
	Network Domains	1
	System Interface	2
	Unicast RPF (uRPF)	2
	IP Addresses	
	Creating an IP Address Range	4
	Router ID	
	Autonomous Systems (AS)	5
	Confederations	
	Proxy ARP	
	DHCP Relay	
	Internet Protocol Versions	
	IPv6 Applications	
	DNS	
	IPv6 Provider Edge Router over MPLS (6PE)	
	Bidirectional Forwarding Detection	
	BFD Control Packet	
	Control Packet Format	
	BFD for RSVP-TE	
	IOM Scale	
	Echo Support	
	BFD Support for BGP	
	Centralized BFD	
	Process Overview.	
	Configuration Notes	
	Configuring an IP Router with CLI	
	Router Configuration Overview.	
	System Interface	
	Network Interface	
	Basic Configuration	
	Common Configuration Tasks	
	Configuring a System Name	
	Configuring Interfaces	
	Configuring a System Interface	
	Configuring a Network Interface	
	Configuring IPv6 Over IPv4 Parameters	
	Tunnel Ingress Node	
	Tunnel Egress Node	
		-

63
64
67
68
72
72
74
75
76
76
77
78
79
91
91
92
05
18
49
55
00
19
25

VRRP

VRRP Overview	 232
VRRP Components	 233
Virtual Router.	 233
IP Address Owner	 233
Primary and Secondary IP Addresses.	 234
Virtual Router Master.	
Virtual Router Backup	
Owner and Non-Owner VRRP	
Configurable Parameters	
Virtual Router ID (VRID)	
Priority	
IP Addresses	
Message Interval and Master Inheritance	 238
Skew Time	
Master Down Interval	 239
Preempt Mode	
VRRP Message Authentication	
Authentication Data	
Virtual MAC Address	 242
VRRP Advertisement Message IP Address List Verification	
Inherit Master VRRP Router's Advertisement Interval Timer	
IPv6 Virtual Router Instance Operationally Up.	
Policies	
VRRP Priority Control Policies	

VRRP Virtual Router Policy Constraints	
VRRP Virtual Router Instance Base Priority	
VRRP Priority Control Policy Delta In-Use Priority Limit	
VRRP Priority Control Policy Priority Events	
Priority Event Hold-Set Timers	
Port Down Priority Event	
LAG Degrade Priority Event	
Host Unreachable Priority Event	
Route Unknown Priority Event	
VRRP Non-Owner Accessibility	
Non-Owner Access Ping Reply	
Non-Owner Access Telnet.	
Non-Owner Access SSH	
VRRP Configuration Process Overview	
Configuration Notes	
General	
Configuring VRRP with CLI	
VRRP Configuration Overview	
Preconfiguration Requirements	
Basic VRRP Configurations	
VRRP Policy	
VRRP IES Service Parameters	
VRRP Router Interface Parameters	
Common Configuration Tasks	
Creating Interface Parameters	
Configuring VRRP Policy Components	
Configuring Service VRRP Parameters	263
Non-Owner VRRP Example	263
Owner Service VRRP	264
Configuring Router Interface VRRP Parameters	265
Router Interface VRRP Non-Owner	265
Router Interface VRRP Owner	266
VRRP Configuration Management Tasks	267
Modifying a VRRP Policy	267
Deleting a VRRP Policy	
Modifying Service and Interface VRRP Parameters	269
Modifying Non-Owner Parameters	
Modifying Owner Parameters	269
Deleting VRRP on an Interface or Service	269
VRRP Command Reference.	271
Configuration Commands	277
Interface Configuration Commands	
Priority Policy Commands	
Priority Policy Event Commands	
Priority Policy Port Down Event Commands	
Priority Policy LAG Events Commands	
Priority Policy Host Unreachable Event Commands	
Priority Policy Route Unknown Event Commands	
Show Commands	

Monitor Commands	328
Clear Commands	
VRRP Debug Commands.	
Filter Policies	
Filter Policy Configuration Overview	334
Service and Network Port-Based Filtering.	334
Filter Policy Entities	
Applying Filter Policies	
Redirect Policies	
Web Redirection (Captive Portal).	
Creating and Applying Policies.	
Packet Matching Criteria	
Ordering Filter Entries	
Applying Filters.	
Configuration Notes	
MAC Filters	
IP Filters	
IPv6 Filters.	
Log Filter	
Configuring Filter Policies with CLI	
Basic Configuration	
Common Configuration Tasks	
Creating an IP Filter Policy	
IP Filter Policy	
IP Filter Entry	
IP Entry Matching Criteria	
Creating an IPv6 Filter Policy	
IPv6 Filter Policy.	
IPv6 Filter Entry	
Creating a MAC Filter Policy	
MAC Filter Policy	
Creating an ISID Filter.	
MAC Filter Entry	
MAC Entry Matching Criteria	
Creating Filter Log Policies	
Applying Filter Policies	
Apply IP and MAC Filter Policies	
Apply an IPv6 Filter Policy to an IES SAP	371
Apply Filter Policies to a Network Port	
Apply an IP Interface	
Apply an IPv6 Interface	
Creating a Redirect Policy	
Configuring Policy-Based Forwarding for Deep Packet Inspection in VPLS	
Filter Management Tasks	
Renumbering Filter Policy Entries	
Modifying an IP Filter Policy	
Modifying an IPv6 Filter Policy	
Modifying a MAC Filter Policy	

Deleting a Filter Policy	.384
From an Ingress SAP	.384
From an Egress SAP	.384
From a Network Interface	.385
From the Filter Configuration	.388
Modifying a Redirect Policy	.389
Deleting a Redirect Policy	.390
Copying Filter Policies	.391
Filter Command Reference.	
Configuration Commands	
Generic Commands	
Global Filter Commands	
Filter Log Destination Commands	
Filter Policy Commands	
General Filter Entry Commands	
IP Filter Entry Commands	
MAC Filter Entry Commands	
IP Filter Match Criteria	.417
MAC Filter Match Criteria	.425
Policy and Entry Maintenance Commands	
Redirect Policy Commands	
Show Commands	
Clear Commands	.467
Monitor Commands	.469

Cflowd

Cflowd Overview	472
Operation	
Version 9	
Cflowd Filter Matching	
Cflowd Configuration Process Overview	
Configuration Notes	
Configuring Cflowd with CLI	
Cflowd Configuration Overview	
Traffic Sampling.	
Collectors	
Aggregation	
Basic Cflowd Configuration.	
Common Configuration Tasks	
Global Cflowd Components.	
Configuring Cflowd	
Enabling Cflowd.	
Configuring Global Cflowd Parameters	
Configuring Cflowd Collectors	
Enabling Cflowd on Interfaces and Filters	
Specifying Cflowd Options on an IP Interface	
Interface Configurations	
5	
Service Interfaces.	
Specifying Sampling Options in Filter Entries	

Filter Configurations	
Filter Configurations	
Cflowd Configuration Management Tasks	
Modifying Global Cflowd Components	
Modifying Cflowd Collector Parameters	
Cflowd Command Reference	
Cflowd Configuration Commands	
Global Commands	
Show Commands	
Clear Commands	
Common CLI Command Descriptions	
Common Service Commands.	
Standards and Protocol Support	
ndex	

List of Tables

Getting St	
Table 1:	Configuration Process
IP Router	Configuration
Table 2:	IPv6 Header Field Descriptions
Table 3:	BFD Control Packet Field Descriptions
Table 4:	Default Route Preferences
VRRP	
Table 5:	LAG Events
Table 6:	Show VRRP Statistics Output
Filter Poli	
Table 7:	Applying Filter Policies
Table 8:	DSCP Name to DSCP Value Table
Table 9:	IP Option Values
Table 10:	MAC Match Criteria Exclusivity Rules
Table 11:	Applying Filter Policies
Cflowd	
Table 12:	Cflowd Configuration Dependencies
Table 13:	Show Cflowd Collector Output Fields
Table 14:	Show Cflowd Collector Detailed Output Fields
Table 15:	Show Cflowd Status Output Fields

List of Tables

LIST OF FIGURES

IP Router Configuration

Figure 1:	Confederation Configuration
Figure 2:	IPv6 Header Format
Figure 3:	IPv6 Internet Exchange
Figure 4:	IPv6 Transit Services
Figure 5:	IPv6 Services to Enterprise Customers and Home Users
Figure 6:	IPv6 over IPv4 Tunnels
Figure 7:	Example of a 6PE Topology within One AS
Figure 8:	Mandatory Frame Format
Figure 9:	BFD for IES/VPRN over Spoke SDP41
Figure 10:	BFD over LAG
VRRP	
Figure 11:	VRRP Configuration
Figure 12:	VRRP Configuration and Implementation Flow
Filter Polic	ies
Figure 13:	Web Redirect Traffic Flow
Figure 14:	Filter Creation and Implementation Flow
Figure 15:	Creating and Applying Filter Policies
Figure 16:	Filtering Process Example
Figure 17:	Applying an IP Filter to an Ingress Interface
Figure 18:	Policy-Based Forwarding for Deep Packet Inspection
Cflowd	
Figure 19:	Basic Cflowd Steps
Figure 20:	V5, V8 and Flow Processing
Figure 21:	Cflowd Configuration and Implementation Flow

List of Figures

Preface

About This Guide

This guide describes logical IP routing interfaces, virtual routers, IP and MAC-based filtering, and cflowd support provided by the 7750 SR OS and presents configuration and implementation examples.

This document is organized into functional chapters and provides concepts and descriptions of the implementation flow, as well as Command Line Interface (CLI) syntax and command usage.

Audience

This manual is intended for network administrators who are responsible for configuring the 7750 SR-Series routers. It is assumed that the network administrators have an understanding of networking principles and configurations. Protocols, standards, and services described in this manual include the following:

- IP router configuration
- Virtual routers
- IP and MAC-based filters
- Cflowd

List of Technical Publications

The 7750 SR documentation set is composed of the following books:

• 7750 SR OS Basic System Configuration Guide

This guide describes basic system configurations and operations.

• 7750 SR OS System Management Guide

This guide describes system security and access configurations as well as event logging and accounting logs.

• 7750 SR OS Interface Configuration Guide

This guide describes card, Media Dependent Adapter (MDA), and port provisioning.

• 7750 SR OS Router Configuration Guide

This guide describes logical IP routing interfaces and associated attributes such as an IP address, port, link aggregation group (LAG) as well as IP and MAC-based filtering, VRRP, and Cflowd.

• 7750 SR OS Routing Protocols Guide

This guide provides an overview of routing concepts and provides configuration examples for RIP, OSPF, IS-IS, Multicast, BGP, and route policies.

• 7750 SR OS MPLS Guide

This guide describes how to configure Multiprotocol Label Switching (MPLS) and Label Distribution Protocol (LDP).

• 7750 SR OS Services Guide

This guide describes how to configure service parameters such as service distribution points (SDPs), customer information, and user services.

• 7750 SR OS OAM and Diagnostic Guide

This guide describes how to configure features such as service mirroring and Operations, Administration and Management (OAM) tools.

• 7750 SR OS Triple Play Guide

This guide describes Triple Play services and support provided by the 7750 SR and presents examples to configure and implement various protocols and services.

• 7750 SR Quality of Service Guide

This guide describes how to configure Quality of Service (QoS) policy management.

• OS Multi-Service ISA Guide

This guide describes services provided by integrated service adapters such as Application Assurance, IPSec, ad insertion (ADI) and Network Address Translation (NAT).

Technical Support

If you purchased a service agreement for your router and related products from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance. If you purchased an Alcatel-Lucent service agreement, contact your welcome center at:

Web: http://www1.alcatel-lucent.com/comps/pages/carrier_support.jhtml

Preface

Getting Started

In This Chapter

This chapter provides process flow information to configure routing entities, virtual routers, IP and MAC filters, and Cflowd.

Alcatel-Lucent 7750 SR-Series Router Configuration Process

Table 1 lists the tasks necessary to configure logical IP routing interfaces, virtual routers, IP and MAC-based filtering, and Cflowd.

This guide is presented in an overall logical configuration flow. Each section describes a software area and provides CLI syntax and command usage to configure parameters for a functional area.

Area	Task	Chapter
Router configuration	Configure router parameters, including router interfaces and addresses, router IDs, autonomous systems, and confederations.	IP Router Configuration on page 19
Protocol configura- tion	VRRP	VRRP on page 231
	IP and MAC filters	Filter Policies on page 333
	Cflowd	Cflowd on page 471
Reference	List of IEEE, IETF, and other proprietary entities.	Standards and Protocol Support on page 523

Table 1: Configuration Process

7750 SR OS Router Configuration Guide

Getting Started

IP Router Configuration

In This Chapter

This chapter provides information about commands required to configure basic router parameters.

Topics in this chapter include:

- Configuring IP Router Parameters on page 20
 - \rightarrow Interfaces on page 20
 - \rightarrow Router ID on page 24
 - \rightarrow Autonomous Systems (AS) on page 25
 - \rightarrow Confederations on page 26
 - \rightarrow Proxy ARP on page 28
- Configuration Notes on page 44

Configuring IP Router Parameters

In order to provision services on a 7750 SR-Series router, logical IP routing interfaces must be configured to associate attributes such as an IP address, port or the system with the IP interface.

A special type of IP interface is the system interface. A system interface must have an IP address with a 32-bit subnet mask. The system interface is used as the router identifier by higher-level protocols such as OSPF and BGP, unless overwritten by an explicit router ID.

The following router features can be configured:

- Interfaces on page 20
- IP Addresses on page 24
- Router ID on page 24
- Autonomous Systems (AS) on page 25
- Confederations on page 26
- DHCP Relay on page 28
- Internet Protocol Versions on page 29

Interfaces

7750 SR-Series routers use different types of interfaces for various functions. Interfaces must be configured with parameters such as the interface type (network and system) and address. A port is not associated with a system interface. An interface can be associated with the system (loopback address).

Network Interface

A network interface (a logical IP routing interface) can be configured on one of the following entities:

- A physical or logical port
- A SONET/SDH channel

Network Domains

In order to determine which network ports (and hence which network complexes) are eligible to transport traffic of individual SDPs, network-domain is introduced. This information is then used for the sap-ingress queue allocation algorithm applied to VPLS SAPs. This algorithm is optimized in such a way that no sap-ingress queues are allocated if the given port does not belong to the network-domain used in the given VPLS. In addition, sap-ingress queues will not be allocated towards network ports (regardless of the network-domain membership) if the given VPLS does not contain any SDPs.

Sap-ingress queue allocation takes into account the following aspects:

- SHG membership of individual SDPs
- Network-domain definition under SDP to restrict the topology the given SDP can be setup in

The implementation supports four network-domains within any given VPLS.

Network-domain configuration at the SDP level is ignored when the given SDP is used for E-PIPE, I-PIPE or A-PIPE bindings.

Network-domain configuration is irrelevant for L3 services (L3 VPN and/or IES service). It can be defined in the base routing context and associated only with network interfaces in this context. Network domains are not applicable to loopback and system interfaces.

The network-domain information will only be used for ingress VPLS sap queue-allocation. It will not be taken into account by routing during SDP setup. As a consequence, if the given SDP is routed through network interfaces that are not part of the configured network domain, the packets will be still forwarded, but their QoS and queuing behavior will be based on default settings. In addition, the packet will not appear in SAP stats.

There will be always one network-domain that exists with reserved name default. The interfaces will always belong to a default network-domain. It will be possible to assign given interface to different user-defined network-domains. The loopback and system interface will be also associated with the default network-domain at the creation. However, any attempt to associate such interfaces with any explicitly defined network-domain will be blocked at the CLI level as there is no benefit for that association.

Any SDP can be assigned only to one network domain. If none is specified, the system will assign the default network-domain. This means that all SAPs in VPLS will have queue reaching all fwd-complexes serving interfaces that belong to the same network-domains as the SDPs.

It is possible to assign/remove network-domain association of the interface/SDP without requiring deletion of the respective object.

System Interface

The system interface is associated with the network entity (such as a specific router or switch), not a specific interface. The system interface is also referred to as the loopback address. The system interface is associated during the configuration of the following entities:

- The termination point of service tunnels
- The hops when configuring MPLS paths and LSPs
- The addresses on a target router for BGP and LDP peering

The system interface is used to preserve connectivity (when routing reconvergence is possible) when an interface fails or is removed. The system interface is also referred to as the loopback address and is used as the router identifier. A system interface must have an IP address with a 32-bit subnet mask.

Unicast RPF (uRPF)

uRPF helps to mitigate problems that are caused by the introduction of malformed or forged (spoofed) IP source addresses into a network by discarding IP packets that lack a verifiable IP source address. For example, a number of common types of denial-of-service (DoS) attacks, including smurf and tribe flood network (TFN), can take advantage of forged or rapidly changing source IP addresses to allow attackers to thwart efforts to locate or filter the attacks. For Internet service providers (ISPs) that provide public access, Unicast RPF deflects such attacks by forwarding only packets that have source addresses that are valid and consistent with the IP routing table. This action protects the network of the ISP, its customer, and the rest of the Internet.

In strict mode, uRPF checks whether the incoming packet has a source address that matches a prefix in the routing table, and whether the interface expects to receive a packet with this source address prefix.

In loose mode, uRPF checks whether the packet has a source address with a corresponding prefix in the routing table; loose mode does not check whether the interface expects to receive a packet with a specific source address prefix.

Loose uRPF check is supported for ECMP, IGP shortcuts and VPRN MP-BGP routes. Packets coming from a source that matches any ECMP, IGP shortcut or VPRN MP-BGP route will pass the uRPF check even when the uRPF mode is set to strict mode on the incoming interface.

If there is a default route in the router and the packets are coming from the interface that the default route is pointing to, the following can occur:

- If uRPF is in loose mode, uRPF check succeeds.
 - \rightarrow If uRPF is in strict mode, then:
 - uRPF check succeeds if one of the following is true:
 - The source IP address of the packet matches any of the routes that can be originated from this specific interface.
 - The source IP address of the packet doesn't match any specific routes in the forwarding table.
 - \rightarrow uRPF check fails if the following is true:
 - The source IP address of the packet matches a route in the forwarding table, but the next-hop of the route is not on this specific interface.

If the source IP address matches a discard/blackhole route, the packet is treated as if it failed uRPF check.

IP Addresses

Creating an IP Address Range

An IP address range can be reserved for exclusive use for services by defining the **config>router>service-prefix** command. When the service is configured, the IP address must be in the range specified as a service prefix. If no service prefix command is configured, then no limitation exists.

Addresses in the range of a service prefix can be allocated to a network port unless the *exclusive* parameter is used. Then, the address range is exclusively reserved for services.

When defining a range that is a superset of a previously defined service prefix, the subset will be replaced with the superset definition. For example, if a service prefix exists for 10.10.10.0/24, and a new service prefix is configured as 10.10.0.0/16, then the old address (10.10.10.0/24) will be replaced with the new address (10.10.0.0/16).

When defining a range that is a subset of a previously defined service prefix, the subset will replace the existing superset, providing addresses used by services are not affected; for example, if a service prefix exists for 10.10.0.0/16, and a new service prefix is configured as 10.10.10.0/24, then the 10.10.0.0/16 entry will be removed, provided that no services are configured that use 10.10.x.x addresses other than 10.10.10.x.x

Router ID

The router ID, a 32-bit number, uniquely identifies the router within an autonomous system (AS) (see Autonomous Systems (AS) on page 25). In protocols such as OSPF, routing information is exchanged between areas, groups of networks that share routing information. It can be set to be the same as the loopback address. The router ID is used by both OSPF and BGP routing protocols in the routing table manager instance.

There are several ways to obtain the router ID. On each 7750 SR-Series router, the router ID can be derived in the following ways.

- Define the value in the config>router router-id context. The value becomes the router ID.
- Configure the system interface with an IP address in the **config**>router>interface *ip-int-name* context. If the router ID is not manually configured in the **config**>router *router-id* context, then the system interface acts as the router ID.
- If neither the system interface or router ID are implicitly specified, then the router ID is inherited from the last four bytes of the MAC address.
- The router can be derived on the protocol level; for example, BGP.

Autonomous Systems (AS)

Networks can be grouped into areas. An area is a collection of network segments within an AS that have been administratively assigned to the same group. An area's topology is concealed from the rest of the AS, which results in a significant reduction in routing traffic.

Routing in the AS takes place on two levels, depending on whether the source and destination of a packet reside in the same area (intra-area routing) or different areas (inter-area routing). In intraarea routing, the packet is routed solely on information obtained within the area; no routing information obtained from outside the area can be used. This protects intra-area routing from the injection of bad routing information.

Routers that belong to more than one area are called area border routers. All routers in an AS do not have an identical topological database. An area border router has a separate topological database for each area it is connected to. Two routers, which are not area border routers, belonging to the same area, have identical area topological databases.

Autonomous systems share routing information, such as routes to each destination and information about the route or AS path, with other ASs using BGP. Routing tables contain lists of next hops, reachable addresses, and associated path cost metrics to each router. BGP uses the information and path attributes to compile a network topology.

Confederations

Configuring confederations is optional and should only be implemented to reduce the IBGP mesh inside an AS. An AS can be logically divided into smaller groupings called sub-confederations and then assigned a confederation ID (similar to an autonomous system number). Each sub-confederation has fully meshed IBGP and connections to other ASs outside of the confederation.

The sub-confederations have EBGP-type peers to other sub-confederations within the confederation. They exchange routing information as if they were using IBGP. Parameter values such as next hop, metric, and local preference settings are preserved. The confederation appears and behaves like a single AS.

Confederations have the following characteristics.

- A large AS can be sub-divided into sub-confederations.
- Routing within each sub-confederation is accomplished via IBGP.
- EBGP is used to communicate *between* sub-confederations.
- BGP speakers within a sub-confederation must be fully meshed.
- Each sub-confederation (member) of the confederation has a different AS number. The AS numbers used are typically in the private AS range of 64512 65535.

To migrate from a non-confederation configuration to a confederation configuration requires a major topology change and configuration modifications on each participating router. Setting BGP policies to select an optimal path through a confederation requires other BGP modifications.

There are no default confederations. Router confederations must be explicitly created. Figure 1 depicts a confederation configuration example.




Figure 1: Confederation Configuration

Proxy ARP

Proxy ARP is the technique in which a router answers ARP requests intended for another node. The router appears to be present on the same network as the "real" node that is the target of the ARP and takes responsibility for routing packets to the "real" destination. Proxy ARP can help nodes on a subnet reach remote subnets without configuring routing or a default gateway.

Typical routers only support proxy ARP for directly attached networks; the 7750 SR-Series is targeted to support proxy ARP for all known networks in the routing instance where the virtual interface proxy ARP is configured.

In order to support DSLAM and other edge like environments, 7750 SR-Series proxy ARP supports policies that allow the provider to configure prefix lists that determine for which target networks proxy ARP will be attempted and prefix lists that determine for which source hosts proxy ARP will be attempted.

In addition, the proxy ARP implementation will support the ability to respond for other hosts within the local subnet domain. This is needed in environments such as DSL where multiple hosts are in the same subnet but can not reach each other directly.

Static ARP is used when a 7750 SR OS needs to know about a device on an interface that cannot or does not respond to ARP requests. Thus, the configuration can state that if it has a packet with a certain IP address to send it to the corresponding ARP address. Use proxy ARP so the router responds to ARP requests on behalf of another device.

DHCP Relay

Refer to 7750 SR OS Triple Play Guide for information about DHCP and support provided by the 7750 SR as well as configuration examples.

Internet Protocol Versions

The TiMOS implements IP routing functionality, providing support for IP version 4 (IPv4) and IP version 6 (IPv6). IP version 6 (IPv6) (RFC 1883, *Internet Protocol, Version 6 (IPv6)*) is a newer version of the Internet Protocol designed as a successor to IP version 4 (IPv4) (RFC-791, *Internet Protocol*). The changes from IPv4 to IPv6 effect the following categories:

- Expanded addressing capabilities IPv6 increases the IP address size from 32 bits (IPv4) to 128 bits, to support more levels of addressing hierarchy, a much greater number of addressable nodes, and simpler auto-configuration of addresses. The scalability of multicast routing is improved by adding a scope field to multicast addresses. Also, a new type of address called an anycast address is defined that is used to send a packet to any one of a group of nodes.
- Header format simplification Some IPv4 header fields have been dropped or made optional to reduce the common-case processing cost of packet handling and to limit the bandwidth cost of the IPv6 header.
- Improved support for extensions and options Changes in the way IP header options are encoded allows for more efficient forwarding, less stringent limits on the length of options, and greater flexibility for introducing new options in the future.
- Flow labeling capability The capability to enable the labeling of packets belonging to particular traffic flows for which the sender requests special handling, such as non-default quality of service or "real-time" service was added in IPv6.
- Authentication and privacy capabilities Extensions to support authentication, data integrity, and (optional) data confidentiality are specified for IPv6.




Figure 2: IPv6 Header Format

Field	Description	
Version	4-bit Internet Protocol version number = 6.	
Prio.	4-bit priority value.	
Flow Label	24-bit flow label.	
Payload Length	16-bit unsigned integer. The length of payload, for example, the rest of the packet following the IPv6 header, in octets. If the value is zero, the payload length is carried in a jumbo payload hop-by-hop option.	
Next Header	8-bit selector. Identifies the type of header immediately following the IPv6 header. This field uses the same values as the IPv4 protocol field.	
Hop Limit	8-bit unsigned integer. Decremented by 1 by each node that forwards the packet. The packet is discarded if the hop limit is decremented to zero.	
Source Address	128-bit address of the originator of the packet.	
Destination Address	128-bit address of the intended recipient of the packet (possibly not the ultimate recipient if a routing header is present).	

Table 2: IPv6 Header Field Descriptions

IPv6 Applications

Examples of the IPv6 applications supported by the TiMOS include:

• IPv6 Internet exchange peering — Figure 3 shows an IPv6 Internet exchange where multiple ISPs peer over native IPv6.




Figure 3: IPv6 Internet Exchange

• IPv6 transit services — Figure 4 shows IPv6 transit provided by an ISP.




Figure 4: IPv6 Transit Services

• IPv6 services to enterprise customers and home users — Figure 5 shows IPv6 connectivity to enterprise and home broadband users.




Figure 5: IPv6 Services to Enterprise Customers and Home Users

• IPv6 over IPv4 relay services — IPv6 over IPv4 tunnels are one of many IPv6 transition methods to support IPv6 in an environment where not only IPv4 exists but native IPv6 networks depend on IPv4 for greater IPv6 connectivity. 7750 SR OS supports dynamic IPv6 over IPv4 tunneling. The ipv4 source and destination address are taken from configuration, the source address is the ipv4 system address and the ipv4 destination is the next hop from the configured 6over4 tunnel.

IPv6 over IPv4 is an automatic tunnel method that gives a prefix to the attached IPv6 network. Figure 6 shows IPv6 over IPv4 tunneling to transition from IPv4 to IPv6.




Figure 6: IPv6 over IPv4 Tunnels

DNS

The DNS client is extended to use IPv6 as transport and to handle the IPv6 address in the DNS AAAA resource record from an IPv4 or IPv6 DNS server. An assigned name can be used instead of an IPv6 address since IPv6 addresses are more difficult to remember than IPv4 addresses.

IPv6 Provider Edge Router over MPLS (6PE)

6PE allows IPv6 domains to communicate with each other over an IPv4 MPLS core network. This architecture requires no backbone infrastructure upgrades and no re-configuration of core routers, because forwarding is purely based on MPLS labels. 6PE is a cost effective solution for IPv6 deployment.




Figure 7: Example of a 6PE Topology within One AS

6PE Control Plane Support

The 6PE MP-BGP routers support:

- IPv4/IPv6 dual-stack
- MP-BGP can be used between 6PE routers to exchange IPv6 reachability information.
 - → The 6PE routers exchange IPv6 prefixes over MP-BGP sessions running over IPv4 transport. The MP-BGP AFI used is IPv6 (value 2).
 - → An IPv4 address of the 6PE router is encoded as an IPv4-mapped IPv6 address in the BGP next-hop field of the IPv6 NLRI. By default, the IPv4 address that is used for peering is used. It is configurable through the route policies.
 - → The 6PE router binds MPLS labels to the IPv6 prefixes it advertises. The SAFI used in MP-BGP is the SAFI (value 4) label. The router uses the IPv6 explicit null (value 2) label for all the IPv6 prefixes that it advertises and can accept an arbitrary label from its peers.
- LDP is used to create the MPLS full mesh between the 6PE routers and the IPv4 addresses that are embedded in the next-hop field are reachable by LDP LSPs. The ingress 6PE router uses the LDP LSPs to reach remote 6PE routers.

6PE Data Plane Support

The ingress 6PE router can push two MPLS labels to send the packets to the egress 6PE router. The top label is an LDP label used to reach the egress 6PE router. The bottom label is advertised in MP-BGP by the remote 6PE router. Typically, the IPv6 explicit null (value 2) label is used but an arbitrary value can be used when the remote 6PE router is from a vendor other than Alcatel-Lucent.

The egress 6PE router pops the top LDP tunnel label. It sees the IPv6 explicit null label, which indicates an IPv6 packet is encapsulated. It also pops the IPv6 explicit null label and performs an IPv6 route lookup to find out the next hop for the IPv6 packet.

Bidirectional Forwarding Detection

Bidirectional Forwarding Detection (BFD) is a light-weight, low-overhead, short-duration detection of failures in the path between two systems. If a system stops receiving BFD messages for a long enough period (based on configuration) it is assumed that a failure along the path has occurred and the associated protocol or service is notified of the failure.

BFD can provide a mechanism used for liveness detection over any media, at any protocol layer, with a wide range of detection times and overhead, to avoid a proliferation of different methods.

There are two modes of operation for BFD:

• Asynchronous mode — Uses periodic BFD control messages to test the path between systems.

A path is only declared operational when two-way communications has been established between both systems.

A separate BFD session is created for each communications path and data protocol in use between two systems.

In addition to the two operational modes, there is also an echo function defined within *draft-ietf-bfd-base-04.txt*, *Bidirectional Forwarding Detection*, that allows either of the two systems to send a sequence of BFD echo packets to the other system, which loops them back within that system's forwarding plane. If a number of these echo packets are lost then the BFD session is declared down.

BFD Control Packet

The base BFD specification does not specify the encapsulation type to be used for sending BFD control packets. Instead it is left to the implementers to use the appropriate encapsulation type for the medium and network. The encapsulation for BFD over IPv4 and IPv6 networks is specified in draft-ietf-bfd-v4v6-1hop-04.txt, *BFD for IPv4 and IPv6 (Single Hop)*. This specification requires that BFD control packets be sent over UDP with a destination port number of 3784 and the source port number must be within the range 49152 to 65535.

In addition, the TTL of all transmitted BFD packets must have an IP TTL of 255. All BFD packets received must have an IP TTL of 255 if authentication is not enabled. If authentication is enabled, the IP TTL should be 255 but can still be processed if it is not (assuming the packet passes the enabled authentication mechanism).

If multiple BFD sessions exist between two nodes, the BFD discriminator is used to de-multiplex the BFD control packet to the appropriate BFD session.

Control Packet Format

The BFD control packet has 2 sections, a mandatory section and an optional authentication section.




Figure 8: Mandatory Frame Format

Field	Description
Vers	The version number of the protocol. The initial protocol version is 0.
Diag	A diagnostic code specifying the local system's reason for the last transition of the session from Up to some other state. Possible values are: 0-No diagnostic 1-Control detection time expired 2-Echo function failed 3-Neighbor signaled session down 4-Forwarding plane reset 5-Path down 6-Concatenated path down 7-Administratively down
H Bit	The "I Hear You" bit. This bit is set to 0 if the transmitting system either is not receiving BFD packets from the remote system, or is in the process of tearing down the BFD session for some reason. Otherwise, during normal operation, it is set to 1.
D Bit	The "demand mode" bit. (Not supported)

Table 3: BFD Control Packet Field Descriptions

Field	Description	
P Bit	The poll bit. If set, the transmitting system is requesting verification of connectivity, or of a parameter change.	
F Bit	The final bit. If set, the transmitting system is responding to a received BFD control packet that had the poll (P) bit set.	
Rsvd	Reserved bits. These bits must be zero on transmit and ignored on receipt.	
Detect Mult	Detect time multiplier. The negotiated transmit interval, multiplied by this value, provides the detection time for the transmitting system in asynchronous mode. Like the IGP hello protocol mechanisms, this is analogous to the hello-multiplier in IS-IS, which can be used to determine the hold-timer. (hello-interval) x (hello-multiplier) = hold-timer. If a hello is not received within the hold-timer, a failure has occurred.	
	Similarly in BFD: (transmit interval) x (detect multiplier) = detect-timer. If a BFD control packet is not received from the remote system within detect-timer, a failure has occurred.	
Length	Length of the BFD control packet, in bytes.	
My Discriminator	A unique, nonzero discriminator value generated by the transmitting system, used to demultiplex multiple BFD sessions between the same pair of systems.	
Your Discriminator	The discriminator received from the corresponding remote system. This field reflects back the received value of my discriminator, or is zero if that value is unknown.	
Desired Min TX Interval	This is the minimum interval, in microseconds, that the local system would like to use when transmitting BFD control packets.	
Required Min RX Interval	This is the minimum interval, in microseconds, between received BFD control packets that this system is capable of supporting.	
Required Min Echo RX Interval	This is the minimum interval, in microseconds, between received BFD echo packets that this system is capable of supporting. If this value is zero, the transmitting system does not support the receipt of BFD echo packets.	

Table 3: BFD Control Packet Field Descriptions (Continued)

BFD for RSVP-TE

BFD will notify RSVP-TE if the BFD session goes down, in addition to notifying other configured BFD enabled protocols (for example, OSPF, IS-IS and PIM). This notification will then be used by RSVP-TE to begin the reconvergence process. This greatly accelerates the overall RSVP-TE response to network failures.

All encapsulation types supporting IPv4 and IPv6 is supported as all BFD packets are carried in IPv4 and IPv6 packets; this includes Frame Relay and ATM.

BFD is supported on the following interfaces:

- Ethernet (Null, Dot1Q & QinQ)
- POS interfaces (including APS)
- Channelized interfaces (PPP, HDLC, FR & ATM) on ASAP (priority 1) and channelized MDAs (Priority 2) including link bundles and IMA
- Spoke SDPs
- LAG interfaces
- VSM interfaces

IOM Scale

BFD has a scaling limit of 500 packets per second per IOM.

Echo Support

Echo support for BFD calls for the support of the echo function within BFD. By supporting BFD echo, the 7750 SR loops back received BFD echo messages to the original sender based on the destination IP address in the packet.

The echo function is useful when the local router does not have sufficient CPU power to handle a periodic polling rate at a high frequency. As a result, it relies on the echo sender to send a high rate of BFD echo messages through the receiver node, which is only processed by the receiver's forwarding path. This allows the echo sender to send BFD echo packets at any rate.

The 7750 does not support the sending of echo requests, only the response of echo requests.

BFD Support for BGP

This feature enhancement allows BGP peers to be associated with the BFD session. If the BFD session failed, then BGP peering will also be torn down.

Centralized BFD

The following applications of centralized BFD require BFD to run on the SF/CPM.

- IES/VPRN Over Spoke SDP
- BFD Over LAG and VSM Interfaces
- Protocol associations using loopback interfaces
- BFD sessions associated with multi-hop BGP peerings

IES/VPRN Over Spoke SDP

One application for a central BFD implementation is so BFD can be supported over spoke SDPs used to inter-connection IES or VPRN interfaces. When there are spoke SDPs for interconnections over an MPLS network between two routers, BFD is used to speed up failure detections between nodes so re-convergence of unicast and multicast routing information can begin as quickly as possible.

The MPLS LSP associated with the spoke SDP can enter or egress from multiple interfaces on the box. BFD for these types of interfaces can not exist on the IOM itself.





Figure 9: BFD for IES/VPRN over Spoke SDP

Configuring IP Router Parameters

BFD Over LAG and VSM Interfaces

A second application for a central BFD implementation is so BFD can be supported over LAG or VSM interface. This is useful where BFD is not used for link failure detection but instead for node failure detection. In this application, the BFD session can run between the IP interfaces associated with the LAG or VSM interface, but there is only one session between the 2 nodes. There is no requirement for the message flow to across a certain link, or VSM, to get to the remote node.



Fig_32

Figure 10: BFD over LAG

Process Overview

The following items are components to configure basic router parameters.

- Interface A logical IP routing interface. Once created, attributes like an IP address, port, link aggregation group or the system can be associated with the IP interface.
- Address The address associates the device's system name with the IP system address. An IP address must be assigned to each IP interface.
- System interface This creates an association between the logical IP interface and the system (loopback) address. The system interface address is the circuitless address (loopback) and is used by default as the router ID for protocols such as OSPF and BGP.
- Router ID (Optional) The router ID specifies the router's IP address.
- Autonomous system (Optional) An autonomous system (AS) is a collection of networks that are subdivided into smaller, more manageable areas.
- Confederation (Optional) Creates confederation autonomous systems within an AS to reduce the number of IBGP sessions required within an AS.

Configuration Notes

The following information describes router configuration caveats.

- A system interface and associated IP address should be specified.
- Boot options file (BOF) parameters must be configured prior to configuring router parameters.
- Confederations can be configured before protocol connections (such as BGP) and peering parameters are configured.
- IPv6 interface parameters can only be configured on systems provisioned with the iom2-20g.
- In order to configure IPv6 interface parameters, the chassis mode must be set to **c** in the **config>system>chassis-mode** context. Use the **force** keyword to upgrade to **c** mode with cards provisioned as iom-20g or iom-20g-b.
- An iom2-20g and a SFM2 card are required to enable the IPv6 CPM filter and per-peer queuing functionality.

Configuring an IP Router with CLI

This section provides information to configure an IP router.

Topics in this section include:

- Router Configuration Overview on page 46
- Basic Configuration on page 47
- Common Configuration Tasks on page 48
 - → Configuring a System Name on page 48
 - \rightarrow Configuring Interfaces on page 50
 - Configuring a System Interface on page 50
 - Configuring a Network Interface on page 50
 - Configuring IPv6 Parameters on page 52
 - Router Advertisement on page 63
 - Configuring Proxy ARP on page 64
 - Creating an IP Address Range on page 67
 - Configuring an LDP Shortcut on page 68
 - \rightarrow Deriving the Router ID on page 72
 - \rightarrow Configuring a Confederation on page 72
 - → Configuring an Autonomous System on page 74
 - → Configuring Overload State on a Single SFM on page 75
 - → Service Management Tasks on page 76
- Service Management Tasks on page 76
 - \rightarrow Changing the System Name on page 76
 - → Modifying Interface Parameters on page 77
 - → Deleting a Logical IP Interface on page 78

Router Configuration Overview

In a 7750 SR, an interface is a logical named entity. An interface is created by specifying an interface name under the configure>router context. This is the global router configuration context where objects like static routes are defined. An IP interface name can be up to 32 alphanumeric characters long, must start with a letter, and is case-sensitive; for example, the interface name "1.1.1.1" is not allowed, but "int-1.1.1" is allowed.

To create an interface on an Alcatel-Lucent 7750 SR-Series router, the basic configuration tasks that must be performed are:

- Assign a name to the interface.
- Associate an IP address with the interface.
- Associate the interface with a network interface or the system interface.
- Configure appropriate routing protocols.

A system interface and network interface should be configured.

System Interface

The system interface is associated with the network entity (such as a specific 7750 SR-Series), not a specific interface. The system interface is also referred to as the loopback address. The system interface is associated during the configuration of the following entities:

- The termination point of service tunnels
- The hops when configuring MPLS paths and LSPs
- The addresses on a target router for BGP and LDP peering.

The system interface is used to preserve connectivity (when routing reconvergence is possible) when an interface fails or is removed. The system interface is used as the router identifier. A system interface must have an IP address with a 32-bit subnet mask.

Network Interface

A network interface can be configured on one of the following entities:

- A physical or logical port
- A SONET/SDH channel

Basic Configuration

NOTE: Refer to each specific chapter for specific routing protocol information and command syntax to configure protocols such as OSPF and BGP.

The most basic router configuration must have the following:

- System name
- System address

The following example displays a router configuration:

```
A:ALA-A> config# info
. . .
#-----
# Router Configuration
#-----
  router
     interface "system"
        address 10.10.10.103/32
     exit
     interface "to-104"
        address 10.0.0.103/24
        port 1/1/1
        exit
      exit
      autonomous-system 100
     confederation 1000 members 100 200 300
  router-id 10.10.10.103
. . .
   exit
   isis
   exit
. . .
#-----
A:ALA-A> config#
```

Common Configuration Tasks

The following sections describe basic system tasks.

- Configuring a System Name on page 48
- Configuring Interfaces on page 50
 - \rightarrow Configuring a System Interface on page 50
 - \rightarrow Configuring a Network Interface on page 50
 - → Configuring IPv6 Parameters on page 52
 - \rightarrow Router Advertisement on page 63
- Configuring Proxy ARP on page 64
- Creating an IP Address Range on page 67
- Deriving the Router ID on page 72
- Configuring a Confederation on page 72
- Configuring an Autonomous System on page 74
- Configuring Overload State on a Single SFM on page 75

Configuring a System Name

Use the system command to configure a name for the device. The name is used in the prompt string. Only one system name can be configured. If multiple system names are configured, the last one configured will overwrite the previous entry.

If special characters are included in the system name string, such as spaces, #, or ?, the entire string must be enclosed in double quotes. Use the following CLI syntax to configure the system name:

CLI Syntax:	config# system name <i>system-name</i>
Example:	config# system config>system# name ALA-A ALA-A>config>system# exit all ALA-A#

The following example displays the system name output.

```
A:ALA-A>config>system# info
#------
# System Configuration
#------
name "ALA-A"
```

location "Mt.View, CA, NE corner of FERG 1 Building" coordinates "37.390, -122.05500 degrees lat." snmp exit . . . exit

A:ALA-A>config>system#

Configuring Interfaces

The following command sequences create a system and a logical IP interface. The system interface assigns an IP address to the interface, and then associates the IP interface with a physical port. The logical interface can associate attributes like an IP address or port.

Note that the system interface cannot be deleted.

Configuring a System Interface

To configure a system interface:

```
CLI Syntax: config>router
    interface interface-name
    address { [ip-address/mask] | [ip-address] [netmask] }
        [broadcast {all-ones|host-ones]
        secondary { [address/mask| ip-address] [netmask] }
        [broadcast {all-ones|host-ones}] [igp-inhibit]
```

Configuring a Network Interface

To configure a network interface:

The following displays an IP configuration output showing interface information.

```
A:ALA-A>config>router# info
#-----
# IP Configuration
#-----
    interface "system"
      address 10.10.0.4/32
     exit
     interface "to-ALA-2"
       address 10.10.24.4/24
       port 1/1/1
       egress
          filter ip 10
       exit
     exit
• • •
#-----
A:ALA-A>config>router#
```

To enable CPU protection:

CLI Syntax: config>router interface interface-name cpu-protection policy-id

CPU protection policies are configured in the **config>sys>security>cpu-protection** context. See the 7750 SR OS System Management Guide.

Configuring IPv6 Parameters

To configure IPv6 parameters, you must first:

• The chassis mode must be set to **c** in the **config>system>chassis-mode** context. Use the **force** keyword to upgrade to **c** mode with cards provisioned as iom-20g or iom-20g-b.

The ASAP MDA can only be configured if the iom2-20g IOM type is provisioned and equipped and the chassis mode is configured as **a** or **b**.

Note that, if you are in chassis-mode **c** and configure an IOM type as iom2-20g and then downgrade to chassis-mode **a** or **b** (must specify **force** keyword), a warning appears about the IOM downgrade. In this case, the IOM's provisioned type will downgrade to iom-20g-b. Once this is done, the ASAP MDA cannot be configured.

If this is the desired behavior, for example, chassis-mode c is configured and IPv6 is running, you can then downgrade to chassis-mode a or b if you want to disable IPv6.

The following displays the interface configuration showing the IPv6 default configuration when IPv6 is enabled on the interface.

A:ALA-49>config>router>if>ipv6# info detail

```
' port 1/2/37
ipv6
    packet-too-big 100 10
    param-problem 100 10
    redirects 100 10
    time-exceeded 100 10
    unreachables 100 10
    exit
A:ALA-49>config>router>if>ipv6# exit all
```

Use the following CLI syntax to configure IPv6 parameters on a router interface.

```
CLI Syntax: config>router# interface interface-name

port port-name

ipv6

address {ipv6-address/prefix-length} [eui-64]

icmp6

packet-too-big [number seconds]

param-problem [number seconds]

redirects [number seconds]

time-exceeded [number seconds]

unreachables [number seconds]

neighbor ipv6-address mac-address
```

The following displays a configuration example showing interface information.

A:ALA-49>config>router>if# info address 10.11.10.1/24 port 1/2/37 ipv6 address 10::1/24 exit A:ALA-49>config>router>if#

Configuring IPv6 Over IPv4 Parameters

This section provides several examples of the features that must be configured in order to implement IPv6 over IPv4 relay services.

- Tunnel Ingress Node on page 54
 - → Learning the Tunnel Endpoint IPv4 System Address on page 56
 - → Configuring an IPv4 BGP Peer on page 57
 - → An Example of a IPv6 Over IPv4 Tunnel Configuration on page 58
- Tunnel Egress Node on page 59
 - → Learning the Tunnel Endpoint IPv4 System Address on page 60
 - \rightarrow Configuring an IPv4 BGP Peer on page 61
 - → An Example of a IPv6 Over IPv4 Tunnel Configuration on page 62

Tunnel Ingress Node

This configuration shows how the interface through which the IPv6 over IPv4 traffic leaves the node. This must be configured on a network interface.

```
CLI Syntax: config>router
    static-route ::C8C8:C802/128 indirect 200.200.200.2
    interface ip-int-name
        address {ip-address/mask|ip-address netmask} [broadcast
        all-ones|host-ones]
        port port-name
```

The following displays configuration output showing interface configuration.

```
A:ALA-49>configure>router# info

...

interface "ip-1.1.1.1"

address 1.1.1.1/30

port 1/1/1

exit

A:ALA-49>configure>router#
```

Both the IPv4 and IPv6 system addresses must to configured

```
CLI Syntax: config>router
    interface ip-int-name
    address {ip-address/mask|ip-address netmask} [broad-
        cast all-ones|host-ones]
        ipv6
        address ipv6-address/prefix-length [eui-64]
```

The following displays configuration output showing interface information.

```
A:ALA-49>configure>router# info

....

interface "system"

address 200.200.200.1/32

ipv6

address 3FFE::C8C8:C801/128

exit

exit

....

A:ALA-49>configure>router#
```

Learning the Tunnel Endpoint IPv4 System Address

This configuration displays the OSPF configuration to learn the IPv4 system address of the tunnel endpoint.

```
CLI Syntax: config>router
ospf
area area-id
interface ip-int-name
```

The following displays a configuration showing OSPF output.

```
A:ALA-49>configure>router# info

....

ospf

area 0.0.0.0

interface "system"

exit

interface "ip-1.1.1.1"

exit

exit

exit

A:ALA-49>configure>router#
```

Configuring an IPv4 BGP Peer

This configuration display the commands to configure an IPv4 BGP peer with (IPv4 and) IPv6 protocol families.

```
CLI Syntax: config>router

bgp

export policy-name [policy-name...(upto 5 max)]

router-id ip-address

group name

family [ipv4] [vpn-ipv4] [ipv6] [mcast-ipv4]

type {internal|external}

neighbor ip-address

local-as as-number [private]

peer-as as-number
```

The following displays a configuration showing BGP output.

```
A:ALA-49>configure>router# info
_____
. . .
     bgp
        export "ospf3"
        router-id 200.200.200.1
        group "main"
           family ipv4 ipv6
           type internal
           neighbor 200.200.200.2
              local-as 1
              peer-as 1
           exit
        exit
     exit
. . .
_____
A:ALA-49>configure>router#
```

An Example of a IPv6 Over IPv4 Tunnel Configuration

The IPv6 address is the next-hop as it is received through BGP. The IPv4 address is the system address of the tunnel's endpoint static-route ::C8C8:C802/128 indirect 200.200.200.2.

This configuration displays an example to configure a policy to export IPv6 routes into BGP.

```
CLI Syntax: config>router
    bgp
    export policy-name [policy-name...(upto 5 max)]
    router-id ip-address
    group name
    family [ipv4] [vpn-ipv4] [ipv6] [mcast-ipv4]
    type {internal|external}
    neighbor ip-address
    local-as as-number [private]
    peer-as as-number
```

The following displays the configuration output.

```
A:ALA-49>configure>router# info
. . .
       policy-options
         policy-statement "ospf3"
            description "Plcy Stmnt For 'From ospf3 To bgp'"
            entry 10
               description "Entry From Protocol ospf3 To bgp"
               from
                  protocol ospf3
               exit
               to
                  protocol bgp
               exit
               action accept
               exit
            exit.
         exit
      exit
. . .
-----
A:ALA-49>configure>router#
```

Tunnel Egress Node

This configuration shows how the interface through which the IPv6 over IPv4 traffic leaves the node. It must be configured on a network interface. Both the IPv4 and IPv6 system addresses must be configured.

```
CLI Syntax: config>router
    configure router static-route ::C8C8:C801/128 indirect
    200.200.200.1
    interface ip-int-name
    address {ip-address/mask>|ip-address netmask} [broad-
        cast all-ones|host-ones]
        ipv6
        address ipv6-address/prefix-length [eui-64]
        port port-name
```

The following displays interface configuration.

```
A:ALA-49>configure>router# info

....

interface "ip-1.1.1.2"

address 1.1.1.2/30

port 1/1/1

exit

interface "system"

address 200.200.200.2/32

ipv6

address 3FFE::C8C8:C802/128

exit

exit
```

Learning the Tunnel Endpoint IPv4 System Address

This configuration displays the OSPF configuration to learn the IPv4 system address of the tunnel endpoint.

CLI Syntax: config>router ospf area area-id interface ip-int-name

The following displays OSPF configuration information.

```
A:ALA-49>configure>router# info

....

ospf

area 0.0.0.0

interface "system"

exit

interface "ip-1.1.1.2"

exit

exit

exit

A:ALA-49>configure>router#
```

Configuring an IPv4 BGP Peer

This configuration display the commands to configure an IPv4 BGP peer with (IPv4 and) IPv6 protocol families.

```
CLI Syntax: config>router
    bgp
    export policy-name [policy-name...(upto 5 max)]
    router-id ip-address
    group name
    family [ipv4] [vpn-ipv4] [ipv6] [mcast-ipv4]
    type {internal|external}
    neighbor ip-address
    local-as as-number [private]
    peer-as as-number
```

The following displays the IPv4 BGP peer configuration example.

```
A:ALA-49>configure>router# info
_____
. . .
     bgp
        export "ospf3"
        router-id 200.200.200.2
        group "main"
           family ipv4 ipv6
           type internal
           neighbor 200.200.200.1
              local-as 1
              peer-as 1
           exit
        exit
     exit
. . .
_____
A:ALA-49>configure>router#
```

An Example of a IPv6 Over IPv4 Tunnel Configuration

The IPv6 address is the next-hop as it is received through BGP. The IPv4 address is the system address of the tunnel's endpoint static-route ::C8C8:C802/128 indirect 200.200.200.2

This configuration displays an example to configure a policy to export IPv6 routes into BGP.

```
CLI Syntax: config>router
    bgp
    export policy-name [policy-name...(upto 5 max)]
    router-id ip-address
    group name
    family [ipv4] [vpn-ipv4] [ipv6] [mcast-ipv4]
    type {internal|external}
    neighbor ip-address
    local-as as-number [private]
    peer-as as-number
```

The following displays an IPv6 over IPv4 tunnel configuration

```
A:ALA-49>configure>router# info
. . .
     policy-options
        policy-statement "ospf3"
           description "Plcy Stmnt For 'From ospf3 To bgp'"
           entry 10
               description "Entry From Protocol ospf3 To bgp"
               from
                 protocol ospf3
               exit
               to
                 protocol bgp
               exit
               action accept
               exit
            exit.
        exit
     exit
A:ALA-49>configure>router#
```

Router Advertisement

To configure the router to originate router advertisement messages, the **router-advertisement** command must be enabled. All other router advertisement configuration parameters are optional. Router advertisement on all IPv6-enabled interfaces will be enabled.

Use the following CLI syntax to enable router advertisement and configure router advertisement parameters:

```
CLI Syntax: config>router# router-advertisement
            interface ip-int-name
               current-hop-limit number
               managed-configuration
               max-advertisement-interval seconds
               min-advertisement-interval seconds
               mtu mtu-bytes
               other-stateful-configuration
               prefix ipv6-prefix/prefix-length
                  autonomous
                  on-link
                  preferred-lifetime {seconds | infinite}
                  valid-lifetime {seconds | infinite}
               reachable-time milli-seconds
               retransmit-time milli-seconds
               router-lifetime seconds
               no shutdown
               use-virtual-mac
```

The following displays a router advertisement configuration example.

```
*A:sim131>config>router>router-advert# info
_____
        interface "n1"
          prefix 3::/64
           exit
           use-virtual-mac
           no shutdown
        exit
_____
*A:sim131>config>router>router-advert# interface n1
*A:sim131>config>router>router-advert>if# prefix 3::/64
*A:sim131>config>router>router-advert>if>prefix# info detail
  -----
              autonomous
              on-link
              preferred-lifetime 604800
              valid-lifetime 2592000
-----
*A:tahi>config>router>router-advert>if>prefix#
```

7750 SR OS Router Configuration Guide

Configuring Proxy ARP

To configure proxy ARP, you can configure:

- A prefix list in the **config>router>policy-options>prefix-list** context.
- A route policy statement in the **config>router>policy-options>policy-statement** context and apply the specified prefix list.
 - → In the policy statement **entry>to** context, specify the host source address(es) for which ARP requests can or cannot be forwarded to non-local networks, depending on the specified action.
 - → In the policy statement **entry>from** context, specify network prefixes that ARP requests will or will not be forwarded to depending on the action if a match is found. For more information about route policies, refer to the 7750 SR OS Routing Protocols Guide.
- Apply the policy statement to the **proxy-arp** configuration in the **config>router>interface** context.

Use the following CLI syntax to configure the policy statement specified in the **proxy-arp-policy** *policy-statement* command.

```
CLI Syntax: config>router# policy-options
    begin
    commit
    policy-statement name
    default-action {accept | next-entry | next-policy | re-
        ject}
        entry entry-id
        action {accept | next-entry | next-policy | reject}
        to
            prefix-list name [name...(upto 5 max)]
        from
            prefix-list name [name...(upto 5 max)]
```

The following displays prefix list and policy statement configuration examples:

```
A:ALA-49>config>router>policy-options# info
-----
         prefix-list "prefixlist1"
               prefix 10.20.30.0/24 through 32
          exit
         prefix-list "prefixlist2"
                prefix 10.10.10.0/24 through 32
         exit
. . .
         policy-statement "ProxyARPpolicy"
             entry 10
                from
                   prefix-list "prefixlist1"
                exit
                to
                   prefix-list "prefixlist2"
                exit
                action reject
             exit
             default-action accept
             exit
          exit
. . .
-----
A:ALA-49>config>router>policy-options#
```

7750 SR OS Router Configuration Guide

Use the following CLI to configure proxy ARP:

The following displays a proxy ARP configuration example:

A:ALA-49>config>router>if# info address 128.251.10.59/24 local-proxy-arp proxy-arp policy-statement "ProxyARPpolicy" exit

A:ALA-49>config>router>if#

Creating an IP Address Range

An IP address range can be reserved for exclusive use for services by defining the config>router>service-prefix command. When the service is configured, the IP address must be in the range specified as a service prefix. If no service prefix command is configured, then no limitation exists.

The no service-prefix ip-prefix/mask command removes all address reservations. A service prefix cannot be removed while one or more services use address(es) in the range to be removed.

CLI Syntax:	config>router service-prefix	ip-prefix/mask	[exclusive]
Example:	config>router#	service-prefix	

Configuring an LDP Shortcut

This command enables you to forward user IP packets and specified control IP packets using LDP shortcuts over all network interfaces in the system that participate in the IS-IS and OSPF routing protocols. The default is to disable the LDP shortcut across all interfaces in the system.

IGP Route Resolution

When LDP shortcut is enabled, LDP populates the RTM with next-hop entries corresponding to all prefixes for which it activated an LDP FEC. For a given prefix, two route entries are populated in RTM. One corresponds to the LDP shortcut next-hop and has an owner of LDP. The other one is the regular IP next-hop. The LDP shortcut next-hop always has preference over the regular IP next-hop for forwarding user packets and specified control packets over a given outgoing interface to the route next-hop.

The prior activation of the FEC by LDP is done by performing an exact match with an IGP route prefix in RTM. It can also be done by performing a longest prefix-match with an IGP route in RTM if the aggregate-prefix-match option is enabled globally in LDP *ldp-interarea-prd*.

Note that the LDP next-hop entry is not exported to LDP control plane or to any other control plane protocols except OSPF, IS-IS, and specific OAM control plane as specified in Handling of Control Packets on page 70.

This feature is not restricted to /32 FEC prefixes. However only /32 FEC prefixes will be populated in the CPM Tunnel Table for use as a tunnel by services.

All user and specified control packets for which the longest prefix match in RTM yields the FEC prefix will be forwarded over the LDP LSP. The following is an example of the resolution process.

Assume the egress LER advertised a FEC for some /24 prefix using the fec-originate command. At the ingress LER, LDP resolves the FEC by checking in RTM that an exact match exists for this prefix. Once LDP activated the FEC, it programs the NHLFE in the egress data path and the LDP tunnel information in the ingress data path tunnel table.

Next, LDP provides the shortcut route to RTM which will associate it with the same /24 prefix. There will be two entries for this /24 prefix, the LDP shortcut next-hop and the regular IP next-hop. The latter was used by LDP to validate and activate the FEC. RTM then resolves all user prefixes which succeed a longest prefix match against the /24 route entry to use the LDP LSP.

Assume now the aggregate-prefix-match was enabled and that LDP found a /16 prefix in RTM to activate the FEC for the /24 FEC prefix. In this case, RTM adds a new more specific route entry of /24 and has the next-hop as the LDP LSP but it will still not have a specific /24 IP route entry. RTM then resolves all user prefixes which succeed a longest prefix match against the /24 route

entry to use the LDP LSP while all other prefixes which succeed a longest prefix-match against the /16 route entry will use the IP next-hop. LDP shortcut will also work when using RIP for routing.

LDP Shortcut Forwarding Plane

Once LDP activated a FEC for a given prefix and programmed RTM, it also programs the ingress Tunnel Table in IOM with the LDP tunnel information.

When an IPv4 packet is received on an ingress network interface, a subscriber IES interface, or a regular IES interface, the lookup of the packet by the ingress IOM will result in the packet being sent labeled with the label stack corresponding to the NHLFE of the LDP LSP when the preferred RTM entry corresponds to an LDP shortcut.

If the preferred RTM entry corresponds to an IP next-hop, the IPv4 packet is forwarded unlabelled.

The switching from the LDP shortcut next-hop to the regular IP next-hop when the LDP FEC becomes unavailable depends on whether the next-hop is still available. If it is (for example, the LDP FEC was withdrawn due to LDP control plane issues) the switchover should be faster. If the next-hop determination requires IGP to re-converge, this will take longer. However no target is set.

The switching from a regular IP next-hop to an LDP shortcut next-hop will normally occur only when both are available. However, the programming of the NHLFE by LDP and the programming of the LDP tunnel information in the ingress IOM tunnel table are asynchronous. If Tunnel Table is configured first, it is possible that traffic will be black holed for some time .

ECMP Considerations

When ECMP is enabled and multiple equal-cost next-hops exit for the IGP route, the ingress IOM will spray the packets for this route based on hashing routine currently supported for IPv4 packets.

When the preferred RTM entry corresponds to an LDP shortcut route, spraying will be performed across the multiple next-hops for the LDP FEC. The FEC next-hops can either be direct link LDP neighbors or T-LDP neighbors reachable over RSVP LSPs in the case of LDP-over-RSVP but not both. This is as per ECMP for LDP in existing implementation.

When the preferred RTM entry corresponds to a regular IP route, spraying will be performed across regular IP next-hops for the prefix.

Spraying across regular IP next-hops and LDP-shortcut next-hops concurrently is not supported.

Handling of Control Packets

All control plane packets will not see the LDP shortcut route entry in RTM with the exception of the following control packets which will be forwarded over an LDP shortcut when enabled:

- A locally generated or in transit ICMP Ping and trace route of an IGP route. The transit message appears as a user packet to the ingress LER node.
- A locally generated response to a received ICMP ping or trace route message.

All other control plane packets that require an RTM lookup and knowledge of which destination is reachable over the LDP shortcut will continue to be forwarded over the IP next-hop route in RTM.

Handling of Multicast Packets

Multicast packets cannot be forwarded or received from an LDP LSP. This is because there is no support for the configuration of such an LSP as a tunnel interfaces in PIM. Only an RSVP P2MP LSP is currently allowed.

If a multicast packet is received over the physical interface, the RPF check will not resolve to the LDP shortcut as the LDP shortcut route in RTM is not made available to multicast application.

Interaction with LDP Shortcut for BGP Route Resolution

There is no interaction between an LDP shortcut for BGP next-hop resolution and the LDP shortcut for IGP route resolution. BGP will continue to resolve a BGP next-hop to an LDP shortcut if the user enabled the LDP shortcut option in BGP *BGP-Shortcut*:

CLI Syntax: config>router>bgp>igp-shortcut ldp

Interaction with LDP Shortcut for Static Route Resolution

There is no interaction between LDP shortcut for static route resolution and the LDP shortcut for IGP route resolution. A static route will continue to be resolved by searching an LDP LSP which FEC prefix matches the specified indirect next-hop for the route. In contrast, the LDP shortcut for IGP route resolution uses the LDP LSP as a route.

LDP Control Plane

In order for the LDP shortcut to be usable, a 7x50 must originate a <FEC, label> binding for each IGP route it learns of even if it did not receive a binding from the next-hop for that route. In other words, it must assume it is an egress LER for the FEC until the route disappears from the routing table or the next-hop advertised a binding for the FEC prefix. In the latter case, the 7x50 becomes a transit LSR for the FEC.

In the current TiMOS, a 7x50 will originate a <FEC, label> binding for its system interface address only by default. The only way to originate a binding for local interfaces and routes which are not local to the system is by using the fec-originate capability.

You must use the **fec-originate** command to generate bindings for all non-local routes for which this node acts as an egress LER for the corresponding LDP FEC. Specifically, this feature must support the FEC origination of IGP learned routes and subscriber/host routes statically configured or dynamically learned over subscriber IES interfaces.

An LDP LSP used as a shortcut by IPv4 packets may also be tunneled using the LDP-over-RSVP feature.

Deriving the Router ID

The router ID defaults to the address specified in the system interface command. If the system interface is not configured with an IP address, then the router ID inherits the last four bytes of the MAC address. The router ID can also be manually configured in the config>router routerid context. On the BGP protocol level, a BGP router ID can be defined in the config>router>bgp router-id context and is only used within BGP.

Note that if a new router ID is configured, protocols are not automatically restarted with the new router ID. The next time a protocol is initialized the new router ID is used. An interim period of time can occur when different protocols use different router IDs. To force the new router ID, issue the shutdown and no shutdown commands for each protocol that uses the router ID, or restart the entire router.

Use the following CLI syntax to configure the router ID:

```
CLI Syntax: config>router
    router-id router-id
    interface ip-int-name
        address {ip-address/mask | ip-address netmask} [broad-
        cast all-ones | host-ones]
```

The following example displays a router ID configuration:

Configuring a Confederation

Configuring a confederation is optional. The AS and confederation topology design should be carefully planned. Autonomous system (AS), confederation, and BGP connection and peering parameters must be explicitly created on each participating SR. Identify AS numbers, confederation numbers, and members participating in the confederation.

Refer to the BGP section for CLI syntax and command descriptions.

Use the following CLI syntax to configure a confederation:

```
CLI Syntax: config>router
confederation confed-as-num members member-as-num
```

The following example displays the commands to configure the confederation topology diagram displayed in Figure 1 on page 27.

NOTES:

- Confederations can be preconfigured prior to configuring BGP connections and peering.
- Each confederation can have up to 15 members.

The following displays a confederation example.

```
A:ALA-B>config>router# info
#-----
# IP Configuration
#-----
     interface "system"
        address 10.10.10.103/32
     exit
     interface "to-104"
        shutdown
        address 10.0.0.103/24
        port 1/1/1
     exit
     autonomous-system 100
     confederation 2002 members 200 300 400
     router-id 10.10.10.103
#-----
A:ALA-B>config>router#
```

Configuring an Autonomous System

Configuring an autonomous system is optional. Use the following CLI syntax to configure an autonomous system:

CLI Syntax: config>router autonomous-system as-number

The following displays an autonomous system configuration example:

```
A;ALA-A>config>router# info
#-----
# IP Configuration
#-----
    interface "system"
      address 10.10.10.103/32
    exit
  interface "to-104"
       address 10.0.0.103/24
       port 1/1/1
       exit
     exit
     autonomous-system 100
    router-id 10.10.10.103
#-----
A:ALA-A>config>router#
```

Configuring Overload State on a Single SFM

A 7x50 system with a single SFM installed has a system multicast throughput that is only a half of a 7x50 system with dual SFMs installed. For example, in a mixed environment in which IOM1s, IOM2s, and IOM3s are installed in the same system (chassis mode B or C), system multicast throughput doubles when redundant SFMs are used instead of a single SFM. If the required system multicast throughput is between 16G and 32G (which means both SFMs are being actively used), when there is an SFM failure, multicast traffic needs to be rerouted around the node.

Some scenarios include:

- There is only one SFM installed in the system
- One SFM (active or standby) failed in a dual SFM configuration
- The system is in the ISSU process

You can use an overload state in IGP to trigger the traffic reroute by setting the overload bit in IS-IS or setting the metric to maximum in OSPF. Since PIM uses IGP to find out the upstream router, a next-hop change in IGP will cause PIM to join the new path and prune the old path, which effectively reroutes the multicast traffic downstream. When the problem is resolved, the overload condition is cleared, which will cause the traffic to be routed back to the router.

Service Management Tasks

This section discusses the following service management tasks:

- Changing the System Name on page 76
- Modifying Interface Parameters on page 77
- Deleting a Logical IP Interface on page 78

Changing the System Name

The system command sets the name of the device and is used in the prompt string. Only one system name can be configured. If multiple system names are configured, the last one configured will overwrite the previous entry.

Use the following CLI syntax to change the system name:

CLI Syntax: config# system name system-name

The following example displays the command usage to change the system name:

Example: A:ALA-A>config>system# name tgif A:TGIF>config>system#

The following example displays the system name change:

```
A:ALA-A>confiq>system# name TGIF
A:TGIF>config>system# info
#-----
# System Configuration
#-----
     name "TGIF"
   location "Mt.View, CA, NE corner of FERG 1 Building"
   coordinates "37.390, -122.05500 degrees lat."
   synchronize
   snmp
      exit
      security
        snmp
            community "private" rwa version both
        exit
      exit
      . . .
_____
A:TGIF>config>system#
```

Modifying Interface Parameters

Starting at the config>router level, navigate down to the router interface context.

To modify an IP address, perform the following steps:

```
Example:A:ALA-A>config>router# interface "to-sr1"
A:ALA-A>config>router>if# shutdown
A:ALA-A>config>router>if# no address
A:ALA-A>config>router>if# address 10.0.0.25/24
A:ALA-A>config>router>if# no shutdown
```

To modify a port, perform the following steps:

```
Example:A:ALA-A>config>router# interface "to-srl"
A:ALA-A>config>router>if# shutdown
A:ALA-A>config>router>if# no port
A:ALA-A>config>router>if# port 1/1/2
A:ALA-A>config>router>if# no shutdown
```

The following example displays the interface configuration:

Deleting a Logical IP Interface

The no form of the interface command typically removes the entry, but all entity associations must be shut down and/or deleted before an interface can be deleted.

- 1. Before an IP interface can be deleted, it must first be administratively disabled with the shutdown command.
- 2. After the interface has been shut down, it can then be deleted with the **no interface** command.

IP Router Command Reference

Command Hierarchies

Configuration Commands

- Router Commands on page 79
- Router L2TP Commands on page 81
- Router Interface Commands on page 83
- Router Interface IPv6 Commands on page 85
- Router Advertisement Commands on page 86
- Show Commands on page 87
- Clear Commands on page 89
- Debug Commands on page 90

Router Commands

config

— router [router-name]

- aggregate ip-prefix/mask [summary-only] [as-set] [aggregator as-number:ip-address]
- no aggregate ip-prefix/mask
- autonomous-system as-number
- no autonomous-system
- confederation confed-as-num members as-number [as-number...(up to 15 max)]
- **no confederation** [confed-as-num **members** as-number....(up to 15 max)]
- ecmp max-ecmp-routes
- no ecmp
- [no] ignore-icmp-redirect
- mc-maximum-routes number [log-only] [threshold threshold]
- no mc-maximum-routes
- multicast-info policy-name
- no multicast-info
- multicast-info
 - **description** *description-string*
 - no description
- router-id ip-address
- no router-id
- service-prefix {ip-prefix/mask | ip-prefix netmask}[exclusive]
- no service-prefix ip-prefix/mask | ip-prefix netmask }
- sgt-qos
 - application dscp-app-name dscp {dscp-value | dscp-name}
 - **application** *dot1p-app-name* **dot1p** *dot1p-priority*
 - no application {dscp-app-name | dot1p-app-name}
 - **dscp** *dscp-name* **fc** *fc-name*

7750 SR OS Router Configuration Guide

- [no] dscp dscp-name
- single-sfm-overload [holdoff-time holdoff-time]
- no single-sfm-overload
- [no] static-route {ip-prefix/prefix-length | ip-prefix netmask} [preference preference] [metric metric] [tag tag] [enable | disable] next-hop ip-int-name | ip-address [mcast-family]
 [bfd-enable | {cpe-check cpe-ip-address [interval seconds] [drop-count count] [log]}]
- [no] static-route {ip-prefix/prefix-length | ip-prefix netmask} [preference preference] [metric metric] [tag tag] [enable | disable] indirect ip-address [ldp | rsvp-te [disallow-igp]]
 [cpe-check cpe-ip-address [interval seconds] [drop-count count] [log]]
- [no] static-route {ip-prefix/prefix-length | ip-prefix netmask} [preference preference] [metric metric] [tag tag] [enable | disable] black-hole [mcast-family]
- [no] triggered-policy

Router L2TP Commands

config

— router [router-name]

— l2tp

- calling-number-format ascii-spec
- no calling-number-format
- exclude-avps calling-number
- no exclude-avps
- group tunnel-group-name [create] [role lac / lns]
- **no group** tunnel-group-name
 - **avp-hiding** sensitive | always
 - no avp-hiding
 - challenge always
 - no challenge
 - **description** description-string
 - no description
 - destruct-timeout destruct-timeout
 - no destruct-timeout
 - hello-interval hello-interval
 - no hello-interval
 - idle-timeout idle-timeout
 - no idle-timeout
 - Ins-group lns-group-id
 - no lns-group
 - local-address ip-address
 - no local-address
 - local-name host-name
 - no local-name
 - max-retries-estab max-retries
 - no max-retries-estab
 - max-retries-not-estab max-retries
 - no max-retries-not-estab
 - **password** *password* [hash | hash2]
 - no password
 - ррр
 - authentication {chap|pap|pref-chap}
 - authentication-policy auth-policy-name
 - no authentication-policy
 - default-group-interface ip-int-name service-id service-id
 - no default-group-interface
 - **keepalive** seconds [**hold-up-multiplier** multiplier]
 - no keepalive
 - mtu mtu-bytes
 - no mtu
 - [no] proxy-authentication
 - [no] proxy-lcp
 - user-db local-user-db-name
 - no user-db
 - session-assign-method weighted
 - no session-assign-method
 - session-limit session-limit
 - no session-limit
 - tunnel tunnel-name [create]
 - **no tunnel** *tunnel-name*

- [no] auto-establish
- avp-hiding {never | sensitive | always}
- no avp-hiding
- challenge challenge-mode
- no challenge
- description description-string
- no description
- **destruct-timeout** destruct-timeout
- no destruct-timeout
- hello-interval hello-interval
- hello-interval infinite
- no hello-interval
- idle-timeout idle-timeout
- idle-timeout infinite
- no idle-timeout
- local-address ip-address
- no local-address
- local-name host-name
- no local-name
- max-retries-estab max-retries
- no max-retries-estab
- max-retries-not-estab max-retries
- no max-retries-not-estab
- password password [hash | hash2]
- no password
- peer ip-address
- no peer
- **preference** preference
- no preference
- remote-name host-name
- no remote-name
- session-limit session-limit
- no session-limit
- [no] shutdown
- peer-address-change-policy {accept | ignore | reject}
- receive-window-size [4..1024]
- no receive-window-size
- [no] shutdown

Router Interface Commands

config

- router [router-name]

- [no] interface ip-int-name
 - address {ip-address/mask | ip-address netmask} [broadcast {all-ones | hostones}]
 - no address
 - [no] allow-directed-broadcasts
 - **arp-timeout** seconds
 - no arp-timeout
 - bfd transmit-interval [receive receive-interval] [multiplier multiplier] [echoreceive echo-interval [type cpm-np]
 - no bfd
 - cflowd {acl | interface}
 - no cflowd
 - **cpu-protection** *policy-id*
 - no cpu-protection
 - delayed-enable seconds
 - no delayed-enable
 - **description** *description-string*
 - no description
 - egress
 - filter ip ip-filter-id
 - filter ipv6 ipv6-filter-id
 - **no filter** [**ip** *ip-filter-id*] [**ipv6** *ipv6-filter-id*]
 - icmp
 - [no] mask-reply
 - redirects [number seconds]
 - no redirects
 - **ttl-expired** [number seconds]
 - no ttl-expired
 - unreachables [number seconds]
 - no unreachables
 - ingress
 - filter ip ip-filter-id
 - filter ipv6 ipv6-filter-id
 - **no filter** [**ip** *ip-filter-id*] [**ipv6** *ipv6-filter-id*]
 - [no] ldp-shortcut
 - **ldp-sync-timer** seconds
 - no ldp-sync-timer
 - [no] local-proxy-arp
 - [no] loopback
 - lsr-load-balancing hashing-algorithm
 - no lsr-load-balancing
 - lsr-label-ip-hash
 - mac ieee-mac-addr
 - no mac
 - [no] multihoming primary|secondary [hold-time holdover-time]
 - **network-domain** *network-domain-name*
 - no network-domain
 - [no] ntp-broadcast
 - port port-name
 - no port
 - [no] proxy-arp-policy

— **qos** network-policy-id [**queue-redirect-group** queue-group-name]

— no qos

- [no] remote-proxy-arp
- secondary {[ip-addr/mask / ip-addr][netmask]} [broadcast {all-ones | hostones}] [igp-inhibit]
- **no** secondary [*ip*-addr/mask / *ip*-addr][netmask]
- [no] shutdown
- **static-arp** *ip-addr ieee-mac-addr*
- **no static-arp** *ip-addr*
- [no] strip-label
- tos-marking-state {trusted | untrusted}
- no tos-marking-state
- **unnumbered** [*ip-addr* | *ip-int-name*]
- no unnumbered
- [no] urpf-check
 - mode {strict | loose}
 - no mode
- [no] mh-primary-interface
 - **address** {*ip-address/mask* | *ip-address netmask*}
 - no address
 - **description** *description-string*
 - no description
 - [no] shutdown
- [no] mh-secondary-interface
 - hold-time holdover-time
 - no hold-time
 - address { *ip-address/mask* / *ip-address netmask* }
 - no address
 - **description** *description-string*
 - no description
 - [no] shutdown

For router interface VRRP commands, see VRRP Command Reference on page 271.

Router Interface IPv6 Commands

config

— router [router-name]

— [no] interface ip-int-name

— [no] ipv6

- address ipv6-address/prefix-length [eui-64]
- **no address** *ipv6-address/prefix-length*
 - icmp6
 - packet-too-big [number seconds]
 - no packet-too-big
 - param-problem [number seconds]
 - no param-problem
 - redirects [number seconds]
 - no redirects
 - time-exceeded[number seconds]
 - no time-exceeded
 - unreachables [number seconds]
 - no unreachables
 - [no] local-proxy-nd
 - **neighbor** *ipv6-address* [*mac-address*]
 - **no neighbor** *ipv6-address*
 - proxy-nd-policy policy-name [policy-name...(up to 5 max)]
 - no proxy-nd-policy

Router Advertisement Commands

config

— router

— [no] router-advertisement

— [no] interface *ip-int-name*

- current-hop-limit number
- no current-hop-limit
- [no] managed-configuration
- max-advertisement-interval seconds
- no max-advertisement-interval
- min-advertisement-interval seconds
- no min-advertisement-interval
- **mtu** mtu-bytes
- no mtu
- [no] other-stateful-configuration
- **prefix** [*ipv6-prefix/prefix-length*]
- no prefix
 - [no] autonomous
 - [no] on-link
 - preferred-lifetime {seconds | infinite }
 - no preferred-lifetime
 - valid-lifetime {seconds | infinite}
 - no valid-lifetime
- **reachable-time** *milli-seconds*
- no reachable-time
- retransmit-time milli-seconds
- no retransmit-time
- router-lifetime seconds
- no router-lifetime
- [no] shutdown
- [no] use-virtual-mac

Show Commands

show

— **router** router-instance

- aggregate [family] [active]
- arp [ip-int-name | ip-address/mask | mac ieee-mac-address / summary] [local | dynamic |
- static | managed]
- authentication
 - statistics
 - statistics interface [ip-int-name | ip-address]
 - statistics policy name
- bfd
 - interface

— session [src *ip*-address [dst *ip*-address] | [detail]]

- dhcp
 - **statistics** [*ip-int-name* | *ip-address*]
 - summary
- dhcp6
 - statistics [ip-int-name | ip-address]
 - summary
- естр
- fib slot-number [family] [ip-prefix/prefix-length] [longer] [secondary]
- fib slot-number [family] summary
- **fib** *slot-number* **nh-table-usage**
- icmp6
 - **interface** [interface-name]
- interface [{[ip-address | ip-int-name] [detail] [family]} | [summary] | [exclude-services]
- interface family [detail]
- 12tp
- group [tunnel-group-name [statistics]]
- peer ip-address
- peer ip-address statistics
- peer [draining] [unreachable]
- session connection-id connection-id [detail]
- session [detail] [session-id session-id (v2)] [state session-state][peer ip-address] [group group-name] [assignment-id assignment-id] [local-namelocal-hostname] [remote-name remote-host-name] [tunnel-id tunnel-id (v2)]]
- session [detail] [state session-state] [peer ip-address] [group group-name]
 [assignment-id assignment-id] [local-name local-host-name] [remote-name remote-host-name] [control-connection-id connection-id (v3)]
- statistics
- tunnel [statistics] [detail] [peer ip-address] [state tunnel-state] [remote-connection-id remote-connection-id (v3)] [group group-name] [assignment-id assignment-id] [local-name host-name] [remote-name host-name]| tunnel [statistics] [detail] [peer ip-address] [state tunnel-state] [remote-tunnel-id remote-tunnel-id (v2)] [group group-name] [assignment-id assignment-id] [local-name host-name] [remote-name host-name]
- tunnel tunnel-id tunnel-id (v2) [statistics] [detail]
- tunnel connection-id connection-id (v3) [statistics] [detail]
- mvpn
- neighbor [ip-address | ip-int-name | mac ieee-mac-address | summary]
- network-domains [detail] [network-domain-name]
- policy [name | damping | prefix-list name | as-path name | community name | admin]
- policy-edits

- route-table [ip-prefix[/prefix-length] [longer | exact | protocol]] | [protocol protocol-name] [next-hop-type tunneled][all]]
- route-table [family] summary
- route-table tunnel-endpoints [ip-prefix[/prefix-length] [longer | exact | protocol]
- route-table [ip-prefix[/prefix-length] next-hop-type tunneled
- **rtr-advertisement** [interface interface-name] [prefix ipv6-prefix[/prefix-length] [conflicts]
- service-prefix
- sgt-qos
 - application [app-name] [dscp-dot1p]
 - dscp-map [dscp-name]
- **static-arp** [*ip-address* | *ip-int-name* | **mac** *ieee-mac-addr*]
- static-route [family] [[ip-prefix /mask] | [preference preference] | [next-hop ip-address]] [tag tag] [detail]

```
— status
```

- tunnel-table [ip-address[/mask]] | [protocol protocol | sdp sdp-id] [summary]
- **neighbor** [interface-name]

Clear Commands

clear

— **router** [router-instance]

- arp {all | ip-addr | interface {ip-int-name | ip-addr}}
- bfd
 - **session src-ip** *ip-address* **dst-ip** *ip-address*
 - statistics src-ip *ip-address* dst-ip *ip-address*
 - statistics all
 - dhcp
 - **statistics** [ip-int-name | ip-address]
 - dhcp6
 - **statistics** [ip-int-name | ip-address]
 - forwarding-table [slot-number]
 - grt-lookup
 - icmp-redirect-route {all | ip-address}
 - icmp6 all
 - icmp6 global
 - **icmp6 interface** *interface-name*
 - **interface** [*ip-int-name* | *ip-addr*] [**icmp**]
 - 12tp
 - group tunnel-group-name
 - statistics
 - statistics
 - **tunnel** tunnel-id
 - statistics
 - neighbor {all | ip-address}
 - neighbor [interface ip-int-name | ip-address]
 - router-advertisement all
 - router-advertisement [interface interface-name]
 - **forwarding-table** [*slot-number*]
 - **interface** [*ip-int-name* | *ip-addr*] [**icmp**]

Debug Commands

debug — trace

- **destination** trace-destination
- enable
- [no] trace-point [module module-name] [type event-type] [class event-class] [task taskname] [function function-name]
- **router** router-instance

— ір

- [no] arp
- icmp
- no icmp
- icmp6 [ip-int-name]
- no icmp6
- **[no] interface** [*ip-int-name* | *ip-address*]
- [no] neighbor
- packet [ip-int-name | ip-address] [headers] [protocol-id]
- **no packet** [*ip-int-name* | *ip-address*]
- route-table [ip-prefix/prefix-length] [longer]
- no route-table
- tunnel-table [ip-address] [ldp | rsvp [tunnel-id tunnel-id]| sdp [sdp-id sdp-id]]
- mtrace
 - [no] misc
 - [no] packet [query | request | response]

Configuration Commands

Generic Commands

shutdown

Syntax	[no] shutdown
Context	config>router>interface
Description	The shutdown command administratively disables the entity. When disabled, an entity does not change, reset, or remove any configuration settings or statistics. Many entities must be explicitly enabled using the no shutdown command.
	The shutdown command administratively disables an entity. The operational state of the entity is disabled as well as the operational state of any entities contained within. Many objects must be shut down before they may be deleted.
	Unlike other commands and parameters where the default state is not indicated in the configuration file, shutdown and no shutdown are always indicated in system generated configuration files.
	The no form of the command puts an entity into the administratively enabled state.
Default	no shutdown

description

Syntax	description description-string no description
Context	config>router>if config>router>if>dhcp config>router>if>vrrp config>router>l2tp>group config>router>l2tp>group>tunnel
Description	This command creates a text description stored in the configuration file for a configuration context.
	The no form of the command removes the description string from the context.
Default	No description is associated with the configuration context.
Parameters	<i>description-string</i> — The description character string. Allowed values are any string up to 80 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

Router Global Commands

router

Syntax	router router-	name	
Context	config		
Description	This command protocols.	enables the contex	t to configure router parameters, and interfaces, route policies, and
Parameters	<i>router-name</i> — Specify the router-name.		
	Values	router-name:	Base, management
	Default	Base	

aggregate

Syntax	aggregate ip-p address] no aggregate		nmary-only] [as-set] [aggregator as-number:ip-
Context	config>router		
Description	This command creates an aggregate route.		
	Use this command to group a number of routes with common prefixes into a single entry in the routing table. This reduces the number of routes that need to be advertised by this router and red the number of routes in the routing tables of downstream routers.		
	Both the original components and the aggregated route (source protocol aggregate) are offered to the Routing Table Manager (RTM). Subsequent policies can be configured to assign protocol-specific characteristics (BGP, IS-IS or OSPF) such as the route type, or OSPF tag, to aggregate routes.		
	Multiple entries with the same prefix but a different mask can be configured; for example, routes are aggregated to the longest mask. If one aggregate is configured as 10.0./16 and another as 10.0.0./24, then route 10.0.128/17 would be aggregated into 10.0/16, and route 10.0.0.128/25 would be aggregated into 10.0.0/24. If multiple entries are made with the same prefix and the same mask, the previous entry is overwritten.		
	The no form of the command removes the aggregate.		
Default	No aggregate routes are defined.		
Parameters	<i>ip-prefix</i> — The destination address of the aggregate route in dotted decimal notation.		
	Values	ipv4-prefix ipv4-prefix-length ipv6-prefix	a.b.c.d (host bits must be 0) 0 — 32 x:x:x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:x:d.d.d.d

	x:	[0 - FFFF]H
	d:	[0—255]D
ipv6-prefix-length	0 — 1	128

The mask associated with the network address expressed as a mask length.

Values 0 — 32

summary-only — This optional parameter suppresses advertisement of more specific component routes for the aggregate.

To remove the **summary-only** option, enter the same aggregate command without the **summary-only** parameter.

as-set — This optional parameter is only applicable to BGP and creates an aggregate where the path advertised for this route will be an AS_SET consisting of all elements contained in all paths that are being summarized.

Use this feature carefully. Aggregating several paths can result in the constant withdrawal and insertion of AS-PATHs as associated component routes of the aggregate that are experiencing changes.

aggregator *as-number:ip-address* — This optional parameter specifies the BGP aggregator path attribute to the aggregate route. When configuring the aggregator, a two-octet AS number used to form the aggregate route must be entered, followed by the IP address of the BGP system that created the aggregate route.

autonomous-system

Syntax	autonomous-system as-number no autonomous-system
Context	config>router
Description	This command configures the autonomous system (AS) number for the router. A router can only belong to one AS. An AS number is a globally unique number with an AS. This number is used to exchange exterior routing information with neighboring ASs and as an identifier of the AS itself.
	If the AS number is changed on a router with an active BGP instance, the new AS number is not used until the BGP instance is restarted either by administratively disabling/enabling (shutdown / no shutdown) the BGP instance or rebooting the system with the new configuration.
Default	No autonomous system number is defined.
Parameters	as-number — The autonomous system number expressed as a decimal integer.
	Values 1 - 65535

confederation

Syntax confederation confed-as-num members as-number [as-number...up to 15 max] no confederation [confed-as-num members as-number...up to 15 max]

Context	config>router		
Description	This command creates confederation autonomous systems within an AS.		
	This technique is used to reduce the number of IBGP sessions required within an AS. Route reflection is another technique that is commonly deployed to reduce the number of IBGP sessions.		
	The no form of the command deletes the specified member AS from the confederation.		
	When no members are specified in the no statement, the entire list is removed and confederation is disabled.		
	When the last member of the list is removed, confederation is disabled.		
Default	no confederation - no confederations are defined.		
Parameters	confed-as-num — The confederation AS number expressed as a decimal integer.		
	Values 1 - 65535		
	members <i>member-as-num</i> — The AS number(s) of members that are part of the confederation, expressed as a decimal integer. Up to 15 members per <i>confed-as-num</i> can be configured.		
	Values 1 - 65535		

ecmp

Syntax	ecmp max-ecmp-routes no ecmp
Context	config>router
Description	This command enables ECMP and configures the number of routes for path sharing; for example, the value 2 means two equal cost routes will be used for cost sharing.
	ECMP can only be used for routes learned with the same preference and same protocol. See the discussion on preferences in the static-route command.
	When more ECMP routes are available at the best preference than configured in <i>max-ecmp-routes</i> , then the lowest next-hop IP address algorithm is used to select the number of routes configured in <i>max-ecmp-routes</i> .
	The no form of the command disables ECMP path sharing. If ECMP is disabled and multiple routes are available at the best preference and equal cost, then the route with the lowest next-hop IP address is used.
Default	no ecmp
Parameters	<i>max-ecmp-routes</i> — The maximum number of equal cost routes allowed on this routing table instance, expressed as a decimal integer. Setting ECMP <i>max-ecmp-routes</i> to 1 yields the same result as entering no ecmp .
	Values 0 – 16

ignore-icmp-redirect

Syntax	[no] ignore-icmp-redirect	
Context	config>router	
Description	This command drops ICMP redirects received on the management interface.	
	The no form of the command accepts ICMP redirects received on the management interface.	

mc-maximum-routes

Syntax	mc-maximum-routes number [log-only] [threshold threshold] no mc-maximum-routes
Context	config>router
Description	This command specifies the maximum number of multicast routes that can be held within a VPN routing/forwarding (VRF) context. When this limit is reached, a log and SNMP trap are sent. If the log-only parameter is not specified and the maximum-routes value is set below the existing number of routes in a VRF, then no new joins will be processed.
	The no form of the command disables the limit of multicast routes within a VRF context. Issue the no form of the command only when the VPRN instance is shutdown.
Default	no mc-maximum-routes
Parameters	number — Specifies the maximum number of routes to be held in a VRF context.
	Values 1 — 2147483647
	log-only — Specifies that if the maximum limit is reached, only log the event. log-only does not disable the learning of new routes.
	threshold <i>threshold</i> — The percentage at which a warning log message and SNMP trap should be sent.
	Values 0 — 100
	Default 10

multicast-info

Syntax	multicast-info-policy policy-name no multicast-info-policy	
Context	configure>router	
Description	This command configures multicast information policy.	
Parameters	policy-name — Specifies the policy name.	
	Values 32 chars max	

7750 SR OS Router Configuration Guide

Router Global Commands

network-domains

Syntax	network-domains
Context	config>router
Description	This command opens context for defining network-domains. This command is applicable only in the base routing context.

description

Syntax	[no] description string		
Context	config>router>network-domains>network-domain		
Description	This command creates a text description stored in the configuration file for a configuration context.		
	The no form of the command removes the description string from the context.		
Default	no description		
Parameters	string — The description character string. Allowed values are any string up to 80 characters long composed of printable, 7-bit ASCII characters. If the string contains special character (#, \$, space, etc.), the entire string must be enclosed within double quotes.		

network-domain

Syntax	network-domain network-domain-name [create] no network-domain network-domain-name	
Context	config>router>network-domains	
Description	This command creates network-domains that can be associated with individual interfaces and SDPs.	
Default	network-domain "default"	
Parameters	network-domain-name — Network domain name character string.	

router-id

Syntax	router-id ip-address no router-id	
Context	config>router	
Description	This command configures the router ID for the router instance.	
	The router ID is used by both OSPF and BGP routing protocols in this instance of the routing table manager. IS-IS uses the router ID value as its system ID.	

7750 SR OS Router Configuration Guide

When configuring a new router ID, protocols are not automatically restarted with the new router ID. The next time a protocol is initialized, the new router ID is used. This can result in an interim period of time when different protocols use different router IDs.

To force the new router ID to be used, issue the **shutdown** and **no shutdown** commands for each protocol that uses the router ID, or restart the entire router.

The **no** form of the command to reverts to the default value.

- DefaultThe system uses the system interface address (which is also the loopback address).If a system interface address is not configured, use the last 32 bits of the chassis MAC address.
- **Parameters** *router-id* The 32 bit router ID expressed in dotted decimal notation or as a decimal value.

service-prefix

Syntax	service-prefix ip-prefix/mask ip-prefix netmask [exclusive] no service-prefix ip-prefix/mask ip-prefix netmask			
Context	config>router			
Description	This command creates an IP address range reserved for IES or VPLS services.			
	The purpose of reserving IP addresses using service-prefix is to provide a mechanism to reserve one or more address ranges for services.			
	When services are defined, the address must be in the range specified as a service prefix. If a service prefix is defined, then IP addresses assigned for services must be within one of the ranges defined in the service-prefix command. If the service-prefix command is not configured, then no limitations exist.			
	Addresses in the range of a service prefix can be allocated to a network port unless the exclusive parameter is used. Then, the address range is exclusively reserved for services.			
	When a range that is a superset of a previously defined service prefix is defined, the subset is replaced with the superset definition; for example, if a service prefix exists for 10.10.10.0/24, and a service prefix is configured as 10.10.0.0/16, then 10.10.10.0/24 is replaced by the new 10.10.0.0/16 configuration.			
	When a range that is a subset of a previously defined service prefix is defined, the subset replaces the existing superset, providing addresses used by services are not affected; for example, if a service prefix exists for 10.10.0.0/16, and a service prefix is configured as 10.10.10.0/24, then the 10.10.0.0/16 entry is removed as long as no services are configured that use 10.10.x.x addresses other than 10.10.10.x.			
	The no form of the command removes all address reservations. A service prefix cannot be while one or more service uses an address or addresses in the range.			
Default	no service-prefi	no service-prefix - no IP addresses are reserved for services.		
Parameters	<i>ip-prefix/mask</i> — The IP address prefix to include in the service prefix allocation in dotted decimal notation.			
	Values	ipv4-prefix: ipv4-prefix-length: ipv6-prefix:	a.b.c.d (host bits must be 0) 0 — 32 x:x:x:x:x:x:x:x (eight 16-bit pieces)	

	x:x:x:x:x:d.d.d.d
	x: [0 — FFFF]H
	d: [0 — 255]D
ipv6-prefix-length:	0 — 128

Values exclusive

When this option is specified, the addresses configured are exclusively used for services and cannot be assigned to network ports.

sgt-qos

Syntax	sgt-qos
Context	config>router
Description	This command configures DSCP/Dot1p re-marking for self-generated traffic.

application

Syntax	application dscp-app-name dscp {dscp-value dscp-name} application dot1p-app-name dot1p dot1p-priority no application {dscp-app-name dot1p-app-name}		
Context	config>router>sgt-qos		
Description	This command configures DSCP/Dot1p re-marking for applications.		
Parameters	<i>dscp-app-name</i> — Specifies the DSCP application name.		
	bgp, cflowd, dhcp, dns, ftp, icmp, igmp, ldp, mld, msdp, ndis, ntp, ospf, pim, radius, rip, rsvp, snmp, snmp-notification, srrp, ssh, syslog, tacplus, telnet, tftp, traceroute, vrrp		
	<i>dscp-value</i> — Specifies the DSCP value		
	Values $0-63$		
	<i>dscp-name</i> — Specifies the DSCP name.		
	none, be, ef, cp1, cp2, cp3, cp4, cp5, cp6, cp7, cp9, cs1, cs2, cs3, cs4, cs5, nc1, nc2, af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, cp11, cp13, cp15, cp17, cp19, cp21, cp23, cp25, cp27, cp29, cp31, cp33, cp35, cp37, cp39, cp41, cp42, cp43, cp44, cp45, cp47, cp49, cp50, cp51, cp52, cp53, cp54, cp55, cp57, cp58, cp59, cp60, cp61, cp62, cp63		
	<i>dot1p-priority</i> — Specifies the Dot1p priority.		
	Values none, 0 — 7		
	<i>dot1p-app-name</i> — Specifies the Dot1p application name.		
	Values arp, isis, pppoe		

dscp

Syntax	dscp dscp-name fc fc-name no dscp dscp-name			
Context	config>router>	config>router>sgt-qos		
Description	This command configures DSCP name to FC mapping.			
Parameters	<i>dscp-name</i> — Specifies the DSCP name.			
	Values	be, ef, cp1, cp2, cp3, cp4, cp5, cp6, cp7, cp9, cs1, cs2, cs3, cs4, cs5, nc1, nc2, af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, cp11, cp13, cp15, cp17, cp19, cp21, cp23, cp25, cp27, cp29, cp31, cp33, cp35, cp37, cp39, cp41, cp42, cp43, cp44, cp45, cp47, cp49, cp50, cp51, cp52, cp53, cp54, cp55, cp57, cp58, cp59, cp60, cp61, cp62, cp63		
	<i>fc-name</i> — Specifies the forward class name.			
	Values	be, 12, af, 11, h2, ef, h1, nc		

triggered-policy

Syntax	triggered-policy no triggered-policy
Context	config>router
Description	This command triggers route policy re-evaluation.
	By default, when a change is made to a policy in the config router policy options context and then committed, the change is effective immediately. There may be circumstances when the changes should or must be delayed; for example, if a policy change is implemented that would affect every BGP peer on a 7750 SR router, the consequences could be dramatic. It would be more effective to control changes on a peer-by-peer basis.
	If the triggered-policy command is enabled, and a given peer is established, and you want the peer to remain up, in order for a change to a route policy to take effect, a clear command with the <i>soft</i> or <i>soft inbound</i> option must be used; for example, clear router bgp neighbor x.x.x soft . This keeps the peer up, and the change made to a route policy is applied only to that peer or group of peers.

single-sfm-overload

Syntax	single-sfm-overload [holdoff-time holdoff-time] no single-sfm-overload		
Context	config>router		
Description	ption This command, if enabled, will cause the IGP protocols (either IS-IS or OSPF) for the service to an overload state when the node only has a single SFM functioning.		
	The no form of this command causes the overload state to be cleared.		

Default	no single-sfm-overload		
Parameters	<i>holdoff-time</i> — This parameter specifies the delay between the detection of a single SFM and enacting the overload state.		
	Values	1— 600 seconds	
	Default	0 seconds	

static-route

 Syntax
 [no] static-route {ip-prefix/prefix-length | ip-prefix netmask} [preference preference]

 [metric metric] [tag tag] [enable | disable] next-hop ip-int-name | ip-address [mcast-family] [bfd-enable|{cpe-check cpe-ip-address [interval seconds] [drop-count count]

 [log]}]
 [no] static-route {ip-prefix/prefix-length | ip-prefix netmask} [preference preference]

 [metric metric] [tag tag] [enable | disable] indirect ip-address [ldp | rsvp-te [disallow-igp]]

 [no] static-route {ip-prefix/prefix-length | ip-prefix netmask} [preference preference]

 [metric metric] [tag tag] [enable | disable] indirect ip-address [ldp | rsvp-te [disallow-igp]]

 [cpe-check cpe-ip-address [interval seconds] [drop-count count] [log]]

 [no] static-route {ip-prefix/prefix-length | ip-prefix netmask} [preference preference]

 [metric metric] [tag tag] [enable | disable] black-hole [mcast-family]

 Context
 config>router

Description This command creates static route entries for both the network and access routes. When configuring a static route, either **next-hop**, **indirect** or **black-hole** must be configured. The **no** form of the command deletes the static route entry. If a static route needs to be removed when multiple static routes exist to the same destination, then as many parameters to uniquely identify the static route must be entered.

If a CPE connectivity check target address is already being used as the target address in a different static route, then cpe-check parameters must match. If they do not, the new configuration command will be rejected.

If a static-route command is issued with no cpe-check target but the destination prefix/netmask and next-hop matches a static route that did have an associated cpe-check, the cpe-check test will be removed from the associated static route.

Default No static routes are defined.

Parameters *ip-prefix/prefix-length* — The destination address of the static route.

Values	ipv4-prefix ipv4-prefix-length ipv6-prefix	a.b.c.d (host bits must be 0) 0 - 32 x:x:x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:d.d.d.d x [0 - FFFF]H d [0 - 255]D
	ipv6-prefix-length	0 - 128

ip-address — The IP address of the IP interface. The *ip-addr* portion of the **address** command specifies the IP host address that will be used by the IP interface within the subnet. This address must be unique within the subnet and specified in dotted decimal notation.

Values	ipv4-address	a.b.c.d (host bits must be 0)
	ipv6-address	x:x:x:x:x:x:x[-interface]
		x:x:x:x:x:d.d.d.d[-interface]
		x: [0FFFF]H
		d: [0255]D
		interface: 32 characters maximum, mandatory for link local
		addresses

netmask — The subnet mask in dotted decimal notation.

Values 0.0.0.0 — 255.255.255 (network bits all 1 and host bits all 0)

preference *preference* — The preference of this static route versus the routes from different sources such as BGP or OSPF, expressed as a decimal integer. When modifing the preference of an existing static route, the metric will not be changed unless specified.

Different protocols should not be configured with the same preference. If this occurs, the tiebreaker is according to the default preference table defined in Table 4 on page 102.

If multiple routes are learned with an identical preference using the same protocol, the lowestcost route is used. If multiple routes are learned with an identical preference using the same protocol, and the costs (metrics) are equal, then the route to use is determined by the configuration of the **ecmp** command.

metric *metric* — The cost metric for the static route, expressed as a decimal integer. This value is used when importing the static route into other protocols such as OSPF. When the metric is configured as 0 then the metric configured in OSPF, default-import-metric, applies. When modifying the metric of an existing static route, the preference will not change unless specified. This value is also used to determine which static route to install in the forwarding table:

- If there are multiple static routes with the same preference but different metrics then the lower cost (metric) route will be installed.
- If there are multiple static routes with equal preferences and metrics then ECMP rules apply.
- If there are multiple routes with different preferences then the lower preference route will be installed.

Default

Values 0 — 65535

1

next-hop [*ip-address* | *ip-int-name*] — Specifies the directly connected next hop IP address used to reach the destination. If the next hop is over an unnumbered interface or a point-to-point interface, the ip-int-name of the unnumbered or point-to-point interface (on this node) can be configured.

The **next-hop** keyword and the **indirect** or **black-hole** keywords are mutually exclusive. If an identical command is entered (with the exception of either the **indirect** or **black-hole** parameters), then this static route will be replaced with the newly entered command, and unless specified, the respective defaults for preference and metric will be applied.

The *ip-address* configured here can be either on the network side or the access side on this node. This address must be associated with a network directly connected to a network configured on this node.

Values	ip-int-name	32 chars max
	ipv4-address	a.b.c.d
	ipv6-address	x:x:x:x:x:x:x[-interface]
		x:x:x:x:x:d.d.d.d[-interface]
		x: [0FFFF]H
		d: [0255]D
		interface: 32 characters maximum, mandatory for link local
		addresses

indirect *ip-address* — Specifies that the route is indirect and specifies the next hop IP address used to reach the destination.

The configured *ip-addr* is not directly connected to a network configured on this node. The destination can be reachable via multiple paths. The indirect address can only resolved from dynamic routing protocol. Another static route cannot be used to resolve the indirect address.

The **indirect** keyword and the **next-hop** or **black-hole** keywords are mutually exclusive. If an identical command is entered (with the exception of either the **next-hop** or **black-hole** parameters), then this static route will be replaced with the newly entered command and unless specified the respective defaults for preference and metric will be applied.

The *ip-addr* configured can be either on the network or the access side and is normally at least one hop away from this node.

black-hole — Specifies the route is a black hole route. If the destination address on a packet matches this static route, it will be silently discarded.

The **black-hole** keyword and the **next-hop** or **indirect** keywords are mutually exclusive. If an identical command is entered (with the exception of either the **next-hop** or **indirect** parameters), then this static route will be replaced with the newly entered command, and unless specified, the respective defaults for preference and metric will be applied.

- **disallow-igp** This value is valid only for indirect static routes. If set and if none of the defined tunneling mechanisms (RSVP-TE, LDP or IP) qualify as a next-hop, the normal IGP next-hop to the indirect next-hop address will not be used. If not set then the IGP next-hop to the indirect next-hop address can be used as the next-hop of the last resort.
- **tag** Adds a 32-bit integer tag to the static route. The tag is used in route policies to control distribution of the route into other protocols.

Table 4: Default Route Preferences

Route Type	Preference	Configurable	
Direct attached	0	No	
Static-route	5	Yes	
OSPF Internal routes	10	Yes	
IS-IS level 1 internal	15	Yes	

Route Type	Preference	Configurable
IS-IS level 2 internal	18	Yes
OSPF External	150	Yes
IS-IS level 1 external	160	Yes
IS-IS level 2 external	165	Yes
BGP	170	Yes

Table 4: Default Route Preferences

Default	5
Values	1 - 255

enable — Static routes can be administratively enabled or disabled. Use the **enable** parameter to reenable a disabled static route. In order to enable a static route, it must be uniquely identified by the IP address, mask, and any other parameter that is required to identify the exact static route.

The administrative state is maintained in the configuration file.

Default enable

disable — Static routes can be administratively enabled or disabled. Use the **disable** parameter to disable a static route while maintaining the static route in the configuration. In order to enable a static route, it must be uniquely identified by the IP address, mask, and any other parameter that is required to identify the exact static route.

The administrative state is maintained in the configuration file.

Default enable

- **bfd-enable** Associates the state of the static route to a BFD session between the local system and the configured nexthop. This keyword cannot be configured if the nexthop is **indirect** or **blackhole** keywords are specified.
- **mcast-family** Enables submission of the IPv4 or IPv6 static route into IPv4 or IPv6 multicast RTM.
- rsvp-te This parameter allows the static route to be resolved via an RSVP-TE based LSP. The static route nexthop will be resolved via the best RSVP-TE based LSP to the associated indirect next hop. By default, if an RSVP-TE LSP is not available, the IGP route table will be used to resolve the associated nexthop. If the keyword "disallow-igp" is configured, the associated static route will not be resolved through the IPv4 route table if an RSVP-TE based LSP is not available.
- **cpe-check** *target-ip-address* This parameter specifies the IP address of the target CPE device. ICMP pings will be sent to this target IP address. This parameter must be configured to enable the CPE connectivity feature for the associated static route. The target-ip-address cannot be in the same subnet as the static route subnet itself to avoid possible circular references. This option is mutually exclusive with BFD support on a given static route.

Default no cpe-check enabled

interval *seconds* — This optional parameter specifies the interval between ICMP pings to the target IP address.

Values	1 —255 seconds
Default	1 seconds

drop-count *count* — This optional parameter specifies the number of consecutive pingreplies that must be missed to declare the CPE down and to de-active the associated static route.

Values	Value range: 1 —255
raidee	vulue lunger 1 200

Default 3

log — This optional parameter enables the ability to log transitions between active and in-active based on the CPE connectivity check. Events should be sent to the system log, syslog and SNMP traps.

Router L2TP Commands

l2tp

Syntax	l2tp
Context	config>router
Description	This command enables the context to configure L2TP parameters. L2TP extends the PPP model by allowing Layer 2 and PPP endpoints to reside on different devices interconnected by a packet-switched network.

calling-number-format

Syntax	calling-numb no calling-nu	er-format ascii-spec mber-format
Context	config>router>	l2tp
Description	This command	specifies the L2TP calling number AVP.
Parameters	ascii-spec — Specified as either char-specification or ascii-spec.	
	char-specification — Ascii-char char-origin	
	<i>char-origin</i> — % origin	
	origin — S r s	
	Values	S: system name, the value of TIMETRA-CHASSIS_MIB::tmnxChassisName
	Values	r : Agent Remote ID
	Values	s : SAP ID, formatted as a character string

exclude-avps

Syntax	exclude-avps calling-number no exclude-avps
Context	config>router>l2tp
Description	This command configures the L2TP AVPs to exclude.

peer-address-change-policy

Syntax peer-ado	dress-change-policy {accept	ignore reject}
-----------------	-----------------------------	------------------

7750 SR OS Router Configuration Guide

Context	config>router>l2tp
Description	This command configures the reaction to a change of tunnel peer address in this router.

receive-window-size

Syntax	receive-window-size [41024] no receive-window-size	
Context	config>router>l2tp	
Description	This command configures the L2TP receive window size.	

session-limit

Syntax	session-limit session-limit no session-limit	
Context	config>router>l2tp	
Description	This command configures the L2TP session limit of this router.	
Parameters	session-limit — Specifies the session limit.	
	Values 1131071	

group

Syntax	group tunnel-group-name [create] [role lac lns] no group tunnel-group-name	
Context	config>router>l2tp	
Description	This command configures an L2TP tunnel group.	
Parameters	tunnel-group-name — Specifies a name string to identify a L2TP group up to 63 characters in length	
	create — This keyword is mandatory when creating a tunnel group name. The create keyword requirement can be enabled/disabled in the environment>create context.	

session-limit

Syntax	session-limit session-limit no session-limit
Context	config>router>l2tp

Description	This command configures the L2TP session limit for the router. L2TP is connection-oriented. The L2TP Network Server (LNS) and LAC maintain state for each call that is initiated or answered by a LAC. An L2TP session is created between the LAC and LNS when an end-to-end PPP connection established between a remote system and the LNS. Datagrams related to the PPP connection are se over the tunnel between the LAC and LNS. There is a one to one relationship between established L2TP sessions and their associated calls.	
Parameters	session-limit —	Specifies the number of sessions allowed.
	Default	no session-limit
	Values	1 — 131071

avp-hiding

Syntax	avp-hiding ser no avp-hiding	nsitive always
Context	config>router>l2tp>group	
Description	This command configures Attribute Value Pair (AVP) hiding. This capability can be used to avoid the passing of sensitive data, such as user passwords, as cleartext in an AVP.	
	The no form of t	he command returns the value to never allow AVP hiding.
Parameters	<i>avp-hiding</i> — Sp group.	ecifies the method to be used for the authentication of the tunnels in this L2TP
	Default	no avp-hiding
	Values	sensitive — AVP hiding is used only for sensitive information (such as username/ password). always — AVP hiding is always used.

challenge

Syntax	challenge alwa no challenge	ays
Context	config>router>l2tp>group	
Description	This command configures the use of challenge-response authentication.	
	The no form of t	he command reverts to the default never value.
Parameters	<i>always</i> — Specifies when challenge-response is to be used for the authentication of the tunnels in this L2TP group.	
	Default	no challenge
	Values	always

destruct-timeout

Syntax	destruct-timeout destruct-timeout no destruct-timeout	
Context	config>router>l2tp>group config>router>l2tp>group>tunnel	
Description	This command configures the period of time that the data of a disconnected tunnel will persist before being removed.	
	The no form of the command removes the value from the configuration.	
Default	no destruct-timeout	
Parameters	<i>destruct-timeout</i> — [Specifies the automatic removal of dynamic L2TP sessions, in seconds, that are no longer active.	
	Default no destruct-timeout	
	Values 60 — 86400	

hello-interval

Syntax	hello-interval no hello-interv	
Context	config>router>l	2tp>group
Description	This command configures the time interval between two consecutive tunnel Hello messages. The Hello message is an L2TP control message sent by either peer of a LAC-LNS control connection. This control message is used as a keepalive for the tunnel.	
	The no form of t	he command removes the interval from the configuration.
Default	60	
Parameters	<i>hello-interval</i> — Specifies the time interval, in seconds, between two consecutive tunnel Hello messages.	
	Default	no hello-interval
	Values	60 — 3600

idle-timeout

Syntax	idle-timeout idle-timeout no idle-timeout
Context	config>router>l2tp>group

Description	This command configures the period of time that an established tunnel with no active sessions will persist before being disconnected.		
	Enter the no form of the command to maintain a persistent tunnel.		
	The no form of the command removes the idle timeout from the configuration.		
Default	no idle-timeout		
Parameters	<i>idle-timeout</i> — Specifies the idle timeout value, in seconds until the group is removed.		
	Default no idle-timeout		
	Values 0 — 3600		

Ins-group

Syntax	Ins-group Ins-group-id no Ins-group		
Context	config>router>l2tp>group		
Description	This command configures the ISA LNS group.		
Parameters	<i>lns-group-id</i> — Specifies the LNS group ID.		
	Values 14		

local-address

Syntax	local-address ip-address no local-address	
Context	config>router>l2tp>group>tunnel	
Description	This command configures the local address.	
Parameters	<i>ip-address</i> — Specifies the IP address used during L2TP authentication.	

local-name

Syntax	local-name host-name no local-name
Context	config>router>l2tp>group config>router>l2tp>group>tunnel
Description	This command creates the local host name used by this system for the tunnels in this L2TP group during the authentication phase of tunnel establishment. It can be used to distinguish tunnels.
	The no form of the command removes thename from the configuration.
Default	local-name

7750 SR OS Router Configuration Guide

Parameters	host-name — Specifies the host name, up to 64 characters in length, that the router will use to identify
	itself during L2TP authentication.

Default no local-name

max-retries-estab

Syntax	max-retries-estab max-retries no max-retries-estab		
Context	config>router>l2tp>group config>router>l2tp>group>tunnel		
Description	This command configures the number of retries allowed for this L2TP tunnel while it is established, before its control connection goes down.		
	The no form of the command removes the value from the configuration.		
Default	no max-retries-estab		
Parameters	max-retries — Specifies the maximum number of retries for an established tunnel.		
	Default no max-retries-estab		
	Values 2 — 7		

max-retries-not-estab

Syntax	max-retries-not-estab max-retries no max-retries-not-estab		
Context	config>router>l2tp>group config>router>l2tp>group>tunnel		
Description	This command configures the number of retries allowed for this L2TP tunnel while it is not established, before its control connection goes down.		
	The no form of the command removes the value from the configuration.		
Default	no max-retries-not-estab		
Parameters	max-retries — Specifies the maximum number of retries for non-established tunnels.		
	Default no max-retries-not-estab		
	Values 2 — 7		

password

Syntax password password [hash | hash2] no password

Context	config>router>l2tp>group config>router>l2tp>group>tunnel		
Description	This command configures the password between L2TP LAC and LNS		
	The no form of the command removes the password.		
Default	no password		
Parameters	password — Configures the password used for challenge/response calculation and AVP hiding. The maximum length can be up to 20 characters if unhashed, 32 characters if hashed, 54 characters if the hash2 keyword is specified.		
	hash — Specifies the key is entered in an encrypted form. If the hash parameter is not used, the ke is assumed to be in a non-encrypted, clear text form. For security, all keys are stored in encrypted		
	hash2 — Specifies the key is entered in a more complex encrypted form. If the hash2 parameter is not used, the less encrypted hash form is assumed.		
	Default no password		

ррр

Syntax	ррр		
Context	config>router>l2tp>group		
Description	This command configures PPP for the L2TP tunnel group.		

authentication

Syntax	authentication {chap pap pref-chap}		
Context	config>router>l2tp>group>ppp		
Description	This command configures the PPP authentication protocol to negotiate.		

authentication-policy

Syntax	authentication-policy auth-policy-name no authentication-policy	
Context	config>router>l2tp>group>ppp	
Description	This command configures the authentication policy.	
Parameters	<i>auth-policy-name</i> — Specifies the authentication policy name.	
	Values 32 chars max	

7750 SR OS Router Configuration Guide

default-group-interface

Syntax	default-group-interface ip-int-name service-id service-id no default-group-interface		
Context	config>router>l2tp>group>ppp		
Description	This command configures the default group interface.		
Parameters	<i>ip-int-name</i> — Specifies the interface name.		
	Values	32 chars max	
	<i>service-id</i> — Specifies the service ID.		
	Values	12147483648	
	svc-name — Specifies the service name (instead of service ID).		
	Values	64 chars max	

keepalive

Syntax	keepalive sec no keepalive	conds [hold-up-multiplier multiplier]
Context	config>router>l2tp>group>ppp	
Description	This command configures the PPP keepalive interval and multiplier.	
Parameters	seconds — Specifies in seconds the interval.	
	Values	10300
	<i>multiplier</i> — Specifies the multiplier.	
	Values	15

mtu

Syntax	mtu <i>mtu-bytes</i> no mtu	
Context	config>router>l2tp>group>ppp	
Description	This command configures the maximum PPP MTU size.	
Parameters	<i>mtu-bytes</i> — Specifies, in bytes, the maximum PPP MTU size.	
	Values 5129212	

proxy-authentication

Syntax	[no] proxy-authentication
Context	config>router>l2tp>group>ppp
Description	This command configures the use of the authentication AVPs received from the LAC.

proxy-lcp

Syntax	[no] proxy-lcp
Context	config>router>l2tp>group>ppp
Description	This command configures the use of the proxy LCP AVPs received from the LAC.

user-db

Syntax	user-db /ocal-u no user-db	iser-db-name
Context	config>router>l2tp>group>ppp	
Description	This command configures the local user database to use for PPP PAP/CHAP authentication.	
Parameters	local-user-db-name — Specifies the local user database name.	
	Values	32 chars max

session-assign-method

Syntax	session-assign-method <i>weighted</i> no session-assign-method		
Context	config>router>	config>router>l2tp>group	
Description	This command specifies how new sessions are assigned to one of the set of suitable tunnels that are available or could be made available.		
Default	no session-assign-method		
Parameters	<i>weighted</i> — specifies that the sessions are shared between the available tunnels. If necessary, new tunnels are set up until the maximum number is reached. The distribution aims at an equal ratio of the actual number of sessions to the maximum number of sessions.		
	Default	no session-assign-method. All new sessions are placed by preference in existing tunnels.	
	Values	weighted — Enables weighted preference to tunnels in the group.	

Router L2TP Commands

session-limit

Syntax	session-limit session-limit no session-limit	
Context	config>router>l2tp>group config>router>l2tp>group>tunnel	
Description	This command configures the session limit. The value controls how many L2TP session will allowed within a given context (system, group, tunnel).	
	The no form of the command removes the value from the configuration.	
Default	no session-limit	
Parameters	session-limit — Specifies the allowed number of sessions within the given context.	
	Values 1 — 131071	

Router L2TP Tunnel Commands

tunnel

Syntax	tunnel tunnel-name [create] no tunnel tunnel-name
Context	config>router>l2tp>group
Description	This command configures an L2TP tunnel. A tunnel exists between a LAC-LNS pair and consists of a Control Connection and zero or more L2TP sessions. The tunnel carries encapsulated PPP datagrams and control messages between the LAC and the L2TP Network Server (LNS).
Parameters	tunnel-name — Specifies a valid string to identify a L2TP up to 32 characters in length.
	create — mandatory while creating a new tunnel

auto-establish

Syntax	[no] auto-establish	
Context	config>router>l2tp>group>tunnel	
Description	This command specifies if this tunnel is to be automatically set up by the system.	
	no auto-establish	

avp-hiding

Syntax	avp-hiding {never sensitive always} no avp-hiding		
Context	config>router>	config>router>l2tp>group>tunnel	
Description	This command configures Attribute Value Pair (AVP) hiding. This capability can be used to avoid the passing of sensitive data, such as user passwords, as cleartext in an AVP.		
	Note that it is recommended that sensitive information not be sent in clear text.		
	The no form of the command removes the parameter of the configuration and indicates that the value on group level will be taken.		
Default	no avp-hiding		
Parameters	avp-hiding — Specifies the method to be used for the authentication of the tunnel.		
	Values	never — AVP hiding is not used. sensitive — AVP hiding is used only for sensitive information (such as username/ password). always — AVP hiding is always used.	

challenge

Syntax	challenge challenge-mode no challenge		
Context	config>router>l2tp>group>tunnel		
Description	This command configures the use of challenge-response authentication.		
	The no form of the command removes the parameter from the configuration and indicates that the value on group level will be taken.		
Default	no challenge		
Parameters	<i>challenge-mode</i> — Specifies when challenge-response is to be used for the authentication of the tunnel.		
	Values	always — Always allows the use of challenge-response authentication. never — Never allows the use of challenge-response authentication.	

hello-interval

Syntax	hello-interval hello-interval hello-interval infinite no hello-interval
Context	config>router>l2tp>group>tunnel
Description	This command configures the number of seconds between sending Hellos for a L2TP tunnel. The no form removes the parameter from the configuration and indicates that the value on group level will be taken.
Parameters	<i>hello-interval</i> — Specifies the time interval, in seconds, between two consecutive tunnel Hello messages.
	Values 60 — 3600
	infinite — Specifies that no hello messages are sent.

idle-timeout

Syntax	idle-timeout idle-timeout
-	idle-timeout infinite
	no idle-timeout
-	

- **Context** config>router>l2tp>group>tunnel
- **Description** This command configures the idle timeout to wait before being disconnect. The no form indicates that the parameter will be removed from the configuration and that the value specified on group level will be taken.

Parameters *idle-timeout* — Specifies the idle timeout, in seconds.

Values 0 — 3600

infinite — Specifies that the tunnel will not be closed when idle.

peer

Syntax	peer ip-address no peer	
Context	config>router>l2tp>group>tunnel	
Description	This command configures the peer address.	
	The no form of the command removes the IP address from the tunnel configuration.	
Default	no peer	
Parameters	<i>ip-address</i> — Sets the LNS IP address for the tunnel.	

preference

Syntax	preference preference no preference		
Context	config>router>l2tp>group>tunnel		
Description	This command configures a preference number that indicates the relative preference assigned tunnel when using a weighted session assignment.		
	The no form of the command removes the preference value from the tunnel configuration.		
Default	no preference		
Parameters	<i>preference</i> — Specifies the tunnel preference number with its group. The value 0 corresponds to t highest preference.		
	Values 0 — 16777215		

remote-name

Syntax	remote-name host-name no remote-name
Context	config>router>l2tp>group>tunnel
Description	This command configures a string to be compared to the host name used by the tunnel peer during the authentication phase of tunnel establishment.
Parameters	host-name — Specifies a remote host name for the tunnel up to 64 characters in length.

Router Interface Commands

interface

Syntax	[no] interface ip-int-name			
Context	config>router			
Description	This command creates a logical IP routing interface. Once created, attributes like IP address, port, or system can be associated with the IP interface.			
	Interface names are case-sensitive and must be unique within the group of IP interfaces defined for config router interface and config service ies interface . Interface names must not be in the dotted decimal notation of an IP address.; for example, the name "1.1.1.1" is not allowed, but "int-1.1.1.1" is allowed. Show commands for router interfaces use either the interface names or the IP addresses. Ambiguity can exist if an IP address is used as an IP address and an interface name. Duplicate interface names can exist in different router instances, although this is not recommended because it is confusing.			
	When a new name is entered, a new logical router interface is created. When an existing interface name is entered, the user enters the router interface context for editing and configuration.			
	Although not a keyword, the ip-int-name " system " is associated with the network entity (such as a specific 7750 SR), not a specific interface. The system interface is also referred to as the loopback address.			
	The no form of the command removes the IP interface and all the associated configurations. The interface must be administratively shut down before issuing the no interface command.			
Default	No interfaces or names are defined within the system.			
Parameters	 <i>ip-int-name</i> — The name of the IP interface. Interface names must be unique within the group of defined IP interfaces for config router interface and config service ies interface commands. An interface name cannot be in the form of an IP address. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes. 			
	Values $1 - 32$ alphanumeric characters.			
	If the <i>ip-int-name</i> already exists, the context is changed to maintain that IP interface. If <i>ip-int-name</i> already exists within another service ID or is an IP interface defined within the config router commands, an error will occur and the context will not be changed to that IP interface. If <i>ip-int-name</i> does not exist, the interface is created and the context is changed to that interface for further command processing.			

address

Syntax	address {ip-address/mask ip-address netmask} [broadcast {all-ones / host-ones}] no address
Context	config>router>interface
Description	This command assigns an IP address, IP subnet, and broadcast address format to an IP interface. Only one IP address can be associated with an IP interface.
	An IP address must be assigned to each IP interface. An IP address and a mask combine to create a local IP prefix. The defined IP prefix must be unique within the context of the routing instance. It cannot overlap with other existing IP prefixes defined as local subnets on other IP interfaces in the same routing context within the router.
	The local subnet that the address command defines must not be part of the services address space within the routing context by use of the config router service-prefix command. Once a portion of the address space is allocated as a service prefix, that portion is not available to IP interfaces for network core connectivity.
	The IP address for the interface can be entered in either CIDR (Classless Inter-Domain Routing) or traditional dotted decimal notation. Show commands display CIDR notation and are stored in configuration files.
	By default, no IP address or subnet association exists on an IP interface until it is explicitly created.
	The no form of the command removes the IP address assignment from the IP interface. Interface- specific configurations for IGP protocols like OSPF are also removed. The no form of this command can only be performed when the IP interface is administratively shut down. Shutting down the IP interface will operationally stop any protocol interfaces or MPLS LSPs that explicitly reference that IP address. When a new IP address is defined, the IP interface can be administratively enabled (no shutdown), which reinitializes the protocol interfaces and MPLS LSPs associated with that IP interface.
	If a new address is entered while another address is still active, the new address will be rejected.
Default	No IP address is assigned to the IP interface.
Parameters	<i>ip-address</i> — The IP address of the IP interface. The <i>ip-addr</i> portion of the address command specifies the IP host address that will be used by the IP interface within the subnet. This address must be unique within the subnet and specified in dotted decimal notation.
	Values 1.0.0.0 — 223.255.255
	/ — The forward slash is a parameter delimiter that separates the <i>ip-addr</i> portion of the IP address from the mask that defines the scope of the local subnet. No spaces are allowed between the <i>ip-addr</i> , the " <i>f</i> " and the <i>mask-length</i> parameter. If a forward slash does not ediately follow the <i>ip-addr</i> , a dotted decimal mask must follow the prefix.
	mask-length — The subnet mask length when the IP prefix is specified in CIDR notation. When the IP prefix is specified in CIDR notation, a forward slash (/) separates the <i>ip-addr</i> from the mask- length parameter. The mask length parameter indicates the number of bits used for the network portion of the IP address; the remainder of the IP address is used to determine the host portion of the IP address. Allowed values are integers in the range 1— 32. Note that a mask length of 32 is reserved for system IP addresses.Values $1-32$

mask — The subnet mask in dotted decimal notation. When the IP prefix is not specified in CIDR notation, a space separates the *ip-addr* from a traditional dotted decimal mask. The mask parameter indicates the complete mask that will be used in a logical 'AND' function to derive the local subnet of the IP address. Note that a mask of 255.255.255.255 is reserved for system IP addresses.

Values 128.0.0.0 — 255.255.255.255

netmask — The subnet mask in dotted decimal notation.

Values 0.0.0.0 — 255.255.255 (network bits all 1 and host bits all 0)

broadcast {all-ones | host-ones} — The optional broadcast parameter overrides the default broadcast address used by the IP interface when sourcing IP broadcasts on the IP interface. If no broadcast format is specified for the IP address, the default value is host-ones, which indictates a subnet broadcast address. Use this parameter to change the broadcast address to all-ones or revert back to a broadcast address of host-ones.

The **all-ones** keyword following the **broadcast** parameter specifies that the broadcast address used by the IP interface for this IP address will be 255.255.255.255, also known as the local broadcast.

The **host-ones** keyword following the **broadcast** parameter specifies that the broadcast address used by the IP interface for this IP address will be the subnet broadcast address. This is an IP address that corresponds to the local subnet described by the *ip-addr* and the *mask-length* or *mask* with all the host bits set to binary 1. This is the default broadcast address used by an IP interface.

The **broadcast** parameter within the **address** command does not have a negate feature, which is usually used to revert a parameter to the default value. To change the **broadcast** type to **host-ones** after being changed to **all-ones**, the **address** command must be executed with the **broadcast** parameter defined.

The broadcast format on an IP interface can be specified when the IP address is assigned or changed.

This parameter does not affect the type of broadcasts that can be received by the IP interface. A host sending either the local broadcast (**all-ones**) or the valid subnet broadcast address (**host-ones**) will be received by the IP interface.

Default host-ones Values all-ones, host-ones

allow-directed-broadcasts

Syntax	[no] allow-directed-broadcasts	
Context	config>router>interface	
Description	This command enables the forwarding of directed broadcasts out of the IP interface.	
	A directed broadcast is a packet received on a local router interface destined for the subnet broadcast address of another IP interface. The allow-directed-broadcasts command on an IP interface enables	

or disables the transmission of packets destined to the subnet broadcast address of the egress IP interface.

When enabled, a frame destined to the local subnet on this IP interface is sent as a subnet broadcast out this interface. **NOTE**: Allowing directed broadcasts is a well-known mechanism used for denial-of-service attacks.

By default, directed broadcasts are not allowed and are discarded at this egress IP interface.

The no form of the command disables directed broadcasts forwarding out of the IP interface.

Default no allow-directed-broadcasts — Directed broadcasts are dropped.

arp-timeout

Syntax	arp-timeout seconds no arp-timeout		
Context	config>router>interface		
Description	This command configures the minimum time, in seconds, an ARP entry learned on the IP interface is stored in the ARP table. ARP entries are automatically refreshed when an ARP request or gratuitous ARP is seen from an IP host. Otherwise, the ARP entry is aged from the ARP table. If the arp-timeout value is set to 0 seconds, ARP aging is disabled.		
	The no form of the command reverts to the default value.		
Default	14400 seconds (4 hours)		
Parameters	<i>seconds</i> — The minimum number of seconds a learned ARP entry is stored in the ARP table, expressed as a decimal integer. A value of 0 specifies that the timer is inoperative and learned ARP entries will not be aged.		
	Values 0 — 65535		

bfd

Syntax	bfd transmit-interval [receive receive-interval] [multiplier multiplier] [echo-receive echo- interval] [type cpm-np] no bfd
Context	config>router>interface
Description	This command specifies the bidirectional forwarding detection (BFD) parameters for the associated IP interface. If no parameters are defined the default values are used.
	The multiplier specifies the number of consecutive BFD messages that must be missed from the peer before the BFD session state is changed to down and the upper level protocols (OSPF, IS-IS, BGP or PIM) is notified of the fault.
	The no form of the command removes BFD from the router interface regardless of the IGP/RSVP.
	Important notes: On the 7750-SR, the <i>transmit-interval</i> and receive <i>receive-interval</i> values can only be modified to a value less than 100 ms when:

	1	. The typ	e cpm-np option is explicitly configured.	
	2		vice is shut down (shutdown)	
	3	3. The interval is specified $10 - 100000$.		
	4	 The service is re-enabled (no shutdown) 		
		To remove the type cpm-np option, re-issue the bfd command without specifying the type parameter.		
De	fault no bfo	1		
Parame	eters transm	<i>transmit-interval</i> — Sets the transmit interval, in milliseconds, for the BFD session.		
	v	alues	100 — 100000 10 — 100000 (see Important Notes above)	
	D	efault	100	
	receiv	receive receive-interval — Sets the receive interval, in milliseconds, for the BFD session.		
	v	alues	100 — 100000 10 — 100000 (see Important Notes above)	
	D	efault	100	
	multi	plier <i>multi</i> j	<i>plier</i> — Set the multiplier for the BFD session.	
	v	alues	3—20	
	D	efault	3	
		receive ech ession.	<i>no-interval</i> — Sets the minimum echo receive interval, in milliseconds, for the BFD	
	v	alues	100 — 100000	
	D	efault	100	
	• =		Selects the CPM network processor as the local termination point for the BFD Important Notes, above.	
cflowd				
Sy	ntax cflow no cf	rd {acl in lowd	terface}	

- **Context** config>router>interface
- **Description** This command enables **cflowd** to collect traffic flow samples through a router for analysis. **cdflowd** is used for network planning and traffic engineering, capacity planning, security, and application, as well as user profiling, performance monitoring, and SLA measurement. When **cflowd** is enabled at the interface level, all IP packets forwarded by the interface are subjected to analysis according to the **cflowd** configuration.

Default no cflowd

Parametersacl — cflowd policy associated with a filter.interface — cflowd policy associated with an IP interface.

cpu-protection

Syntax	cpu-protection <i>policy-id</i> no cpu-protection		
Context	config>router>interface		
Description	This command assigns an existing CPU protection policy for the interface. The CPU protection policies are configured in the config>sys>security>cpu-protection>policy <i>cpu-protection-policy-id</i> context.		
Parameters	<i>policy-id</i> — Specifies an existing CPU protection policy.		
	Values 1 – 255		

delayed-enable

Syntax	delayed-enable seconds no delayed-enable		
Context	config>router>if		
Description	This command creates a delay to make the interface operational by the specified number of seconds		
	The value is used whenever the system attempts to bring the interface operationally up.		
Parameters	seconds — Specifies a delay, in seconds, to make the interface operational.		
	Values 1 — 1200		

local-proxy-arp

Syntax	[no] local-proxy-arp		
Context	config>router>interface		
Description	This command enables local proxy ARP on the interface.		
Default	no local-proxy-arp		

Idp-shortcut

Syntax	[no] Idp-shortcut
Context	config>router

7750 SR OS Router Configuration Guide

Description This command enables the resolution of IGP routes using LDP LSP across all network interfaces participating in the IS-IS and OSPF routing protocol in the system.

When LDP shortcut is enabled, LDP populates the routing table with next-hop entries corresponding to all prefixes for which it activated an LDP FEC. For a given prefix, two route entries are populated in the system routing table. One route corresponds to the LDP shortcut next-hop and has an owner of LDP. The other route is the regular IP next-hop. The LDP shortcut next-hop always has preference over the regular IP next-hop for forwarding user packets and specified control packets over a given outgoing interface to the route next-hop.

All user and specified control packets for which the longest prefix match in RTM yields the FEC prefix will be forwarded over the LDP LSP.

When an IPv4 packet is received on an ingress network interface, a subscriber IES interface, or a regular IES interface, the lookup of the packet by the ingress IOM will result in the packet being sent labeled with the label stack corresponding to the NHLFE of the LDP LSP when the preferred RTM entry corresponds to an LDP shortcut.

If the preferred RTM entry corresponds to an IP next-hop, the IPv4 packet is forwarded unlabelled.

When ECMP is enabled and multiple equal-cost next-hops exit for the IGP route, the ingress IOM will spray the packets for this route based on hashing routine currently supported for IPv4 packets. When the preferred RTM entry corresponds to an LDP shortcut route, spraying will be performed across the multiple next-hops for the LDP FEC. The FEC next-hops can either be direct link LDP neighbors or T-LDP neighbors reachable over RSVP LSPs in the case of LDP-over-RSVP but not both.

When the preferred RTM entry corresponds to a regular IP route, spraying will be performed across regular IP next-hops for the prefix..

The no form of this command disables the resolution of IGP routes using LDP shortcuts.

Default no ldp-shortcut

ldp-sync-timer

SyntaxIdp-sync-timer seconds
no Idp-sync-timerContextconfig>router>interface

Description This command enables synchronization of IGP and LDP. When a link is restored after a failure, IGP sets the link cost to infinity and advertises it. The actual value advertised in OSPF is 0xFFFF (65535). The actual value advertised in IS-IS regular metric is 0x3F (63) and in IS-IS wide-metric is 0xFFFFE (16777214). This feature is not supported on RIP interfaces.

Note that if an interface belongs to both IS-IS and OSPF, a physical failure will cause both IGPs to advertise infinite metric and to follow the IGP-LDP synchronization procedures. If only one IGP bounced on this interface or on the system, then only the affected IGP advertises the infinite metric and follow the IGP-LDP synchronization procedures.

Next LDP hello adjacency is brought up with the neighbour. The LDP synchronization timer is started by IGP from the time the LDP session to the neighbor is UP over the interface. This is to allow time for the label-FEC bindings to be exchanged.

When the LDP synchronization timer expires, the link cost is restored and is re-advertised. IGP will announce a new best next-hop and LDP will use it if the label binding for the neighbor's FEC is available.

If the user changes the cost of an interface, the new value is advertised at the next flooding of link attributes by IGP. However, if the LDP synchronization timer is still running, the new cost value will only be advertised after the timer expired. Also, the new cost value will be advertised after the user executes any of the following commands if the currently advertised cost is different:

- tools>perform>router>isis>ldp-sync-exit
- tools>perform>router>ospf>ldp-sync-exit
- config>router>interface>no ldp-sync-timer
- config>router>ospf>disable-ldp-sync
- router>isis>disable-ldp-sync

If the user changes the value of the LDP synchronization timer parameter, the new value will take effect at the next synchronization event. In other words, if the timer is still running, it will continue using the previous value.

If parallel links exist to the same neighbor, then the bindings and services should remain UP as long as there is one interface that is UP. However, the user configured LDP synchronization timer still applies on the failed then restored interface. In this case, the 7750 will only consider this interface for forwarding after IGP re-advertized its actual cost value.

Note that the LDP Sync Timer State is not always synched across to the standby CPM, so after an activity switch the timer state might not be same as it was on the previous active CPM.

The no form of this command disables IGP/LDP synchronization and deletes the configuration

Default no ldp-sync-timer

Parameters seconds — Specifies the time interval for the IGP-LDP synchronization timer in seconds.

Values 1 – 1800

loopback

Syntax	[no] loopback
Context	config>router>interface
Description	This command configures the interface as a loopback interface.
Default	Not enabled

Isr-load-balancing

Syntax Isr-load-balancing hashing-algorithm no Isr-load-balancing

Context config>router>if

7750 SR OS Router Configuration Guide

Description	This command specifies whether the IP header is used in the LAG and ECMP LSR hashing algorithm. This is the per interface setting.		
Default	no lsr-load-balancing		
Parameters	lbl-only — Only the label is used in the hashing algorithm.		
	lbl-ip — The IP header is included in the hashing algorithm.		
	ip-only — the IP header is used exclusively in the hashing algorithm		

lsr-label-ip-hash

Syntax	Isr-label-ip-hash	
Context	config>router>interface	
Description	This command enables the LSR hashing on label stack and IP header. Isr-label-ip-hash provides ability to hash on the IP header if a packet is IP. An LSR will consider a packet to be IP if the fir nibble following the bottom of the label stack is either 4 (IPv4) or 6 (IPv6).	
Users can also selectively enable or disable this option on a specific network interface in config>system>lsr-label-ip-hash context.		
	When the LSR hash routine is disabled on the system or on a specific interface interface, the LSR will fall back to the hashing on label stack only behavior.	

mac

Syntax	mac ieee-mac-addr no mac
Context	config>router>interface
Description	This command assigns a specific MAC address to an IP interface. Only one MAC address can be assigned to an IP interface. When multiple mac commands are entered, the last command overwrites the previous command.
	The no form of the command returns the MAC address of the IP interface to the default value.
Default	IP interface has a system-assigned MAC address.
Parameters	<i>ieee-mac-addr</i> — Specifies the 48-bit MAC address for the IP interface in the form <i>aa:bb:cc:dd:ee:ff</i> or <i>aa-bb-cc-dd-ee-ff</i> , where <i>aa</i> , <i>bb</i> , <i>cc</i> , <i>dd</i> , <i>ee</i> and <i>ff</i> are hexadecimal numbers. Allowed values are any non-broadcast, non-multicast MAC and non-IEEE reserved MAC addresses.

multihoming

Syntax [no] multihoming primary|secondary [hold-time holdover-time]

Context config>router>interface

Description This command sets the associated loopback interface to be an anycast address used in multi-homing resiliency, as either the primary or a secondary (a primary address on the alternate router). The optional hold-time parameter is only applicable for the secondary context and specifies how long label information learned about the secondary anycast address should be kept after that peer is declared down. This timer should be set to a value large enough for the remainder of the network to detect the failure and complete the reconvergence process.

The no form of the command disables this setting.

Default no multihoming

Parameters *holdover-time* — Specifies the number of seconds the router should hold label information learned from the alternate router in its secondary table. This is to allow the reset of the network to reconverge after a router failure before the anycase based label assignments are flushed from the forwarding plane.

Values	0 - 65535
Default	90

network-domain

Syntax	network-domain network-domain-name no network-domain
Context	config>router>interface
Description	This command assigns a given interface to a given network-domain. The network-domain is then taken into account during sap-ingress queue allocation for VPLS SAP.
	The network-domain association can only be done in a base-routing context. Associating a network domain with an loop-back or system interface will be rejected. Associating a network-domain with an interface that has no physical port specified will be accepted, but will have no effect as long as a corresponding port, or LAG, is defined
	Single interfaces can be associated with multiple network-domains.
Default	per default "default" network domain is assigned

ntp-broadcast

Syntax	[no] ntp-broadcast		
Context	config>router>interface		
Description	This command enables SNTP broadcasts received on the IP interface. This parameter is only valid when the SNTP broadcast-client global parameter is configured.		
	The no form of the command disables SNTP broadcast received on the IP interface.		

Default no ntp-broadcast

port

Syntax	port port-name no port				
Context	config>router>interface				
Description	This command creates an association with a logical IP interface and a physical port.				
	An interface car	n also be ass	sociated with th	ne system (loopb	ack address).
		sociation m	ust be deleted b		ociated with another port or the system. In and is re-attempted. The <i>port-id</i> can be in
	• Etherno	et Interfaces	5		
		example, 1/	1/3 specifies p		number/MDA_number/port_number A installed in MDA slot 1 on the card
	• SONE	Г/SDH inter	rfaces		
			sents a POS int gured as a netv		<i>id</i> must include the <i>channel-id</i> . The POS
	The no form of a only be perform				he port. The no form of this command can own.
Default	No port is assoc	iated with t	he IP interface.		
Parameters	<i>port-id</i> — The physical port identifier to associate with the IP interface.				
	Values	port-id	<i>slot/mda/port</i> bundle-id	t[.channel]	t/mda. <i>bundle-num</i> keyword ima, ppp 1 — 256
			bpgrp-id	bpgrp- <i>type-bpg</i>	rp-num
				bpgrp	keyword
				type bpgrp-num	ima, ppp 1 — 1280
			aps-id	aps-group-id[.c	
				aps group-id	keyword 1 — 64
			ccag-id -	ccag-id.path-id[
				ccag	keyword
				id path-id	1 — 8 a, b
				cc-type	.sap-net, .net-sap
			eth-tunnel-id	- eth-tunnel- <i>id</i>	
				eth-tunnel id	keyword 1 — 64
			lag-id	lag- <i>id</i>	1 07
			-	-	

lag	keyword
id	1 - 200

proxy-arp-policy

Syntax	[no] proxy-arp-policy policy-name [policy-name(up to 5 max)]		
Context	config>router>interface		
Description	This command enables and configure proxy ARP on the interface and specifies an existing policy- statement to analyze match and action criteria that controls the flow of routing information to and from a given protocol, set of protocols, or a particular neighbor. The policy-name is configured in the config>router>policy-options context.		
	Use proxy ARP so the 7750 SR responds to ARP requests on behalf of another device. Static ARP is used when a 7750 SR needs to know about a device on an interface that cannot or does not respond to ARP requests. Thus, the 7750 SR OS configuration can state that if it has a packet that has a certain IP address to send it to the corresponding ARP address.		
Default	no proxy-arp-policy		
Parameters	<i>policy-name</i> — The export route policy name. Allowed values are any string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes. The specified policy name(s) must already be defined.		

qos

Syntax	<pre>qos network-policy-id [queue-redirect-group queue-group-name] no qos</pre>
Context	config>router>interface

allows for the packets that match the policy criteria to be remarked.

DescriptionThis command associates a network Quality of Service (QoS) policy with an IP interface. Only one
network QoS policy can be associated with an IP interface at one time. Attempts to associate a second
QoS policy return an error.
Packets are marked using QoS policies on edge devices. Invoking a QoS policy on a network port

The queue-redirect-group parameter creates an association between the IP interface and an egress port queue group. When the network QoS policy ID contains an egress forwarding plane that is directed to a queue group queue ID, the network QoS policy must be applied to the IP interface with a valid egress port queue group name. The queue group name must exist on the egress port associated with the IP interface and the group must contain a queue ID matching the queue ID for each redirected

The IP interface may redirect its forwarding classes to a single port queue group. Forwarding classes that are not redirected to a queue within the group are mapped to the default forwarding class egress queue on the port.

forwarding class in the QoS policy.

If the QoS command is re-executed without the queue-redirect-group parameter specified, all forwarding classes will be remapped to the default port forwarding class egress queues.

The **no** form of the command removes the QoS policy association from the SAP or IP interface, and the QoS policy reverts to the default.

Default qos 1 — IP interface associated with network QoS policy 1.

Parameters *network-policy-id* — An existing network policy ID to associate with the IP interface.

Values 1 — 65535

queue-redirect-group *queue-group-name* — This optional parameter specifies that the *queue-group-name* will be used for all egress forwarding class redirections within the network QoS policy ID. The specified *queue-group-name* must exist as a port egress queue group on the port associated with the IP interface.

remote-proxy-arp

Context	config>router>interface
Description	This command enables remote proxy ARP on the interface.
Default	no remote-proxy-arp

secondary

Syntax	secondary {[<i>ip-addressImask</i> <i>ip-address netmask</i>]} [broadcast {all-ones host-ones}] [igp-inhibit] no secondary <i>ip-addr</i>
Context	config>router>interface
Description	Use this command to assign up to 16 secondary IP addresses to the interface. Each address can be configured in an IP address, IP subnet or broadcast address format.
	<i>ip-address</i> — The IP address of the IP interface. The <i>ip-address</i> portion of the address command specifies the IP host address that will be used by the IP interface within the subnet. This address must be unique within the subnet and specified in dotted decimal notation.
	Values 1.0.0.0 — 223.255.255
	/ — The forward slash is a parameter delimiter that separates the <i>ip-address</i> portion of the IP address from the mask that defines the scope of the local subnet. No spaces are allowed between the <i>ip-addr</i> , the " <i>l</i> " and the <i>mask-length</i> parameter. If a forward slash does not ediately follow the <i>ip-addr</i> , a dotted decimal mask must follow the prefix.
	<i>mask-length</i> — The subnet mask length when the IP prefix is specified in CIDR notation. When the IP prefix is specified in CIDR notation, a forward slash (/) separates the <i>ip-address</i> from the <i>mask-length</i> parameter. The mask length parameter indicates the number of bits used for the network portion of the IP address; the remainder of the IP address is used to determine the host

7750 SR OS Router Configuration Guide

portion of the IP address. Allowed values are integers in the range 1— 32. Note that a mask length of 32 is reserved for system IP addresses.

Values 1 — 32

mask — The subnet mask in dotted decimal notation. When the IP prefix is not specified in CIDR notation, a space separates the *ip-addr* from a traditional dotted decimal mask. The mask parameter indicates the complete mask that will be used in a logical 'AND' function to derive the local subnet of the IP address. Note that a mask of 255.255.255.255 is reserved for system IP addresses.

Values 128.0.0.0 — 255.255.255.255

broadcast {all-ones | host-ones} — The optional broadcast parameter overrides the default broadcast address used by the IP interface when sourcing IP broadcasts on the IP interface. If no broadcast format is specified for the IP address, the default value is host-ones, which indicates a subnet broadcast address. Use this parameter to change the broadcast address to all-ones or revert back to a broadcast address of host-ones.

The **all-ones** keyword following the **broadcast** parameter specifies that the broadcast address used by the IP interface for this IP address will be 255.255.255.255, also known as the local broadcast.

The **host-ones** keyword following the **broadcast** parameter specifies that the broadcast address used by the IP interface for this IP address will be the subnet broadcast address. This is an IP address that corresponds to the local subnet described by the *ip-addr* and the *mask-length* or *mask* with all the host bits set to binary 1. This is the default broadcast address used by an IP interface.

The **broadcast** parameter within the **address** command does not have a negate feature, which is usually used to revert a parameter to the default value. To change the **broadcast** type to **host-ones** after being changed to **all-ones**, the **address** command must be executed with the **broadcast** parameter defined.

The broadcast format on an IP interface can be specified when the IP address is assigned or changed.

This parameter does not affect the type of broadcasts that can be received by the IP interface. A host sending either the local broadcast (**all-ones**) or the valid subnet broadcast address (**host-ones**) will be received by the IP interface.

igp-inhibit — The secondary IP address should not be recognized as a local interface by the running IGP.

static-arp

Syntax	static-arp ip-addr ieee-mac-addr no static-arp ip-addr
Context	config>router>interface
Description	This command configures a static Address Resolution Protocol (ARP) entry associating an IP address with a MAC address for the core router instance. This static ARP appears in the core routing ARP table. A static ARP can only be configured if it exists on the network attached to the IP interface.

	If an entry for a particular IP address already exists and a new MAC address is configured for the IP address, the existing MAC address is replaced by the new MAC address. The number of static-arp entries that can be configured on a single node is limited to 1000. Static ARP is used when a 7750 SR needs to know about a device on an interface that cannot or does not respond to ARP requests. Thus, the 7750 SR OS configuration can state that if it has a packet that has a certain IP address to send it to the corresponding ARP address. Use proxy ARP so the 7750 SR responds to ARP requests on behalf of another device.
	The no form of the command removes a static ARP entry.
Default	No static ARPs are defined.
Parameters	<i>ip-addr</i> — Specifies the IP address for the static ARP in IP address dotted decimal notation.
	<i>ieee-mac-addr</i> — Specifies the 48-bit MAC address for the static ARP in the form <i>aa:bb:cc:dd:ee:ff</i> or <i>aa-bb-cc-dd-ee-ff</i> , where <i>aa</i> , <i>bb</i> , <i>cc</i> , <i>dd</i> , <i>ee</i> and <i>ff</i> are hexadecimal numbers. Allowed values are any non-broadcast, non-multicast MAC and non-IEEE reserved MAC addresses.

strip-label

Syntax [no] strip-label

Context config>router>interface

Description This command forces packets to be stripped of all (max 5) MPLS labels before the packets are handed over for possible filter (PBR) processing.

If the packets do not have an IP header ediately following the MPLS label stack after the strip, they are discarded. Only MPLS encapsulated IP, IGP shortcuts and VPRN over MPLS packets will be processed.

This command is only supported on:

- Optical ports
- IOM3-XP cards
- Null/Dot1q encaps
- Network ports
- IPv4

The no form removes the strip-label command.

In order to associate an interface that is configured with the strip-label parameter with a port, the port must be configured as single-fiber for the command to be valid.

Default no strip-label

tos-marking-state

Syntax	tos-marking-state {trusted untrusted} no tos-marking-state
Context	config>router>interface
Description	This command is used on a network IP interface to alter the default trusted state to a non-trusted state. When unset or reverted to the trusted default, the ToS field will not be remarked by egress network IP interfaces unless the egress network IP interface has the remark-trusted state set, in which case the egress network interface treats all IES and network IP interface as untrusted. When the ingress network IP interface is set to untrusted, all egress network IP interfaces will remark IP packets received on the network interface according to the egress marking definitions on each network interface. The egress network remarking rules also apply to the ToS field of IP packets routed using IGP shortcuts (tunneled to a remote next-hop). However, the tunnel QoS markings are always derived from the egress network QoS definitions. Egress marking and remarking is based on the internal forwarding class and profile state of the packet once it reaches the egress interface. The forwarding class is derived from ingress policing. The default marking state for network IP interfaces is trusted. This is equivalent to declaring no tosmarking-state on the network IP interface. When undefined or set to tos-marking-state trusted, the trusted state of the interface will not be displayed when using show config or show info unless the detail parameter is given. The save config command will not store the default tos-marking-state trusted state for network IP interfaces unless the detail parameter is also specified.
Default	is equivalent to executing the tos-marking-state trusted command.
Default	trusted
Parameters	trusted — The default prevents the ToS field to not be remarked by egress network IP interfaces unless the egress network IP interface has the remark-trusted state set
	untrusted — Specifies that all egress network IP interfaces will remark IP packets received on the network interface according to the egress marking definitions on each network interface.
unnumbered	
Syntax	unnumbered [<i>ip-address</i> <i>ip-int-name</i>] no unnumbered
Context	config>router>interface
Description	This command sets an IP interface as an unnumbered interface and specifies the IP address to be used for the interface.
	To conserve IP addresses, unnumbered interfaces can be configured. The address used when

To conserve IP addresses, unnumbered interfaces can be configured. The address used when generating packets on this interface is the *ip-addr* parameter configured. An error message will be generated if an **unnumbered** interface is configured, and an IP address already exists on this interface.

The **no** form of the command removes the IP address from the interface, effectively removing the unnumbered property. The interface must be **shutdown** before **no unnumbered** is issued to delete the IP address from the interface, or an error message will be generated.

Parameters *ip-addr | ip-int-name* — Optional. The IP address or IP interface name to associate with the unnumbered IP interface in dotted decimal notation. The configured IP address must exist on this node. It is recommended to use the system IP address as it is not associated with a particular interface and is therefore always reachable. The system IP address is the default if no *ip-addr* or *ip-int-name* is configured.

Default no unnumbered

urpf-check

Syntax	[no] urpf-check
Context	config>router>if
Description	This command enables unicast RPF (uRPF) Check on this interface.
	The no form of the command disables unicast RPF (uRPF) Check on this interface.
Default	disabled

mode

Syntax	mode {strict loose} no mode
Context	config>router>if>urpf-check
Description	This command specifies the mode of unicast RPF check.
	The no form of the command reverts to the default (strict) mode.
Default	strict
Parameters	strict — When specified, uRPF checks whether incoming packet has a source address that matches a prefix in the routing table, and whether the interface expects to receive a packet with this source address prefix.
	loose — In loose mode, uRPF checks whether incoming packet has source address with a corresponding prefix in the routing table. However, the loose mode does not check whether the interface expects to receive a packet with a specific source address prefix. This object is valid only when urpf-check is enabled.

mh-primary-interface

Syntax [no] mh-primary-interface

Context config>router

Description This command creates a loopback interface for use in multihoming resiliency. Once active, this interface can be used to advertise reachability information to the rest of the network using the primary address, which is backed up by the secondary.

The reachability for this address is advertised via IGPs and LDP protocols to allow the resolution of BGP routes advertised with this address.

The no form of the command disables this setting.

Default no multihoming

address

Syntax	address {ip-address/mask ip-address netmask} no address
Context	config>router>mh-primary-interface config>router>mh-secondary-interface
Description	This command assigns an IP address, IP subnet and broadcast address format to an IP interface. Only one IP address can be associated with an IP interface. An IP address must be assigned to each IP interface for the interface to be active. An IP address and a mask combine to create a local IP prefix. The defined IP prefix must be unique within the context of the routing instance. It cannot overlap with other existing IP prefixes defined as local subnets on other IP interface in the same routing context within the router.
	The local subnet that the address command defines must not be part of the services address space within the routing context by use of the config>router>service-prefix command. Once a portion of the address space is allocated as a service prefix, that portion is not available to IP interfaces for network core connectivity. The IP address for the interface can be entered in either CIDR (Classless Inter-Domain Routing) or traditional dotted decimal notation. Show commands display CIDR notation and are stored in configuration files.
	By default, no IP address or subnet association exists on an IP interface until it is explicitly created.
	The no form of the command removes the IP address assignment from the IP interface. Interface specific configurations for IGP protocols like OSPF are also removed. The no form of this command can only be performed when the IP interface is administratively shut down. Shutting down the IP interface will operationally stop any protocol interfaces or MPLS LSPs that explicitly reference that IP address. When a new IP address is defined, the IP interface can be administratively enabled (no shutdown), which reinitializes the protocol interfaces and MPLS LSPs associated with that IP interface.
	If a new address is entered while another address is still active, the new address wil be rejected.
Parameters	<i>ip-address</i> — The IP address of the IP interface. The ip-addr portion of the address command specifies the IP host address that will be used by the IP interface within the subnet. This address must be unique within the subnet and specified in dotted decimal notation.
	Values 1.0.0.0 - 223.255.255.255
	/— The forward slash is a parameter delimiter that separates the ipp-addr portion of the IP address from the mask that defines the scope of the local subnet. No spaces are allowed between the ip-

addr, the "/" and the mask-length parameter. If a forward slash does not immediately follow the ip-addr, a dotted decimal mask must follow the prefix.

mask-length — The subnet mask length when the IP prefix is specified in CIDR notation. When the IP prefix is specified in CIDR notation, a forward slash (/) separates the ip-addr from the mask-length parameter. The mask length parameter indicates the number of bits used for the network portion of the IP address; the remainder of the IP address is used to determine the host portion of the IP address. Allowed values are integers in the range 1-32. Note that a mask length of 32 is reserved for system IP addresses.

Values 1-32

mask — The subnet mask in dotted decimal notation. When the IP prefix is not specified in CIDR notation, a space separates the ip-addr from a traditional dotted decimal mask. The mask parameters indicates the complete mask that will be used ina logical 'AND' function to derive the local subnet of the IP address. Note that a mask of 255.255.255.255 is reserved for system IP addresses.

Values 128.0.0.0 - 255.255.255.255

netmask — The subnet mask in dotted decimal notation.

Values 0.0.0.0 - 255.255.255 (nework bits all 1 and host bits all 0).

description

Syntax	description description-string no description
Context	config>router>mh-primary-interface config>router>mh-secondary-interface
Description	This command creates a text description stored in the configuration file for a configuration context. The no form of the command removes the description string from the context.
Default	no description
Parameters	<i>description-string</i> — The description character string. Allowed values are any string up to 80 characters long composed of printable, 7-bit ASCII characters. If the string contains special character (#, \$, space, etc.), the entire string must be enclosed within double quotes.

shutdown

Syntax	[no] shutdown
Context	config>router>mh-primary-interface config>router>mh-secondary-interface

Description	The shutdown command administratively disables an entity. The operational state of the entity is disabled as well as the operational state of any entities contained within. Many objects must be shut down before they may be deleted.
	Unlike other commands and parameters where the default state is not indicated in the configuration file, shutdown and no shutdown are always indicated in system generated configuration files.
	The no form of the command puts an entity into the administratively enabled state.
Default	no shutdown

mh-secondary-interface

Syntax	[no] mh-secondary-interface		
Context	config>router		
Description	This command creates a loopback interface for use in multihoming resiliency. This address is considered the secondary multihoming address and is only used to resolve routes advertised by t primary router in the event that router becomes unavailable. For this purpose, the reachability for address is advertised via IGPs and LDP protocols to allow the resolution of BGP routes advertise with this address by the primary multihoming router.		
	The no form of the command disables this setting.		
Default	no mh-secondary-interface		

hold-time

Syntax	hold-time holdover-time no hold-time			
Context	config>router>mh-secondary-interface			
Description	The optional hold-time parameter is only applicable for the secondary context and specifies how long label information leraned about the secondary anycast address should be kept after that peer is declared down. This timer should be set to a value large enough for the remainder of the network to detect the failure and complete the reconvergence process.			
	The no form of the command resets the hold-time back to the default value.			
Default	no hold-time			
Parameters	<i>holdover-time</i> — Specifies the number of seconds the router should hold label information learned from the alternate router in its secondary label table. This is to allow the reset of the network to reconverge after a router failure before the anycast based label assignments are flushed from the forwarding plane.			
	Values 0-65535			
	Default 90			

Router Interface Filter Commands

egress

Syntax	egress
Context	config>router>interface
Description	This command enables access to the context to configure egress network filter policies for the IP interface. If an egress filter is not defined, no filtering is performed.

ingress

Syntax	ingress
Context	config>router>interface
Description	This command enables access to the context to configure ingress network filter policies for the IP interface. If an ingress filter is not defined, no filtering is performed.

filter

Syntax	filter ip ip-filter-id filter ipv6 ipv6-filter-id no filter [ip ip-filter-ip] [ipv6 ipv6-filter-id]			
Context	config>router>if>ingress config>router>if>egress			
Description	This command associates an IP filter policy with an IP interface.			
	Filter policies control packet forwarding and dropping based on IP match criteria.			
	The <i>ip-filter-id</i> must have been pre-configured before this filter command is executed. If the filter ID does not exist, an error occurs.			
	Only one filter ID can be specified.			
	The no form of the command removes the filter policy association with the IP interface.			
Default	No filter is specified.			
Parameters	 ip <i>ip-filter-id</i> — The filter name acts as the ID for the IP filter policy expressed as a decimal integer. The filter policy must already exist within the config>filter>ip context. 			
	Values 1 — 16384			

ipv6 *ipv6-filter-id* — The filter name acts as the ID for the IPv6 filter policy expressed as a decimal integer. The filter policy must already exist within the **config>filter>ipv6** context.

Values 1—65535

Router Interface ICMP Commands

icmp

Syntax	icmp
Context	config>router>interface
Description	This command enables access to the context to configure Internet Control Message Protocol (ICMP) parameters on a network IP interface. ICMP is a message control and error reporting protocol that also provides information relevant to IP packet processing.

mask-reply

Syntax	[no] mask-reply		
Context	config>router>if>icmp		
Description	This command enables responses to ICMP mask requests on the router interface.		
	If a local node sends an ICMP mask request to the router interface, the mask-reply commar configures the router interface to reply to the request.		
The no form of the command disables replies to ICMP mask requests on the rou			
Default	mask-reply — Replies to ICMP mask requests.		

redirects

Syntax	redirects [number seconds] no redirects
Context	config>router>if>icmp
Description	This command enables and configures the rate for ICMP redirect messages issued on the router interface.
	When routes are not optimal on this router, and another router on the same subnetwork has a better route, the router can issue an ICMP redirect to alert the sending node that a better route is available.
	The redirects command enables the generation of ICMP redirects on the router interface. The rate at which ICMP redirects are issued can be controlled with the optional <i>number</i> and <i>time</i> parameters by indicating the maximum number of redirect messages that can be issued on the interface for a given time interval.
	By default, generation of ICMP redirect messages is enabled at a maximum rate of 100 per 10 second time interval.
	The no form of the command disables the generation of ICMP redirects on the router interface.

Default redirects 100 10 — Maximum of 100 redirect messages in 10 seconds.

Parameters *number* — The maximum number of ICMP redirect messages to send, expressed as a decimal integer. This parameter must be specified with the *time* parameter.

Values 10 – 1000

seconds — The time frame, in seconds, used to limit the *number* of ICMP redirect messages that can be issued, expressed as a decimal integer.

Values 1 – 60

ttl-expired

Syntax	ttl-expired [number seconds] no ttl-expired			
Context	config>router>if>icmp			
Description	This command configures the rate that Internet Control Message Protocol (ICMP) Time To Live (TTL) expired messages are issued by the IP interface.			
	By default, generation of ICMP TTL expired messages is enabled at a maximum rate of 100 per 10 second time interval.			
	The no form of the command disables the generation of TTL expired messages.			
Default	ttl-expired 100 10 — Maximum of 100 TTL expired message in 10 seconds.			
Parameters	<i>number</i> — The maximum number of ICMP TTL expired messages to send, expressed as a decimal integer. The <i>seconds</i> parameter must also be specified.			
	Values 10 — 1000			
	<i>seconds</i> — The time frame, in seconds, used to limit the <i>number</i> of ICMP TTL expired messages that can be issued, expressed as a decimal integer.			

Values 1 – 60

unreachables

Syntax	unreachables [number seconds] no unreachables			
Context	config>router>if>icmp			
Description	This command enables and configures the rate for ICMP host and network destination unreachab messages issued on the router interface.			
	The unreachables command enables the generation of ICMP destination unreachables on the rout interface. The rate at which ICMP unreachables is issued can be controlled with the optional <i>numb</i> and <i>seconds</i> parameters by indicating the maximum number of destination unreachable messages th can be issued on the interface for a given time interval.			
	By default, generation of ICMP destination unreachables messages is enabled at a maximum rate of 100 per 10 second time interval.			
	The no form of the command disables the generation of ICMP destination unreachables on the router interface.			
Default	unreachables 100 10 — Maximum of 100 unreachable messages in 10 seconds.			
Parameters	<i>number</i> — The maximum number of ICMP unreachable messages to send, expressed as a decimal integer. The <i>seconds</i> parameter must also be specified.			
	Values 10 — 1000			

seconds — The time frame, in seconds, used to limit the *number* of ICMP unreachable messages that can be issued, expressed as a decimal integer.

Values 1 – 60

Router Interface IPv6 Commands

ipv6

Syntax	[no] ipv6	
Context	config>router>interface	
Description	n This command configures IPv6 for a router interface.	
	The no form of the command disables IPv6 on the interface.	
Default	not enabled	

address

Syntax	address {ipv6-address/prefix-length} [eui-64] no address {ipv6-address/prefix-length}		
Context	config>router>if>ipv6		
Description	This command assigns an IPv6 address to the interface.		
Default	none		
Parameters	ipv6-address/prefix-length — Specify the IPv6 address on the interface.		
	Values	ipv6-address/prefix: ipv6-address	x:x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:x:d.d.d x [0 — FFFF]H d [0 — 255]D
		prefix-length	1 128
	eui-64 — When the eui-64 keyword is specified, a complete IPv6 address from the s and 64-bit interface identifier is formed. The 64-bit interface identifier is derived address on Ethernet interfaces. For interfaces without a MAC address, for examp interfaces, the Base MAC address of the chassis should be used.		-bit interface identifier is derived from MAC ithout a MAC address, for example POS

icmp6

Syntax	icmp6
Context	config>router>if>ipv6
Description	This command enables the context to configure ICMPv6 parameters for the interface.

packet-too-big

Syntax	packet-too-big [number seconds] no packet-too-big	
Context	config>router>if>ipv6>icmp6	
Description	This command configures the rate for ICMPv6 packet-too-big messages.	
Parameters	<i>number</i> — Limits the number of packet-too-big messages issued per the time frame specifed in the <i>seconds</i> parameter.	
	Values 10 — 1000	
	<i>seconds</i> — Determines the time frame, in seconds, that is used to limit the number of packet-too-big messages issued per time frame.	

Values 1 – 60

param-problem

Syntax	param-problem [number seconds] no param-problem	
Context	config>router>if>ipv6>icmp6	
Description	This command configures the rate for ICMPv6 param-problem messages.	
Parameters	<i>number</i> — Limits the number of param-problem messages issued per the time frame specifed in the <i>seconds</i> parameter.	
	Values 10 — 1000	
	<i>seconds</i> — Determines the time frame, in seconds, that is used to limit the number of param-problem messages issued per time frame.	

Values 1 — 60

redirects

Syntax	redirects [number seconds] no redirects	
Context	config>router>if>ipv6>icmp6	
Description	This command configures the rate for ICMPv6 redirect messages. When configured, ICMPv6 redirects are generated when routes are not optimal on the router and another router on the same subnetwork has a better route to alert that node that a better route is available.	
	The no form of the command disables ICMPv6 redirects.	
Default	100 10 (when IPv6 is enabled on the interface)	

Parameters *number* — Limits the number of redirects issued per the time frame specifed in *seconds* parameter.

Values 10 - 1000

seconds — Determines the time frame, in seconds, that is used to limit the number of redirects issued per time frame.

Values 1 – 60

time-exceeded

Syntax	time-exceeded [number seconds] no time-exceeded	
Context	config>router>if>ipv6>icmp6	
Description	This command configures rate for ICMPv6 time-exceeded messages.	
Parameters	<i>number</i> — Limits the number of time-exceeded messages issued per the time frame specifed in <i>seconds</i> parameter.	
	Values 10 — 1000	
	<i>seconds</i> — Determines the time frame, in seconds, that is used to limit the number of time-exceeded messages issued per time frame.	
	Values 1 – 60	

unreachables

Syntax	unreachables [number seconds] no unreachables	
Context	config>router>if>ipv6>icmp6	
Description	This command configures the rate for ICMPv6 unreachable messages. When enabled, ICMPv6 he and network unreachable messages are generated by this interface.	
	The no form of the command disables the generation of ICMPv6 host and network unreachable messages by this interface.	
Default	100 10 (when IPv6 is enabled on the interface)	
Parameters	<i>number</i> — Determines the number destination unreachable ICMPv6 messages to issue in the time frame specified in <i>seconds</i> parameter.	
	Values 10 — 1000	
	<i>seconds</i> — Sets the time frame, in seconds, to limit the number of destination unreachable ICMPv6 messages issued per time frame.	
	Values 1 — 60	

link-local-address

Syntax	link-local-address ipv6-address [preferred] no link-local-address
Context	config>router>if>ipv6
Description	This command configures the link local address.

local-proxy-nd

Syntax	[no] local-proxy-nd	
Context	config>router>if>ipv6	
Description	This command enables local proxy neighbor discovery on the interface.	
	The no form of the command disables local proxy neighbor discovery.	

proxy-nd-policy

Syntax	<pre>proxy-nd-policy policy-name [policy-name(up to 5 max)] no proxy-nd-policy</pre>
Context	config>router>if>ipv6
Description	This command configure a proxy neighbor discovery policy for the interface.
Parameters	<i>policy-name</i> — The neighbor discovery policy name. Allowed values are any string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes. The specified policy name(s) must already be defined.

neighbor

Syntax	neighbor [ipv6-address] [mac-address] no neighbor [ipv6-address]	
Context	config>router>if>ipv6	
Description	This command configures an IPv6-to-MAC address mapping on the interface. Use this command if a directly attached IPv6 node does not support ICMPv6 neighbor discovery, or for some reason, a static address must be used. This command can only be used on Ethernet media.	
	The <i>ipv6-address</i> must be on the subnet that was configured from the IPv6 address command or a link-local address.	

Parameters	ipv6-address —	- The IPv6 address	assigned to a router interface.
	Values	ipv6-address:	x:x:x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:d.d.d.d
			x: [0 - FFFF]H
			d: [0 - 255]D
	mac-address —	- Specifies the MA	C address for the neighbor in the form of xx:xx:xx:xx:xx or xx-

XX-XX-XX-XX-XX.

Router Advertisement Commands

router-advertisement

Syntax	[no] router-advertisement	
Context	config>router	
Description	This command configures router advertisement properties. By default, it is disabled for all IPv6 enabled interfaces.	
	The no form of the command disables all IPv6 interface. However, the no interface <i>interface-name</i> command disables a specific interface.	
Default	disabled	

interface

Syntax	[no] interface ip-int-name	
Context	config>router>router-advertisement	
Description	This command configures router advertisement properties on a specific interface. The interface must already exist in the config>router>interface context.	
Default	No interfaces are configured by default.	
Parameters	<i>ip-int-name</i> — Specify the interface name. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.	

current-hop-limit

Syntax	current-hop-limit <i>number</i> no current-hop-limit
Context	config>router>router-advert>if
Description	This command configures the current-hop-limit in the router advertisement messages. It informs the nodes on the subnet about the hop-limit when originating IPv6 packets.
Default	64
Parameters	<i>number</i> — Specifies the hop limit.

Values 0 - 255. A value of zero means there is an unspecified number of hops.

managed-configuration

Syntax	[no] managed-configuration
Context	config>router>router-advert>if
Description	This command sets the managed address configuration flag. This flag indicates that DHCPv6 is available for address configuration in addition to any address autoconfigured using stateless address autoconfiguration. See RFC 3315, <i>Dynamic Host Configuration Protocol (DHCP) for IPv6</i> .
Default	no managed-configuration

max-advertisement-interval

Syntax	[no] max-advertisement-interval seconds
Context	config>router>router-advert>if
Description	This command configures the maximum interval between sending router advertisement messages.
Default	600
Parameters	<i>seconds</i> — Specifies the maximum interval in seconds between sending router advertisement messages.
	Values 4 – 1800

min-advertisement-interval

Syntax	[no] min-advertisement-interval seconds
Context	config>router>router-advert>if
Description	This command configures the minimum interval between sending ICMPv6 neighbor discovery router advertisement messages.
Default	200
Parameters	seconds — Specify the minimum interval in seconds between sending ICMPv6 neighbor discovery router advertisement messages.
	Values 3 – 1350

mtu

Syntax	[no] mtu mtu-bytes
Context	config>router>router-advert>if

Description	This command configures the MTU for the nodes to use to send packets on the link.
-------------	---

Default no mtu — The MTU option is not sent in the router advertisement messages.

Parameters*mtu-bytes* — Specify the MTU for the nodes to use to send packets on the link.Values1280 — 9212

other-stateful-configuration

Syntax	[no] other-stateful-configuration
Description	This command sets the "Other configuration" flag. This flag indicates that DHCPv6lite is available for autoconfiguration of other (non-address) information such as DNS-related information or information on other servers in the network. See RFC 3736, <i>Stateless Dynamic Host Configuration Protocol (DHCP) for IPv6</i> .
Default	no other-stateful-configuration

prefix

Syntax	[no] prefix [ipv6-prefix/prefix-length]			
Context	config>router>	config>router>router-advert>if		
Description	This command configures an IPv6 prefix in the router advertisement messages. To support multiple IPv6 prefixes, use multiple prefix statements. No prefix is advertised until explicitly configured using prefix statements.			
Default	none			
Parameters	<i>ip-prefix</i> — The IP prefix for prefix list entry in dotted decimal notation.			
	Values	ipv4-prefix ipv4-prefix-length ipv6-prefix ipv6-prefix-length	x:x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:d.d.d.d x: [0 — FFFF]H d: [0 — 255]D	
	prefix-length –	- Specifies a route must m	atch the most significant bits and have a prefix length.	
	Values	1 — 128		

autonomous

Syntax [no] autonomous

7750 SR OS Router Configuration Guide

Context	config>router>router-advert>if>prefix
Description	This command specifies whether the prefix can be used for stateless address autoconfiguration.
Default	enabled

on-link

Syntax	[no] on-link
Context	config>router>router-advert>if>prefix
Description	This command specifies whether the prefix can be used for onlink determination.
Default	enabled

preferred-lifetime

Syntax	[no] preferred-lifetime {seconds infinite}
Context	config>router>router-advert>if
Description	This command configures the remaining length of time in seconds that this prefix will continue to be preferred, such as, time until deprecation. The address generated from a deprecated prefix should not be used as a source address in new communications, but packets received on such an interface are processed as expected.
Default	604800
Parameters	<i>seconds</i> — Specifies the remaining length of time in seconds that this prefix will continue to be preferred.
	infinite — Specifies that the prefix will always be preferred. A value of 4,294,967,295 represents infinity.

valid-lifetime

Syntax	valid-lifetime {seconds infinite}
Context	config>router>router-advert>if
Description	This command specifies the length of time in seconds that the prefix is valid for the purpose of on- link determination. A value of all one bits (0xffffffff) represents infinity.
	The address generated from an invalidated prefix should not appear as the destination or source address of a packet.
Default	2592000
Parameters	seconds — Specifies the remaining length of time in seconds that this prefix will continue to be valid.

infinite — Specifies that the prefix will always be valid. A value of 4,294,967,295 represents infinity.

reachable-time

Syntax	reachable-time <i>milli-seconds</i> no reachable-time	
Context	config>router>router-advert>if	
Description	This command configures how long this router should be considered reachable by other nodes on the link after receiving a reachability confirmation.	
Default	no reachable-time	
Parameters	milli-seconds — Specifies the length of time the router should be considered reachable.	
	Values 0 — 3600000	

retransmit-time

Syntax	retransmit-timer milli-seconds no retransmit-timer	
Context	config>router>router-advert>if	
Description	This command configures the retransmission frequency of neighbor solicitation messages.	
Default	no retransmit-time	
Parameters	milli-seconds — Specifies how often the retransmission should occur.	
	Values 0 — 1800000	

router-lifetime

Syntax	router-lifetime seconds no router-lifetime	
Context	config>router>router-advert>if	
Description	This command sets the router lifetime.	
Default	1800	
Parameters	<i>seconds</i> — The length of time, in seconds, (relative to the time the packet is sent) that the prefix is valid for route determination.	
	Values 0, 4 — 9000 seconds. 0 means that the router is not a default router on this link.	

7750 SR OS Router Configuration Guide

Router Advertisement Commands

use-virtual-mac

Syntax	[no] use-virtual-mac	
Context	config>router>router-advert>if	
Description	This command enables sending router advertisement messages using the VRRP virtual MAC address, provided that the virtual router is currently the master.	
	If the virtual router is not the master, no router advertisement messages are sent.	
	The no form of the command disables sending router advertisement messages.	
Default	no use-virtual-mac	

Show Commands

aggregate

Syntax	aggregate [family] [active]	
Context	show>router	
Description	This command displays aggregate routes.	
Parameters	family — Specifies to display IPv4 or IPv6 aggregate routes.	
	Values ipv4, ipv6	
	active — When the active keyword is specified, inactive aggregates are filtered out.	

arp

Syntax	arp [ip-int-name ip-address/mask mac ieee-mac-address summary] [local dynamic static managed]	
Context	show>router	
Description	This command displays the router ARP table sorted by IP address. If no command line options are spec- ified, all ARP entries are displayed.	
Parameters	<i>ip-address/mask</i> — Only displays ARP entries associated with the specified IP address and mask.	
	<i>ip-int-name</i> — Only displays ARP entries associated with the specified IP interface name.	
	mac ieee-mac-addr — Only displays ARP entries associated with the specified MAC address.	
	summary — Displays an abbreviate list of ARP entries.	
	[local dynamic static managed] — Only displays ARP information associated with the keyword.	
Output	ARP Table Output — The following table describes the ARP table output fields:	

Label	Description
IP Address	The IP address of the ARP entry.
MAC Address	The MAC address of the ARP entry.
Expiry	The age of the ARP entry.
Туре	 Dyn - The ARP entry is a dynamic ARP entry. Inv - The ARP entry is an inactive static ARP entry (invalid). Oth - The ARP entry is a local or system ARP entry. Sta - The ARP entry is an active static ARP entry.

Label	Description (Continued)
*Man	The ARP entry is a managed ARP entry.
Int	The ARP entry is an internal ARP entry.
[I]	The ARP entry is in use.
Interface	The IP interface name associated with the ARP entry.
No. of ARP Entries	The number of ARP entries displayed in the list.

Sample Output

*B:7710-Red-RR# show router arp

ARP Table (Router: Base)				
IP Address	MAC Address	Expiry	Туре	Interface
10.20.1.24 10.10.4.11 10.10.4.24	00:16:4d:23:91:b8 00:03:fa:00:d0:c9 00:03:fa:41:8d:20	00h57m03s	Dyn[I]	
No. of ARP Entries: 3				

```
A:ALA-A# show router ARP 10.10.0.3

ARP Table

IP Address MAC Address Expiry Type Interface

10.10.0.3 04:5d:ff:00:00:00 00:00:00 Oth system

A:ALA-A#
```

```
A:ALA-A# show router ARP to-ser1

ARP Table

IP Address MAC Address Expiry Type Interface

10.10.13.1 04:5b:01:01:00:02 03:53:09 Dyn to-ser1

A:ALA-A#
```

authentication

Syntax	authentication
Context	show>router>authentication
Description	This command enables the command to display authentication statistics.

statistics

Syntax	statistics statistics interface [ip-int-name ip-address] statistics policy name		
Context	show>router>authentication		
Description	This command displays interface or policy authentication statistics.		
Parameters	interface [<i>ip-int-name</i> <i>ip-address</i>] — Specifies an existing interface name or IP address.		
	Values	<i>ip-int-name:</i> 32 chars max <i>ip-address:</i> a.b.c.d	
	policy <i>name</i> — Specifies an existing policy name.		
Output	Authenticatio	on Statistics Output — The following table describes the show authentication	

Output Authentication Statistics Output — The following table describes the show authentication statistics output fields:

Label	Description
Client Packets Authenticate Fail	The number of packets that failed authentication.
Client Packets Authenticate Ok	The number of packets that were authenticated.

Sample Output

A:ALU-3>show>router>auth# statistics Authentication Global Statistics Client Packets Authenticate Fail : 0 Client Packets Authenticate Ok : 12 A:ALU-3>

bfd

SyntaxbfdContextshow>router

Description This command enables the context to display bi-directional forwarding detection (BFD) information.

Sample Output

	router 3 bfd s						
BFD Session							
InterfaceState		Tx Intvl					
Remote Addre	ss 	Protocols				Rx Pkts	11
ies-3-121.1.3.		Up (3)		10		10	3
121.1.3.2		ospf2		N/A		N/A	cpm-np
ies-3-122.1.4.	3	Up (3)		100		100	3
122.1.4.2		pim				464	
No. of BFD ses	sions: 2						
*A:Dut-D#							
	router bfd ses						
BFD Session							
		============					
Remote Address							
Admin State	: Up		Oper Sta	ite	:	Up (3)	
Protocols	: static						
	: 10			rval			
Multiplier			Echo Int	erval	:	0	
-	: 1d 19:03:28		Up Trans	sitions	:	2	
Down Time	: None		Down Tra	insitions	:	1	
			Version	Mismatch	:	0	
Forwarding Inf	ormation						
Local Discr	: 19269		Local St	ate	:	Up (3)	
Local Diag	: 0 (None)		Local Mc	ode	:	Async	
Local Min Tx	: 10		Local Mu	ılt	:	3	
Last Sent (ms)	: 6		Local Mi	n Rx	:	10	
	: cpm-np						
Remote Discr	: 5101		Remote S	State	:	Up (3)	
Remote Diag	: 0 (None)		Remote M	Iode	:	Async	
Remote Min Tx	: 1000		Remote M	Iult	:	3	
Last Recv (ms)			Remote M	lin Rx	:	10	
======================================		===========					
"A:Dut-C#							

interface

Context show>router>bfd

Description This command displays interface information.

Output BFD interface Output — The following table describes the show BFD interface output fields:

Label	Description
TX Interval	Displays the interval, in milliseconds, between the transmitted BFD messages to maintain the session
RX Interval	Displays the expected interval, in milliseconds, between the received BFD messages to maintain the session
Multiplier	Displays the integer used by BFD to declare when the neighbor is down.

Sample Output

B:CORE2# show router bfd interface

BFD Interface				
Interface name	Tx Interval	Rx Interval	Multiplier	
net10_1_2	100	100	3	
net11_1_2	100	100	3	
net12_1_2	100	100	3	
net13_1_2	100	100	3	
net14_1_2	100	100	3	
net15_1_2	100	100	3	
net16_1_2	100	100	3	
net17_1_2	100	100	3	
net18_1_2	100	100	3	
net19_1_2	100	100	3	
net1_1_2	100	100	3	
net1_2_3	100	100	3	
net20_1_2	100	100	3	
net21_1_2	100	100	3	
net22_1_2	100	100	3	
net23_1_2	100	100	3	
net24_1_2	100	100	3	
net25_1_2	100	100	3	
net2_1_2	100	100	3	
net3_1_2	100	100	3	
net4_1_2	100	100	3	
net5_1_2	100	100	3	
net6_1_2	100	100	3	
net7_1_2	100	100	3	
net8_1_2	100	100	3	
net9_1_2	100	100	3	

No. of BFD Interfaces: 26

session

Syntax	session [src ip-address [dst ip-address] detail]		
	show>router>	bfd	Context
Description	This command	displays session in	formation.
Parameters	ip-address — C	only displays the in	terface information associated with the specified IP address.
	Values	ipv4-address	a.b.c.d (host bits must be 0)
_		_	

Output BFD Session Output — The following table describes the show BFD session output fields:

Label	Description
State	Displays the administrative state for this BFD session.
Protocol	Displays the active protocol.
Tx Intvl	Displays the interval, in milliseconds, between the transmitted BFD mes- sages to maintain the session
Tx Pkts	Displays the number of transmitted BFD packets.
Rx Intvl	Displays the expected interval, in milliseconds, between the received BFD messages to maintain the session
Rx Pkts	Displays the number of received packets.
Mult	Displays the integer used by BFD to declare when the neighbor is down.

Sample Output

A:Dut-D# show router bfd sess	ion			
BFD Session				
Interface	State	Tx Intvl	Rx Intvl	Mult
Remote Address	Protocol	Tx Pkts	Rx Pkts	
if10.120.1.4	Up (3)	100	100	3
10.120.1.2	ospf2	25140	25130	
if12.120.1.4	Up (3)	100	100	3
12.120.1.3	ospf2	25184	25175	
if14.120.1.4	Up (3)	100	100	3
14.120.1.6	ospf2	25175	25174	
spk1	Up (3)	100	100	3
195.168.9.3	ospf2	19157	19148	

```
Up (3)
spk2
                                           100
                                                  100
                                                          3
                       ospf2 pim
                                          24868 24858
  13.120.1.3
                      Up (3)
spk3
                                          100
                                                  100
                                                           3
                                           24516 24523
 16.120.1.6
                       ospf2
_____
No. of BFD sessions: 6
_____
A:Dut-D#
A:Dut-D# show router bfd session src 14.120.1.4 dest 14.120.1.6
 BFD Session
_____
Remote Address : 14.120.1.6
                                Oper State
                                              : Up (3)
Admin State : Up
Rx Interval : 100
Multiplier : 3
Recd Macc
                                Tx Interval
                                              : 100
Multiplier: 3Echo Interval: 0Recd Msgs: 26257Sent Msgs: 26Up Time: 0d 00:43:46Up Transitions: 1Down Time: NoneDown Transitions: 0
                               Echo Interval
                                             : 26257
                                Version Mismatch : 0
Local Discr: 2Local State: Up (3)Local Diag: 0 (None)Local Mode: AsyncLocal Min Tx: 100Local Mult: 3Last Sent: 01/26/2009 16:44:32Local Min Rx: 100Type: IomRemote DiscrIon
 Forwarding Information
Remote Discr: 37Remote State: Up (3)Remote Diag: 0 (None)Remote Mode: AsyncRemote Min Tx: 100Remote Mult: 3
Remote Discr : 37
Last Recv : 01/26/2009 16:44:32 Remote Min Rx : 100
_____
A:Dut-D#
```

dhcp

Syntax	dhcp
Context	show>router
Description	This command enables the context to display DHCP related information.

dhcp6

Syntax	dhcp6
Context	show>router
Description	This command enables the context to display DHCP6 related information.

Show Commands

statistics

Syntax	statistics [ip-int-name ip-address]
Context	show>router>dhcp show>router>dhcp6
Description	This command displays statistics for DHCP relay and DHCP snooping.
	If no IP address or interface name is specified, then all configured interfaces are displayed.
	If an IP address or interface name is specified, then only data regarding the specified interface is displayed.
Parameters	<i>ip-int-name ip-address</i> — Displays statistics for the specified IP interface.
Output	Show DHCP Statistics Output — The following table describes the output fields for DHCP.

Output Show DHCP Statistics Output — The following table describes the output fields for DHCP. statistics.

Label	Description
Received Packets	The number of packets received from the DHCP clients.
Transmitted Pack- ets	The number of packets transmitted to the DHCP clients.
Received Mal- formed Packets	The number of malformed packets received from the DHCP clients.
Received Untrusted Packets	The number of untrusted packets received from the DHCP clients.
Client Packets Discarded	The number of packets received from the DHCP clients that were dis- carded.
Client Packets Relayed	The number of packets received from the DHCP clients that were for- warded.
Client Packets Snooped	The number of packets received from the DHCP clients that were snooped.
Server Packets Discarded	The number of packets received from the DHCP server that were discarded.
Server Packets Relayed	The number of packets received from the DHCP server that were for- warded.
Server Packets Snooped	The number of packets received from the DHCP server that were snooped.

Sample Output

A:ALA-1# show router dhcp6 statistics

Isg-type	Rx	Tx	Dropped		
SOLICIT	0	0	0		
ADVERTISE	0	0	0		
REQUEST	0	0	0		
CONFIRM	0	0	0		
RENEW	0	0	0		
REBIND	0	0	0		
REPLY	0	0	0		
RELEASE	0	0	0		
DECLINE	0	0	0		
0 RECONFIGURE	0	0	0		
1 INFO_REQUEST	0	0	0		
2 RELAY_FORW	0	0	0		
3 RELAY_REPLY	0	0	0		
Hop Count Limit rea Missing Relay Msg og Unable to determine Out of Memory No global Pfx on Cl	ption, or illegal destinatinon cli	5 11			
9 Unable to determine	0				
0 No route to server	õ				
1 Subscr. Mqmt. Updat	õ				
2 Received Relay Forw	õ				
B Packet too small to	õ				
4 Server cannot respo	0				
5 No Server Id option	0				
6 Missing or illegal	2		0		
	-	5	0		
5 5	17 Server 1d option in client msg 18 Server DUID in client msg does not match our own				
7 Server Id option in	nt msg does not m	18 Server Dold in client msg does not match our own 19 Client sent message to unicast while not allowed			
7 Server Id option in 3 Server DUID in clie:	5	e not allowed	0		
7 Server Id option in 3 Server DUID in clie: 9 Client sent message	to unicast while		0 0		
7 Server Id option in 3 Server DUID in clie: 9 Client sent message 0 Client sent message	to unicast while with illegal sro	c Ip address			
7 Server Id option in 3 Server DUID in clie: 9 Client sent message 0 Client sent message 1 Client message type	to unicast while with illegal sro not supported in	c Ip address n pfx delegation	0		
7 Server Id option in 8 Server DUID in clie: 9 Client sent message 0 Client sent message 1 Client message type 2 Nbr of addrs or pfx	to unicast while with illegal sro not supported in s exceeds allowed	c Ip address n pfx delegation d max (128) in msg	0		
7 Server Id option in 8 Server DUID in clie:	to unicast while with illegal sro not supported in s exceeds allowed lient's mac addre	c Ip address n pfx delegation d max (128) in msg ess	0 0 0		

summary

Syntax summary

Context show>router>dhcp

Description Display the status of the DHCP Relay and DHCP Snooping functions on each interface.

Output Show DHCP Summary Output — The following table describes the output fields for DHCP summary.

Label	Description
Interface Name	Name of the router interface.
Info Option	Indicates whether Option 82 processing is enabled on the interface.
Auto Filter	Indicates whether IP Auto Filter is enabled on the interface.
Snoop	Indicates whether Auto ARP table population is enabled on the interface.
Interfaces	Indicates the total number of router interfaces on the 7750 SR.

Sample Output

A:ALA-1# show router dhcp summary

DHCP6 Summary (Router: Base)				
Interface Name SapId	Nbr Resol.	Used/Max Relay Used/Max Server	====== Admin Admin	Oper Relay Oper Server
<pre>interfaceServiceDefault sap:1/2/12:1</pre>	No	0/0 0/8000	Up Up	NoServerCo* Up
<pre>interfaceService sap:1/2/1</pre>	No	0/0 0/8000	Down Down	Down Down
<pre>interfaceServiceNonDefault sap:1/2/12:2</pre>	No	0/0 0/8000	Up Down	NoServerCo* Down
ip-61.4.113.4 sap:1/1/1:1	Yes	575/8000 580/8000	Up Up	Up Up
======================================				

ecmp

Syntax	ecmp
Context	show>router
Description	This command displays the ECMP settings for the router.
Output	ECMP Settings Output — The following table describes the output fields for the router ECMP settings.

Label	Description
Instance	The router instance number.
Router Name	The name of the router instance.

Label	Description (Continued)
ECMP	False - ECMP is disabled for the instance.
	True – ECMP is enabled for the instance.
Configured-ECMP-Routes	The number of ECMP routes configured for path sharing.

Sample Output

A:ALA-A# show	router ecmp		
Router ECMP			
Instance	Router Name	ECMP	Configured-ECMP-Routes
1	Base	True	8
A:ALA-A#			

fib

Syntax	fib slot-numbe	er [family] [ip-prefix/prefix- er [family] summary er nh-table-usage	length] [longer] [secondary] [exclude-services]
Context	show>router		
Description	This command o	displays the active FIB entri	ies for a specific IOM.
Parameters	slot-number — I	Displays routes only matchi	ng the specified chassis slot number.
	Default	all IOMs	
	Values	1 — 10	
	family — Displ	ays the router IP interface t	able to display.
	Values	ipv4 — Displays only the ipv6 — Displays the peer	ose peers that have the IPv4 family enabled. rs that are IPv6-capable.
	ip-prefix/prefix-	length — Displays FIB entr	ies only matching the specified ip-prefix and length.
	Values	ipv4-prefix: ipv4-prefix-length:[a.b.c.d (host bits must be 0) 0 - 32
	Values	ipv6-prefix: ipv6-prefix-length:	x:x:x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:x:d.d.d.d x: [0 — FFFF]H d: [0 — 255]D 0 — 128
	longon Digg1		in mafinian ask and mutae with langer masks

longer — Displays FIB entries matching the *ip-prefix/mask* and routes with longer masks.

7750 SR OS Router Configuration Guide

secondary — Displays secondary VRF ID information.
summary — Displays summary FIB information for the specified slot number.
nh-table-usage — Displays next-hop table usage.

Sample Output

```
show router fib 1 131.132.133.134/32
_____
FIB Display
_____
Prefix
                   Protocol
 NextHop
_____
131.132.133.134/32
                   OSPF
 66.66.66.66 (loop7)
 Next-hop type: tunneled, Owner: RSVP, Tunnel-ID: <out-ifindex-from-route>
Total Entries : 1
_____
_____
*A:Dut-C# show router fib 1 1.1.1.1/32
FIB Display
_____
Prefix
                   Protocol
 NextHop
1.1.1.1/32
                   BGP
 10.20.1.1 (Transport:RSVP LSP:1)
_____
Total Entries : 1
_____
_____
```

icmp6

Syntax	icmp6
Context	show>router
Description	This command dis
	generates error me

This command displays Internet Control Message Protocol Version 6 (ICMPv6) statistics. ICMP generates error messages (for example, ICMP destination unreachable messages) to report errors during processing and other diagnostic functions. ICMPv6 packets can be used in the neighbor discovery protocol and path MTU discovery.

Output icmp6 Output — The following table describes the show router icmp6 output fields:

Label	Description
Total	The total number of all messages.
Destination Unreachable	The number of message that did not reach the destination.
Time Exceeded	The number of messages that exceeded the time threshold.
Echo Request	The number of echo requests.
Router Solicits	The number of times the local router was solicited.
Neighbor Solicits	The number of times the neighbor router was solicited.
Errors	The number of error messages.
Redirects	The number of packet redirects.
Pkt Too big	The number of packets that exceed appropriate size.
Echo Reply	The number of echo replies.
Router Advertise- ments	The number of times the router advertised its location.
Neighbor Adver- tisements	The number of times the neighbor router advertised its location.

Sample Output

A:SR-3>show>router>auth# show router icmp6					
	==			==	
Global ICMPv6 Stats					
	==			==	
Received					
Total	:	14	Errors	:	0
Destination Unreachable	:	5	Redirects	:	5
Time Exceeded	:	0	Pkt Too Big	:	0
Echo Request	:	0	Echo Reply	:	0
Router Solicits	:	0	Router Advertisements	:	4
Neighbor Solicits	:	0	Neighbor Advertisements	:	0
Sent					
Total	:	10	Errors	:	0
Destination Unreachable	:	0	Redirects	:	0
Time Exceeded	:	0	Pkt Too Big	:	0
Echo Request	:	0	Echo Reply	:	0
Router Solicits	:	0	Router Advertisements	:	0
Neighbor Solicits	:	5	Neighbor Advertisements	:	5
	==			==	
A:SR-3>show>router>auth	#				

Show Commands

interface

Syntax	interface [interface-name]
Context	show>router>icmpv6
Description	This command displays interface ICMPv6 statistics.
Parameters	interface-name — Only displays entries associated with the specified IP interface name.

Output icmp6 interface Output — The following table describes the show router icmp6 interface output fields:

Label	Description
Total	The total number of all messages.
Destination Unreachable	The number of message that did not reach the destination.
Time Exceeded	The number of messages that exceeded the time threshold.
Echo Request	The number of echo requests.
Router Solicits	The number of times the local router was solicited.
Neighbor Solicits	The number of times the neighbor router was solicited.
Errors	The number of error messages.
Redirects	The number of packet redirects.
Pkt Too big	The number of packets that exceed appropriate size.
Echo Reply	The number of echo replies.
Router Advertise- ments	The number of times the router advertised its location.
Neighbor Adver- tisements	The number of times the neighbor router advertised its location.

Sample Output

mp6 interface net	t1_1_2	
: 41	Errors	: 0
: 0	Redirects	: 0
: 0	Pkt Too Big	: 0
: 0	Echo Reply	: 0
-	: 41 : 0 : 0	: 0 Redirects : 0 Pkt Too Big

7750 SR OS Router Configuration Guide

Router Solicits	:	0	Router Advertisements	:	0
Neighbor Solicits	:	20	Neighbor Advertisements	:	21
Sent					
Total	:	47	Errors	:	0
Destination Unreachable	:	0	Redirects	:	0
Time Exceeded	:	0	Pkt Too Big	:	0
Echo Request	:	0	Echo Reply	:	0
Router Solicits	:	0	Router Advertisements	:	0
Neighbor Solicits	:	27	Neighbor Advertisements	:	20
B:CORE2#					

interface

Syntax interface [{[*ip*-address | *ip*-*int*-*name*] [detail] [family]} | [summary] | [exclude-services] interface family [detail]]

Context show>router

Description This command displays the router IP interface table sorted by interface index.

Parameters *ip-address* — Only displays the interface information associated with the specified IP address.

Values	ipv4-address ipv6-address	a.b.c.d (host bits must be 0) x:x:x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:x:d.d.d.d
		x: [0 — FFFF]H
		d: [0 — 255]D

ip-int-name — Only displays the interface information associated with the specified IP interface name.

detail — Displays detailed IP interface information.

summary — Displays summary IP interface information for the router.

exclude-services — Displays IP interface information, excluding IP interfaces configured for customer services. Only core network IP interfaces are displayed.

family — Specifies the router IP interface family to display.

Valuesipv4 — Displays only those peers that have the IPv4 family enabled.ipv6 — Displays the peers that are IPv6-capable.

Output Standard IP Interface Output — The following table describes the standard output fields for an IP interface.

Label	Description
Interface-Name	The IP interface name.
Туре	n/a - No IP address has been assigned to the IP interface, so the IP address type is not applicable. Pri - The IP address for the IP interface is the Primary address on the IP interface.

Label	Description (Continued)
	Sec $-$ The IP address for the IP interface is a secondary address on the IP interface.
IP-Address	The IP address and subnet mask length of the IP interface. n/a — Indicates no IP address has been assigned to the IP interface.
Adm	Down – The IP interface is administratively disabled. Up – The IP interface is administratively enabled.
Opr	Down $-$ The IP interface is operationally disabled. Up $-$ The IP interface is operationally disabled.
Mode	Network – The IP interface is a network/core IP interface. Service – The IP interface is a service IP interface.
Port/SAP Id	The physical network port or the SAP identifier associated with the IP interface.

Sample Output

A:ALA-A# show router interface

Interface Table (Router: Base)				
Interface-Name IP-Address		Opr(v4/v6)		Port/SapId PfxState
ip-100.0.0.2 100.0.0.2/10 3FFE:1::2/64 FE80::200:FF:FE00:4/64	Up/Up	Up/Up	Network	lag-1 n/a PREFERRED PREFERRED
ip-100.128.0.2 100.128.0.2/10 3FFE:2::2/64 FE80::200:FF:FE00:4/64	Up/Up	Up/Up	Network	lag-2 n/a PREFERRED PREFERRED
ip-11.2.4.4 11.2.4.4/24 15::2/120	Up/Up	Down/Down	Network	3/1/1 n/a
<pre>ip-11.4.101.4 11.4.101.4/24 3FFE::B04:6504/120 FE80::200:FF:FE00:4/64</pre>	Up/Up	Up/Up	Network	5/2/1 n/a PREFERRED PREFERRED
<pre>ip-11.4.113.4 11.4.113.4/24 3FFE::B04:7104/120 FE80::200:FF:FE00:4/64</pre>	Up/Up	Up/Up	Network	6/1/1 n/a PREFERRED PREFERRED
<pre>ip-11.4.114.4 11.4.114.4/24 3FFE::B04:7204/120 FE80::200:FF:FE00:4/64</pre>	Up/Up	Up/Up	Network	6/1/2 n/a PREFERRED PREFERRED
ip-12.2.4.4 12.2.4.4/24 3FFE::C02:404/120	Up/Up	Down/Down	Network	3/1/2 n/a
ip-13.2.4.4	Up/Up	Down/Down	Network	3/1/3

13.2.4.4/24				n/a
3FFE::D02:404/120				
ip-14.2.4.4	Up/Up	Down/Down	Network	
14.2.4.4/24				n/a
3FFE::E02:404/120				
ip-15.2.4.4	Up/Up	Down/Down	Network	
15.2.4.4/24				n/a
3FFE::F02:404/120				
ip-21.2.4.4	Up/Up	Up/Up	Network	
21.2.4.4/24				n/a
3FFE::1502:404/120				PREFERRED
FE80::200:FF:FE00:4/64				PREFERRED
ip-22.2.4.4	Up/Up	Up/Up	Network	6/2/12
22.2.4.4/24				n/a
3FFE::1602:404/120				PREFERRED
FE80::200:FF:FE00:4/64				PREFERRED
ip-23.2.4.4	Up/Up	Up/Up	Network	6/2/13
23.2.4.4/24				n/a
3FFE::1702:404/120				PREFERRED
FE80::200:FF:FE00:4/64				PREFERRED
ip-24.2.4.4	Up/Up	Up/Up	Network	6/2/14
24.2.4.4/24				n/a
3FFE::1802:404/120				PREFERRED
FE80::200:FF:FE00:4/64				PREFERRED
system	Up/Up	Up/Up	Network	system
200.200.200.4/32				n/a
3FFE::C8C8:C804/128				PREFERRED
Interfaces : 15				
A:ALA-A#				

A:ALA-A# show router interface 10.10.0.3/32

	=====				
Interface Table					
	=====			=====	
Interface-Name	Туре	IP-Address	Adm	Opr	Mode
system	Pri	10.10.0.3/32	Up	Up	Network
	=====:			=====	
A:ALA-A#					

A:ALA-A# show router interface to-ser1

	====		======	=====	
Interface Table					
	=====			=====	
Interface-Name	Туре	IP-Address	Adm	Opr	Mode
to-ser1	Pri	10.10.13.3/24	Up	Up	Network
A:ALA-A#					
A:ALA-A# show router interface e	xclud	e-services			
	=====				
Interface Table					
Interface-Name	Туре	IP-Address	Adm	Opr	Mode
system	Pri	10.10.0.3/32	Up	Up	Network

to-ser1	Pri	10.10.13.3/24	Up	Up	Network
to-ser4	Pri	10.10.34.3/24	Up	Up	Network
to-ser5	Pri	10.10.35.3/24	Up	Up	Network
to-ser6	n/a	n/a	Up	Down	Network
management	Pri	192.168.2.93/20	Up	Up	Network
A:ALA-A#					

Detailed IP Interface Output — The following table describes the detailed output fields for an IP interface.

Label	Description
If Name	The IP interface name.
Admin State	Down $-$ The IP interface is administratively disabled.
	Up - The IP interface is administratively enabled.
Oper State	Down – The IP interface is operationally disabled.
	Up - The IP interface is operationally enabled.
IP Addr/mask	The IP address and subnet mask length of the IP interface. Not Assigned – Indicates no IP address has been assigned to the IP interface.
IPV6 Addr	The IPv6 address of the interface.
If Index	The interface index of the IP router interface.
Virt If Index	The virtual interface index of the IP router interface.
Last Oper Change	The last change in operational status.
Global If Index	The global interface index of the IP router interface.
Sap ID	The SAP identifier.
TOS Marker	The TOS byte value in the logged packet.
If Type	Network – The IP interface is a network/core IP interface.
	Service – The IP interface is a service IP interface.
SNTP B.cast	Displays if the broadcast-client global parameter is configured.
IES ID	The IES identifier.
QoS Policy	The QoS policy ID associated with the IP interface.
MAC Address	The MAC address of the interface.
Arp Timeout	The ARP timeout for the interface, in seconds, which is the time an ARP entry is maintained in the ARP cache without being refreshed.

Label	Description (Continued)
ICMP Mask Reply	False – The IP interface will not reply to a received ICMP mask request. True – The IP interface will reply to a received ICMP mask request.
Arp Populate	Displays whether ARP is enabled or disabled.
Host Conn Verify	The host connectivity verification.
LdpSyncTimer	Specifies the IGP/LDP sync timer value.
Cflowd	Specifies the type of Cflowd analysis that is applied to the interface. acl – ACL Cflowd analysis is applied to the interface. interface – Interface cflowd analysis is applied to the interface. none – No Cflowd analysis is applied to the interface.

Sample Output

```
A:Dut-A# show router interface ip-10.10.1.1 detail
_____
Interface Table (Router: Base)
Interface
_____
If Name : ip-10.10.1.1
Admin State : Up
                                Oper (v4/v6) : Down/--
Protocols : ISIS LDP
IP Addr/mask : Not Assigned
_____
Details
_____

      If Index : 2
      Virt. If Index : 2

      Last Oper Chg: 02/13/2008 19:32:08
      Global If Index : 127

Port Id : 1/1/1
SDP Id
        : spoke-1:100
Spoke-SDP Details
Admin State : Up
                                 Oper State : Up
Hash Label : Disabled
Peer Fault Ip: None
Peer Pw Bits : pwFwdingStandby
Peer Vccv CV Bits : lspPing
Peer Vccv CC Bits : mplsRouterAlertLabel
Flaqs
        : None
TOS Marking : Trusted
                                 If Type : Network
                                 Ingress Filter : none
Egress Filter: none
Eqr IPv6 Flt : none
                                 Ingr IPv6 Flt : none
                                QoS Policy : 1
Arp Timeout : 14400
SNTP B.Cast : False
MAC Address : 0c:a1:01:01:00:01
                                 ICMP Mask Reply : True
IP MTU : 1500
Arp Populate : Disabled
Cflowd : None
LdpSyncTimer : None
```

Proxy ARP Details Rem Proxy ARP: Disabled Local Proxy ARP : Disabled Policies : none Proxy Neighbor Discovery Details Local Pxy ND : Disabled Policies : none ICMP Details Time (seconds) - 10 Time (seconds) - 10 Redirects : Number - 100 Unreachables : Number - 100 Time (seconds) - 10 TTL Expired : Number - 100 IPCP Address Extension Details Peer IP Addr*: Not configured Peer Pri DNS*: Not configured _____ *A:Dut-A#

Summary IP Interface Output — The following table describes the summary output fields for the router IP interfaces.

Label	Description
Instance	The router instance number.
Router Name	The name of the router instance.
Interfaces	The number of IP interfaces in the router instance.
Admin-Up	The number of administratively enabled IP interfaces in the router instance.
Oper-Up	The number of operationally enabled IP interfaces in the router instance.

Sample Output

```
A:ALA-A# show router interface summary

Router Summary (Interfaces)

Instance Router Name Interfaces Admin-Up Oper-Up

Base 7 7 5

A:ALA-A#
```

mvpn

Syntax	mvpn
Context	show>router router-instance
Description	This command displays Multicast VPN related information. The router instance must be specified.

Sample Output

*A:Dut-C# show router 1 mvpn			
MVPN 1 configuration data			
signaling	: Bgp	auto-discovery	: Enabled
UMH Selection	: Highest-Ip	intersite-shared	: Enabled
vrf-import	: N/A		
vrf-export	: N/A		
vrf-target	: target:1:1		
C-Mcast Import RT	: target:10.20.1.3:2		
ipmsi	: pim-asm 224.1.1.1		
admin status	: Up	three-way-hello	: N/A
hello-interval	: N/A	hello-multiplier	: 35 * 0.1

tracking support : Disabled Improved Assert : N/A
spmsi : pim-ssm 225.0.0.0/32
join-tlv-packing : N/A
data-delay-interval: 3 seconds
data-threshold : 224.0.0.0/4 --> 1 kbps

neighbor

Syntax	neighbor [ip-int-name ip-address mac ieee-mac-address summary]	
Context	show>router	
Description	This command displays information about the IPv6 neighbor cache.	
Parameters	<i>ip-int-name</i> — Specify the IP interface name.	
	<i>ip-address</i> — Specify the address of the IPv6 interface address.	
	mac <i>ieee-mac-address</i> — Specify the MAC address.	
	summary — Displays summary neighbor information.	

Output Neighbor Output — The following table describes neighbor output fields.

Label	Description
IPv6 Address	Displays the IPv6 address.
Interface	Displays the name of the IPv6 interface name.
MAC Address	Specifies the link-layer address.
State	Displays the current administrative state.
Exp	Displays the number of seconds until the entry expires.
Туре	Displays the type of IPv6 interface.
Interface	Displays the interface name.
Rtr	Specifies whether a neighbor is a router.
Mtu	Displays the MTU size.

Sample Output

```
B:CORE2# show router neighbor

Neighbor Table (Router: Base)

IPv6 Address Interface
```

MAC Address	State	Expiry	Туре	RTR
FE80::203:FAFF:FE78:5C88 00:16:4d:50:17:a3	STALE	net1_1_2 03h52m08s	Dynamic	Yes
FE80::203:FAFF:FE81:6888		net1_2_3		
00:03:fa:1a:79:22	STALE	03h29m28s	Dynamic	Yes
No. of Neighbor Entries: 2				
======================================				

network-domains

Syntax	network-domains [detail] [network-domain-name]	
Context	show>router	
Description	This command displays network-domains information.	
Parameters	detail — Displays detailed network-domains information.	
	network-domain-name — Displays information for a specific network domain.	

Sample

*A:Dut-T>config>router# show router network-domains			
Network Domain Table			
Network Domain	Description		
net1 default	Network domain 1 Default Network Domain		
Network Domains : 2 *A:Dut-T>config>router#			
*A:Dut-T>config>router# show rou Network Domain Table (Router: Ba			
Network Domain	: netl		
Description No. Of Ifs Associated	: Network domain 1 : 2 : 0		
Network Domain	: default		
	: Default Network Domain : 3		

```
No. Of SDPs Associated
           : 0
_____
*A:Dut-T>config>router#
*A:Dut-T>config>router# show router network-domains "net1" interface-association
Interface Network Domain Association Table
_____
Interface Name
           Port
                 Network Domain
_____
intf1
           1/2/2
                 net1
intf2
           6/1/2
                 net1
Interfaces : 2
*A:Dut-T>config>router#
*A:Dut-T>config>service# show router network-domains "net1" sdp-association
SDP Network Domain Association Table
_____
SDP Id
            Network Domain
_____
```

policy

Syntax	policy [name damping prefix-list name as-path name community name admin]	
Context	show>router	
Description	This command displays policy-related information.	
Parameters	name — Specify an existing policy-statement name.	
	damping — Specify damping to display route damping profiles.	
	prefix-list <i>name</i> — Specify a prefix list name to display the route policy entries.	
	as-path name — Specify the route policy AS path name to display route policy entries.	
	community <i>name</i> — Specify a route policy community name to display information about a particular community member.	
	admin — Specify the admin keyword to display the entities configured in the config>router>policy- options context.	

Output Policy Output — The following table describes policy output fields.

Label	Description
Policy	The policy name.
Description	Displays the description of the policy.

Sample Output

```
B:CORE2# show router policy

Route Policies

Policy Description

fromStatic

Policies : 1

B:CORE2#
```

policy-edits

Syntax	policy-edits
Context	show>router
Description	This command displays edited policy information.

route-table

Syntax	route-table [<i>ip-prefix</i> [/ <i>prefix-length</i>] [longer exact protocol]] [protocol <i>protocol-name</i>] [all]] route-table [family] summary route-table <i>tunnel-endpoints</i> [<i>ip-prefix</i> [/ <i>prefix-length</i>] [longer exact protocol] route-table [<i>ip-prefix</i> [/ <i>prefix-length</i>] next-hop-type tunneled route-table [next-hop-type tunneled]		
Context	show>router		
Description	This command displays the active routes in the routing table.		
	If no command	line arguments are specified, all routes are displayed, sorted by prefix.	
Parameters	family — Specify the type of routing information to be distributed by this peer group.		
	Values	 ipv4 — Displays only those BGP peers that have the IPv4 family enabled and not those capable of exchanging IP-VPN routes. ipv6 — Displays the BGP peers that are IPv6 capable. mcast-ipv4 — Displays the BGP peers that are IPv4 multicast capable. 	

7750 SR OS Router Configuration Guide

mcast-ipv6 — Displays multicast IPv6 route table.

ip-prefix[lprefix-length] — Displays routes only matching the specified ip-address and length.

Values	ipv4-prefix: ipv4-prefix-length:		a.b.c.d (host bits must be set to 0) 0 - 32
	ipv6	ipv6-prefix[/pref*:	x:x:x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:x:d.d.d.d x: [0 — FFFF]H d: [0 — 255]D
		prefix-length:	1 — 128ipv6

longer — Displays routes matching the *ip-prefix/mask* and routes with longer masks.

exact — Displays the exact route matching the *ip-prefix/mask* masks.

protocol protocol-name — Displays routes learned from the specified protocol.

Values local, sub-mgmt, managed, static, ospf, ospf3, isis, rip, aggregate, bgp, bgp-vpn summary — Displays a route table summary information.

tunnel-endpoints — Specifies to include tunnel endpoint information.

Output Standard Route Table Output — The following table describes the standard output fields for the route table.

Label	Description	
Dest Address	The route destination address and mask.	
Next Hop	The next hop IP address for the route destination.	
Туре	Local – The route is a local route.	
	Remote – The route is a remote route.	
Protocol	The protocol through which the route was learned.	
Age	The route age in seconds for the route.	
Metric	The route metric value for the route.	
Pref	The route preference value for the route.	
No. of Routes	The number of routes displayed in the list.	

*A:Dut-C# show router route-table 1.1.1.1/32

Route Table (Router: Base)				
Dest Prefix Next Hop[Interface Name]	Туре	Proto	Age Metric	Pref
1.1.1.1/32 10.20.1.1 (tunneled:RSVP:1)	Remote	BGP	00h00m09s 0	170
No. of Routes: 1				

A:ALA# show router route-table ====================================			
Dest Prefix Age Pref	Туре		
Next Hop[Interface Name]			Metric
11.2.103.0/24 00h59m02s 10	Remote		
21.2.4.2 11.2.103.0/24	Remote	OSPF	2
00h59m02s 10 22.2.4.2			2
11.2.103.0/24 00h59m02s 10	Remote	OSPF	
23.2.4.2 11.2.103.0/24	Remote	OSPF	2
00h59m02s 10 24.2.4.2	Demete	OGDE	2
11.2.103.0/24 00h59m02s 10 100.0.0.1	Remote	OSPF	2
11.2.103.0/24 00h59m02s 10	Remote	OSPF	2
100.128.0.1 11.4.101.0/24	Local	Local	2 02h14m29s 0
A:ALA#			
B:ALA-B# show router route-table 100.10.0.0 e			
Route Table (Router: Base)			
Dest Address Next Hop Type Proto Age Metric H	Pref		
100.10.0.0/16 Black Hole Remote Static 00h03m	n17s 1 5		

No. of Routes: 1

B:ALA-B#

```
A:ALA-A# show router route-table 10.10.0.4/32 longer
```

Route Table _____ Metric Pref Dest Address Next Hop Type Protocol Age _____ 10.10.0.4/32 10.10.34.4 Remote OSPF 3523 1001 10 _____ No. of Routes: 1 _____ + : indicates that the route matches on a longer prefix A:ALA-A#

```
A:ALA-A# show router route-table protocol ospf
_____
Route Table
_____
Dest Address
           Next Hop
                      Type Protocol Age
                                          Metric Pref
 _____
10.10.0.1/32

        10.10.13.1
        Remote
        OSPF

        10.10.13.1
        Remote
        OSPF

                                   65844
                                           1001 10
                                   65844
                                               10
10.10.0.2/32
                                           2001
           10.10.34.4
10.10.0.4/32
                      Remote OSPF
                                   3523
                                           1001 10
           10.10.35.5
                     Remote OSPF
                                   1084022 1001 10
10.10.0.5/32
10.10.12.0/24
           10.10.13.1 Remote OSPF
                                   65844 2000 10
10.10.15.0/24
           10.10.13.1
                     Remote OSPF
                                   58836
                                           2000 10
10.10.24.0/24
                                   3523
                                               10
           10.10.34.4
                      Remote OSPF
                                           2000
                      Remote OSPF 3500
10.10.25.0/2410.10.35.5RemoteOSPF10.10.45.0/2410.10.34.4RemoteOSPF
                                           2000
                                                10
                                          2000
                                                10
_____
A:ALA-A#
```

show router route-table 131.132.133.134/32 next-hop-type tunneled

Route Table (Router: Base)				
Dest Prefix	Туре	Proto	Age	Pref
Next Hop[Interface Name]			Metric	
	aan			
131.132.133.134/32	Remote OSP	F 00h02m09s	10	
66.66.66			10	
Next-hop type: tunneled,	Owner: RSVP, Tun	nel-ID: <out-if< td=""><td>index-from-</td><td>route></td></out-if<>	index-from-	route>
			Nc	. of Routes:
1				

*A:Dut-B# show router route-table next-hop-type tunneled

Route Table (Router: Base)				
Dest Prefix	Type	Proto	Age	Pref
Next Hop[Interface Name]			Metric	:
				·
10.10.5.0/24	Remote	OSPF	00h02m20s	10
10.20.1.5 (tunneled:RSVP:1)			1100	
10.10.10/24	Remote	OSPF	00h02m20s	10
10.20.1.5 (tunneled:RSVP:1)			1100	
10.20.1.5/32	Remote	OSPF	00h02m20s	10
10.20.1.5 (tunneled:RSVP:1)			100	
10.20.1.6/32	Remote	OSPF	00h02m20s	10
10.20.1.5 (tunneled:RSVP:1)			1100	
No. of Routes: 4				
				:=====

*A:Dut-B# show router route-table 10.20.1.5/32 next-hop-type tunneled

Route Table (Router: Base)				
Dest Prefix Next Hop[Interface Name]	Туре	Proto	Age Metric	Pref
10.20.1.5/32 10.20.1.5 (tunneled:RSVP:1)	Remote	OSPF	00h03m55s 100	10
No. of Routes: 1				

Summary Route Table Output — Summary output for the route table displays the number of active routes and the number of routes learned by the router by protocol. Total active and available routes are also displayed.

Sample Output

A:ALA-A# show router route-ta	able summary	
Route Table Summary		
	Active	Available
Static	1	1
Direct	6	6
BGP	0	0
OSPF	9	9
ISIS	0	0
RIP	0	0
Aggregate	0	0
Total	16	16

A:ALA-A#

rtr-advertisement

Syntax	rtr-advertiseı rtr-advertiseı	-	-	[prefix ipv6-prefix[/prefix-length]]
Context	show>router			
Description		1.	router advertisement inform	
_		Ũ		ttes are displayed, sorted by prefix.
Parameters	<i>interface-name</i> — Maximum 32 characters.			
	ipv6-prefix[/pre	fix-length	 Displays routes only i 	matching the specified ip-address and length.
	Values	ipv6	ipv6-prefix[/pref*:	x:x:x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:x:d.d.d.d x: [0 — FFFF]H d: [0 — 255]D
			prefix-length:	1 - 128

Output Router-Advertisement Table Output — The following table describes the output fields for router-advertisement.

Label	Description
Rtr Advertisement Tx/Last Sent	The number of router advertisements sent and time since they were sent.
Nbr Solicitation Tx	The number of neighbor solicitations sent and time since they were sent.
Nbr Advertisement Tx	The number of neighbor advertisements sent and time since they were sent.
Rtr Advertisement Rx	The number of router advertisements received and time since they were received.
Nbr Advertisement Rx	The number of neighbor advertisements received and time since they were received.
Max Advert Inter- val	The maximum interval between sending router advertisement mes- sages.
Managed Config	True – Indicates that DHCPv6 has been configured.
	False - Indicates that DHCPv6 is not available for address configuration.

Label	Description (Continued)
Reachable Time	The time, in milliseconds, that a node assumes a neighbor is reachable after receiving a reachability confirmation.
Retransmit Time	The time, in milliseconds, between retransmitted neighbor solicitation messages.
Link MTU	The MTU number the nodes use for sending packets on the link.
Rtr Solicitation Rx	The number of router solicitations received and time since they were received.
Nbr Solicitation Rx	The number of neighbor solicitations received and time since they were received.
Min Advert Inter- val	The minimum interval between sending ICMPv6 neighbor discovery router advertisement messages.
Other Config	True – Indicates there are other stateful configurations.
	False - Indicates there are no other stateful configurations.
Router Lifetime	Displays the router lifetime in seconds.
Hop Limit	Displays the current hop limit.

A:Dut-A# show router rtr-advertisement					
				==:	========
Router Advertisement					
Interface: interface					
Rtr Advertisement Tx	:	8	Last Sent	:	00h01m28s
Nbr Solicitation Tx	:	83	Last Sent	:	00h00m17s
Nbr Advertisement Tx	:	74	Last Sent	:	00h00m25s
Rtr Advertisement Rx	:	8	Rtr Solicitation Rx	:	0
Nbr Advertisement Rx	:	83	Nbr Solicitation Rx	:	74
			Min Direct Tetrand		
			Min Advert Interval		
			Other Config		
			Router Lifetime		
Link MTU			Hop Limit	:	63
LINK MIU	:	1500			
Prefix: 211::/120					
Autonomous Flag	:	FALSE	On-link flag	:	FALSE
Preferred Lifetime	:	07d00h00m	Valid Lifetime	:	30d00h00m
Prefix: 231::/120					
Autonomous Flag	:	FALSE	On-link flag	:	FALSE
Preferred Lifetime	:	49710d06h	Valid Lifetime	:	49710d06h

Prefix: 241::/120 Autonomous Flag : TRUE Preferred Lifetime : 00h00m00s On-link flag : TRUE Valid Lifetime : 00h00m00s Prefix: 251::/120 Autonomous Flag : TRUE On-link flag Autonomous Flag: TRUEOn-link flag: TRUEPreferred Lifetime: 07d00h00mValid Lifetime: 30d00h00m : TRUE _____ Advertisement from: FE80::200:FF:FE00:2 Managed Config: FALSEOther Config: FALSEReachable Time: 00h00m00s0msRouter Lifetime: 00h30m00sRetransmit Time: 00h00m00s0msHop Limit: 64 Link MTU : 0 _____ Interface: interfaceServiceNonDefault _____

 Rtr Advertisement Tx : 8
 Last Sent : 00h06m41s

 Nbr Solicitation Tx : 166
 Last Sent : 00h00m04s

 Nbr Advertisement Tx : 143
 Last Sent : 00h00m05s

 Rtr Advertisement Tx : 2
 0

 Rtr Advertisement Rx : 8Rtr Solicitation Rx : 0Nbr Advertisement Rx : 166Nbr Solicitation Rx : 143 _____ Max Advert Interval: 601Min Advert Interval: 201Managed Config: TRUEOther Config: TRUEReachable Time: 00h00m00s400msRouter Lifetime: 00h30m01sRetransmit Time: 00h00m00s400msHop Limit: 63Link MTU: 1500 Prefix: 23::/120 Autonomous Flag: FALSEOn-link flag: FALSEPreferred Lifetime: infiniteValid Lifetime: infinite Prefix: 24::/120 Valid Lifetime · Ooboo : TRUE Autonomous Flag : TRUE Preferred Lifetime : 00h00m00s Autonomous Flag On-link flag : 00h00m00s Prefix: 25::/120 Autonomous Flag: TRUEOn-link flag: TRUEPreferred Lifetime: 07d00h00mValid Lifetime: 30d00 : 30d00h00m _____ Advertisement from: FE80::200:FF:FE00:2 Managed Config: FALSEOther Config: FALSEReachable Time: 00h00m00s0msRouter Lifetime: 00h30m00sRetransmit Time: 00h00m00s0msHop Limit: 64 Link MTU : 0 Prefix: 2::/120 Autonomous Flag: TRUEOn-link flag: TRUEPreferred Lifetime: 07d00h00mValid Lifetime: 30d00h00m Prefix: 23::/120 Autonomous Flag Autonomous Flag : TRUE Preferred Lifetime : 07d00h00m : TRUE On-link flaq ---- 11ag Valid Lifetime : TRUE : 30d00h00m Prefix: 24::/119 Autonomous Flag : TRUE Preferred Lifetime : 07d00h00m On-link flag : TRUE Valid Lifetime : 30d00h00m Prefix: 25::/120

```
Autonomous Flag : TRUE On-link flag : TRUE

Preferred Lifetime : 07d00h00m Valid Lifetime : infinite

Prefix: 231::/120

Autonomous Flag : TRUE On-link flag : TRUE

Preferred Lifetime : 07d00h00m Valid Lifetime : 30d00h00m

...

A:Dut-A#
```

```
Output Router-Advertisement Conflicts Output — The following table describes the output fields for router- advertisement conflicts.
```

Label	Description
Advertisement from	The address of the advertising router.
Reachable Time	The time, in milliseconds, that a node assumes a neighbor is reachable after receiving a reachability confirmation.
Router Lifetime	Displays the router lifetime in seconds.
Retransmit Time	The time, in milliseconds, between retransmitted neighbor solicitation messages.
Hop Limit	Displays the current hop limit
Link MTU	The MTU number the nodes use for sending packets on the link.

```
A:Dut-A# show>router# rtr-advertisement conflicts
_____
Router Advertisement
_____
Interface: interfaceNetworkNonDefault
_____
Advertisement from: FE80::200:FF:FE00:2
Managed Config : FALSE [TRUE]
Other Config : FALSE [TRUE]
Reachable Time : 00h00m00s0ms [00h00m00s400ms]
Router Lifetime : 00h30m00s [00h30m01s]
Retransmit Time : 00h00m00s0ms [00h00m00s400ms]
Hop Limit : 64 [63]
Link MTU : 0 [1500]
Prefix not present in neighbor router advertisement
Prefix: 211::/120
                                  Valid Lifetime : 30000
Autonomous Flag : FALSE
Preferred Lifetime : 07d00h00m
                                                       : 30d00h00m
Prefix not present in neighbor router advertisement
Prefix: 231::/120On-link flag: FALSEAutonomous Flag: FALSEOn-link flag: FALSEPreferred Lifetime: 49710d06hValid Lifetime: 49710d06h
```

```
Prefix not present in neighbor router advertisement
Prefix: 241::/120
Prefix: 241::/120Autonomous Flag: TRUEPreferred Lifetime: 00h00m00sValid Lifetime: 00h00m00s
Prefix not present in neighbor router advertisement
Prefix: 251::/120
Autonomous Flag: TRUEOn-link flag: TRUEPreferred Lifetime: 07d00h00mValid Lifetime: 30d00h00m
_____
Interface: interfaceServiceNonDefault
_____
Advertisement from: FE80::200:FF:FE00:2
Managed Config : FALSE [TRUE]
Other Config : FALSE [TRUE]
Reachable Time : 00h00m00s0ms [00h00m00s400ms]
Router Lifetime : 00h30m00s [00h30m01s]
Retransmit Time : 00h00m00s0ms [00h00m00s400ms]
Hop Limit : 64 [63]
Link MTU : 0 [1500]
Prefix not present in own router advertisement
Prefix: 2::/120
               : TRUE
Autonomous Flag: TRUEOn-link flag: TRUEPreferred Lifetime: 07d00h00mValid Lifetime: 30d00h00m
Prefix: 23::/120
Autonomous Flag : TRUE [FALSE]
On-link flag : TRUE [FALSE]
Preferred Lifetime: 07d00h00m [infinite]
Valid Lifetime : 30d00h00m [infinite]
Prefix not present in own router advertisement
Prefix: 24::/119
                 : TRUE
                                  On-link flag : TRUE
Valid Lifetime : 30d00h00m
Autonomous Flag
Preferred Lifetime : 07d00h00m
Prefix not present in neighbor router advertisement
Prefix: 24::/120
Prelix: 24::/120Autonomous Flag: TRUEPreferred Lifetime: 00h00m00sValid Lifetime: 00h00m00s
Prefix: 25::/120
Valid Lifetime : infinite [30d00h00m]
Prefix not present in own router advertisement
Prefix: 231::/120
                                   On-link flag : TRUE
Valid Lifetime : 30d00h00m
Autonomous Flag : TRUE
                                   On-link flag
Preferred Lifetime : 07d00h00m
_____
A:Dut-A#
```

static-arp

Syntax	static-arp [ip-addr ip-int-name mac ieee-mac-addr]
Context	show>router
Description	This command displays the router static ARP table sorted by IP address. If no options are present, all ARP entries are displayed.
Parameters	 <i>ip-addr</i> — Only displays static ARP entries associated with the specified IP address. <i>ip-int-name</i> — Only displays static ARP entries associated with the specified IP interface name. mac <i>ieee-mac-addr</i> — Only displays static ARP entries associated with the specified MAC address.

Output Static ARP Table Output — The following table describes the output fields for the ARP table.

Label	Description
IP Address	The IP address of the static ARP entry.
MAC Address	The MAC address of the static ARP entry.
Age	The age of the ARP entry. Static ARPs always have 00:00:00 for the age.
Туре	Inv – The ARP entry is an inactive static ARP entry (invalid).
	Sta – The ARP entry is an active static ARP entry.
Interface	The IP interface name associated with the ARP entry.
No. of ARP Entries	The number of ARP entries displayed in the list.

Sample Output

```
A:ALA-A# show router static-arp

ARP Table

IP Address MAC Address Age Type Interface

10.200.0.253 00:00:5a:40:00:01 00:00:00 Sta to-ser1

12.200.1.1 00:00:5a:01:00:33 00:00 Inv to-ser1a

No. of ARP Entries: 1

A:ALA-A#

A:ALA-A# show router static-arp 12.200.1.1
```

ARP Table				
IP Address	MAC Address	Age	Type Interface	

```
12.200.1.1
     00:00:5a:01:00:33 00:00:00 Inv to-ser1
_____
A:ALA-A#
A:ALA-A# show router static-arp to-ser1
_____
ARP Table
_____
IP Address MAC Address Age Type Interface
_____
10.200.0.253 00:00:5a:40:00:01 00:00:00 Sta to-ser1
_____
A:ALA-A#
A:ALA-A# show router static-arp mac 00:00:5a:40:00:01
_____
ARP Table
_____
IP Address MAC Address Age Type Interface
_____
10.200.0.253 00:00:5a:40:00:0100:00:00 Sta to-ser1
_____
A:ALA-A#
```

static-route

Syntax	static-route [family] [[ip-prefix Imask] [preference preference] [next-hop ip-address] tag tag]					
Context	show>router					
Description	This command displays the static entries in the routing table. If no options are present, all static routes are displayed sorted by prefix.					
Parameters	family — Specify the type of routing information to be distributed by this peer group.					
	Values	 ipv4 — Displays only those BGP peers that have the IPv4 family enable those capable of exchanging IP-VPN routes. ipv6 — Displays the BGP peers that are IPv6 capable. mcast-ipv4 — Displays the BGP peers that are IPv4 multicast capable. 				
	ip-prefix Imask -	- Displays static routes only matching the specified <i>ip-prefix</i> and <i>mask</i> .				
	Values	ipv4-prefix: ipv4-prefix-length: 0 - 32 ipv6-prefix: x:x:x:x:x:x:x: (eight 16-bit pieces) x:x:x:x:x:x:x:d.d.d.d x: [0 - FFFF]H d: [0 - 255]D ipv6-prefix-length: 0 - 128				
	preference <i>preference</i> — Only displays static routes with the specified route preference.					
	Values	Values 0 — 65535				
	next-hop <i>ip-address</i> — Only displays static routes with the specified next hop IP address.					
	Values	ipv4-address: ipv6-address: a.b.c.d (host bits must be 0) x:x:x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:x:d.d.d.d x: [0 - FFFF]H d: [0 - 255]D				
	tag <i>tag</i> — Displays the tag used to add a 32-bit integer tag to the static route. The tag is used in route policies to control distribution of the route into other protocols.					
	Values	1 — 4294967295				
Output	Static Route C	utput — The following table describes the output fields for the static re	oute table.			
	Label	Description				
	IP Addr/mas	The static route destination address and mask.				
	Pref	The route preference value for the static route.				
	Metric	The route metric value for the static route.				
	Туре	BH – The static route is a black hole route. The Nexthop for route is black-hole.	this type of			

Label	Description (Continued)
	ID - The static route is an indirect route, where the nexthop for this type of route is the non-directly connected next hop.
	NH – The route is a static route with a directly connected next hop. The Nexthop for this type of route is either the next hop IP address or an egress IP interface name.
Next Hop	The next hop for the static route destination.
Protocol	The protocol through which the route was learned.
Interface	The egress IP interface name for the static route. n/a - indicates there is no current egress interface because the static route is inactive or a black hole route.
Active	N - The static route is inactive; for example, the static route is disabled or the next hop IP interface is down.
	Y – The static route is active.
No. of Routes	The number of routes displayed in the list.

A:ALA-A# show router static-route

IP Addr/mask	Pref	Metric	Туре	Nexthop	Interface	Active
192.168.250.0/24	5	1	ID	10.200.10.1	to-ser1	Y
192.168.252.0/24	5	1	NH	10.10.0.254	n/a	N
192.168.253.0/24	5	1	NH	to-ser1	n/a	N
192.168.253.0/24	5	1	NH	10.10.0.254	n/a	N
192.168.254.0/24	4	1	BH	black-hole	n/a	Y

```
A:ALA-A# show router static-route 192.168.250.0/24

Route Table

IP Addr/mask Pref Metric Type Nexthop Interface Active

192.168.250.0/24 5 1 ID 10.200.10.1 to-ser1 Y

A:ALA-A#
```

```
A:ALA-A# show router static-route preference 4
Route Table
```

```
IP Addr/mask
         Pref Metric Type Nexthop
                               Interface
                                        Active
-----
192.168.254.0/24 4 1 BH black-hole n/a
                                          Y
_____
A:ALA-A#
A:ALA-A# show router static-route next-hop 10.10.0.254
_____
Route Table
IP Addr/mask Pref Metric Type Nexthop
                               Interface
                                        Active
_____
192.168.253.0/24 5 1 NH 10.10.0.254 n/a
                                          N
_____
A:ALA-A#
*A:sim1# show router static-route 10.10.0.0/16 detail
_____
Static Route Table (Router: Base)
                        Family : [IPv4 | MCast-IPv4 | IPv6]
Network : 3FFD:FFFF:FFFF:FFFF:FFFF:FFFF:FFF5:FFF2/120 Type : [Nexthop|Indirect|Black-
hole]
Nexthop : [address | LSP label & name]
                              Nexthop type: [IP|LDP|RSVP-TE]
Interface :
Metric : 1
                            Prefence : 5
Active : [Y|N]
                            Admin State : [Up Down]
Tag :
BFD: [enable|disabled]
CPE-check: [enabled|disabled]
                           State: [Up|Down]
Target : <address>
Interval : [value | n/a]
                           Drop Count : <value>
Log : [Y|N]
CPE Host Up/Dn Time : 0d 16:32:28
CPE Echo Req Tx : 0
                            CPE Echo Reply Rx: 0
CPE Up Transitions : 0
                            CPE Down Transitions : 0
CPE TTL : 13
_____
A:sim1#
```

service-prefix

Syntax	service-prefix
Description	This command displays the address ranges reserved by this node for services sorted by prefix.
Output	Service Prefix Output — The following table describes the output fields for service prefix information.

Label	Description
IP Prefix	The IP prefix of the range of addresses included in the range for services.
Mask	The subnet mask length associated with the IP prefix.

Label	Description (Continued)
Exclusive	 false - Addresses in the range are not exclusively for use for service IP addresses. true - Addresses in the range are exclusively for use for service IP addresses and cannot be assigned to network IP interfaces.

```
A:ALA-A# show router service-prefix

Address Ranges reserved for Services

IP Prefix Mask Exclusive

172.16.1.0 24 true

172.16.2.0 24 false

A:ALA-A#
```

sgt-qos

Syntax	sgt-qos
Context	show>router
Description	This command displays self-generated traffic QoS related information.

application

Syntax	application [app-name] [dscp dot1p]		
Context	show>router>sgt-qos		
Description	This command displays application QoS settings.		
Parameters	app-name — The specific application.		
	Values	arp, bgp, cflowd, dhcp, dns, ftp, icmp, igmp, isis, ldp, mld, msdp, ndis, ntp, ospf, pimradius, rip, rsvpsnmp, snmp-notification, srrp, ssh, syslog, tacplus, telnet, tftp, traceroute, vrrp, pppoe	

dscp-map

Syntax	dscp-map [dscp-name]		
Context	show>router>sgt-qos		
Description	This command displays DSCP to FC mappings.		
Parameters	<i>dscp-name</i> — The specific DSCP name.		
	Values	be, ef, cp1, cp2, cp3, cp4, cp5, cp6, cp7, cp9, cs1, cs2, cs3, cs4, cs5, nc1, nc2, af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, cp11, cp13, cp15, cp17, cp19, cp21, cp23, cp25, cp27, cp29, cp31, cp33, cp35, cp37, cp39, cp41, cp42, cp43, cp44, cp45, cp47, cp49, cp50, cp51, cp52, cp53, cp54, cp55, cp57, cp58, cp59, cp60, cp61, cp62, cp63	

status

Syntax	status
Context	show>router
Description	This command displays the router status.
Output	Router Status Output — The following table describes the output fields for router status information.

Label	Description
Router	The administrative and operational states for the router.
OSPF	The administrative and operational states for the OSPF protocol.
RIP	The administrative and operational states for the RIP protocol.
ISIS	The administrative and operational states for the IS-IS protocol.
MPLS	The administrative and operational states for the MPLS protocol.
RSVP	The administrative and operational states for the RSVP protocol.
LDP	The administrative and operational states for the LDP protocol.
BGP	The administrative and operational states for the BGP protocol.
Max Routes	The maximum number of routes configured for the system.
Total Routes	The total number of routes in the route table.
ECMP Max Routes	The number of ECMP routes configured for path sharing.

Label	Description (Continued)
service-id	<pre>state - Current single SFM state start - Last time this vRtr went into overload, after having respected the hold-off time interval - How long the vRtr remained or is in overload</pre>
Triggered Poli- cies	No – Triggered route policy re-evaluation is disabled. Yes – Triggered route policy re-evaluation is enabled.

Note that there are multiple instances of OSPF. OSPF-0 is persistent. OSPF-1 through OSPF-31 are present when that particular OSPF instance is configured.

*A:Performance# show router status							
Router Status (Router: Base)							
	Admin State	Oper State					
Router	Up	Up					
OSPFv2-0	Up	Up					
RIP	Up	Up					
ISIS	Up	Up					
MPLS	Not configured	Not configured					
RSVP	Not configured	Not configured					
LDP	Not configured	Not configured					
BGP	Up	Up					
IGMP	Not configured	Not configured					
PIM	Not configured	Not configured					
OSPFv3	Not configured	Not configured					
MSDP	Not configured	Not configured					
Max Routes No Limit Total IPv4 Routes 244285 Total IPv6 Routes 0 Max Multicast Routes No Limit Total Multicast Routes PIM not configured ECMP Max Routes 1 Triggered Policies No ====================================							
	Admin State	Oper State					
Router	Up	Up					
OSPFv2-0	Up	Up					
OSPFv2-1	Down	Down					
OSPFv2-2	Down	Down					
OSPFv2-2 OSPFv2-3	Down	Down					
OBFFV2-3	SSIT 2 DOWN DOWN						

OSPFv2-4	Down	Down
OSPFv2-5	Down	Down
OSPFv2-6	Down	Down
OSPFv2-7	Down	Down
OSPFv2-8	Down	Down
OSPFv2-9	Down	Down
OSPFv2-10	Down	Down
OSPFv2-11	Down	Down
OSPFv2-12	Down	Down
OSPFv2-13	Down	Down
OSPFv2-14	Down	Down
OSPFv2-15	Down	Down
OSPFv2-16	Down	Down
OSPFv2-17	Down	Down
OSPFv2-18	Down	Down
OSPFv2-19	Down	Down
OSPFv2-20	Down	Down
OSPFv2-21	Down	Down
OSPFv2-22	Down	Down
OSPFv2-23	Down	Down
OSPFv2-24	Down	Down
OSPFv2-25	Down	Down
OSPFv2-26	Down	Down
OSPFv2-27	Down	Down
OSPFv2-28	Down	Down
OSPFv2-29	Down	Down
OSPFv2-30	Down	Down
OSPFv2-31	Down	Down
RIP	Up	Up
ISIS	Up	Up
MPLS	Not configured	Not configured
RSVP	Not configured	Not configured
LDP	Not configured	Not configured
BGP	Up	Up
IGMP	Not configured	Not configured
PIM	Not configured	Not configured
OSPFv3	Not configured	Not configured
MSDP	Not configured	Not configured
Max Routes	No Limit	
Total IPv4 Routes	244277	
Total IPv6 Routes	0	
Max Multicast Routes	No Limit	
Total Multicast Routes	PIM not configured	
ECMP Max Routes	1 Decklod	hald aff on man
Single SFM Overload	Enabled	hold-off 30 sec
Single SFM State	normal	
Single SFM Start	004 19:03:39.680	
Single SFM Interval Triggered Policies	0d 00:16:06 No	
======================================		
*A:Performance#		
A.FEIIOIMAIICE#		

Show Commands

tunnel-table

Syntax	tunnel-table [ip-address[/mask]] [protocol protocol sdp sdp-id] [summary]
Context	show>router
Description	This command displays tunnel table information. Note that auto-bind GRE tunnels are not displayed in show command output. GRE tunnels are not the same as SDP tunnels that use the GRE encapsulation type. When the auto-bind command is used when configuring a VPRN service, it means the MP-BGP NH resolution is referring to the core routing instance for IP reachability. For a VPRN service this object specifies the lookup to be used by the routing instance if no SDP to the destination exists.
Parameters	 <i>ip-address</i>[/mask] — Displays the specified tunnel table's destination IP address and mask. protocol protocol — Dislays LDP protocol information. sdp sdp-id — Displays information pertaining to the specified SDP. summary — Displays summary tunnel table information.
Output	Tunnel Table Output — The following table describes tunnel table output fields.

Label	Description
Destination	The route's destination address and mask

Destination	The route's destination address and mask.
Owner	Specifies the tunnel owner.
Encap	Specifies the tunnel's encapsulation type.
Tunnel ID	Specifies the tunnel (SDP) identifier.
Pref	Specifies the route preference for routes learned from the configured peer(s).
Nexthop	The next hop for the route's destination.
Metric	The route metric value for the route.

Sample Output

A:ALA-A>config>service# show router tunnel-table						
Tunnel Table						
Destination Owne	er Encap	Tunnel Id	Pref	Nexthop	Metric	
10.0.0.1/32 sd	D GRE	10	5	10.0.0.1	0	
10.0.0.1/32 sd	GRE GRE	21	5	10.0.0.1	0	
10.0.0.1/32 sd	GRE GRE	31	5	10.0.0.1	0	
10.0.0.1/32 sd	GRE GRE	41	5	10.0.0.1	0	
A:ALA-A>config>service#						

A:ALA-A>config>service# show router tunnel-table summary					
Tunnel Table Summary (Router:	Base)				
	Active	Available			
LDP	1	1			
SDP	1	1			
A:ALA-A>config>service#					

L2TP Show Commands

l2tp

Syntax	l2tp
Context	show>router
Description	This command enables the context to display L2TP related information.

group

Syntax	group [tunnel-group-name [statistics]]
Context	show>router>l2tp
Description	This command displays L2TP group operational information.
Parameters	tunnel-group-name — Displays information for the specified tunnel group.
	statistics — Displays statistics for the specified tunnel group.

Sample Output

*A:Dut-C# show router l2tp group						
L2TP Groups						
	=====					
Group Name	Ses	Limit Ses	Assign State	Tun Ac	tive Ses Activ	/e
						Ses Total
ispl.group-1						
		131071	existingFirst	active	1	1
					1	1
ispl.group-2						
		131071	weighted	active	2	5
					3	8
No. of L2TP Grou	ps: 2	2				
*A:Dut-C#						
*A:Dut-C# show router l2tp group isp1.group-2						
	=====					
Group Name: isp1	.grou	1p-2				
	=====					
Conn ID		I	Loc-Tu-ID Rem-Tu	-ID Stat	e	Ses Active
Group						Ses Total
Assignment						

143523840	2190	17525	established	2
ispl.group-2				3
isp1.tunnel-3				
236912640	3615	58919	closedByPeer	0
ispl.group-2				2
isp1.tunnel-2				
658178048	10043	33762	draining	3
ispl.group-2				3
isp1.tunnel-2				
No. of tunnels: 3				
*A:Dut-C#				

*A:Dut-C# show router l2tp group ispl.group-2 statistics Group Name: ispl.group-2

	Attempts	Failed	Failed-Aut	Active	Total
	3 8	0 0	0 N/A	2 5	3 8
	Pkt-Ctl		Pkt-Err	Octets	
Rx	51		0	1224	
Tx	51		0	2796	
*A:Dut-C#					

peer

Syntax	peer <i>ip-address</i> peer <i>ip-address</i> statistics peer [draining] [unreachable]
Context	show>router>l2tp
Description	This command displays L2TP peer operational information.
Parameters	<i>ip-address</i> — Display information for the specified IP address of the peer.
	draining — Displays peer objects set to drain.
	unreachable — Displays peers that are deemed unreachable.
	statistics — Displays the statistics for the given IP address.

Sample Output

*A:Dut-C# show router l2tp peer L2TP Peers

```
_____
Peer IP
                        Tun Active Ses Active
               Drain Unreach Role Tun Total Ses Total
_____
10.10.14.8
                        1
                            1
                     LAC 1
                            1
10.10.20.100
                        1
                            3
                drain LAC 2
                            5
10.10.20.101
                            0
                       0
                 unreach LAC 1
                            1
_____
No. of peers: 3
_____
*A:Dut-C#
*A:Dut-C# show router l2tp peer unreachable
_____
L2TP Peers
_____
Peer IP
                        Tun Active Ses Active
               Drain Unreach Role Tun Total Ses Total
_____
                     0
10.10.20.101
                            0
                  unreach LAC 1
                            1
_____
No. of peers: 1
_____
*A:Dut-C#
*A:Dut-C# show router l2tp peer 10.10.20.101
_____
Peer IP: 10.10.20.101
_____
Tunnels : 1
Sessions
       : LAC
               Draining
                       : false
                Tunnels Active : 0
Sessions : 1
Unreachable : true
               Sessions Active : 0
                Time Unreachable : 04/17/2009 19:34:04
_____
Conn ID
            Loc-Tu-ID Rem-Tu-ID State
                            Ses Active
Group
                            Ses Total
 Assignment
_____
18284544
           279 0 closed 0
isp1.group-2
                            1
 isp1.tunnel-3
_____
No. of tunnels: 1
_____
*A:Dut-C#
*A:Dut-C# show router 12tp peer draining
_____
L2TP Peers
_____
Peer IP
                        Tun Active Ses Active
                Drain Unreach Role Tun Total Ses Total
```

_____ 1 3 drain LAC 2 5 10.10.20.100 _____ No. of peers: 1 _____ *A:Dut-C# *A:Fden-Dut2-BSA2# show router l2tp peer 10.0.0.1 statistics Peer IP: 10.0.0.1 _____ tunnels : 1 tunnels active : 1 sessions : 1 sessions active : 1 rx ctrl octets · 541 rx ctrl packets : 5 tx ctrl octets : 272 tx ctrl packets : 5 : 0 tx error packets : 0 rx error packets rx accepted msq : 4 rx duplicate msg : 0 rx out of window msg : 0 acceptedMsgType StartControlConnectionRequest : 1 StartControlConnectionConnected : 1 IncomingCallRequest : 1 IncomingCallConnected : 1 ZeroLengthBody : 1 originalTransmittedMsgType StartControlConnectionReply : 1 IncomingCallReply : 1 ZeroLengthBody : 3 last cleared time : N/A _____

session

Syntax	session connection-id connection-id [detail]		
	session [detail] [session-id session-id (v2)] [state session-state][peer ip-address] [group group-name] [assignment-id assignment-id] [local-name local-host-name] [remote-name remote-host-name] [tunnel-id tunnel-id (v2)]]		
	session [detail] [state session-state] [peer ip-address] [group group-name] [assignment-id assignment-id] [local-name local-host-name] [remote-name remote-host-name] [control-connection-id connection-id (v3)]		
Context	show>router>l2tp		
Description	This command displays L2TP session operational information.		

Parameters connection-id — Specifies the identification number for a Layer Two Tunneling Protocol connection.

Values 1 — 429496729

detail — Displays detailed L2TP session information.

session-id *session-id* (v2) — Specifies the identification number for a Layer Two Tunneling Protocol session.

Values 1 — 65535

state session-state — Specifies the values to identify the operational state of the L2TP session.

Values closed, closed-by-peer, established, idle, wait-reply, wait-tunnel

peer ip-address - Specifies the IP address of the peer.

Values

ipv4-address	a.b.c.d (host bits must be 0)
ipv6-address	x:x:x:x:x:x:x:x[-interface]
	x:x:x:x:x:d.d.d.d[-interface]
	x: [0FFFF]H
	d: [0255]D
	interface: 32 characters maximum, mandatory for link local
	addresses

group group-name — Specifies a string to identify a Layer Two Tunneling Protocol Tunnel group.

- **assignment-id** *assignment-id* Specifies a string that distinguishes this Layer Two Tunneling Protocol tunnel.
- **local-name** *local-host-name* Specifies the host name used by this system during the authentication phase of tunnel establishment.
- **remote-name** *remote-host-name* Specifies a string that is compared to the host name used by the tunnel peer during the authentication phase of tunnel establishment.
- **tunnel-id** tunnel-id (v2) Specifies the local identifier of this Layer Two Tunneling Protocol tunnel, when L2TP version 2 is used.

Values 1 — 65535

control-connection-id (v3) — Specifies an identification number for a Layer Two Tunneling Protocol session.

Values 1 — 429496729

Sample Output

```
*A:Dut-C# show router l2tp session

L2TP Session Summary

ID Control Conn ID Tunnel-ID Session-ID State

143524786 143523840 2190 946 established

143526923 143523840 2190 3083 established

143531662 143523840 2190 7822 closed
```

```
236912640
                      3615
236926987
                              14347
                                     closed
236927915
           236912640
                       3615
                              15275
                                     closed
                       5789
379407426
           379387904
                              19522
                                     established
                                     established
658187773
          658178048
                       10043
                              9725
                                    established
           658178048
                       10043 20227
658198275
                              32558
           658178048
                       10043
658210606
                                      established
_____
No. of sessions: 9
_____
*A:Dut-C#
*A:Dut-C# show router 12tp session state established
_____
L2TP Session Summarv
Control Conn ID Tunnel-ID Session-ID State
ΤD
_____
                              946
143524786
           143523840
                       2190
                                     established
                       2190 946
2190 3083
5789 19522
143526923
           143523840
                                     established
379407426
           379387904
                       5789
                              19522
                                     established
658187773
           658178048
                       10043
                              9725
                                     established
                                    established
        65817804810043202276581780481004332558
658198275
                              32558
                                     established
658210606
_____
No. of sessions: 6
*A . Dut - C#
*A:Dut-C# show router 12tp session state closed detail
_____
L2TP Session Status
_____
Connection ID : 143531662
State
       : closed
Tunnel Group : isp1.group-2
Assignment ID : ispl.tunnel-3
Error Message : Terminated by PPPoE: RX PADT
Control Conn ID : 143523840 Remote Conn ID : 1148557524
Tunnel ID: 2190Remote Tunnel ID: 17525Session ID: 7822Remote Session ID: 39124
Session ID : 7822
Time Started : 04/17/2009 18:44:37
                       Remote Session ID : 39124
Time Established : 04/17/2009 18:44:37 Time Closed
                                  : 04/17/2009 18:44:50
                       General Error
CDN Result : generalError
                                   : noError
_____
_____
L2TP Session Status
_____
Connection ID : 236926987
       : closed
State
Tunnel Group : ispl.group-2
Assignment ID : isp1.tunnel-2
Error Message : tunnel was closed
Control Conn ID : 236912640
Tunnel ID : 3615
                       Remote Conn ID : 3861360381
                      Remote Tunnel ID : 58919
Session ID
         : 14347
                       Remote Session ID : 44797
```

```
Time Started
          : 04/17/2009 18:41:55
                                    : 04/17/2009 18:43:20
Time Established : 04/17/2009 18:41:55 Time Closed
                                     : noError
CDN Result : generalError General Error
_____
_____
L2TP Session Status
Connection ID : 236927915
State : closed
Tunnel Group : isp1.group-2
Assignment ID : isp1.tunnel-2
Error Message : tunnel was closed
Control Conn ID: 236912640Remote Conn ID. ....Tunnel ID: 3615Remote Tunnel ID: 58919. 15275Remote Session ID: 1626
                         Remote Conn ID : 3861317210
Session ID : 15275
Time Started : 04/17/2009 18:41:03
Time Established : 04/17/2009 18:41:03 Time Closed
                                     : 04/17/2009 18:43:20
                         General Error
CDN Result : generalError
                                     : noError
No. of sessions: 3
_____
*A:Dut-C#
*A:Dut-C# show router l2tp session session-id 946
L2TP Session Summary
_____
ID
            Control Conn ID Tunnel-ID Session-ID State
_____
143524786
                         2190 946 established
            143523840
   _____
No. of sessions: 1
_____
*A:Dut-C# show router l2tp session connection-id 143524786 detail
_____
L2TP Session Status
_____
Connection ID : 143524786
State : established
Tunnel Group : isp1.group-2
Assignment ID : ispl.tunnel-3
Error Message : N/A

        Control Conn ID
        : 143523840
        Remote Conn ID
        : 1148528691

        Tunnel ID
        : 2190
        Remote Tunnel ID
        : 17525

        Constront ID
        : 046
        Remote Tunnel ID
        : 10001

Session ID : 946
Time Started : 04/17/2009 18:42:01
                         Remote Session ID : 10291
                    General Error : N/A
Time Established : 04/17/2009 18:42:01 Time Closed
CDN Result : noError
                                     : noError
 -----
*A:Dut-C#
*A:Dut-C# show router 12tp session group isp1.group-2
L2TP Session Summary
```

```
ТD
               Control Conn ID
                               Tunnel-ID Session-ID State
_____
143524786 143523840 2190 946
                                                   established
                                         3083
               143523840
143526923
                               2190
                                                   established

        2190
        3003

        2190
        7822

        3615
        14347

        3615
        15275

        10043
        9725

        10043
        20227

        10043
        32558

                                         7822
143531662
               143523840
                                                   closed
                                                   closed
              236912640
236912640
236926987
236927915
                                                    closed
               658178048
658187773
                                                    established
                                                   established
               658178048
658198275
                                                   established
               658178048
658210606
                        -----
No. of sessions: 8
_____
*A:Dut-C#
*A:Dut-C# show router l2tp session tunnel-id 2190 state closed detail
_____
L2TP Session Status
Connection ID : 143531662
     : closed
State
Tunnel Group : isp1.group-2
Assignment ID : isp1.tunnel-3
Error Message : Terminated by PPPoE: RX PADT

        Control Conn ID
        : 143523840
        Remote Conn ID
        : 1148557524

        Tunnel ID
        : 2190
        Remote Tunnel ID
        : 17525

        Session ID
        : 7822
        Remote Session ID
        : 39124

Time Started : 04/17/2009 18:44:37
Time Established : 04/17/2009 18:44:37 Time Closed
                                              : 04/17/2009 18:44:50
CDN Result : generalError General Error : noError
_____
No. of sessions: 1
_____
*A:Dut-C#
*A:Dut-C# show router l2tp session assignment-id ispl.tunnel-2
_____
L2TP Session Summary
_____
                Control Conn ID Tunnel-ID Session-ID State
ΤD
_____

        236926987
        236912640
        3615
        14347
        closed

        236927915
        236912640
        3615
        15275
        closed

               236912640
               658178048
                               10043
                                         9725
                                                   established
658187773
                               10043202271004332558
                                                   established
               658178048
658198275
                                                  established
658210606
               658178048
No. of sessions: 5
_____
*A:Dut-C#
*A:Dut-C# show router l2tp session assignment-id isp1.tunnel-2 state established
_____
L2TP Session Summary
```

-

```
Control Conn ID Tunnel-ID Session-ID State
ТD
_____
           658178048
                       10043 9725
658187773
                                     established
                                    established
        65817804810043202276581780481004332558
658198275
658210606
_____
No. of sessions: 3
_____
*A:Dut-C#
*A:Dut-C# show router l2tp session control-connection-id 658178048
_____
L2TP Session Summary
ID
           Control Conn ID Tunnel-ID Session-ID State
_____
                       >125established1004320227established1004332558established
658187773
           658178048
658198275
           658178048
           658178048
658210606
_____
No. of sessions: 3
_____
*A:Dut-C#
*A:Dut-C# show router l2tp session peer 10.10.20.100
_____
L2TP Session Summarv
_____
ID
           Control Conn ID Tunnel-ID Session-ID State
_____
                                    closed
                        3615
236926987
           236912640
                               14347
236927915
           236912640
                        3615
                               15275
                                      closed
           658178048
                       10043
                               9725
658187773
                                      established
           658178048
                       10043
                               20227
                                      established
658198275
                       10043
                               32558
658210606
           658178048
                                      established
_____
No. of sessions: 5
_____
*A:Dut-C#
*A:Dut-C# show router l2tp session peer 10.10.20.100 state closed detail
_____
L2TP Session Status
_____
Connection ID : 236926987
State : closed
Tunnel Group : isp1.group-2
Assignment ID : isp1.tunnel-2
Error Message : tunnel was closed

        Control Conn ID
        : 236912640
        Remote Conn ID
        : 3861360381

        Tunnel ID
        : 3615
        Remote Tunnel ID
        : 58919

        Session ID
        : 14347
        Remote Session ID
        : 44797

Time Started : 04/17/2009 18:41:55
Time Established: 04/17/2009 18:41:55Time Closed: 04/17/2009 18:43:20CDN Result: generalErrorGeneral Error: noError
```

```
_____
_____
L2TP Session Status
_____
Connection ID : 236927915
      : closed
State
Tunnel Group : isp1.group-2
Assignment ID : isp1.tunnel-2
Error Message : tunnel was closed

        Control Conn ID
        : 236912640
        Remote Conn ID
        : 3861317210

        Tunnel ID
        : 3615
        Remote Tunnel ID
        : 58919

Session ID
         : 15275
                      Remote Session ID : 1626
Time Started : 04/17/2009 18:41:03
                   General Error : noError
Time Established : 04/17/2009 18:41:03 Time Closed
CDN Result : generalError
No. of sessions: 2
_____
*A:Dut-C#
*A:Dut-C# show router l2tp session local-name lac1.wholesaler.com
_____
L2TP Session Summary
Control Conn ID Tunnel-ID Session-ID State
ID
_____
                   2190 946
2190 3083
          143523840
                                   established
143524786
          143523840
                                   established
143526923
                            3083
143531662
          143523840
                     2190
                            7822
                                   closed
236926987
          236912640
                     3615
                            14347
                                   closed
          236912640
                            15275
                                   closed
                     3615
236927915
                            19522
          379387904
                      5789
379407426
                                   established
658187773
          658178048
                      10043
                             9725
                                   established
658198275
           658178048
                      10043
                             20227
                                   established
                      10043
658210606
          658178048
                            32558
                                   established
_____
No. of sessions: 9
_____
*A:Dut-C#
*A:Dut-C# show router 12tp session local-name lac1.wholesaler.com remote-name
lns.retailer1.net
_____
L2TP Session Summary
_____
ID
          Control Conn ID Tunnel-ID Session-ID State
_____
379407426
          379387904
                     5789 19522 established
_____
No. of sessions: 1
_____
*A:Dut-C#
```

*A:Fden-Dut2-BSA2# show router l2tp session connection-id 600407016

```
L2TP Session Summary
_____
               Control Conn ID Tunnel-ID Session-ID State
ID
_____
600407016 600375296 9161 31720 established
 simon@base.lac.base.lns
 interface: gi_base_lns_base_lac
 service-id: 100
 ip-address: 10.100.2.1
_____
*A:Fden-Dut2-BSA2# show router l2tp session connection-id 600407016 detail
_____
L2TP Session Status
_____
Connection ID: 600407016
State : established
Tunnel Group : base lns base lac
Assignment ID: t1
Error Message: N/A

        Control Conn ID
        : 600375296
        Remote Conn ID
        : 1026712216

        Tunnel ID
        : 9161
        Remote Tunnel ID
        : 15666

Tunnel ID : 9161
Session ID : 31720
                                Remote Session ID : 25240
Time Started : 02/02/2010 09:08:54
Time Established: 02/02/2010 09:08:54Time Closed: N/ACDN Result: noErrorGeneral Error: noError
Time Established : 02/02/2010 09:08:54 Time Closed
_____
PPP information
Service Id : 100
Interface : gi_base_lns_base_lac
LCP State : opened
LCP State
IPCP State
IPv6CP State
                : opened
               : initial
PPP MTU
                : 1492
PPP Auth-Protocol : chap
PPP User-Name : simon@base.lac.base.lns
Subscriber Origin : radius
Strings Origin : radius
IPCP Info Origin : radius
IPv6CP Info Origin : none
Subscriber
                 : "simon"
Sub-Profile-String : "sub1"
SLA-Profile-String : "sla1"
ANCP-String : ""
                 : ""
Int-Dest-Id
App-Profile-String : ""
                 : ""
Category-Map-Name
IP Address
                : 10.100.2.1
Primary DNS: N/ASecondary DNS: N/APrimary NBNS: N/A
```

Secondary NBNS	: N/A
Address-Pool	: N/A
IPv6 Prefix	: N/A
IPv6 Del.Pfx.	: N/A
Primary IPv6 DNS	: N/A
Secondary IPv6 DNS	: N/A
Circuit-Id	: (Not Specified)
Remote-Id	: (Not Specified)
Session-Timeout	: N/A
Radius Class	: (Not Specified)
Radius User-Name	: simon@base.lac.base.lns

statistics

Syntax	statistics
Context	show>router>l2tp
Description	This command displays L2TP statistics.

Sample Output

*A:Dut-C# show router l2tp statistics				
L2TP Statistics				
Tunnels		Sessions		
Active	: 3	Active	: 6	
Setup history since 04/17/2009 18:38:41				
Total	: 4	Total	: 9	
Failed	: 0	Failed	: 0	
Failed Auth	: 0			
======================================				

tunnel

Syntax tunnel [statistics] [detail] [peer *ip*-address] [state *tunnel*-state] [remote-connection-id remote-connection-id (v3)] [group group-name] [assignment-id assignment-id] [local-name host-name] [remote-name host-name]

Show Commands

tunnel [statistics] [detail] [peer ip-address] [state tunnel-state] [remote-tunnel-id remotetunnel-id (v2)] [group group-name] [assignment-id assignment-id [local-name host-name] [remote-name host-name] tunnel tunnel-id tunnel-id (v2) [statistics] [detail] tunnel connection-id connection-id (v3) [statistics] [detail] Context show>router>l2tp Description This command displays L2TP tunnel operational information. **Parameters** statistics — Displays L2TP tunnel statistics. detail — Displays detailed L2TP tunnel information. peer *ip-address* — Displays information for the the IP address of the peer. state *tunnel-state* — Displays the operational state of the tunnel. **remote-connection-id** remote-connection-id (v3) — Displays information for the specified remote connection ID. **group** group-name — Displays L2TP tunnel information for the specified tunnel group. assignment-id assignment-id local-name host-name — Specifies a local host name used by this system. remote-name host-name — Specifies a remote host name used by this system. connection-id connection-id — Specifies the identification number for a Layer Two Tunneling Protocol connection. Values 1-429496729 detail — Displays detailed L2TP session information. session-id session-id (v2) — Displays information for the specified the L2TP session. Values 1 - 65535state session-state — Displays the operational state of the L2TP session. Values closed, closed-by-peer, draining, drained, established, established-idle, idle, waitreply, wait-conn peer *ip-address* — Displays information for the specified peer IP address. Values ipv4-address a.b.c.d (host bits must be 0) ipv6-address x:x:x:x:x:x:x:[-interface] x:x:x:x:x:d.d.d.d[-interface] x: [0..FFFF]H d: [0..255]D interface: 32 characters maximum, mandatory for link local addresses tunnel-id tunnel-id (v2) — Displays information for the specified ID of a L2TP tunnel. In L2TP version 2, it is the 16-bit tunnel ID.

Values 1 — 65535

control-connection-id *(v3)* — Displays information for the specified ID of a L2TP tunnel. In L2TP version 3, it is the 32-bit control connection ID.

Values 1 — 429496729

Sample Output

*A:Dut-C# show router l2tp tunnel Conn ID Loc-Tu-ID Rem-Tu-ID State Ses Active Group Ses Total Assignment _____ 2190 17525 established 2 143523840 ispl.group-2 3 isp1.tunnel-3 3615 58919 closedByPeer 0 236912640 isp1.group-2 2 isp1.tunnel-2 5789 4233 established 379387904 1 ispl.group-1 1 isp1.tunnel-1 10043 33762 draining 658178048 3 isp1.group-2 3 isp1.tunnel-2 _____ No. of tunnels: 4 _____ *A:Dut-C# *A:Dut-C# show router 12tp tunnel state closed-by-peer detail _____ L2TP Tunnel Status _____ Connection ID : 236912640 State : closedByPeer IP : 10.20.1.3 Name : lac1.wholesaler.com Remote Name : lns2.retoil Assignment ID : isp1.tunnel-2 Group Name : isp1.group-2 Error Message : Goodbye! Remote Conn ID : 3861315584 Remote Tunnel ID : 58919 Remote IDP Port : 1701 Tunnel ID : 3615 UDP Port : 1701 Preference : 100 Remote UDP Port : 1701 Hello Interval (s): infinite Heilo Interval (s): InfiniteIdle TO (s): 60Destruct TO (s): 7200Max Retr Estab: 5Max Retr Not Estab: 5Session Limit: 1000AVP Hiding: neverTransport Type: udpIpChallenge: neverTime Started: 04/17/2009 18:41:03Time Idle: 04/17/2009 18:43:20Time Established: 04/17/2009 18:41:03Time Closed: 04/17/2009 18:43:20Stop CCN Result: generalReqGeneral Error: noError _____

```
No. of tunnels: 1
_____
*A:Dut-C#
*A:Dut-C# show router l2tp tunnel state established
Conn ID
          Loc-Tu-ID Rem-Tu-ID State
                        Ses Active
Group
                        Ses Total
 Assignment
_____
143523840
          2190 17525 established
                        2
isp1.group-2
                        3
 isp1.tunnel-3
          5789 4233 established
379387904
                        1
ispl.group-1
                        1
 isp1.tunnel-1
_____
No. of tunnels: 2
_____
*A:Dut-C#
*A:Dut-C# show router l2tp tunnel tunnel-id 2190 statistics
_____
L2TP Tunnel Statistics
Connection ID: 143523840
_____
    Attempts Failed
                    Active Total
_____
Sessions 3
        0
                    2
                        3
_____
_____
    Rx
                    Τx
_____
Ctrl Packets 47
                    47
Ctrl Octets 954
                    1438
                    0
Error Packets 0
_____
*A:Dut-C#
*A:Dut-C# show router l2tp tunnel connection-id 143523840 statistics
_____
L2TP Tunnel Statistics
_____
Connection ID: 143523840
_____
    Attempts Failed
                    Active Total
Sessions
    3
        0
                    2
                        3
_____
_____
    Rx
                    Τx
_____
Ctrl Packets 48
                    48
Ctrl Octets 974
                    1450
Error Packets 0
                    0
```

```
_____
*A:Dut-C#
*A:Dut-C# show router l2tp tunnel remote-tunnel-id 17525 detail
_____
L2TP Tunnel Status
_____
Connection ID : 143523840
    : established
State
IP
       : 10.20.1.3
Peer IP : 10.10.20.101
Name : lac1.wholesaler.com
Remote Name : lns3.retailer1.net
Assignment ID : isp1.tunnel-3
Group Name : isp1.group-2
Error Message : N/A
                     Remote Conn ID : 1148518400
Tunnel ID : 2190
                     Remote Tunnel ID : 17525
UDP Port : 1701
Preference : 100
                     Remote UDP Port : 1701
Hello Interval (s): 300
                   Destruct TO (s) : 7200
Idle TO (s): 0Max Retr Estab: 5
                     Max Retr Not Estab: 5
Session Limit: 1000AVP Hiding: neverTransport Type: udpIpChallenge: neverTime Started: 04/17/2009 18:41:14Time Idle: N/A
                               : N/A
Time Established : 04/17/2009 18:41:14 Time Closed
                               : N/A
Stop CCN Result : noError General Error : noError
_____
No. of tunnels: 1
_____
*A:Dut-C#
*A:Dut-C# show router l2tp tunnel remote-connection-id 1148518400 statistics
L2TP Tunnel Statistics
_____
Connection ID: 143523840
_____
       Attempts Failed
                               Active Total
_____
Sessions 3 0
                               2 3
_____
_____
       Rx
                               Τx
-----
                                 ------
Ctrl Packets 50
                               50
Ctrl Octets 1014
                               1474
Error Packets 0
                               0
         _____
  _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _
No. of tunnels: 1
_____
*A:Dut-C#
```

*A:Dut-C# show router l2tp tunnel peer 10.10.20.100 state closed-by-peer detail

_____ L2TP Tunnel Status Connection ID : 236912640 State : closedByPeer IP : 10.20.1.3 Peer IP : 10.10.20.100 Name : lac1.wholesaler.com Remote Name : lns2.retailer1.net Assignment ID : isp1.tunnel-2 Group Name : isp1.group-2 Error Message : Goodbye! Remote Conn ID : 3861315584 Tunnel ID: 3615UDP Port: 1701Preference: 100 Remote Tunnel ID : 58919 Remote UDP Port : 1701 Hello Interval (s): infinite Destruct TO (s) : 7200 Idle TO (s) : 60 Max Retr Estab: 5Max Retr Not Estab: 5Session Limit: 1000AVP Hiding: neverTransport Type: udpIpChallenge: neverTime Started: 04/17/2009 18:41:03Time Idle: 04/17/2009

 . v+/1//2009 18:41:03 Time Idle
 : 04/17/2009 18:43:20

 Time Established
 : 04/17/2009 18:41:03 Time Closed
 : 04/17/2009 18:43:20

 Stop CCN Result
 : generalPace

 Stop CCN Result : generalReq General Error : noError No. of tunnels: 1 _____ *A:Dut-C# *A:Dut-C# show router l2tp tunnel group isp1.group-2 _____ Conn ID Loc-Tu-ID Rem-Tu-ID State Ses Active Ses Total Group Assignment _____ 2190 17525 established 2 143523840 isp1.group-2 3 isp1.tunnel-3 3615 58919 closedByPeer 236912640 0 ispl.group-2 2 isp1.tunnel-2 10043 33762 draining 658178048 3 isp1.group-2 3 isp1.tunnel-2 _____ No. of tunnels: 3 _____ *A . Dut - C# *A:Dut-C# show router l2tp tunnel assignment-id isp1.tunnel-3 state established statistics _____ L2TP Tunnel Statistics _____ Connection ID: 143523840 _____

```
Attempts Failed
                      Active Total
------
            _____
                        -----
Sessions 3 0
                      2
                          3
_____
_____
     Rx
                      Τx
_____
                        _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _
Ctrl Packets 66
                      66
Ctrl Octets 1310
                      1690
Error Packets 0
                      0
No. of tunnels: 1
_____
*A:Dut-C#
*A:Dut-C# show router l2tp tunnel local-name lac1.wholesaler.com remote-name
lns2.retailer1.net state draining
_____
Conn ID
           Loc-Tu-ID Rem-Tu-ID State
                          Ses Active
Group
                          Ses Total
 Assignment
_____
          10043 33762 draining
658178048
                          3
isp1.group-2
                           3
 isp1.tunnel-2
No. of tunnels: 1
_____
*A:Dut-C#
*A:Fden-Dut2-BSA2# show router l2tp tunnel connection-id 600375296 statistics
_____
L2TP Tunnel Statistics
_____
Connection ID: 600375296
_____
    Attempts Failed
                     Active Total
_____
Sessions 1 0
                      1
                          1
_____
     Rx
                      Τx
_____
                        _____
Ctrl Packets 6
                      6
Ctrl Octets 553
                      292
Error Packets 0
                      0
_____
    Accepted Duplicate
                     Out-Of-Wnd
_____
        0
Fsm Messages 4
                     0
_____
```

	Unser	t Max Unsent Cur	Ack Max	Ack Cur
Q Length	1	0	1	0
Window Siz	e Cur		: 4	
acceptedMs	дТуре			
StartCon	trolConn	lectionRequest	: 1	
StartControlConnectionConnected			: 1	
IncomingCallRequest			: 1	
IncomingCallConnected		: 1		
ZeroLengthBody		: 3		
originalTr	ansmitte	dMsgType		
StartControlConnectionReply		: 1		
Hello		: 2		
IncomingCallReply		: 1		
ZeroLengthBody			: 3	
last clear	ed time		: N/A	

Clear Commands

router

Syntax	router router-instance		
Context	clear>router		
Description	This command clears for a the router instance in which they are entered.		
Parameters	<i>router-instance</i> — Specify the router name or service ID.		
	Values	router-name: service-id:	Base, management, vpls-management 1 — 2147483647
	Default	Base	

arp

Syntax	arp {all ip-addr interface {ip-int-name ip-addr}}	
Context	clear>router	
Description	This command clears all or specific ARP entries.	
	The scope of ARP cache entries cleared depends on the command line option(s) specified.	
Parameters	all — Clears all ARP cache entries.	
	<i>ip-addr</i> — Clears the ARP cache entry for the specified IP address.	
	interface <i>ip-int-name</i> — Clears all ARP cache entries for the IP interface with the specified name.	
	interface <i>ip-addr</i> — Clears all ARP cache entries for the specified IP interface with the specified IP address.	

bfd

Syntax	bfd src-ip <i>ip-address</i> dst-ip <i>ip-address</i> bfd all
Context	clear>router
Description	This command enables the context to clear bi-directional forwarding (BFD) sessions and statistics.

7750 SR OS Router Configuration Guide

Clear Commands

session

Syntax	session src-ip ip-address dst-ip ip-address	
Context	clear>router>bfd	
Description	This command clears BFD sessions.	
Parameters	src-ip <i>ip-address</i> — Specifies the address of the local endpoint of this BFD session.	
	dst-ip <i>ip-address</i> — Specifies the address of the remote endpoint of this BFD session.	

statistics

Syntax	statistics src-ip ip-address dst-ip ip-address statistics all	
Context	clear>router>bfd	
Description	This command clears BFD statistics.	
Parameters	src-ip <i>ip-address</i> — Specifies the address of the local endpoint of this BFD session.	
	dst-ip <i>ip-address</i> — Specifies the address of the remote endpoint of this BFD session.	
	all — Clears statistics for all BFD sessions.	

dhcp

Syntax	dhcp
Context	clear>router
Description	This command enables the context to clear DHCP related information.

dhcp6

Syntax	dhcp6
Context	clear>router
Description	This command enables the context to clear DHCP6 related information.

forwarding-table

Syntax	forwarding-table [slot-number]		
Context	clear>router		
Description	This command clears entries in the forwarding table (maintained by the IOMs).		
	If the slot number is not specified, the command forces the route table to be recalculated.		
Parameters	slot-number — Clears the specified card slot.		
	Default all IOMs		
	Values 1 — 10		

grt-lookup

Syntax	grt-lookup
Context	clear>router
Description	This command re-evaluates route policies for GRT.

icmp-redirect-route

Syntax	icmp-redirect-route {all ip-address}
Context	clear>router
Description	This command deletes routes created as a result of ICMP redirects received on the management interface.
Parameters	all — Clears all routes.
	<i>ip-address</i> — Clears the routes associated with the specified IP address.

icmp6

Syntax	icmp6 all icmp6 global icmp6 interface interface-name
Context	clear>router
Description	This command clears ICMP statistics.
Parameters	all — Clears all statistics.
	global — Clears global statistics.

 $interface\text{-}name-Clears\ ICMP6\ statistics\ for\ the\ specified\ interface.$

interface

Syntax	interface [ip-int-name ip-addr] [icmp]		
Context	clear>router		
Description	This command clears IP interface statistics.		
	If no IP interface is specified either by IP interface name or IP address, the command will perform the clear operation on all IP interfaces.		
Parameters	<i>ip-int-name ip-addr</i> — The IP interface name or IP interface address.		
	Default All IP interfaces.		
	icmp — Specifies to reset the ICMP statistics for the IP interface(s) used for ICMP rate limiting.		

l2tp

Syntax	l2pt
Context	clear>router
Description	This command enables the context to clear L2PT data.

group

Syntax	group tunnel-group-name
Context	clear>router>l2tp
Description	This command clears L2PT data.
Parameters	tunnel-group-name — Specifies a Layer Two Tunneling Protocol Tunnel Group name.

tunnel

Syntax	tunnel tunnel-id		
Context	clear>router>l2tp		
Description	This command clears L2PT data.		
Parameters	tunnel-group-name — Clears L2TP tunnel statistics.		

statistics

Syntax	statistics
Context	clear>router>l2tp clear>router>l2tp>group clear>router>l2tp> tunnel
Description	This command clears statistics for the specified context.

statistics

Syntax	statistics [ip-address ip-int-name]
Context	clear>router>dhcp clear>router>dhcp6
Description	This command clear statistics for DHCP and DHCP6and DHCP6 relay and snooping statistics.
	If no IP address or interface name is specified, then statistics are cleared for all configured interfaces.
	If an IP address or interface name is specified, then only data regarding the specified interface is cleared.
Parameters	<i>ip-address ip-int-name</i> — Displays statistics for the specified IP interface.

neighbor

Syntax	neighbor {all <i>ip-address</i> } neighbor [interface ip-int-name ip-address]		
Context	clear>router		
Description	This command clears IPv6 neighbor information.		
Parameters	all — Clears IPv6 neighbors.		
	<i>ip-int-name</i> — Clears the specified neighbor interface information.		
	Values32 characters maximum		
	<i>ip-address</i> — Clears the specified IPv6 neighbors.		
	x:x:x:: x: [0 -	x:x:x:x:x (eight 16-bit pieces) x:x:x:d.d.d — FFFF]H — 255]D	

7750 SR OS Router Configuration Guide

router-advertisement

Syntax	router-advertisement all router-advertisement [interface interface-name]	
Context	clear>router	
Description	This command clears all router advertisement counters.	
Parameters	all — Clears all router advertisement counters for all interfaces.	
	interface <i>interface-name</i> — Clear router advertisement counters for the specified interface.	

Debug Commands

destination

Syntax	destination trace-destination		
Context	debug>trace		
Description	This command specifies the destination to send trace messages.		
Parameters	<i>trace-destination</i> — The destination to send trace messages.		
	Values stdout, console, logger, memory		

enable

Syntax	[no] enable	
Context	debug>trace	
Description	This command enables the trace.	
	The no form of the command disables the trace.	

trace-point

Syntax	[no] trace-point [module module-name] [type event-type] [class event-class] [task task- name] [function function-name]	
Context	debug>trace	
Description	This command adds trace points.	
	The no form of the command removes the trace points.	

router

Syntax	router router-instance		
Context	debug		
Description	This command configures debugging for a router instance.		
Parameters	<i>router-instance</i> — Specify the router name or service ID.		
	Values	router-name: service-id:	Base, management 1 — 2147483647

7750 SR OS Router Configuration Guide

Debug Commands

Default Base

ip

Syntax	ip
Context	debug>router
Description	This command configures debugging for IP.

arp

Syntax	arp
Context	debug>router>ip
Description	This command configures route table debugging.

icmp

Syntax	[no] icmp
Context	debug>router>ip
Description	This command enables ICMP debugging.

icmp6

Syntax	icmp6 [<i>ip-int-name</i>] no icmp6
Context	debug>router>ip
Description	This command enables ICMP6 debugging.

interface

Syntax	[no] interface [ip-int-name ip-address ipv6-address]
Context	debug>router>ip
Description	This command displays the router IP interface table sorted by interface index.

Parameters *ip-address* — Only displays the interface information associated with the specified IP address.

Values	ipv4-address	a.b.c.d (host bits must be 0)
	ipv6-address	x:x:x:x:x:x:x (eight 16-bit pieces)
		x:x:x:x:x:d.d.d.d
		x: [0 — FFFF]H
		d: [0 — 255]D

ip-int-name — Only displays the interface information associated with the specified IP interface name.

Values 32 characters maximum

packet

Syntax	packet [ip-int-name ip-address] [headers] [protocol-id] no packet [ip-int-name ip-address]	
Context	debug>router>ip	
Description	This command enables debugging for IP packets.	
Parameters	<i>ip-int-name</i> — Only displays the interface information associated with the specified IP interface name.	
	Values32 characters maximum	
	<i>ip-address</i> — Only displays the interface information associated with the specified IP address.	
	headers — Only displays information associated with the packet header.	
	protocol-id — Specifies the decimal value representing the IP protocol to debug. Well known protoc numbers include ICMP(1), TCP(6), UDP(17). The no form the command removes the protocol from the criteria.	
	Values 0 — 255 (values can be expressed in decimal, hexidecimal, or binary) keywords: none, crtp, crudp, egp, eigrp, encap, ether-ip, gre, icmp, idrp, igmp, igp, ip, ipv6, ipv6-frag, ipv6-icmp, ipv6-no-nxt, ipv6-opts, ipv6-route, isis, iso-ip, l2tp, ospf-igp, pim, pnni, ptp, rdp, rsvp, stp, tcp, udp, vrrp	

* — udp/tcp wildcard

route-table

Syntax	route-table [ip-prefix/prefix-length] route-table ip-prefix/prefix-length longer no route-table		
Context	debug>router>ip		
Description	This command configures route table debugging.		
Parameters	<i>ip-prefix</i> — The IP prefix for prefix list entry in dotted decimal notation.		
	Values	ipv4-prefix ipv4-prefix-length ipv6-prefix ipv6-prefix-length	a.b.c.d (host bits must be 0) 0 - 32 x:x:x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:x:d.d.d x: [0 - FFFF]H d: [0 - 255]D 0 - 128

longer — Specifies the prefix list entry matches any route that matches the specified *ip-prefix* and prefix *mask* length values greater than the specified *mask*.

tunnel-table

Syntax	tunnel-table [ip-address] [ldp rsvp [tunnel-id tunnel-id] sdp [sdp-id sdp-id]]
Context	debug>router>ip
Description	This command enables debugging for tunnel tables.

mtrace

Syntax	[no] mtrace
Context	debug>router
Description	This command configures debugging for mtrace.

misc

Syntax	[no] misc
Context	debug>router>mtrace
Description	This command enables debugging for mtrace miscellaneous.

packet

Syntax	[no] packet [query request response]
Context	debug>router>mtrace
Description	This command enables debugging for mtrace packets.

Debug Commands

VRRP

In This Chapter

This chapter provides information about configuring Virtual Router Redundancy Protocol (VRRP) parameters. Topics in this chapter include:

- VRRP Overview on page 232
 - → Virtual Router on page 233
 - \rightarrow IP Address Owner on page 233
 - → Primary and Secondary IP Addresses on page 234
 - → Virtual Router Master on page 234
 - → Virtual Router Backup on page 235
 - → Owner and Non-Owner VRRP on page 235
 - → Configurable Parameters on page 236
- VRRP Priority Control Policies on page 244
 - → VRRP Virtual Router Policy Constraints on page 244
 - → VRRP Virtual Router Instance Base Priority on page 244
 - → VRRP Priority Control Policy Delta In-Use Priority Limit on page 245
 - → VRRP Priority Control Policy Priority Events on page 245
- VRRP Non-Owner Accessibility on page 250
 - \rightarrow Non-Owner Access Ping Reply on page 250
 - \rightarrow Non-Owner Access Telnet on page 250
 - \rightarrow Non-Owner Access SSH on page 251
 - → VRRP Advertisement Message IP Address List Verification on page 242
- VRRP Configuration Process Overview on page 252
- Configuration Notes on page 253

VRRP Overview

The Virtual Router Redundancy Protocol (VRRP) for IPv4 is defined in the IETF RFC 3768, *Virtual Router Redundancy Protocol*. VRRP for IPv6 is specified in *draft-ietf-vrrp-unified-spec-02.txt*. VRRP describes a method of implementing a redundant IP interface shared between two or more routers on a common LAN segment, allowing a group of routers to function as one virtual router. When this IP interface is specified as a default gateway on hosts directly attached to this LAN, the routers sharing the IP interface prevent a single point of failure by limiting access to this gateway address. VRRP can be implemented on IES service interfaces and on core network IP interfaces.

If the master virtual router fails, the backup router configured with the highest acceptable priority becomes the master virtual router. The new master router assumes the normal packet forwarding for the local hosts.

Figure 11 displays an example of a VRRP configuration.




Figure 11: VRRP Configuration

VRRP Components

VRRP consists of the following components:

- Virtual Router on page 233
- IP Address Owner on page 233
- Primary and Secondary IP Addresses on page 234
- Virtual Router Master on page 234
- Virtual Router Backup on page 235
- Owner and Non-Owner VRRP on page 235

Virtual Router

A virtual router is a logical entity managed by VRRP that acts as a default router for hosts on a shared LAN. It consists of a Virtual Router Identifier (VRID) and a set of associated IP addresses (or address) across a common LAN. A VRRP router can backup one or more virtual routers.

The purpose of supporting multiple IP addresses within a single virtual router is for multi-netting. This is a common mechanism that allows multiple local subnet attachment on a single routing interface. Up to four virtual routers are possible on a single Alcatel-Lucent IP interface. The virtual routers must be in the same subnet. Each virtual router has its own VRID, state machine and messaging instance.

IP Address Owner

VRRP can be configured in either an owner or non-owner mode. The owner is the VRRP router whose virtual router IP address is the same as the real interface IP address. This is the router that responds to packets addressed to one of the IP addresses for ICMP pings, TCP connections, etc. All other virtual router instances participating in this message domain must have the same VRID configured and cannot be configured as owner.

7750 SR OS allows the virtual routers to be configured as non-owners of the IP address. VRRP on a 7750 SR router can be configured to allow non-owners to respond to ICMP echo requests when they become the virtual router master for the virtual router. Telnet and other connection-oriented protocols can also be configured for non-owner master response. However, the individual application conversations (connections) will not survive a VRRP failover. A non-owner VRRP

router operating as a backup will not respond to any packets addressed to any of the virtual router IP addresses.

Primary and Secondary IP Addresses

A primary address is an IP address selected from the set of real interface address. VRRP advertisements are always sent using the primary IP address as the source of the IP packet.

A 7750 SR IP interface must always have a primary IP address assigned for VRRP to be active on the interface. 7750 SR OS supports both primary and secondary IP addresses (multi-netting) on the IP interface. The virtual router's VRID primary IP address is always the primary address on the IP interface. VRRP uses the primary IP address as the IP address placed in the source IP address field of the IP header for all VRRP messages sent on that interface.

Virtual Router Master

The VRRP router which controls the IP address(es) associated with a virtual router is called the master. The master is responsible for forwarding packets sent to the VRRP IP addresses. An election process provides dynamic failover of the forwarding responsibility if the master becomes unavailable. This allows any of the virtual router IP addresses on the LAN to be used as the default first hop router by end hosts. This enables a higher availability default path without requiring configuration of dynamic routing or router discovery protocols on every end host.

If the master is unavailable, each backup virtual router for the VRID compare the configured priority values to determine the master role. In case of a tie, the virtual router with the highest primary IP address becomes master.

The preempt parameter can be set to false to prevent a backup virtual router with a better priority value from becoming master when an existing non-owner virtual router is the current master. This is determined on a first-come, first-served basis.

While master, a virtual router routes and originates all IP packets into the LAN using the physical MAC address for the IP interface as the Layer 2 source MAC address, not the VRID MAC address. ARP packets also use the parent IP interface MAC address as the Layer 2 source MAC address while inserting the virtual router MAC address in the appropriate hardware address field. VRRP messages are the only packets transmitted using the virtual router MAC address as the Layer 2 source MAC address as the Layer 2 source MAC.

Virtual Router Backup

A new virtual router master is selected from the set of VRRP routers available to assume forwarding responsibility for a virtual router should the current master fail.

Owner and Non-Owner VRRP

The owner controls the IP address of the virtual router and is responsible for forwarding packets sent to this IP address. The owner assumes the role of the master virtual router. Only one virtual router in the domain can be configured as owner. All other virtual router instances participating in this message domain must have the same VRID configured.

The most important parameter to be defined on a non-owner virtual router instance is the priority. The priority defines a virtual router's selection order in the master election process. The priority value and the preempt mode determine the virtual router with the highest priority to become the master virtual router.

The base priority is used to derive the in-use priority of the virtual router instance as modified by any optional VRRP priority control policy. VRRP priority control policies can be used to either override or adjust the base priority value depending on events or conditions within the chassis.

For information about non-owner access parameters, refer to VRRP Non-Owner Accessibility on page 250.

Configurable Parameters

In addition to backup IP addresses, to facilitate configuration of a virtual router on 7750 SR routers, the following parameters can be defined in owner configurations:

- Virtual Router ID (VRID) on page 236
- Message Interval and Master Inheritance on page 238
- VRRP Message Authentication on page 240
- Authentication Data on page 242
- Virtual MAC Address on page 242

The following parameters can be defined in non-owner configurations:

- Virtual Router ID (VRID) on page 236
- Priority on page 236
- Message Interval and Master Inheritance on page 238
- Master Down Interval on page 239
- Preempt Mode on page 239
- VRRP Message Authentication on page 240
- Authentication Data on page 242
- Virtual MAC Address on page 242
- Inherit Master VRRP Router's Advertisement Interval Timer on page 243
- Policies on page 243

Virtual Router ID (VRID)

The VRID must be configured with the same value on each virtual router associated with the redundant IP address (IP addresses). It is placed in all VRRP advertisement messages sent by each virtual router.

Priority

The priority value affects the interaction between this VRID and the same VRID of other virtual routers participating on the same LAN. A higher priority value defines a greater priority in becoming the virtual router master for the VRID. The priority value can only be configured when

7750 SR OS Router Configuration Guide

the defined IP address on the IP interface is different than the virtual router IP address (non-owner mode).

When the IP address on the IP interface matches the virtual router IP address (owner mode), the priority value is fixed at 255, the highest value possible. This virtual router member is considered the owner of the virtual router IP address. There can only be one owner of the virtual router IP address for all virtual router members.

The priority value 0 is reserved for VRRP advertisement message purposes. It is used to tell other virtual routers in the same VRID that this virtual router is no longer acting as master, triggering a new election process. When this happens, each backup virtual router sets its master down timer equal to the skew time value. This shortens the time until one of the backup virtual routers becomes master.

The current master virtual router must transmit a VRRP advertisement message immediately upon receipt of a VRRP message with priority set to 0. This prevents another backup from becoming master for a short period of time.

Non-owner virtual routers may be configured with a priority of 254 through 1. The default value is 100. Multiple non-owners can share the same priority value. When multiple non-owner backup virtual routers are tied (transmit VRRP advertisement messages simultaneously) in the election process, both become master simultaneously, the one with the best priority will win the election. If the priority value in the message is equal to the master's local priority value, then the primary IP address of the local master and the message is evaluated as the tie breaker. The higher IP address becomes master. (The primary IP address is the source IP address of the VRRP advertisement message.)

The priority is also used to determine when to preempt the existing master. If the preempt mode value is true, VRRP advertisement messages from inferior (lower priority) masters are discarded, causing the master down timer to expire and the transition to master state.

The priority value also dictates the skew time added to the master timeout period.

IP Addresses

Each virtual router participating in the same VRID should be defined with the same set of IP addresses. These are the IP addresses being used by hosts on the LAN as gateway addresses. Multi-netting supports 16 IP addresses on the IP interface, up to 16 addresses can be assigned to a specific a virtual router instance.

Message Interval and Master Inheritance

Each virtual router is configured with a message interval per VRID within which it participates. This parameter must be the same for every virtual router on the VRID.

For IPv4, the default advertisement interval is 1 second and can be configured between 100 milliseconds and 255 seconds 900 milliseconds. For IPv6, the default advertisement interval is 1 second and can be configured between 100 milliseconds and 40 seconds 950 milliseconds.

As specified in the RFC, the advertisement interval field in every received VRRP advertisement message must match the locally configured advertisement interval. If a mismatch occurs, depending on the inherit configuration, the current master's advertisement interval setting can be used to operationally override the locally configured advertisement interval setting. If the current master changes, the new master setting is used. If the local virtual router becomes master, the locally configured advertisement interval is enforced.

If a VRRP advertisement message is received with an advertisement interval set to a value different than the local value and the inherit parameter is disabled, the message is discarded without processing.

The master virtual router on a VRID uses the advertisement interval to load the advertisement timer, specifying when to send the next VRRP advertisement message. Each backup virtual router on a VRID uses the advertisement interval (with the configured local priority) to derive the master down timer value.

VRRP advertisements messages that are fragmented, contain IP options (IPv4), or contain extension headers (IPv6) require a longer message interval to be configured.

Skew Time

The skew time is used to add a time period to the master down interval. This is not a configurable parameter. It is derived from the current local priority of the virtual router's VRID. To calculate the skew time, the virtual router evaluates the following formula:

For IPv4:	Skew Time = $((256 - priority) / 256)$ seconds
For IPv6:	Skew Time = (((256 - priority) * Master_Adver_Interval) / 256) centiseconds

The higher priority value, the smaller the skew time will be. This means that virtual routers with a lower priority will transition to master slower than virtual routers with higher priorities.

Master Down Interval

The master down interval is a calculated value used to load the master down timer. When the master down timer expires, the virtual router enters the master state. To calculate the master down interval, the virtual router evaluates the following formula:

Master Down Interval = (3 x Operational Advertisement Interval) + Skew Time

The operational advertisement interval is dependent upon the state of the inherit parameter. When the inherit parameter is enabled, the operational advertisement interval is derived from the current master's advertisement interval field in the VRRP advertisement message. When inherit is disabled, the operational advertisement interval must be equal to the locally configured advertisement interval.

The master down timer is only operational when the local virtual router is operating in backup mode.

Preempt Mode

Preempt mode is a true or false configured value which controls whether a specific backup virtual router preempts a lower priority master. The IP address owner will always become master when available. Preempt mode cannot be set to false on the owner virtual router. The default value for preempt mode is true.

When preempt mode is true, the advertised priority from the incoming VRRP advertisement message from the current master is compared to the local configured priority. If the local priority is higher, the received VRRP advertisement message is discarded. This will result in the eventual expiration of the master down timer causing a transition to the master state. If the received priority is equal to the local priority, the message is not discarded and the current master will not be discarded. Note that when in the backup state, the received primary IP address is not part of the decision to preempt and is not used as a tie breaker when the received and local priorities are equal.

When preempt is enabled, the virtual router instance overrides any non-owner master with an inuse message priority value less than the virtual router instance in-use priority value. If preempt is disabled, the virtual router only becomes master if the master down timer expires before a VRRP advertisement message is received from another virtual router.

VRRP Message Authentication

The authentication type parameter defines the type of authentication used by the virtual router in VRRP advertisement message authentication. VRRP message authentication is applicable to IPv4 only. The current master uses the configured authentication type to indicate any egress message manipulation that must be performed in conjunction with any supporting authentication parameters before transmitting a VRRP advertisement message. The configured authentication type value is transmitted in the message authentication type field with the appropriate authentication data field filled in. Backup routers use the authentication type message field value in interpreting the contained authentication data field within received VRRP advertisement messages.

VRRP supports three message authentication methods which provide varying degrees of security. The supported authentication types are:

- 0-No Authentication
- 1 Simple Text Password
- 2 IP Authentication Header

Authentication Type 0 – No Authentication

The use of type 0 indicates that VRRP advertisement messages are not authenticated (provides no authentication). The master transmitting VRRP advertisement messages will transmit the value 0 in the egress messages authentication type field and the authentication data field. Backup virtual routers receiving VRRP advertisement messages with the authentication type field equal to 0 will ignore the authentication data field in the message.

All compliant VRRP advertisement messages are accepted. The following fields within the received VRRP advertisement message are checked for compliance (the VRRP specification may require additional checks).

- IP header checks specific to VRRP
 - \rightarrow IP header destination IP address Must be 224.0.0.18
 - → IP header TTL field Must be equal to 255, the packet must not have traversed any IP routed hops
 - \rightarrow IP header protocol field must be 112 (decimal)

- VRRP message checks
 - \rightarrow Version field Must be set to the value 2
 - \rightarrow Type field Must be set to the value of 1 (advertisement)
 - → Virtual router ID field Must match one of the configured VRID on the ingress IP interface (All other fields are dependent on matching the virtual router ID field to one of the interfaces configured VRID parameters)
 - → Priority field Must be equal to or greater than the VRID in-use priority or be equal to 0 (Note, equal to the VRID in-use priority and 0 requires further processing regarding master/backup and senders IP address to determine validity of the message)
 - \rightarrow Authentication type field Must be equal to 0
 - → Advertisement interval field Must be equal to the VRID configured advertisement interval
 - \rightarrow Checksum field Must be valid
 - \rightarrow Authentication data fields Must be ignored.

VRRP messages not meeting the criteria are silently dropped.

Authentication Type 1 – Simple Text Password

The use of type 1 indicates that VRRP advertisement messages are authenticated with a clear (simple) text password. All virtual routers participating in the virtual router instance must be configured with the same 8 octet password. Transmitting virtual routers place a value of 1 in the VRRP advertisement message authentication type field and put the configured simple text password into the message authentication data field. Receiving virtual routers compare the message authentication data field with the local configured simple text password based on the message authentication type field value of 1.

The same checks are performed for type 0 with the following exceptions (the VRRP specification may require additional checks):

- VRRP message checks
 - \rightarrow Authentication type field Must be equal to 1
 - → Authentication data fields Must be equal to the VRID configured simple text password

Any VRRP message not meeting the type 0 verification checks with the exceptions above are silently discarded.

Authentication Failure

Any received VRRP advertisement message that fails authentication must be silently discarded with an invalid authentication counter incremented for the ingress virtual router instance.

Authentication Data

This feature is different than the VRRP advertisement message field with the same name. This is any required authentication information that is pertinent to the configured authentication type. The type of authentication data used for each authentication type is as follows:

Authentication Type	Authentication Data
0	None, authentication is not performed
1	Simple text password consisting of 8 octets

Virtual MAC Address

The MAC address can be used instead of an IP address in ARP responses when the virtual router instance is master. The MAC address configuration must be the same for all virtual routers participating as a virtual router or indeterminate connectivity by the attached IP hosts will result. All VRRP advertisement messages are transmitted with *ieee-mac-addr* as the source MAC.

VRRP Advertisement Message IP Address List Verification

VRRP advertisement messages contain an IP address count field that indicates the number of IP addresses listed in the sequential IP address fields at the end of the message. The 7750 SR OS implementation always logs mismatching events. The decision on where and whether to forward the generated messages depends on the configuration of the event manager.

To facilitate the sending of mismatch log messages, each virtual router instance keeps the mismatch state associated with each source IP address in the VRRP master table. Whenever the state changes, a mismatch log message is generated indicating the source IP address within the message, the mismatch or match event and the time of the event.

With secondary IP address support, multiple IP addresses may be found in the list and it should match the IP address on the virtual router instance. Owner and non-owner virtual router instances

have the supported IP addresses explicitly defined, making mismatched supported IP address within the interconnected virtual router instances a provisioning issue.

Inherit Master VRRP Router's Advertisement Interval Timer

The virtual router instance can inherit the master VRRP router's advertisement interval timer which is used by backup routers to calculate the master down timer.

The inheritance is only configurable in the non-owner nodal context. It is used to allow the current virtual router instance master to dictate the master down timer for all backup virtual routers.

IPv6 Virtual Router Instance Operationally Up

Once the IPv6 virtual router is properly configured with a minimum of one link-local backup address, the parent interface's router advertisement must be configured to use the virtual MAC address for the virtual router to be considered operationally up.

Policies

Policies can be configured to control VRRP priority with the virtual router instance. VRRP priority control policies can be used to override or adjust the base priority value depending on events or conditions within the chassis.

The policy can be associated with more than one virtual router instance. The priority events within the policy override or diminish the base priority dynamically affecting the in-use priority. As priority events clear in the policy, the in-use priority can eventually be restored to the base priority value.

Policies can only be configured in the non-owner VRRP context. For non-owner virtual router instances, if policies are not configured, then the base priority is used as the in-use priority.

VRRP Priority Control Policies

This implementation of VRRP supports control policies to manipulate virtual router participation in the VRRP master election process and master self-deprecation. The local priority value for the virtual router instance is used to control the election process and master state.

VRRP Virtual Router Policy Constraints

Priority control policies can only be applied to non-owner VRRP virtual router instances. Owner VRRP virtual routers cannot be controlled by a priority control policy because they are required to have a priority value of 255 that cannot be diminished. Only one VRRP priority control policy can be applied to a non-owner virtual router instance.

Multiple VRRP virtual router instances may be associated with the same IP interface, allowing multiple priority control policies to be associated with the IP interface.

An applied VRRP priority control policy only affects the in-use priority on the virtual router instance when the preempt mode has been enabled. A virtual router instance with preempt mode disabled will always use the base priority as the in-use priority, ignoring any configured priority control policy.

VRRP Virtual Router Instance Base Priority

Non-owner virtual router instances must have a base priority value between 1 and 254. The value 0 is reserved for master termination. The value 255 is reserved for owners. The default base priority for non-owner virtual router instances is the value 100.

The base priority is the starting priority for the VRRP instance. The actual in-use priority for the VRRP instance is derived from the base priority and an optional VRRP priority control policy.

VRRP Priority Control Policy Delta In-Use Priority Limit

A VRRP priority control policy enforces an overall minimum value that the policy can inflict on the VRRP virtual router instance base priority. This value provides a lower limit to the delta priority events manipulation of the base priority.

A delta priority event is a conditional event defined in the priority control policy that subtracts a given amount from the current, in-use priority for all VRRP virtual router instances to which the policy is applied. Multiple delta priority events can apply simultaneously, creating a dynamic priority value. The base priority for the instance, less the sum of the delta values derives the actual priority value in-use.

An explicit priority event is a conditional event defined in the priority control policy that explicitly defines the in-use priority for the virtual router instance. The explicitly defined values are not affected by the delta in-use priority limit. When multiple explicit priority events happen simultaneously, the lowest value is used for the in-use priority. The configured base priority is not a factor in explicit priority overrides of the in-use priority.

The allowed range of the Delta In-Use Priority Limit is 1 to 254. The default is 1, which prevents the delta priority events from operationally disabling the virtual router instance.

VRRP Priority Control Policy Priority Events

The main function of a VRRP priority control policy is to define conditions or events that impact the system's ability to communicate with outside hosts or portions of the network. When one or multiple of these events are true, the base priority on the virtual router instance is either overwritten with an explicit value, or a sum of delta priorities is subtracted from the base priority. The result is the in-use priority for the virtual router instance. Any priority event may be configured as an explicit event or a delta event.

Explicit events override all delta events. When multiple explicit events occur, the event with the lowest priority value is assigned to the in-use priority. As events clear, the in-use priority is reevaluated accordingly and adjusted dynamically.

Delta priority events also have priority values. When no explicit events have occurred within the policy, the sum of the occurring delta events priorities is subtracted from the base priority of each virtual router instance. If the result is lower than the delta in-use priority limit, the delta in-use priority limit is used as the in-use priority for the virtual router instance. Otherwise, the in-use priority is set to the base priority less the sum of the delta events.

Each event generates a VRRP priority event message indicating the policy-id, the event type, the priority type (delta or explicit) and the event priority value. Another log message is generated when the event is no longer true, indicating that it has been cleared.

Priority Event Hold-Set Timers

Hold-set timers are used to dampen the effect of a flapping event. A flapping event is where the event continually transitions between clear and set. The hold-set value is loaded into a hold set timer that prevents a set event from transitioning to the cleared state until it expires.

Each time an event transitions between cleared and set, the timer is loaded and begins to count down to zero. If the timer reaches zero, the event will be allowed to enter the cleared state once more. Entering the cleared state is always dependent on the object controlling the event conforming to the requirements defined in the event itself. It is possible, on some event types, to have a further set action reload the hold set timer. This extends the amount of time that must expire before entering the cleared state.

For an example of a hold-set timer setting, refer to LAG Degrade Priority Event on page 246.

Port Down Priority Event

The port down priority event is tied to either a physical port or a SONET/SDH channel. The port or channel operational state is evaluated to determine a port down priority event or event clear.

When the port or channel operational state is up, the port down priority event is considered false or cleared. When the port or channel operational state is down, the port down priority event is considered true or set.

LAG Degrade Priority Event

The LAG degrade priority event is tied to an existing Link Aggregation Group (LAG). The LAG degrade priority event is conditional to percentage of available port bandwidth on the LAG. Multiple bandwidth percentage thresholds may be defined, each with its own priority value.

If the LAG transitions from one threshold to the next, the previous threshold priority value is subtracted from the total delta sum while the new threshold priority value is added to the sum. The new sum is then subtracted from the base priority and compared to the delta in-use priority limit to derive the new in-use priority on the virtual router instance.

VRRP

The following example illustrates a LAG priority event and it's interaction with the hold set timer in changing the in-use priority.

The following state and timer settings are used for the LAG events displayed in Table 5:

- User-defined thresholds: 2 ports down 4 ports down 6 ports down
- LAG configured ports: 8 ports
- Hold set timer (hold-set): 5 seconds

Table 5: LAG Events

Time	LAG Port State	Parameter	State	Comments
0	All ports down	Event State	Set - 8 ports down	
		Event Threshold	6 ports down	
		Hold Set Timer	5 seconds	Set to hold-set parameter
1	One port up	Event State	Set - 8 ports down	Cannot change until Hold Set Timer expires
		Event Threshold	6 ports down	
		Hold Set Timer	5 seconds	Event does not affect timer
2	All ports up	Event State	Set - 8 ports down	Still waiting for Hold Set Timer expires
		Event Threshold	6 ports down	
		Hold Set Timer	3 seconds	
5	All ports up	Event State	Cleared - All ports up	
		Event Threshold	None	Event cleared
		Hold Set Timer	Expired	
100	Five ports down	Event State	Set - 5 ports down	
		Event Threshold	4 ports down	
		Hold Set Timer	Expired	Set to hold-set parameter
102	Three ports down	Event State	Set - 5 ports down	
		Event Threshold	4 ports down	
		Hold Set Timer	3 seconds	
103	All ports up	Event State	Set - 5 ports down	
		Event Threshold	4 ports down	
		Hold Set Timer	2 second	

VRRP Priority Control Policies

Table 5: LAG Events (Continued)

Time	LAG Port State	Parameter	State	Comments
104	Two ports down	Event State	Set - 5 ports down	
		Event Threshold	4 ports down	
		Hold Set Timer	1 second	Current threshold is 5, so 2 down has no effect
105	Two ports down	Event State	Set - 2 ports down	
		Event Threshold	2 ports down	
		Hold Set Timer	Expired	
200	Four ports down	Event State	Set - 2 ports down	
		Event Threshold	4 ports down	
		Hold Set Timer	5 seconds	Set to hold-set parameter
202	Seven ports down	Event State	Set - 7 ports down	Changed due to increase
		Event Threshold	6 ports down	
		Hold Set Timer	5 seconds	Set to hold-set due to threshold increase
206	All ports up	Event State	Set - 7 ports down	
		Event Threshold	6 ports down	
		Hold Set Timer	1 second	
207	All ports up	Event State	Cleared - All ports up	
		Event Threshold	None	Event cleared
		Hold Set Timer	Expired	

Host Unreachable Priority Event

The host unreachable priority event creates a continuous ping task that is used to test connectivity to a remote host. The path to the remote host and the remote host itself must be capable and configured to accept ICMP echo request and replies for the ping to be successful.

The ping task is controlled by interval and size parameters that define how often the ICMP request messages are transmitted and the size of each message. A historical missing reply parameter defines when the ping destination is considered unreachable.

When the host is unreachable, the host unreachable priority event is considered true or set. When the host is reachable, the host unreachable priority event is considered false or cleared.

Route Unknown Priority Event

The route unknown priority event defines a task that monitors the existence of a given route prefix in the system's routing table.

The route monitoring task can be constrained by a condition that allows a prefix that is less specific than the defined prefix to be considered as a match. The source protocol can be defined to indicate the protocol the installed route must be populated from. To further define match criteria when multiple instances of the route prefix exist, an optional next hop parameter can be defined.

When a route prefix exists within the active route table that matches the defined match criteria, the route unknown priority event is considered false or cleared. When a route prefix does not exist within the active route table matching the defined criteria, the route unknown priority event is considered true or set.

VRRP Non-Owner Accessibility

Although the RFC states that only VRRP owners can respond to ping and other managementoriented protocols directed to the VRID IP addresses, 7750 SR OS allows an override of this restraint on a per VRRP virtual router instance basis.

Non-Owner Access Ping Reply

When non-owner access ping reply is enabled on a virtual router instance, ICMP echo request messages destined to the non-owner virtual router instance IP addresses are not discarded at the IP interface when operating in master mode. ICMP echo request messages are always discarded in backup mode.

When non-owner access ping reply is disabled on a virtual router instance, ICMP echo request messages destined to the non-owner virtual router instance IP addresses are silently discarded in both the master and backup modes.

Non-Owner Access Telnet

When non-owner access Telnet is enabled on a virtual router instance, authorized Telnet sessions may be established that are destined to the virtual router instance IP addresses when operating in master mode. Telnet sessions are always discarded at the IP interface when destined to a virtual router IP address operating in backup mode. Enabling non-owner access Telnet does not guarantee Telnet access, proper management and security features must be enabled to allow Telnet on this interface and possibly from the given source IP address.

When non-owner access Telnet is disabled on a virtual router instance, Telnet sessions destined to the non-owner virtual router instance IP addresses are silently discarded in both master and backup modes.

Non-Owner Access SSH

When non-owner access SSH is enabled on a virtual router instance, authorized SSH sessions may be established that are destined to the virtual router instance IP addresses when operating in master mode. SSH sessions are always discarded at the IP interface when destined to a virtual router IP address operating in backup mode. Enabling non-owner access SSH does not guarantee SSH access, proper management and security features must be enabled to allow SSH on this interface and possibly from the given source IP address. SSH is applicable to IPv4 VRRP only.

When non-owner access SSH is disabled on a virtual router instance, SSH sessions destined to the non-owner virtual router instance IP addresses are silently discarded in both master and backup modes.

VRRP Configuration Process Overview

Figure 12 displays the process to provision VRRP parameters.




Figure 12: VRRP Configuration and Implementation Flow

Configuration Notes

This section describes VRRP configuration caveats.

General

- Creating and applying VRRP policies are optional.
- Backup command:
 - → The backup IP address(es) must be on the same subnet. The backup addresses explicitly define which IP addresses are in the VRRP advertisement message IP address list.
 - → In the owner mode, the backup IP address must be identical to one of the interface's IP addresses. The backup address explicitly defines which IP addresses are in the VRRP advertisement message IP address list.
 - \rightarrow For IPv6, one of the backup addresses configured must be the link-local address of the owner VRRP instance.

Configuration Notes

Configuring VRRP with CLI

This section provides information to configure VRRP using the command line interface.

Topics in this section include:

- VRRP Configuration Overview on page 256
- Basic VRRP Configurations on page 257
- Common Configuration Tasks on page 260
- Configuring VRRP Policy Components on page 262
- VRRP Configuration Management Tasks on page 267
- Modifying a VRRP Policy on page 267
- Deleting a VRRP Policy on page 268
 - → Modifying Service and Interface VRRP Parameters on page 269
 - Modifying Non-Owner Parameters on page 269
 - Modifying Owner Parameters on page 269
 - Deleting VRRP on an Interface or Service on page 269

VRRP Configuration Overview

Configuring VRRP policies and configuring VRRP instances on interfaces and router interfaces is optional. The basic owner and non-owner VRRP configurations on an IES or router interface must specify the **backup** *ip-address* parameter.

VRRP helps eliminate the single point of failure in a routed environment by using virtual router IP address shared between two or more routers connecting the common domain. VRRP provides dynamic fail over of the forwarding responsibility if the master becomes unavailable.

The VRRP implementation allows one master per IP subnet. All other VRRP instances in the same domain must be in backup mode.

Preconfiguration Requirements

VRRP policies:

• VRRP policies must be configured before they can be applied to an interface or IES or VPRN VRRP instance. VRRP policies are configured in the **config>vrrp** context.

Configuring VRRP on an IES or VPRN service interface:

- The service customer account must be created prior to configuring an IES or VPRN VRRP instance.
- The interface address must be specified in the both the owner and non-owner IES, VPRN or router interface instances.

Basic VRRP Configurations

Configure VRRP parameters in the following contexts:

- VRRP Policy on page 257
- VRRP IES Service Parameters on page 258
- VRRP Router Interface Parameters on page 259

VRRP Policy

Configuring and applying VRRP policies are optional. There are no default VRRP policies. Each policy must be explicitly defined. A VRRP configuration must include the following:

- Policy ID
- Define at least one of the following priority events:
 - \rightarrow Port down
 - \rightarrow LAG port down
 - \rightarrow Host unreachable
 - \rightarrow Route unknown

The following example displays a sample configuration of a VRRP policy.

```
A:SR2>config>vrrp>policy# info
_____
         delta-in-use-limit 50
         priority-event
            port-down 4/1/2
               hold-set 43200
               priority 100 delta
             exit
             port-down 4/1/3
                priority 200 explicit
             exit
             lag-port-down 1
               number-down 3
                   priority 50 explicit
                exit
             exit
             host-unreachable 10.10.24.4
                drop-count 25
             exit
             route-unknown 10.10.0.0/32
               priority 50 delta
               protocol bgp
             exit
         exit
-----
```

7750 SR OS Router Configuration Guide

VRRP IES Service Parameters

VRRP parameters are configured within an IES service with two contexts, owner or nonowner. The status is specified when the VRRP configuration is created. When configured as owner, the virtual router instance owns the backup IP addresses. All other virtual router instances participating in this message domain must have the same **vrid** configured and cannot be configured as owner.

For IPv4, up to 4 virtual routers IDs (vrid) can be configured on an IES service interface. Each virtual router instance can manage up to 16 backup IP addresses. For IPv6, only one virtual router instance can be configured on an IES service interface.

VRRP parameters configured within an IES service must include the following:

- VRID
- Backup IP address(es)

The following example displays a sample configuration of a IES service owner and non-owner VRRP configurations.

```
A:SR2>config>service>ies# info
_____
          interface "tuesday" create
             address 10.10.36.2/24
              sap 7/1/1.2.2 create
              vrrp 19 owner
                 backup 10.10.36.2
                 authentication-type password
                 authentication-key "testabc"
              exit
          exit
          interface "testing" create
              address 10.10.10.16/24
              sap 1/1/55:0 create
              vrrp 12
                 backup 10.10.10.15
                 policy 1
                 authentication-type password
                 authentication-key "testabc"
              exit
          exit
          no shutdown
  . . . . . . . . .
                      A:SR2>config>service>ies#
```

VRRP Router Interface Parameters

VRRP parameters are configured on a router interface with two contexts, owner or non-owner. The status is specified when the VRRP configuration is created. When configured as owner, the virtual router instance owns the backed up IP addresses. All other virtual router instances participating in this message domain must have the same vrid configured and cannot be configured as owner.

For IPv4, up to 4 virtual routers IDs (vrid) can be configured on a router interface. Each virtual router instance can manage up to 16 backup IP addresses. For IPv6, only one virtual router instance can be configured on a router interface.

VRRP parameters configured on a router interface must include the following:

- VRID
- Backup IP address(es)

The following example displays a sample configuration of a router interface owner and nonowner VRRP configurations.

```
A:SR4>config>router# info
#-----
echo "IP Configuration "
#-----
     interface "system"
        address 10.10.0.4/32
      exit
      interface "test1"
        address 10.10.14.1/24
        secondary 10.10.16.1/24
        secondary 10.10.17.1/24
        secondary 10.10.18.1/24
      exit
      interface "test2"
         address 10.10.10.23/24
         vrrp 1 owner
            backup 10.10.10.23
            authentication-type password
            authentication-key "testabc"
         exit
     exit
#-----
A:SR4>config>router#
```

Common Configuration Tasks

This section provides a brief overview of the tasks that must be performed to configure VRRP and provides the CLI commands.

VRRP parameters are defined under a service interface or a router interface context. An IP address must be assigned to each IP interface. Only one IP address can be associated with an IP interface but several secondary IP addresses also be associated.

Owner and non-owner configurations must include the following parameters:

- All participating routers in a VRRP instance must be configured with the same *vrid*.
- All participating *non-owner* routers can specify up to 16 backup IP addresses (IP addresses the master is representing). The *owner* configuration must include at least one backup IP address.
- For IPv6, all participating routers must be configured with the same link-local backup address (the one configured for the owner instance.)

Other owner and non-owner configurations include the following optional commands:

- authentication-type
- authentication-key
- MAC
- message-interval

In addition to the common parameters, the following non-owner commands can be configured:

- master-int-inherit
- priority
- policy
- ping-reply
- preempt
- telnet-reply
- ssh-reply (IPv4 only)
- [no] shutdown

Creating Interface Parameters

If you have multiple subnets configured on an Ethernet interface, you can configure VRRP on each subnet.

The following displays an IP interface configuration example:

```
A:SR1>config>router# info
#-----
echo "IP Configuration "
#-----
     interface "system"
        address 10.10.0.1/32
     exit
     interface "testA"
        address 123.123.123.123/24
     exit
     interface "testB"
        address 10.10.14.1/24
        secondary 10.10.16.1/24
        secondary 10.10.17.1/24
        secondary 10.10.18.1/24
     exit
     router-id 10.10.0.1
#-----
A:SR1>config>router#
```

Configuring VRRP Policy Components

The following displays a VRRP policy configuration example:

```
A:SR1>config>vrrp# info
-----
     policy 1
       delta-in-use-limit 50
       priority-event
          port-down 1/1/2
            hold-set 43200
            priority 100 delta
          exit
          route-unknown 0.0.0.0/0
             protocol isis
          exit
        exit
     exit
-----
         -----
```

A:SR1>config>vrrp#

Configuring Service VRRP Parameters

VRRP parameters can be configured on an interface in aservice to provide virtual default router support which allows traffic to be routed without relying on a single router in case of failure. VRRP can be configured the following ways:

- Non-Owner VRRP Example on page 263
- Owner Service VRRP on page 264

Non-Owner VRRP Example

The following displays a basic non-owner VRRP configuration example:

```
A:SR2>config>service>ies# info

....

interface "testing" create

address 10.10.10.16/24

sap 1/1/55:0 create

vrrp 12

backup 10.10.10.15

policy 1

authentication-type password

authentication-key "testabc"

exit

exit

no shutdown
```

A:SR2>config>service>ies#

Configuring VRRP Policy Components

Owner Service VRRP

The following displays the owner VRRP configuration example:

Configuring Router Interface VRRP Parameters

VRRP parameters can be configured on an interface in an interface to provide virtual default router support which allows traffic to be routed without relying on a single router in case of failure.

VRRP can be configured the following ways:

• Router Interface VRRP Non-Owner on page 265

Router Interface VRRP Non-Owner

The following displays a non-owner interface VRRP configuration example:

```
A:SR2>config># info
#-----
    interface "if-test"
         address 10.20.30.40/24
         secondary 10.10.50.1/24
         secondary 10.10.60.1/24
         secondary 10.10.70.1/24
         vrrp 1
             backup 10.10.50.2
            backup 10.10.60.2
            backup 10.10.70.2
            backup 10.20.30.41
            ping-reply
            telnet-reply
             authentication-type password
            authentication-key "testabc"
         exit
      exit
#-----
A:SR2>config>#
```

Router Interface VRRP Owner

The following displays router interface owner VRRP configuration example:

VRRP Configuration Management Tasks

This section discusses the following VRRP configuration management tasks:

- Modifying a VRRP Policy on page 267
- Deleting a VRRP Policy on page 268
- Modifying Service and Interface VRRP Parameters on page 269
 - → Modifying Non-Owner Parameters on page 269
 - → Modifying Owner Parameters on page 269
 - → Deleting VRRP on an Interface or Service on page 269

Modifying a VRRP Policy

To access a specific VRRP policy, you must specify the policy ID. To display a list of VRRP policies, use the show vrrp policy command.

The following example displays the modified VRRP policy configuration:

```
A:SR2>config>vrrp>policy# info
_____
        delta-in-use-limit 50
        priority-event
           port-down 1/1/2
             hold-set 43200
              priority 100 delta
           exit
           port-down 1/1/3
              priority 200 explicit
           exit
           host-unreachable 10.10.24.4
              drop-count 25
           exit
        exit
                 A:SR2>config>vrrp>policy#
```

Deleting a VRRP Policy

Policies are only applied to non-owner VRRP instances. A VRRP policy cannot be deleted if it is applied to an interface or to an IES service. Each instance in which the policy is applied must be deleted.

The Applied column in the following example displays whether or not the VRRP policies are applied to an entity.

A:SR2# _____ VRRP Policies PolicyCurrentCurrentDeltaAppliedIdPriority & EffectExplicitDelta SumLimit _____
 1
 200 Explicit
 200
 100
 50
 Yes

 15
 254
 None
 None
 1
 No

 32
 100
 None
 None
 1
 No

A:SR2#

Modifying Service and Interface VRRP Parameters

Modifying Non-Owner Parameters

Once a VRRP instance is created as non-owner, it cannot be modified to the owner state. The vrid must be deleted and then recreated with the owner keyword to invoke IP address ownership.

Modifying Owner Parameters

Once a VRRP instance is created as owner, it cannot be modified to the non-owner state. The vrid must be deleted and then recreated *without* the owner keyword to remove IP address ownership.

Entering the owner keyword is optional when entering the vrid for modification purposes.

Deleting VRRP on an Interface or Service

The *vrid* does not need to be shutdown to remove the virtual router instance from an interface or service.

```
Example: config>router#interface
    config>router# interface if-test
    config>router>if# shutdown
    config>router>if# exit
    config>router# no interface if-test
    config>router#
```

The following example displays the command usage to delete a VRRP instance from an interface or IES service:

```
Example: config>service#ies 10
    config>service>ies# interface "test"
    config>service>ies>if# vrrp 1
    config>service>ies>if>vrrp# shutdown
    config>service>ies>if>vrrp# exit
    config>service>ies>if# no vrrp 1
    config>service>ies>if# no vrrp 1
```

7750 SR OS Router Configuration Guide

VRRP Configuration Management Tasks

VRRP Command Reference

Command Hierarchies

Configuration Commands

- VRRP Network Interface Commands on page 271
- Router Interface IPv6 Commands on page 272
- Router Interface IPv6 VRRP Commands on page 273
- VRRP Priority Control Event Policy Commands on page 274
- Show Commands on page 275
- Clear Commands on page 275

VRRP Network Interface Commands

config

— router

- [**no**] **interface** *interface-name*
 - address {ip-address/mask | ip-address netmask} [broadcast all-ones | host-ones]
 - no address
 - [no] allow-directed-broadcasts
 - arp-timeout seconds
 - no arp-timeout
 - **description** *description-string*
 - no description
 - secondary {ip-address/mask | ip-address netmask} [broadcast all-ones | hostones] [igp-inhibit]
 - no secondary {ip-address/mask | ip-address netmask}
 - [no] shutdown
 - **static-arp** *ip-address ieee-address*
 - [no] static-arp ip-address
 - tos-marking-state {trusted | untrusted}
 - no tos-marking-state
 - **unnumbered** [*ip-int-name* | *ip-address*]
 - no unnumbered
 - vrrp virtual-router-id [owner] *
 - **no vrrp** virtual-router-id
 - **authentication-key** [authentication-key | hash-key] [hash | hash2]
 - no authentication-key
 - [no] backup ip-address
 - [no] bfd-enable [service-id] interface interface-name dst-ip ip-address
 - init-delay seconds
 - no <mark>init-de</mark>lay
 - mac mac-address
 - no mac
 - [no] master-int-inherit
 - message-interval {[seconds] [milliseconds milliseconds]}

- no message-interval
 [no] ping-reply
 policy policy-id
 no policy
 [no] preempt
 priority priority
- no priority
- [no] ssh-reply
- [no] standby-forwarding
- [no] telnet-reply
- [no] shutdown
- [no] traceroute-reply

* Note that VRRP commands are applicable to router interfaces, IES interfaces and VPRN. The **authentication-key**, **authentication-type**, **bfd-enable**, and **ssh-reply** commands are applicable only to IPv4 contexts, not IPv6.

Router Interface IPv6 Commands

config

— router [router-name]

— [no] interface ip-int-name

— [no] ipv6

- address ipv6-address/prefix-length [eui-64]
- **no address** *ipv6-address/prefix-length*
- icmp6
 - packet-too-big [number seconds]
 - no packet-too-big
 - param-problem [number seconds]
 - no param-problem
 - redirects [number seconds]
 - no redirects
 - time-exceeded[number seconds]
 - no time-exceeded
 - unreachables [number seconds]
 - no unreachables
- link-local-address ipv6-address [preferred]
- no link-local-address
- [no] local-proxy-nd
- **neighbor** *ipv6-address* [*mac-address*]
- **no neighbor** *ipv6-address*
- proxy-nd-policy policy-name [policy-name...(up to 5 max)]
- no proxy-nd-policy

Router Interface IPv6 VRRP Commands

config

— **router** [router-name]

— [no] interface ip-int-name

— [no] ipv6

- vrrp virtual-router-id [owner]
 no vrrp virtual-router-id
 - [**no**] **backup** *ipv6-address*
 - init-delay seconds
 - no init-delay
 - mac mac-address
 - no mac
 - [no] master-int-inherit
 - message-interval {[seconds] [milliseconds milliseconds]}
 - no message-interval
 - [no] ping-reply
 - **policy** *vrrp-policy-id*
 - no policy
 - [no] preempt
 - **priority** priority
 - no priority
 - [no] shutdown [no] standby-forwarding
 - [no] telnet-reply
 - [no] traceroute-reply


VRRP Priority Control Event Policy Commands

config

— vrrp


- [no] policy policy-id [context service-id]
 - delta-in-use-limit limit
 - no delta-in-use-limit
 - **description** description string
 - no description
 - [no] priority-event
 - [no] host-unreachable ip-address
 - drop-count consecutive-failures
 - no drop-count
 - hold-clear seconds
 - no hold-clear
 - hold-set seconds
 - no hold-set
 - interval seconds
 - no interval
 - priority priority-level [{delta | explicit}]
 - no priority
 - timeout seconds
 - no timeout
 - [no] lag-port-down lag-id
 - hold-clear seconds
 - no hold-clear
 - **hold-set** seconds
 - no hold-set
 - [no] number-down number-of-lag-ports-down
 - priority priority-level [delta | explicit]
 - no priority
 - [no] port-down port-id
 - hold-clear seconds
 - no hold-clear
 - hold-set seconds
 - no hold-set
 - priority priority-level [delta | explicit]
 - no priority
 - [no] route-unknown ip-prefix/mask
 - hold-clear seconds
 - no hold-clear
 - hold-set seconds
 - no hold-set
 - less-specific [allow-default]
 - no less-specific
 - [no] next-hop ip-address
 - priority priority-level [delta | explicit]
 - no priority
 - protocol protocol
 - no protocol[protocol]
 - [no] protocol bgp
 - [no] protocol bgp -vpn
 - [no] protocol ospf
 - [no] protocol isis
 - [no] protocol rip
 - [no] protocol static

Show Commands





Clear Commands



Debug Commands

debug — router

— vrrp

— events

- events interface *ip-int-name* [vrid virtual-router-id]
- events interface *ip-int-name* vrid *virtual-router-id* ipv6
- no events
- **no events interface** *ip-int-name* [**vrid** *virtual-router-id*]
- no events interface *ip-int-name* vrid *virtual-router-id* ipv6
- packets
- packets interface ip-int-name [vrid virtual-router-id]
- packets interface *ip-int-name* vrid *virtual-router-id* ipv6
 no packets
- **no packets interface** *ip-int-name* [**vrid** *virtual-router-id*]
- no packets interface ip-int-name vrid virtual-router-id ipv6

Configuration Commands

Interface Configuration Commands

authentication-key

Syntax	authentication-key [authentication-key hash-key] [hash hash2] no authentication-key	
Context	config>router>if>vrrp	
Description	This command sets the simple text authentication key used to generate master VRRP advertisement messages and validates VRRP advertisements.	
	If simple text password authentication is not required, the authenticaton-key command is not required.	
	The command is configurable in both non-owner and owner vrrp nodal contexts.	
is enabled on the virtual router instance. Type 1 uses an eight octet long string that is in transmitted VRRP advertisement messages and is compared against all received VRRP a	The <i>key</i> parameter identifies the simple text password to be used when VRRP Authentication Type 1 is enabled on the virtual router instance. Type 1 uses an eight octet long string that is inserted into all transmitted VRRP advertisement messages and is compared against all received VRRP advertisement messages. The authentication data fields are used to transmit the <i>key</i> .	
	The <i>key</i> string is case sensitive and is left justified in the VRRP advertisement message authentication data fields. The first field contains the first four characters with the first octet (starting with IETF RFC bit position 0) containing the first character. The second field similarly holds the fifth through eighth characters. Any unspecified portion of the authentication data field is padded with a 0 value in the corresponding octet.	
	If the command is re-executed with a different password key defined, the new key is used ediately.	
	The authentication-key command can be executed at anytime.	
	To change the current in-use password key on multiple virtual router instances:	
	1. Identify the current master.	
	2. Shutdown the virtual router instance on all backups.	
	3. Execute the authentication-key command on the master to change the password key.	
	4. Execute the authentication-key command and no shutdown command on each backup.	
	The no form of the command reverts to the default value.	
Default	no authentication-key — The authentication key value is the null string.	
Parameters	<i>authentication-key</i> — The authentication key. Allowed values are any string up to 8 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.	

hash-key — The hash key. The key can be any combination of ASCII characters up to 22 (hash-key1) or 121 (hash-key2) characters in length (encrypted). If spaces are used in the string, enclose the entire string in quotation marks ("").

This is useful when a user must configure the parameter, but for security purposes, the actual unencrypted key value is not provided.

- **hash** Specifies the key is entered in an encrypted form. If the **hash** parameter is not used, the key is assumed to be in a non-encrypted, clear text form. For security, all keys are stored in encrypted form in the configuration file with the **hash** parameter specified.
- hash2 Specifies the key is entered in a more complex encrypted form. If the hash2 parameter is not used, the less encrypted hash form is assumed.

backup

Syntax [no] backup *ip-address* Context config>router>if>vrrp

Description This command associates router IP addresses with the parental IP interface IP addresses.

The **backup** command has two distinct functions when used in an **owner** or a **non-owner** context of the virtual router instance.

Non-owner virtual router instances actually create a routable IP interface address that is operationally dependent on the virtual router instance mode (master or backup). The **backup** command in **owner** virtual router instances does not create a routable IP interface address; it simply defines the existing parental IP interface IP addresses that are advertised by the virtual router instance.

For **owner** virtual router instances, the **backup** command defines the IP addresses that are advertised within VRRP advertisement messages. This communicates the IP addresses that the master is representing to backup virtual routers receiving the messages. Advertising a correct list is important. The specified *ip-addr* must be equal to one of the existing parental IP interface IP addresses (primary or secondary) or the **backup** command will fail.

For non-owner virtual router instances, the **backup** command actually creates an IP interface IP address used for routing IP packets and communicating with the system when the access commands are defined (**ping-reply**, **telnet-reply**, and **ssh-reply**). The specified *ip-addr* must be an IP address that is within one of the parental IP interface local subnets created with the **address** or **secondary** commands. If a local subnet does not exist that includes the specified *ip-addr* or if *ip-addr* is the same IP address as the parental IP interface IP address, the **backup** command will fail.

The new interface IP address created with the **backup** command assumes the mask and parameters of the corresponding parent IP interface IP address. The *ip-addr* is only active when the virtual router instance is operating in the master state. When not operating as master, the virtual router instance acts as if it is operationally down. It will not respond to ARP requests to *ip-addr*, nor will it route packets received with its *vrid* derived source MAC address. A non-master virtual router instance always silently discards packets destined to *ip-addr*. A single virtual router instance may only have a single virtual router IP address from a given parental local subnet. Multiple virtual router instances can define a virtual router IP address from the same local subnet as long as each is a different IP address.

In IPv4, up to sixteen **backup** *ip-addr* commands can be executed within the same virtual router instance. Executing **backup** multiple times with the same *ip-addr* results in no operation performed and no error generated. At least one successful **backup** *ip-addr* command must be executed before the virtual router instance can enter the operational state.

When operating as (non-owner) master, the default functionality associated with *ip-addr* is ARP response to ARP requests to *ip-addr*, routing of packets destined to the virtual router instance source MAC address and silently discarding packets destined to *ip-addr*. Enabling the non-owner-access parameters selectively allows ping, Telnet and SSH connectivity to *ip-addr* when the virtual router instance is operating as master.

The **no** form of the command removes the specified virtual router IP address from the virtual router instance. For non-owner virtual router instances, this causes all routing and local access associated with the *ip-addr* to cease. For **owner** virtual router instances, the **no backup** command only removes *ip-addr* from the list of advertised IP addresses. If the last *ip-addr* is removed from the virtual router instance, the virtual router instance will enter the operationally down state

Special Cases Assigning the Virtual Router ID IP Address — Once the *vrid* is created on the parent IP interface, IP addresses need to be assigned to the virtual router instance. If the *vrid* was created with the keyword **owner**, the virtual router instance IP addresses must have one or more of the parent IP interface defined IP addresses (primary and secondary). For non-owner virtual router instances, the virtual router IP addresses each must be within one of the parental IP interface IP address defined local subnets. For both **owner** and non-owner virtual router instances, the virtual router IP addresses must be explicitly defined using the **backup** *ip-addr* command.

Virtual Router Instance IP Address Assignment Conditions — The RFC does not specify that the assigned IP addresses to the virtual router instance must be in the same subnet as the parent IP interface primary IP address or secondary IP addresses. The only requirement is that all virtual routers participating in the same virtual router instance have the same virtual router IP addresses assigned. To avoid confusion, the assigned virtual router IP addresses must be in a local subnet of one of the parent IP interfaces IP addresses. For **owner** virtual router instances the assigned virtual router IP address must be the same as one of the parental IP interface primary or secondary IP addresses.

The following rules apply when adding, changing, or removing parental and virtual router IP addresses:

Owner Virtual Router IP Address Parental Association — When an IP address is assigned to an **owner** virtual router instance, it must be associated with one of the parental IP interface-assigned IP addresses. The virtual router IP address must be equal to the primary or one of the secondary IP addresses within the parental IP interface.

Example - Owner Virtual Router Instance

Parent IP addresses:	10.10.10.10/24 11.11.11.11/24	
Virtual router IP addresses:	10.10.10.11	Invalid (not equal to parent IP address)
	10.10.10.10	Associated (same as parent IP address 10.10.10.10)
	10.10.11.11	Invalid (not equal to parent IP address)

11.11.11.254	Invalid (not equal to parent IP address)
11.11.11.255	Invalid (not equal to parent IP address)

Non-Owner Virtual Router IP Address Parental Association — When an IP address is assigned to a non-owner virtual router instance, it must be associated with one of the parental IP interface assigned IP addresses. The virtual router IP address must be a valid IP address within one of the parental IP interfaces local subnet. Local subnets are created by the primary or secondary IP addresses in conjunction with the IP addresses mask. If the defined virtual router IP address is equal to the associated subnet's broadcast address, it is invalid. Virtual router IP addresses for non-owner virtual router instances that are equal to a parental IP interface IP address are also invalid.

The same virtual router IP address may not be assigned to two separate virtual router instances. If the virtual router IP address already exists on another virtual router instance, the virtual router IP address assignment will fail.

Example - Non-Owner Virtual Router Instance

Parent IP addresses:	10.10.10.10/24 11.11.11.11/24	
Virtual router IP addresses:	10.10.10.11	Associated with 10.10.10.10 (in subnet)
	10.10.10.10	Invalid (same as parent IP address)
	10.10.11.11	Invalid (outside of all Parent IP subnets)
	11.11.11.254	Associated with 11.11.11.11 (in subnet)
	11.11.11.255	Invalid (broadcast address of 11.11.11.11/ 24)

Virtual Router IP Address Assignment without Parent IP Address — When assigning an IP address to a virtual router instance, an associated IP address (see Owner Virtual Router IP Address Parental Association and Non-Owner Virtual Router IP Address Parental Association) on the parental IP interface must already exist. If an associated IP address on the parental IP interface is not configured, the virtual router IP address assignment fails.

Parent Primary IP Address Changed — When a virtual router IP address is set and the associated parent IP interface IP address is changed, the new parent IP interface IP address is evaluated to ensure it meets the association rules defined in **Owner Virtual Router IP Address Parental Association** or **Non-Owner Virtual Router IP Address Parental Association**. If the association check fails, the parental IP address change is not allowed. If the parental IP address change fails, the previously configured IP address definition remains in effect.

Only the primary parent IP address can be changed. Secondary addresses must be removed before the new IP address can be added. **Parent Primary or Secondary IP Address Removal** explains IP address removal conditions.

Parent Primary or Secondary IP Address Removal — When a virtual router IP address is successfully set, but removing the associated parent IP interface IP address is attempted and fails. All virtual router IP addresses associated with the parental IP interface IP address must be deleted prior

to removing the parental IP address. This includes virtual router IP address associations from multiple virtual router instances on the IP interface.

- **Default** no backup No virtual router IP address is assigned.
- Parameters
 ip-address The virtual router IP address expressed in dotted decimal notation. The IP virtual router IP address must be in the same subnet of the parental IP interface IP address or equal to one of the primary or secondary IP addresses for **owner** virtual router instances.
 - Values 1.0.0.1 223.255.255.254

backup

Syntax	config>router>if>ipv6>vrrp
Description	This command associates router IPv6 addresses with the parental IP interface IP addresses.
	The backup command has two distinct functions when used in an owner or a non-owner context of the virtual router instance.
	Non-owner virtual router instances actually create a routable IP interface address that is operationally dependent on the virtual router instance mode (master or backup). The backup command in owner virtual router instances does not create a routable IP interface address; it simply defines the existing parental IP interface IP addresses that are advertised by the virtual router instance.
	For owner virtual router instances, the backup command defines the IP addresses that are advertised within VRRP advertisement messages. This communicates the IP addresses that the master is representing to backup virtual routers receiving the messages. Advertising a correct list is important. The specified <i>ipv6-addr</i> must be equal to one of the existing parental IP interface IP addresses (link-local or global) or the backup command will fail.
	For non-owner virtual router instances, the backup command actually creates an IP interface IP address used for routing IP packets and communicating with the system when the access commands are defined (ping-reply , telnet-reply , and ssh-reply). The specified <i>ipv6-addr</i> must be an IP address that is within one of the parental IP interface local subnets created with the link-local-address or address commands. If a local subnet does not exist that includes the specified <i>ipv6-addr</i> or if <i>ipv6-addr</i> is the same IP address as the parental IP interface IP address, the backup command will fail.
	The new interface IP address created with the backup command assumes the mask and parameters of the corresponding parent IP interface IP address. The <i>ipv6-addr</i> is only active when the virtual router instance is operating in the master state. For IPv6 VRRP, the parental interface's IP address that is in the same subnet as the backup address must be manually-configured, non EUI-64 and configured to be in the preferred state.
	When not operating as master, the virtual router instance acts as if it is operationally down. It will not respond to ARP requests to <i>ipv6-addr</i> , nor will it route packets received with its <i>vrid</i> derived source MAC address. A non-master virtual router instance always silently discards packets destined to <i>ipv6-addr</i> . A single virtual router instance may only have a single virtual router IP address from a given parental local subnet. Multiple virtual router instances can define a virtual router IP address from the same local subnet as long as each is a different IP address.

Executing **backup** multiple times with the same *ipv6-addr* results in no operation performed and no error generated. At least one successful **backup** *ipv6-addr* command must be executed before the virtual router instance can enter the operational state.

When operating as (non-owner) master, the default functionality associated with *ipv6-addr* is ARP response to ARP requests to *ip-addr*, routing of packets destined to the virtual router instance source MAC address and silently discarding packets destined to *ipv6-addr*. An IPv6 virtual router instance can enter the operational state only if one of the configured backup address is a link-local address and the router advertisement of the interface is configured to use the virtual MAC address. Enabling the non-owner-access parameters selectively allows ping, Telnet and traceroute connectivity to *ipv6-addr* when the virtual router instance is operating as master.

The **no** form of the command removes the specified virtual router IP address from the virtual router instance. For non-owner virtual router instances, this causes all routing and local access associated with the *ipv6-addr* to cease. For **owner** virtual router instances, the **no backup** command only removes *ipv6-addr* from the list of advertised IP addresses. If the last *ipv6-addr* or the link-local address is removed from the virtual router instance, the virtual router instance will enter the operationally down state

Special Cases Assigning the Virtual Router ID Address — Once the *vrid* is created on the parent IP interface, IP addresses need to be assigned to the virtual router instance. If the *vrid* was created with the keyword **owner**, the virtual router instance IP addresses must have one or more of the parent IP interface defined IP addresses. For non-owner virtual router instances, the virtual router IP addresses each must be within one of the parental IP interface IP address defined local subnets. For both **owner** and non-owner virtual router instances, the virtual router IP addresses must be explicitly defined using the **backup** *ipv6-addr* command.

The following rules apply when adding, changing, or removing parental and virtual router IP addresses:

Owner Virtual Router IP Address Parental Association — When an IP address is assigned to an **owner** virtual router instance, it must be associated with one of the parental IP interface-assigned IP addresses.

Example - Owner Virtual Router Instance

Parent IP addresses:	10.10.10.10/24 11.11.11.11/24	
Virtual router IP addresses:	10.10.10.11	Invalid (not equal to parent IP address)
	10.10.10.10	Associated (same as parent IP address 10.10.10.10)
	10.10.11.11	Invalid (not equal to parent IP address)
	11.11.11.254	Invalid (not equal to parent IP address)
	11.11.11.255	Invalid (not equal to parent IP address)

Non-Owner Virtual Router IP Address Parental Association — When an IP address is assigned to a non-owner virtual router instance, it must be associated with one of the parental IP interface assigned IP addresses. The virtual router IP address must be a valid IP address within one of

7750 SR OS Router Configuration Guide

the parental IP interfaces local subnet. Local subnets are created by the link-local or global IP addresses in conjunction with the IP addresses mask. If the defined virtual router IP address is equal to the associated subnet's broadcast address, it is invalid. Virtual router IP addresses for non-owner virtual router instances that are equal to a parental IP interface IP address are also invalid.

The same virtual router IP address may not be assigned to two separate virtual router instances. If the virtual router IP address already exists on another virtual router instance, the virtual router IP address assignment will fail.

One exception to this rule is for the IPv6 link-local address that is configured as a backup address. The same link-local address can be configured in all virtual routers that use the same vrid.

Example - Non-Owner Virtual Router Instance

Parent IP addresses:	10.10.10.10/24 11.11.11.11/24	
Virtual router IPv6 addresses:	10.10.10.11	Associated with 10.10.10.10 (in subnet)
	10.10.10.10	Invalid (same as parent IP address)
	10.10.11.11	Invalid (outside of all Parent IP subnets)
	11.11.11.254	Associated with 11.11.11.11 (in subnet)
	11.11.11.255	Invalid (broadcast address of 11.11.11.11/24)

Virtual Router IP Address Assignment without Parent IP Address — When assigning an IP address to a virtual router instance, an associated IP address (see Owner Virtual Router IP Address Parental Association and Non-Owner Virtual Router IP Address Parental Association) on the parental IP interface must already exist. If an associated IP address on the parental IP interface is not configured, the virtual router IP address assignment fails.

Virtual Router IPv6 Address Assignment — An IPv6 backup address requires that the parental IP address that is in the same subnet as the backup address must be manually configured, non-EUI-64 and configured to be in the preferred state.

Default no backup — No virtual router IP address is assigned.

Parameters*ipv6-address* — The virtual router IP address expressed in dotted decimal notation. The IP virtual
router IP address must be in the same subnet of the parental IP interface IP address or equal to
one of the the parent interface addresses for **owner** virtual router instances.

Values	ipv6-address	x:x:x:x:x:x:x:x (eight 16-bit pieces)
		x:x:x:x:x::d.d.d.d
		x: [0FFFF]H
		d: [0255]D

bfd-enable [no] bfd-enable [service-id] interface interface-name dst-ip ip-address Syntax Context config>router>if>vrrp Description This commands assigns a bi-directional forwarding (BFD) session providing heart-beat mechanism for the given VRRP/SRRP instance. There can be only one BFD session assigned to any given VRRP/SRRP instance, but there can be multiple SRRP/VRRP sessions using the same BFD session. BFD control the state of the associated interface. By enabling BFD on a given protocol interface, the state of the protocol interface is tied to the state of the BFD session between the local node and the remote node. The parameters used for the BFD are set by the BFD command under the IP interface. The specified interface may not be configured with BFD; when it is, the virtual router will then initiate the BFD session. The no form of this command removes BFD from the configuration. Default none Parameters service-id — Specifies the service ID of the interface running BFD. Values service-id: 1-2147483647 svc-name: 64 characters maximum interface interface-name — Specifies the name of the interface running BFD. The specified interface may not yet be configured with BFD. However, when it is, this virtual router will then initiate the BFD session. dst-ip *ip-address* — Specifies the destination address to be used for the BFD session.

init-delay

Syntax	init-delay seconds no init-delay
Context	config>router>if>vrrp config>router>if>ipv6>vrrp
Description	This command configures a VRRP initialization delay timer.
Parameters	seconds — Specifies the initialization delay timer for VRRP, in seconds.
	Values 1 – 65535

mac

Syntax	mac mac-address no mac
Context	config>router>if>vrrp config>router>if>ipv6>vrrp
Description	This command sets an explicit MAC address used by the virtual router instance overriding the VRRP default derived from the VRID.
	Changing the default MAC address is useful when an existing HSRP or other non-VRRP default MAC is in use by the IP hosts using the virtual router IP address. Many hosts do not monitor unessential ARPs and continue to use the cached non-VRRP MAC address after the virtual router becomes master of the host's gateway address.
	The mac command sets the MAC address used in ARP responses when the virtual router instance is master. Routing of IP packets with <i>mac-address</i> as the destination MAC is also enabled. The mac setting must be the same for all virtual routers participating as a virtual router or indeterminate connectivity by the attached IP hosts will result. All VRRP advertisement messages are transmitted with <i>mac-address</i> as the source MAC.
	The command can be configured in both non-owner and owner vrrp nodal contexts.
	The mac command can be executed at any time and takes effect ediately. When the virtual router MAC on a master virtual router instance changes, a gratuitous ARP is ediately sent with a VRRP advertisement message. If the virtual router instance is disabled or operating as backup, the gratuitous ARP and VRRP advertisement message is not sent.
	The no form of the command restores the default VRRP MAC address to the virtual router instance.
Default	no mac — The virtual router instance uses the default VRRP MAC address derived from the VRID.
Parameters	<i>mac-address</i> — The 48-bit MAC address for the virtual router instance in the form <i>aa:bb:cc:dd:ee:ff</i> or <i>aa-bb-cc-dd-ee-ff</i> where <i>aa</i> , <i>bb</i> , <i>cc</i> , <i>dd</i> , <i>ee</i> and <i>ff</i> are hexadecimal numbers. Allowed values are any non-broadcast, non-multicast MAC, and non-IEEE reserved MAC addresses.

master-int-inherit

Syntax	[no] master-int-inherit
Context	config>router>if>vrrp config>router>if>ipv6>vrrp
Description	This command enables the virtual router instance to inherit the master VRRP router's advertisement interval timer which is used by backup routers to calculate the master down timer.

The **master-int-inherit** command is only available in the non-owner nodal context and is used to allow the current virtual router instance master to dictate the master down timer for all backup virtual routers. The **master-int-inherit** command has no effect when the virtual router instance is operating as master.

If **master-int-inherit** is not enabled, the locally configured **message-interval** must match the master's VRRP advertisement message advertisement interval field value or the message is discarded.

The **no** form of the command restores the default operating condition which requires the locally configured **message-interval** to match the received VRRP advertisement message advertisement interval field value.

Default no master-int-inherit — The virtual router instance does not inherit the master VRRP router's advertisement interval timer and uses the locally configured message interval.

message-interval

Syntax	message-interval {[seconds] [milliseconds milliseconds]} no message-interval
Context	config>router>if>vrrp config>router>if>ipv6>vrrp
Description	This command configures the administrative advertisement message timer used by the master virtual router instance to send VRRP advertisement messages and to derive the master down timer as backup.
	For an owner virtual router instance, the administrative advertisement timer directly sets the operational advertisement timer and indirectly sets the master down timer for the virtual router instance.
	Non-owner virtual router instances usage of the message-interval setting is dependent on the state of the virtual router (master or backup) and the state of the master-int-inherit parameter.
	• When a non-owner is operating as master for the virtual router, the configured message-interval is used as the operational advertisement timer similar to an owner virtual router instance. The master-int-inherit command has no effect when operating as master.
	• When a non-owner is in the backup state with master-int-inherit disabled, the configured mes-sage-interval value is used to match the incoming VRRP advertisement message advertisement interval field. If the locally configured message interval does not match the advertisement interval field, the VRRP advertisement is discarded.
	• When a non-owner is in the backup state with master-int-inherit enabled, the configured mes-sage-interval is ignored. The master down timer is indirectly derived from the incoming VRRP advertisement message advertisement interval field value.
	VRRP advertisements messages that are fragmented, contain IP options (IPv4), or contain extension headers (IPv6) require a longer message interval to be configured.
	The in-use value of the message interval is used to derive the master down timer to be used when the virtual router is operating in backup mode based on the following formula:
	(3x (in-use message interval) + skew time)
	The skew time portion is used to slow down virtual routers with relatively low priority values when competing in the master election process.

The command is available in both non-owner and owner vrrp nodal contexts.

By default, a **message-interval** of 1 second is used.

The **no** form of the command reverts to the default value.

- **Default** 1 Advertisement timer set to 1 second
- **Parameters** *seconds* The number of seconds that will transpire before the advertisement timer expires expressed as a decimal integer.

Values	IPv4: 1 — 255
	IPv6: 1 — 40

milliseconds *milliseconds* — Specifies the time interval, in milliseconds, between sending advertisement messages. This parameter is not supported on the 7750 SR-1 or 7450 ESS-1 chassis.

Values	100 — 900
	IPv6: 10 — 990

policy

Syntax	policy policy-id no policy
Context	config>router>if>vrrp config>router>if>ipv6>vrrp
Description	This command adds a VRRP priority control policy association with the virtual router instance.
	To further augment the virtual router instance base priority, VRRP priority control policies can be used to override or adjust the base priority value depending on events or conditions within the chassis.
	The policy can be associated with more than one virtual router instance. The priority events within the policy either override or diminish the base priority set with the priority command dynamically affecting the in-use priority. As priority events clear in the policy, the in-use priority can eventually be restored to the base priority value.
	The policy command is only available in the non-owner vrrp nodal context. The priority of owner virtual router instances is permanently set to 255 and cannot be changed by VRRP priority control policies. For non-owner virtual router instances, if the policy command is not executed, the base priority is used as the in-use priority.
	The no form of the command removes existing VRRP priority control policy associations from the virtual router instance. All associations must be removed prior to deleting the policy from the system.
Default	no policy — No VRRP priority control policy is associated with the virtual router instance.
Parameters	<i>policy-id</i> — The policy ID of the VRRP priority control expressed as a decimal integer. The <i>vrrp-policy-id</i> must already exist for the command to function.
	Values 1 — 9999

preempt

	Syntax	[no] preempt
	Context	config>router>if>vrrp config>router>if>ipv6>vrrp
Description		This command enables the overriding of an existing VRRP master if the virtual router's in-use priority is higher than the current master.
		The priority of the non-owner virtual router instance, the preempt mode allows the best available virtual router to force itself as the master over other available virtual routers.
		When preempt is enabled, the virtual router instance overrides any non-owner master with an in-use message priority value less than the virtual router instance in-use priority value. If preempt is disabled, the virtual router only becomes master if the master down timer expires before a VRRP advertisement message is received from another virtual router.
		Enabling preempt mode improves the effectiveness of the base priority and the VRRP priority control policy mechanisms on the virtual router instance. If the virtual router cannot preempt an existing non-owner master, the affect of the dynamic changing of the in-use priority is diminished.
		The preempt command is only available in the non-owner vrrp nodal context. The owner may not be preempted because the priority of non-owners can never be higher than the owner. The owner always preempts all other virtual routers when it is available.
		Non-owner virtual router instances only preempt when preempt is set and the current master has an in-use message priority value less than the virtual router instances in-use priority.
		A master non-owner virtual router only allows itself to be preempted when the incoming VRRP advertisement message priority field value is one of the following:
		• Greater than the virtual router in-use priority value.
		• Equal to the in-use priority value and the source IP address (primary IP address) is greater than the virtual router instance primary IP address.
		By default, preempt mode is enabled on the virtual router instance.
		The no form of the command disables preempt mode and prevents the non-owner virtual router instance from preempting another, less desirable virtual router.
	Default	preempt — The preempt mode enabled on the virtual router instance where it will preempt a VRRP master with a lower priority.
priority		
	Syntax	priority base-priority no priority

Context config>router>if>vrrp config>router>if>ipv6>vrrp

Description This command configures the base router priority for the virtual router instance used in the master election process.

The priority is the most important parameter set on a non-owner virtual router instance. The priority defines a virtual router's selection order in the master election process. Together, the priority value and the **preempt** mode allow the virtual router with the best priority to become the master virtual router.

The *base-priority* is used to derive the in-use priority of the virtual router instance as modified by any optional VRRP priority control policy. VRRP priority control policies can be used to either override or adjust the base priority value depending on events or conditions within the chassis.

The **priority** command is only available in the non-owner **vrrp** nodal context. The priority of **owner** virtual router instances is permanently set to 255 and cannot be changed.

For non-owner virtual router instances, the default base priority value is 100.

The **no** form of the command reverts to the default value.

Default 100

 Parameters
 base-priority — The base priority used by the virtual router instance expressed as a decimal integer. If no VRRP priority control policy is defined, the base-priority is the in-use priority for the virtual router instance.

Values 1 – 254

ping-reply

Syntax	[no] ping-reply
Context	config>router>if>vrrp config>router>if>ipv6>vrrp
Description	This command enables the non-owner master to reply to ICMP echo requests directed at the vritual router instances IP addresses.
	Non-owner virtual router instances are limited by the VRRP specifications to responding to ARP requests destined to the virtual router IP addresses and routing IP packets not addressed to the virtual router IP addresses. Many network administrators find this limitation frustrating when troubleshooting VRRP connectivity issues.
	7750 SR OS allows this access limitation to be selectively lifted for certain applications. Ping, Telnet and SSH can be individually enabled or disabled on a per-virtual-router-instance basis.
	The ping-reply command enables the non-owner master to reply to ICMP echo requests directed at the virtual router instances IP addresses. The Ping request can be received on any routed interface. Ping must not have been disabled at the management security level (either on the parental IP interface or based on the Ping source host address).
	When ping-reply is not enabled, ICMP echo requests to non-owner master virtual IP addresses are silently discarded.
	Non-owner backup virtual routers never respond to ICMP echo requests regardless of the ping-reply setting.
	The ping-reply command is only available in non-owner vrrp nodal context.
	By default, ICMP echo requests to the virtual router instance IP addresses are silently discarded.

The no form of the command configures discarding all ICMP echo request messages destined to the non-owner virtual router instance IP addresses.

Default no ping-reply — ICMP echo requests to the virtual router instance IP addresses are discarded.

shutdown

Syntax	[no] shutdown
Context	config>router>if>vrrp config>router>if>ipv6>vrrp
Description	This command administratively disables an entity. When disabled, an entity does not change, reset, or remove any configuration settings or statistics.
	The operational state of the entity is disabled as well as the operational state of any entities contained within. Many objects must be shut down before they may be deleted.
	The no form of this command administratively enables an entity.
Special Cases	Non-Owner Virtual Router — Non-owner virtual router instances can be administratively shutdown. This allows the termination of VRRP participation in the virtual router and stops all routing and other access capabilities with regards to the virtual router IP addresses. Shutting down the virtual router instance provides a mechanism to maintain the virtual routers without causing false backup/master state changes.
	If the shutdown command is executed, no VRRP advertisement messages are generated and all received VRRP advertisement messages are silently discarded with no processing.
	By default, virtual router instances are created in the no shutdown state.
	Whenever the administrative state of a virtual router instance transitions, a log message is generated.
	Whenever the operational state of a virtual router instance transitions, a log message is generated.
	Owner Virtual Router — An owner virtual router context does not have a shutdown command. To administratively disable an owner virtual router instance, use the shutdown command within the parent IP interface node which administratively downs the IP interface.

ssh-reply

Syntax	[no] ssh-reply
Context	config>router>if>vrrp
Description	This command enables the non-owner master to reply to SSH requests directed at the virtual router instance IP addresses. This command is only applicable to IPv4.
	Non-owner virtual router instances are limited by the VRRP specifications to responding to ARP requests destined to the virtual router IP addresses and routing IP packets not addressed to the virtual

router IP addresses.

This limitation can be disregarded for certain applications. Ping, Telnet and SSH can be individually enabled or disabled on a per-virtual-router-instance basis.

The **ssh-reply** command enables the non-owner master to reply to SSH requests directed at the virtual router instances IP addresses. The SSH request can be received on any routed interface. SSH must not have been disabled at the management security level (either on the parental IP interface or based on the SSH source host address). Proper login and CLI command authentication is still enforced.

When **ssh-reply** is not enabled, SSH requests to non-owner master virtual IP addresses are silently discarded.

Non-owner backup virtual routers never respond to SSH requests regardless of the ssh-reply setting.

The ssh-reply command is only available in non-owner vrrp nodal context.

By default, SSH requests to the virtual router instance IP addresses are silently discarded.

The **no** form of the command discards all SSH request messages destined to the non-owner virtual router instance IP addresses.

Default no ssh-reply — SSH requests to the virtual router instance IP addresses are discarded.

standby-forwarding

Syntax	[no] standby-forwarding	
Context	config>router>if>vrrp config>router>if>ipv6>vrrp	
Description	This command specifies whether this VRRP ins	

Description This command specifies whether this VRRP instance allows forwarding packets to a standby router. When disabled, a standby router should not forward traffic sent to virtual router's MAC address. However, the standby router should forward traffic sent to the standby router's real MAC address. When enabled, a standby router should forward all traffic.

telnet-reply

Syntax	[no] telnet-reply
Context	config>router>if>vrrp config>router>if>ipv6>vrrp
Description	This command enables the non-owner master to reply to TCP port 23 Telnet requests directed at the virtual router instances' IP addresses.
	Non-owner virtual router instances are limited by the VRRP specifications to responding to ARP requests destined to the virtual router IP addresses and routing IP packets not addressed to the virtual router IP addresses. Many network administrators find this limitation frustrating when troubleshooting VRRP connectivity issues.
	This limitation can be disregarded for certain applications. Ping, SSH and Telnet can each be individually enabled or disabled on a per-virtual-router-instance basis.

The **telnet-reply** command enables the non-owner master to reply to Telnet requests directed at the virtual router instances' IP addresses. The Telnet request can be received on any routed interface. Telnet must not have been disabled at the management security level (either on the parental IP interface or based on the Telnet source host address). Proper login and CLI command authentication is still enforced.

When **telnet-reply** is not enabled, Telnet requests to non-owner master virtual IP addresses are silently discarded.

Non-owner backup virtual routers never respond to Telnet requests regardless of the **telnet-reply** setting.

The telnet-reply command is only available in non-owner vrrp nodal context.

By default, Telnet requests to the virtual router instance IP addresses will be silently discarded.

The **no** form of the command configures discarding all Telnet request messages destined to the nonowner virtual router instance IP addresses.

Default no telnet-reply — Telnet requests to the virtual router instance IP addresses are discarded.

traceroute-reply

Syntax	[no] traceroute-reply
Context	config>router>if>vrrp config>router>if>ipv6>vrrp
Description	This command is valid only if the VRRP virtual router instance associated with this entry is a non- owner.
	When this command is enabled, a non-owner master can reply to traceroute requests directed to the virtual router instance IP addresses.
	A non-owner backup virtual router never responds to such traceroute requests regardless of the trace - route-reply status.
Default	no traceroute-reply

vrrp

Syntax	vrrp vrid [owner] no vrrp vrid
Context	config>router>interface <i>ip-int-name</i> config>router>if>ipv6
Description	This command creates the context to configure a VRRP virtual router instance. A virtual router is defined by its virtual router identifier (VRID) and a set of IP addresses.
	The optional owner keyword indicates that the owner controls the IP address of the virtual router and is responsible for forwarding packets sent to this IP address. The owner assumes the role of the master virtual router.

All other virtual router instances participating in this message domain must have the same *vrid* configured and cannot be configured as **owner**. Once created, the **owner** keyword is optional when entering the *vrid* for configuration purposes.

A *vrid* is internally associated with the IP interface. This allows the *vrid* to be used on multiple IP interfaces while representing different virtual router instances.

For IPv4, up to four **vrrp** *vrid* nodes can be configured on a router interface. Each virtual router instance can manage up to 16 backup IP addresses. For IPv6, only one virtual router ID can be configured on a router interface.

The **no** form of the command removes the specified *vrid* from the IP interface. This terminates VRRP participation and deletes all references to the *vrid* in conjunction with the IP interface. The *vrid* does not need to be shutdown to remove the virtual router instance.

Special Cases Virtual Router Instance Owner IP Address Conditions — It is possible for the virtual router instance owner to be created prior to assigning the parent IP interface primary or secondary IP addresses. When this is the case, the virtual router instance is not associated with an IP address. The operational state of the virtual router instance is down.

VRRP Owner Command Exclusions — By specifying the VRRP *vrid* as **owner**, The following commands are no longer available:

- **vrrp priority** The virtual router instance **owner** is hard-coded with a **priority** value of 255 and cannot be changed.
- vrrp master-int-inherit Owner virtual router instances do not accept VRRP advertisement messages; the advertisement interval field is not evaluated and cannot be inherited.
- **ping-reply**, **telnet-reply** and **ssh-reply** The **owner** virtual router instance always allows Ping, Telnet and SSH if the management and security parameters are configured to accept them on the parent IP interface.
- vrrp shutdown The owner virtual router instance cannot be shutdown in the vrrp node. If this was allowed, VRRP messages would not be sent, but the parent IP interface address would continue to respond to ARPs and forward IP packets. Another virtual router instance may detect the missing master due to the termination of VRRP advertisement messages and become master. This would cause two routers responding to ARP requests for the same IP addresses. To shut-down the owner virtual router instance, use the shutdown command in the parent IP interface context. This will prevent VRRP participation, IP ARP reply and IP forwarding. To continue parent IP interface ARP reply and forwarding without VRRP participation, remove the vrrp vrid instance.
- · traceroute-reply

Default no vrrp — No VRRP virtual router instance is associated with the IP interface.

Parameters *vrid* — The virtual router ID for the IP interface expressed as a decimal integer.

Values 1 — 255

owner — Identifies this virtual router instance as owning the virtual router IP addresses. If the owner keyword is not specified at the time of *vrid* creation, the vrrp backup commands must be specified to define the virtual router IP addresses. The owner keyword is not required when entering the *vrid* for editing purposes. Once created as owner, a *vrid* on an IP interface cannot

have the **owner** parameter removed. The *vrid* must be deleted and than recreated without the **owner** keyword to remove ownership.

Priority Policy Commands

delta-in-use-limit

Syntax	delta-in-use-limit in-use-priority-limit no delta-in-use-limit
Context	config>vrrp>policy vrrp-policy-id
Description	This command sets a lower limit on the virtual router in-use priority that can be derived from the delta priority control events.
	Each <i>vrrp-priority-id</i> places limits on the delta priority control events to define the in-use priority of the virtual router instance. Setting this limit prevents the sum of the delta priority events from lowering the in-use priority value of the associated virtual router instances below the configured value.
	The limit has no effect on explicit priority control events. Explicit priority control events are controlled by setting the in-use priority to any value between 1 and 254.
	Only non-owner virtual router instances can be associated with VRRP priority control policies and their priority control events.
	Once the total sum of all delta events is calculated and subtracted from the base priority of the virtual router instance, the result is compared to the delta-in-use-limit value. If the result is less than the limit, the delta-in-use-limit value is used as the virtual router in-use priority value. If an explicit priority control event overrides the delta priority control events, the delta-in-use-limit has no effect.
	Setting the limit to a higher value than the default of 1 limits the effect of the delta priority control events on the virtual router instance base priority value. This allows for multiple priority control events while minimizing the overall effect on the in-use priority.
	Changing the <i>in-use-priority-limit</i> causes an ediate re-evaluation of the in-use priority values for all virtual router instances associated with this <i>vrrp-policy-id</i> based on the current sum of all active delta control policy events.
	The no form of the command reverts to the default value.
Default	1 — The lower limit of 1 for the in-use priority, as modified, by delta priorty control events.
Parameters	<i>in-use-priority-limit</i> — The lower limit of the in-use priority base, as modified by priority control policies. The <i>in-use-priority-limit</i> has the same range as the non-owner virtual router instance base-priority parameter. If the result of the total delta priority control events minus the virtual router instances base-priority, is less than the <i>in-use-priority-limit</i> , the <i>in-use-priority-limit</i> value is used as the virtual router instances in-use priority value.
	Setting the <i>in-use-priority-limit</i> to a value equal to or larger than the virtual router instance <i>base-priority</i> prevents the delta priority control events from having any effect on the virtual router instance in-use priority value.
	Values 1 – 254

Priority Policy Commands

description

Syntax	description string no description
Context	config>vrrp>policy vrrp-policy-id
Description	This command creates a text description stored in the configuration file for a configuration context.
	The description command associates a text string with a configuration context to help identify the content in the configuration file.
	The no form of the command removes the string from the configuration.
Default	none
Parameters	string — The description character string. Allowed values are any string up to 80 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

policy

Syntax	policy policy-id [context service-id] no policy policy-id
Context	config>vrrp
Description	This command creates the context to configure a VRRP priority control policy which is used to control the VRRP in-use priority based on priority control events. It is a parental node for the various VRRP priority control policy commands that define the policy parameters and priority event conditions.
	The virtual router instance priority command defines the initial or base value to be used by non- owner virtual routers. This value can be modified by assigning a VRRP priority control policy to the virtual router instance. The VRRP priority control policy can override or diminish the base priority setting to establish the actual in-use priority of the virtual router instance.
	The policy <i>policy-id</i> command must be created first, before it can be associated with a virtual router instance.
	Because VRRP priority control policies define conditions and events that must be maintained, they can be resource intensive. The number of policies is limited to 1000.
	The <i>policy-id</i> do not have to be consecutive integers. The range of available policy identifiers is from 1 to 9999.
	The no form of the command deletes the specific <i>policy-id</i> from the system. The <i>policy-id</i> must be removed first from all virtual router instances before the no policy command can be issued. If the <i>policy-id</i> is associated with a virtual router instance, the command will fail.
Default	none

 Parameters
 vrrp-policy-id — The VRRP priority control ID expressed as a decimal integer that uniquely identifies this policy from any other VRRP priority control policy defined on the system. Up to 1000 policies can be defined.

Values 1 — 9999

context *service-id* — Specifies the service ID to which this policy applies. A value of zero (0) means that this policy does not apply to a service but applies to the base router instance.

Values 1 — 2147483647

priority-event

Syntax	[no] priority-event
Context	config>vrrp>policy vrrp-priority-id
Description	This command creates the context to configure VRRP priority control events used to define criteria to modify the VRRP in-use priority.
	A priority control event specifies an object to monitor and the effect on the in-use priority level for an associated virtual router instance.
	Up to 32 priority control events can be configured within the priority-event node.
	The no form of the command clears any configured priority events.

Priority Policy Event Commands

hold-clear

Syntax	hold-clear seconds no hold-clear
Context	config>vrrp>policy>priority-event>port-down config>vrrp>policy>priority-event>lag-port-down config>vrrp>policy>priority-event>route-unknown
Description	This command configures the hold clear time for the event. The <i>seconds</i> parameter specifies the hold- clear time, the amount of time in seconds by which the effect of a cleared event on the associated virtual router instance is delayed.
	The hold-clear time is used to prevent black hole conditions when a virtual router instance advertises itself as a master before other conditions associated with the cleared event have had a chance to enter a forwarding state.
Default	no hold-clear
Parameters	<i>seconds</i> — Specifies the amount of time in seconds by which the effect of a cleared event on the associated virtual router instance is delayed.
	Values 0 — 86400

hold-set

Syntax	hold-set seconds no hold-set
Context	config>vrrp>policy>priority-event>host-unreachable config>vrrp>policy>priority-event>lag-port-down config>vrrp>policy>priority-event>port-down config>vrrp>policy>priority-event>route-unknown
Description	This command specifies the amount of time that must pass before the set state for a VRRP priority control event event can transition to the cleared state to dampen flapping events. A flapping event continually transitions between clear and set.
	The hold-set command is used to dampen the effect of a flapping event. The hold-set value is loaded into a hold set timer that prevents a set event from transitioning to the cleared state until it expires.
	Each time an event transitions between cleared and set, the timer is loaded and begins a countdown to zero. When the timer reaches zero, the event is allowed to enter the cleared state. Entering the cleared state is dependent on the object controlling the event, conforming to the requirements defined in the event itself. It is possible, on some event types, to have another set action reload the hold-set timer. This extends the amount of time that must expire before entering the cleared state.

Once the hold set timer expires and the event meets the cleared state requirements or is set to a lower threshold, the current set effect on the virtual router instances in-use priority can be removed. As with **lag-port-down** events, this may be a decrease in the set effect if the *clearing* amounts to a lower set threshold.

The **hold-set** command can be executed at anytime. If the hold-set timer value is configured larger than the new *seconds* setting, the timer is loaded with the new **hold-set** value.

The no form of the command reverts the default value.

Default 0 — The hold-set timer is disabled so event transitions are processed ediately.

Parameters *seconds* — The number of seconds that the hold set timer waits after an event enters a set state or enters a higher threshold set state, depending on the event type.

The value of 0 disables the hold set timer, preventing any delay in processing lower set thresholds or cleared events.

Values 0 — 86400

priority

Syntax	priority <i>priority-level</i> [{delta explicit}] no priority
Context	config>vrrp>policy>priority-event>host-unreachable <i>ip-addr</i> config>vrrp>policy>priority-event>lag-port-down <i>lag-id</i> >number-down <i>number-of-lag-ports- down</i> config>vrrp>policy>priority-event>port-down <i>port-id</i> [. <i>channel-id</i>] config>vrrp>policy>priority-event>route-unknown <i>prefix/mask-length</i>
Description	This command controls the effect the set event has on the virtual router instance in-use priority.
	When the event is set, the <i>priority-level</i> is either subtracted from the base priority of each virtual router instance or it defines the explicit in-use priority value of the virtual router instance depending on whether the delta or explicit keywords are specified.
	Multiple set events in the same policy have interaction constraints:
	• If any set events have an explicit priority value, all the delta priority values are ignored.
	• The set event with the lowest explicit priority value defines the in-use priority that are used by all virtual router instances associated with the policy.
	• If no set events have an explicit priority value, all the set events delta priority values are added and subtracted from the base priority value defined on each virtual router instance associated with the policy.
	• If the delta priorities sum exceeds the delta-in-use-limit parameter, then the delta-in-use-limit parameter is used as the value subtracted from the base priority value defined on each virtual router instance associated with the policy.
	If the priority command is not configured on the priority event, the <i>priority-value</i> defaults to 0 and the qualifier keyword defaults to delta , thus, there is no impact on the in-use priority.
	The no form of the command reverts to the default values.

Default 0 delta — The set event will subtract 0 from the base priority (no effect).

Parameters *priority-level* — The priority level adjustment value expressed as a decimal integer.

Values 0 — 254

delta | explicit — Configures what effect the *priority-level* will have on the base priority value.

When **delta** is specified, the *priority-level* value is subtracted from the associated virtual router instance's base priority when the event is set and no explicit events are set. The sum of the priority event *priority-level* values on all set delta priority events are subtracted from the virtual router base priority to derive the virtual router instance in-use priority value. If the **delta** priority event is cleared, the *priority-level* is no longer used in the in-use priority calculation.

When **explicit** is specified, the *priority-level* value is used to override the base priority of the virtual router instance if the priority event is set and no other **explicit** priority event is set with a lower *priority-level*. The set **explicit** priority value with the lowest *priority-level* determines the actual in-use protocol value for all virtual router instances associated with the policy.

Default delta

Values delta, explicit

Priority Policy Port Down Event Commands

port-down

Syntax [no] port-down port-id

Context config>vrrp>policy>priority-event

Description This command configures a port down priority control event that monitors the operational state of a port or SONET/SDH channel. When the port or channel enters the operational down state, the event is considered set. When the port or channel enters the operational up state, the event is considered cleared.

Multiple unique **port-down** event nodes can be configured within the **priority-event** context up to the overall limit of 32 events. Up to 32 events can be defined in any combination of types.

The **port-down** command can reference an arbitrary port or channel. The port or channel does not need to be pre-provisioned or populated within the system. The operational state of the **port-down** event will indicate:

- Set non-provisioned
- Set not populated
- Set down
- Cleared up

When the port or channel is provisioned, populated, or enters the operationally up or down state, the event operational state is updated appropriately.

When the event enters the operationally down, non-provisioned, or non-populated state, the event is considered to be set. When an event transitions from clear to set, the set is processed ediately and must be reflected in the associated virtual router instances in-use priority value. As the event transitions from cleared to set, a hold set timer is loaded with the value configured by the events **hold-set** command. This timer prevents the event from clearing until it expires, damping the effect of event flapping. If the event clears and becomes set again before the hold set timer expires, the timer is reset to the **hold-set** value, extending the time before another clear can take effect.

When the event enters the operationally up state, the event is considered to be cleared. Once the events **hold-set** expires, the effects of the events **priority** value are ediately removed from the in-use priority of all associated virtual router instances.

The actual effect on the virtual router instance in-use priority value depends on the defined event priority and its delta or explicit nature.

The **no** form of the command deletes the specific port or channel monitoring event. The event may be removed at anytime. When the event is removed, the in-use priority of all associated virtual router instances will be re-evaluated. The events **hold-set** timer has no effect on the removal procedure.

Default no port-down — No port down priority control events are defined.

Parameters *port-id* — The port ID of the port monitored by the VRRP priority control event.

The *port-id* can only be monitored by a single event in this policy. The port can be monitored by multiple VRRP priority control policies. A port and a specific channel on the port are considered to be separate entities. A port and a channel on the port can be monitored by separate events in the same policy.

Values	port-id	slot/mda/port[.channel]		
		aps-id	aps-group-id	[.channel]
			aps	keyword
			group-id	1 — 64
		bundle-type-sl	ot/mda. <bund< th=""><th>le-num></th></bund<>	le-num>
			bundle	keyword
			type	ima, ppp
			bundle-num	1 —256
		ccag-id	ccag-id. path	n-id[cc-type]
			ccag	keyword
			id	1 — 8
			path-id	a, b
			cc-type	.sap-net, .net-sap

The POS channel on the port monitored by the VRRP priority control event. The *port-id.channel-id* can only be monitored by a single event in this policy. The channel can be monitored by multiple VRRP priority control policies. A port and a specific channel on the port are considered to be separate entities. A port and a channel on the port can be monitored by separate events in the same policy.

If the port is provisioned, but the *channel* does not exist or the port has not been populated, the appropriate event operational state is Set – non-populated.

If the port is not provisioned, the event operational state is Set – non-provisioned.

If the POS interface is configured as a clear-channel, the *channel-id* is 1 and the channel bandwidth is the full bandwidth of the port.

Priority Policy LAG Events Commands

lag-port-down

Syntax [no] lag-port-down lag-id

Context config>vrrp>policy>priority-event

Description This command creates the context to configure Link Aggregation Group (LAG) priority control events that monitor the operational state of the links in the LAG.

The **lag-port-down** command configures a priority control event. The event monitors the operational state of each port in the specified LAG. When one or more of the ports enter the operational down state, the event is considered to be set. When all the ports enter the operational up state, the event is considered to be clear. As ports enter the operational up state, any previous set threshold that represents more down ports is considered cleared, while the event is considered to be set.

Multiple unique **lag-port-down** event nodes can be configured within the **priority-event** node up to the maximum of 32 events.

The **lag-port-down** command can reference an arbitrary LAG. The *lag-id* does have to already exist within the system. The operational state of the **lag-port-down** event will indicate:

- Set non-existent
- Set one port down
- Set two ports down
- Set three ports down
- Set four ports down
- Set five ports down
- Set six ports down
- Set seven ports down
- Set eight ports down
- Cleared all ports up

When the *lag-id* is created, or a port in *lag-id* becomes operationally up or down, the event operational state must be updated appropriately.

When one or more of the LAG composite ports enters the operationally down state or the *lag-id* is deleted or does not exist, the event is considered to be set. When an event transitions from clear to set, the set is processed ediately and must be reflected in the associated virtual router instances in-use priority value. As the event transitions from clear to set, a hold set timer is loaded with the value configured by the events **hold-set** command. This timer prevents the event from clearing until it expires, damping the effect of event flapping. If the event clears and becomes set again before the hold set timer expires, the timer is reset to the **hold-set** value, extending the time before another clear can take effect.

	The lag-port-down event is considered to have a tiered event set state. While the priority impact per number of ports down is totally configurable, as more ports go down, the effect on the associated virtual router instances in-use priority is expected to increase (lowering the priority). When each configured threshold is crossed, any higher thresholds are considered further event sets and are processed ediately with the hold set timer reset to the configured value of the hold-set command. As the thresholds are crossed in the opposite direction (fewer ports down then previously), the priority effect of the event is not processed until the hold set timer expires. If the number of ports down threshold again increases before the hold set timer expires, the timer is only reset to the hold-set value if the number of ports down is equal to or greater than the threshold that set the timer.
	The event contains number-down nodes that define the priority delta or explicit value to be used based on the number of LAG composite ports that are in the operationally down state. These nodes represent the event set thresholds. Not all port down thresholds must be configured. As the number of down ports increase, the number-down <i>ports-down</i> node that expresses a value equal to or less than the number of down ports describes the delta or explicit priority value to be applied.
	The no form of the command deletes the specific LAG monitoring event. The event can be removed at anytime. When the event is removed, the in-use priority of all associated virtual router instances must be reevaluated. The events hold-set timer has no effect on the removal procedure.
Default	no lag-port-down — No LAG priority control events are created.
Parameters	<i>lag-id</i> — The LAG ID that the specific event is to monitor expressed as a decimal integer. The <i>lag-id</i> can only be monitored by a single event in this policy. The LAG may be monitored by multiple VRRP priority control policies. A port within the LAG and the LAG ID itself are considered to be separate entities. A composite port may be monitored with the port-down event while the <i>lag-id</i> the port is in is monitored by a lag-port-down event in the same policy.
	Values 1 — 200

number-down

Syntax	[no] number-down number-of-lag-ports-down	
Context	config>vrrp>policy>priority-event>lag-port-down lag-id	
Description	This command creates a context to configure an event set threshold within a lag-port-down priority control event.	
	The number-down command defines a sub-node within the lag-port-down event and is uniquely identified with the <i>number-of-lag-ports-down</i> parameter. Each number-down node within the same lag-port-down event node must have a unique <i>number-of-lag-ports-down</i> value. Each number-down node has its own priority command that takes effect whenever that node represents the current threshold.	
	The total number of sub-nodes (uniquely identified by the <i>number-of-lag-ports-down</i> parameter) allowed in a single lag-port-down event is equal to the total number of possible physical ports allowed in a LAG.	
	A number-down node is not required for each possible number of ports that could be down. The active threshold is always the closest lower threshold. When the number of ports down equals a given threshold, that is the active threshold.	

The **no** form of the command deletes the event set threshold. The threshold may be removed at any time. If the removed threshold is the current active threshold, the event set thresholds must be re-evaluated after removal.

Default no number-down — No threshold for the LAG priority event is created.

 Parameters
 number-of-lag-ports-down — The number of LAG ports down to create a set event threshold. This is the active threshold when the number of down ports in the LAG equals or exceeds number-oflag-ports-down, but does not equal or exceed the next highest configured number-of-lag-portsdown.

Values 1 – 8

Priority Policy Host Unreachable Event Commands

drop-count

Syntax	drop-count consecutive-failures no drop-count		
Context	config>vrrp vrrp-policy-id>priority-event>host-unreachable ip-addr		
Description	This command configures the number of consecutively sent ICMP echo request messages that must fail before the host unreachable priority control event is set.		
	The drop-count command is used to define the number of consecutive message send attempts that must fail for the host-unreachable priority event to enter the set state. Each unsuccessful attempt increments the event's consecutive message drop counter. With each successful attempt, the event's consecutive message drop counter resets to zero.		
	If the event's consecutive message drop counter reaches the drop-count value, the host-unreachable priority event enters the set state.		
	The event's hold-set value defines how long the event must stay in the set state even when a successful message attempt clears the consecutive drop counter. The event is not cleared until the consecutive drop counter is less than the drop-count value and the hold-set timer has a value of zero (expired).		
	The no form of the command reverts to the default value.		
Default	3 - 3 consecutive ICMP echo request failures are required before the host unreachable priority control event is set.		
Parameters	<i>consecutive-failures</i> — The number of ICMP echo request message attempts that must fail for the event to enter the set state. It also defines the threshold so a lower consecutive number of failures can clear the event state.		
	Values 1 — 60		

host-unreachable

Syntax	[no] host-unreachable ip-address	
Context	config>vrrp>policy>priority-event	
Description	This command creates the context to configure a host unreachable priority control event to monitor the ability to receive ICMP echo reply packets from an IP host address.	
	A host unreachable priority event creates a continuous ICMP echo request (ping) probe to the specified <i>ip-address</i> . If a ping fails, the event is considered to be set. If a ping is successful, the event is considered to be cleared.	
	Multiple unique (different <i>ip-address</i>) host-unreachable event nodes can be configured within the priority-event node to a maximum of 32 events.	

The **host-unreachable** command can reference any valid local or remote IP address. The ability to ARP a local IP address or find a remote IP address within a route prefix in the route table is considered part of the monitoring procedure. The **host-unreachable** priority event operational state tracks ARP or route table entries dynamically appearing and disappearing from the system. The operational state of the **host-unreachable** event can be one of the following:

Host Unreachable Operational State	Description
Set – no ARP	No ARP address found for <i>ip-addr</i> for drop-count consecutive attempts. Only applies when IP address is considered local.
Set – no route	No route exists for <i>ip-addr</i> for drop-count consecutive attempts. Only when IP address is considered remote.
Set – host unreachable	ICMP host unreachable message received for drop-count consecutive attempts.
Set – no reply	ICMP echo request timed out for drop-count consecutive attempts.
Set – reply received	Last ICMP echo request attempt received an echo reply but historically not able to clear the event.
Cleared – no ARP	No ARP address found for <i>ip-addr</i> - not enough failed attempts to set the event.
Cleared – no route	No route exists for <i>ip-addr</i> - not enough failed attempts to set the event.
Cleared – host unreachable	ICMP host unreachable message received - not enough failed attempts to set the event.
Cleared – no reply	ICMP echo request timed out - not enough failed attempts to set the event.
Cleared – reply received	Event is cleared - last ICMP echo request received an echo reply.

Unlike other priority event types, the **host-unreachable** priority event monitors a repetitive task. A historical evaluation is performed on the success rate of receiving ICMP echo reply messages. The operational state takes its cleared and set orientation from the historical success rate. The informational portion of the operational state is derived from the last attempt's result. It is possible for the previous attempt to fail while the operational state is still cleared due to an insufficient number of failures to cause it to become set. It is also possible for the state to be set while the previous attempt was successful.

When an event transitions from clear to set, the set is processed ediately and must be reflected in the associated virtual router instances in-use priority value. As the event transitions from clear to set, a hold set timer is loaded with the value configured by the events **hold-set** command. This timer prevents the event from clearing until it expires, damping the effect of event flapping. If the event clears and becomes set again before the hold set timer expires, the timer is reset to the **hold-set** value, extending the time before another clear can take effect.

The hold-set timer be expired and the historical success rate must be met prior to the event operational state becoming cleared.

The **no** form of the command deletes the specific IP host monitoring event. The event may be deleted at anytime. When the event is deleted, the in-use priority of all associated virtual router instances must be reevaluated. The event's **hold-set** timer has no effect on the removal procedure.

Default no host-unreachable — No host unreachable priority events are created.

Parameters*ip-addr* — The IP address of the host for which the specific event will monitor connectivity. The *ip-addr* can only be monitored by a single event in this policy. The IP address can be monitored by multiple VRRP priority control policies. The IP address can be used in one or multiple ping requests. Each VRRP priority control host-unreachable and ping destined to the same *ip-addr* is uniquely identified on a per message basis. Each session originates a unique identifier value for the ICMP echo request messages it generates. This allows received ICMP echo reply messages to be directed to the appropriate sending application.

Values	ipv4-address :	a.b.c.d
	ipv6-address :	x:x:x:x:x:x:x:[-interface]
		x: [0FFFF]H
		interface: 32 chars maximum, mandatory for link local addresses

Note that the link-local IPv6 address must have an interface name specified. The global IPv6 address must not have an interface name specified.

interval

Syntax	interval seconds no interval	
Context	config>vrrp vrrp-policy-id>priority-event>host-unreachable ip-addr	
Description	This command configures the number of seconds between host unreachable priority event ICMP echo request messages directed to the host IP address.	
	The no form of the command reverts to the default value.	
Default	1	
Parameters	seconds — The number of seconds between the ICMP echo request messages sent to the host I address for the host unreachable priority event.	
	Values 1 – 60	

timeout

Syntax	timeout seconds no timeout		
Context	config>vrrp vrrp-policy-id>priority-event>host-unreachable ip-addr		
Description	This command defines the time, in seconds, that must pass before considering the far-end IP host unresponsive to an outstanding ICMP echo request message.		
	The timeout value is not directly related to the configured interval parameter. The timeout value may be larger, equal, or smaller, relative to the interval value.		
	If the timeout value is larger than the interval value, multiple ICMP echo request messages may be outstanding. Every ICMP echo request message transmitted to the far end host is tracked individually according to the message identifier and sequence number.		
	With each consecutive attempt to send an ICMP echo request message, the timeout timer is loaded with the timeout value. The timer decrements until:		
	• An internal error occurs preventing message sending (request unsuccessful).		
	• An internal error occurs preventing message reply receiving (request unsuccessful).		
	• A required route table entry does not exist to reach the IP address (request unsuccessful).		
	• A required ARP entry does not exist and ARP request timed out (request unsuccessful).		
	• A valid reply is received (request successful).		
	Note that it is possible for a required ARP request to succeed or timeout after the message timeout timer expires. In this case, the message request is unsuccessful.		
	If an ICMP echo reply message is not received prior to the timeout period for a given ICMP echo request, that request is considered to be dropped and increments the consecutive message drop counter for the priority event.		
	If an ICMP echo reply message with the same sequence number as an outstanding ICMP echo request message is received prior to that message timing out, the request is considered successful. The consecutive message drop counter is cleared and the request message no longer is outstanding.		
	If an ICMP Echo Reply message with a sequence number equal to an ICMP echo request sequence number that had previously timed out is received, that reply is silently discarded while incrementing the priority event reply discard counter.		
	The no form of the command reverts to the default value.		
Default	1		
Parameters	<i>seconds</i> — The number of seconds before an ICMP echo request message is timed out. Once a message is timed out, a reply with the same identifier and sequence number is discarded.		
	Values 1 – 60		

Priority Policy Route Unknown Event Commands

less-specific

Syntax	[no] less-specific [allow-default]
Context	config>vrrp>policy>priority-event>route-unknown prefix/mask-length
Description	This command allows a CIDR shortest match hit on a route prefix that contains the IP route prefix associated with the route unknown priority event.
	The less-specific command modifies the search parameters for the IP route prefix specified in the route-unknown priority event. Specifying less-specific allows a CIDR shortest match hit on a route prefix that contains the IP route prefix.
	The less-specific command eases the RTM lookup criteria when searching for the <i>prefix/mask-length</i> . When the route-unknown priority event sends the prefix to the RTM (as if it was a destination lookup), the result route table prefix (if a result is found) is checked to see if it is an exact match or a less specific match. The less-specific command enables a less specific route table prefix to match the configured prefix. When less-specific is not specified, a less specific route table prefix fails to match the configured prefix. The allow-default optional parameter extends the less-specific match to include the default route (0.0.0.0).
	The no form of the command prevents RTM lookup results that are less specific than the route prefix from matching.
Default	no less-specific — The route unknown priority events requires an exact prefix/mask match.
Parameters	allow-default — When the allow-default parameter is specified with the less-specific command, an RTM return of 0.0.0.0 matches the IP prefix. If less-specific is entered without the allow-default parameter, a return of 0.0.0.0 will not match the IP prefix. To disable allow-default , but continue to allow less-specific match operation, only enter the less-specific command (without the allow-default parameter).

next-hop

Syntax	[no] next-hop ip-address	
Context	config>vrrp>policy>priority-event>route-unknown prefix/mask-length	
Description This command adds an allowed next hop IP address to match the IP route prefix for a ropriority control event.		
	If the next-hop IP address does not match one of the defined <i>ip-address</i> , the match is considered unsuccessful and the route-unknown event transitions to the set state.	
	The next-hop command is optional. If no next-hop <i>ip-address</i> commands are configured, the comparison between the RTM prefix return and the route-unknown IP route prefix are not included in the next hop information.	

When more than one next hop IP addresses are eligible for matching, a **next-hop** command must be executed for each IP address. Defining the same IP address multiple times has no effect after the first instance.

The **no** form of the command removes the *ip-address* from the list of acceptable next hops when looking up the **route-unknown** prefix. If this *ip-address* is the last next hop defined on the **route-unknown** event, the returned next hop information is ignored when testing the match criteria. If the *ip-address* does not exist, the **no next-hop** command returns a warning error, but continues to execute if part of an **exec** script.

Default no next-hop — No next hop IP address for the route unknown priority control event is defined.

Parameters *ip-address* — The IP address for an acceptable next hop IP address for a returned route prefix from the RTM when looking up the **route-unknown** route prefix.

Values ipv4-address : a.b.c.d ipv6-address : x:x:x:x:x:[-interface] x: [0.FFFF]H interface: 32 chars maximum, mandatory for link local addresses

Note that the link-local IPv6 address must have an interface name specified. The global IPv6 address must not have an interface name specified.

protocol

Syntax	protocol {bgp bgp-vpn ospf is-is rip static} no protocol		
Context	config>vrrp>policy>priority-event>route-unknown prefix/mask-length		
Description	This command adds one or more route sources to match the route unknown IP route prefix for a route unknown priority control event.		
	If the route source does not match one of the defined protocols, the match is considered unsuccessful and the route-unknown event transitions to the set state.		
	The protocol command is optional. If the protocol command is not executed, the comparison between the RTM prefix return and the route-unknown IP route prefix will not include the source of the prefix. The protocol command cannot be executed without at least one associated route source parameter. All parameters are reset each time the protocol command is executed and only the explicitly defined protocols are allowed to match.		
	The no form of the command removes protocol route source as a match criteria for returned RTM route prefixes.		
	To remove specific existing route source match criteria, execute the protocol command and include only the specific route source criteria. Any unspecified route source criteria is removed.		
Default	no protocol — No route source for the route unknown priority event is defined.		
Parameters	bgp — This parameter defines BGP as an eligible route source for a returned route prefix from the RTM when looking up the route-unknown route prefix. The bgp parameter is not exclusive from the other available protocol parameters. If protocol is executed without the bgp parameter,		

a returned route prefix with a source of BGP will not be considered a match and will cause the event to enter the set state.

- bgp-vpn This parameter defines bgp-vpn as an eligible route source for a returned route prefix from the RTM when looking up the route-unknown route prefix. The bgp-vpn parameter is not exclusive from the other available protocol parameters. If protocol is executed without the bgp-vpn parameter, a returned route prefix with a source of bgp-vpn will not be considered a match and will cause the event to enter the set state.
- **ospf** This parameter defines OSPF as an eligible route source for a returned route prefix from the RTM when looking up the **route-unknown** route prefix. The **ospf** parameter is not exclusive from the other available **protocol** parameters. If **protocol** is executed without the **ospf** parameter, a returned route prefix with a source of OSPF will not be considered a match and will cause the event to enter the set state.
- is-is This parameter defines IS-IS as an eligible route source for a returned route prefix from the RTM when looking up the **route-unknown** route prefix. The **is-is** parameter is not exclusive from the other available **protocol** parameters. If **protocol** is executed without the **is-is** parameter, a returned route prefix with a source of IS-IS will not be considered a match and will cause the event to enter the set state.
- rip This parameter defines RIP as an eligible route source for a returned route prefix from the RTM when looking up the route-unknown route prefix. The rip parameter is not exclusive from the other available protocol parameters. If protocol is executed without the rip parameter, a returned route prefix with a source of RIP will not be considered a match and will cause the event to enter the set state.
- static This parameter defines a static route as an eligible route source for a returned route prefix from the RTM when looking up the route-unknown route prefix. The static parameter is not exclusive from the other available protocol parameters. If protocol is executed without the static parameter, a returned route prefix with a source of static route will not be considered a match and will cause the event to enter the set state.

route-unknown

D

Syntax	[no] route-unknown prefixImask-length
Context	config>vrrp>policy>priority-event
Description	This command creates a context to configure a route unknown priority control event that monitors the existence of a specific active IP route prefix within the routing table.
	The route-unknown command configures a priority control event that defines a link between the VRRP priority control policy and the Route Table Manager (RTM). The RTM registers the specified route prefix as monitored by the policy. If any change (add, delete, new next hop) occurs relative to the prefix, the policy is notified and takes proper action according to the priority event definition. If the route prefix exists and is active in the routing table according to the conditions defined, the event is in the cleared state. If the route prefix is removed, becomes inactive or fails to meet the event criteria, the event is in the set state.
	The command creates a route-unknown node identified by <i>prefix/mask-length</i> and containing event control commands.

7750 SR OS Router Configuration Guide

Multiple unique (different *prefix/mask-length*) **route-unknown** event nodes can be configured within the **priority-event** node up to the maximum limit of 32 events.

The **route-unknown** command can reference any valid IP address mask-length pair. The IP address and associated mask length define a unique IP router prefix. The dynamic monitoring of the route prefix results in one of the following event operational states:

route-unknown Operational State	Description
Set – non-existent	The route does not exist in the route table.
Set – inactive	The route exists in the route table but is not being used.
Set – wrong next hop	The route exists in the route table but does not meet the next-hop requirements.
Set – wrong protocol	The route exists in the route table but does not meet the protocol requirements.
Set – less specific found	The route exists in the route table but does is not an exact match and does not meet any less-specific requirements.
Set – default best match	The route exists in the route table as the default route but the default route is not allowed for route matching.
Cleared – less specific found	A less specific route exists in the route table and meets all criteria including the less-specific requirements.
Cleared – found	The route exists in the route table manager and meets all criteria.

An existing route prefix in the RTM must be active (used by the IP forwarding engine) to clear the event operational state. It may be less specific (the defined prefix may be contained in a larger prefix according to Classless Inter-Domain Routing (CIDR) techniques) if the event has the **less-specific** statement defined. The less specific route that incorporates the router prefix may be the default route (0.0.0.0) if the **less-specific allow-default** statement is defined. The matching prefix may be required to have a specific next hop IP address if defined by the event **next-hop** command. Finally, the source of the RTM prefix may be required to be one of the dynamic routing protocols or be statically defined if defined by the event **protocol** command. If an RTM prefix is not found that matches all the above criteria (if defined in the event control commands), the event is considered to be set. If a matching prefix is found in the RTM, the event is considered to be cleared.

When an event transitions from clear to set, the set is processed ediately and must be reflected in the associated virtual router instances in-use priority value. As the event transitions from clear to set, a hold set timer is loaded with the value configured by the events **hold-set** command. This timer prevents the event from clearing until it expires, damping the effect of event flapping. If the event clears and becomes set again before the hold set timer expires, the timer is reset to the **hold-set** value, extending the time before another clear can take effect.

The **no** form of the command is used to remove the specific *prefix/mask-length* monitoring event. The event can be removed at anytime. When the event is removed, the in-use priority of all associated

virtual router instances must be reevaluated. The events **hold-set** timer has no effect on the removal procedure.

- **Default** no route-unknown No route unknown priority control events are defined for the priority control event policy.
- **Parameters** *prefix* The IP prefix address to be monitored by the route unknown priority control event in dotted decimal notation.

Values 0.0.0.0 — 255.255.255.255

mask-length — The subnet mask length expressed as a decimal integer associated with the IP *prefix* defining the route prefix to be monitored by the route unknown priority control event.

Values 0 — 32

ip-address — The IP address of the host for which the specific event will monitor connectivity. The *ip-addr* can only be monitored by a single event in this policy. The IP address can be monitored by multiple VRRP priority control policies. The IP address can be used in one or multiple **ping** requests. Each VRRP priority control **host-unreachable** and **ping** destined to the same *ip-addr* is uniquely identified on a per message basis. Each session originates a unique identifier value for the ICMP echo request messages it generates. This allows received ICMP echo reply messages to be directed to the appropriate sending application.

Values	ip-prefix/mask:	ip-prefix mask	a.b.c.d (host bits must be 0) 0 - 32
	ipv6-address/pre	fix:	
		ipv6-address x:	x:x:x:x:x:x:x (eight 16-bit pieces)
		x:x:x:x	:x:x:d.d.d.d
		x:	[0FFFF]H
		prefix-length	1 — 128

Show Commands

instance

Syntax	instance instance [interface interface-name [vrid virtual-router instance interface interface-name vrid virtual-router-	-	
Context	show>vrrp		
Description	ion This command displays information for VRRP instances.		
	If no command line options are specified, summary information for all VRRP instances displays.		
Parameters	interface <i>ip-int-name</i> — Displays detailed information for the VRRP instances on the specified interface including status and statistics.		
	Default Summary information for all VRRP insta	nces.	
	vrid <i>virtual-router-id</i> — Displays detailed information for interface.	he specified VRRP instance on the IP	
	Default All VRIDs for the IP interface.		
	Values 1 — 255		
ipv6 — Specifies the IPv6 instance.			

Output VRRP Instance Output — The following table describes the instance command output fields for VRRP.

Label	Description
Interface name	The name of the IP interface.
VR ID	The virtual router ID for the IP interface
Own Owner	Yes $-$ Specifies that the virtual router instance as owning the virtual router IP addresses.
	NO - Indicates that the virtual router instance is operating as a non-owner.
Adm	Up - Indicates that the administrative state of the VRRP instance is up.
	Down - Indicates that the administrative state of the VRRP instance is down.
Opr	Up – Indicates that the operational state of the VRRP instance is up.
	Down - Indicates that the operational state of the VRRP instance is down.

Label	Description (Continued)
State	When owner, backup defines the IP addresses that are advertised within VRRP advertisement messages.
	When non-owner, backup actually creates an IP interface IP address used for routing IP packets and communicating with the system when the access commands are defined (ping-reply, telnet-reply, and ssh- reply).
Pol Id	The value that uniquely identifies a Priority Control Policy.
Base Priority	The <i>base-priority</i> value used to derive the in-use priority of the virtual router instance as modified by any optional VRRP priority control policy.
InUse Priority	The current in-use priority associated with the VRRP virtual router instance.
Msg Int	The administrative advertisement message timer used by the master virtual router instance to send VRRP advertisement messages and to derive the master down timer as backup.
Inh Int	Yes – When the VRRP instance is a non-owner and is operating as a backup and the master-int-inherit command is enabled, the master down timer is indirectly derived from the value in the advertisement interval field of the VRRP message received from the current master.
	NO - When the VRRP instance is operating as a backup and the master-int-inherit command is <i>not</i> enabled, the configured advertisement interval is matched against the value in the advertisement interval field of the VRRP message received from the current master. If the two values do not match then the VRRP advertisement is discarded.
	If the VRRP instance is operating as a master, this value has no effect.
Backup Addr	The backup virtual router IP address.
BFD	Indicates BFD is enabled.
VRRP State	Specifies whether the VRRP instance is operating in a master or backup state.
Policy ID	The VRRP priority control policy associated with the VRRP virtual router instance.
	A value of 0 indicates that no control policy policy is associated with the virtual router instance.
Preempt Mode	Yes $-$ The preempt mode is enabled on the virtual router instance where it will preempt a VRRP master with a lower priority.
	NO - The preempt mode is disabled and prevents the non-owner virtual router instance from preempting another, less desirable virtual router.

Label	Description (Continued)
Ping Reply	Yes – A non-owner master is enabled to reply to ICMP Echo requests directed to the virtual router instance IP addresses.
	Ping Reply is valid only if the VRRP virtual router instance associated with this entry is a non-owner.
	A non-owner backup virtual router never responds to such ICMP echo requests irrespective if Ping Reply is enabled.
	NO - ICMP echo requests to the virtual router instance IP addresses are discarded.
Telnet Reply	Yes – Non-owner masters can to reply to TCP port 23 Telnet requests directed at the virtual router instances IP addresses.
	NO - Telnet requests to the virtual router instance IP addresses are discarded.
SSH Reply	Yes $-$ Non-owner masters can to reply to SSH requests directed at the virtual router instances IP addresses.
	NO – All SSH request messages destined to the non-owner virtual router instance IP addresses are discarded.
Primary IP of Mas- ter	The IP address of the VRRP master.
Primary IP	The IP address of the VRRP owner.
Up Time	The date and time when the operational state of the event last changed.
Virt MAC Addr	The virtual MAC address used in ARP responses when the VRRP vir- tual router instance is operating as a master.
Auth Type	Specifies the VRRP authentication Type 0 (no authentication), Type 1 (simple password), or Type 2 (MD5) for the virtual router.
Addr List Mismatch	Specifies whether a trap was generated when the IP address list received in the advertisement messages received from the current master did not match the configured IP address list.
	This is an edge triggered notification. A second trap will not be gener- ated for a packet from the same master until this event has been cleared.
Master Priority	The priority of the virtual router instance which is the current master.
Master Since	The date and time when operational state of the virtual router changed to master.
	For a backup virtual router, this value specifies the date and time when it received the first VRRP advertisement message from the virtual router which is the current master.

Sample Output

```
*A:ALA-A# show router vrrp instance
_____
VRRP Instances
_____
Interface Name
                     VR Id Own Adm State Base Pri Msg Int
                     IP Opr Pol Id
                                       InUse Pri Inh Int
_____
                     1 No Up Master
n2
                                        100 1
                                       100
                      IPv4 Up n/a
                                              No
 Backup Addr: 5.1.1.10

        10
        No
        Up
        Master
        100
        1.0

        IPv6
        Up
        n/a
        100
        Yes

n2
 Backup Addr: 5::10
         FE80::10
_____
Instances : 2
_____
*A:ALA-A#
*A:ALA-A# show router vrrp instance interface n2 vrid 1
VRRP Instance 1 for interface "n2"
_____
                           VRRP State : Master
Owner
            : No
Primary IP of Master: 5.1.1.2 (Self)
Primary IP : 5.1.1.2
                           Standby-Forwarding: Disabled
VRRP Backup Addr : 5.1.1.10

        Admin State
        : Up
        Oper State
        : Up

        Up Time
        : 09/23/2004 06:53:45 Virt MAC Addr
        : 00:00:5e:00:01:01

        Auth Type
        : None

Config Mesg Intvl : 1
                           In-Use Mesq Intvl : 1
Master Inherit Intvl: No
Base Priority: 100Policy ID: n/aPing Reply: NoSSH Reply: No
                           In-Use Priority : 100
                           Preempt Mode : Yes
Telnet Reply : No
                           Telnet Reply
SSH Reply
                            Traceroute Reply : No
            : No
            : 0
                            Init Timer Expires: 0.000 sec
Init Delay
Creation State
            : Active
 _____
Master Information
_____
Primary IP of Master: 5.1.1.2 (Self)
Addr List Mismatch : No
                           Master Priority : 100
Master Since : 09/23/2004 06:53:49
_____
Masters Seen (Last 32)
_____
Primary IP of Master Last Seen Addr List Mismatch Msq Count
_____
5.1.1.2
              09/23/2004 06:53:49 No
                                                  0
Statistics
_____
Become Master : 1
Adv Sent : 103
                           Master Changes : 1
            : 103
                           Adv Received : 0
Adv Sent
Pri Zero Pkts Sent : 0
                            Pri Zero Pkts Rcvd: 0
Preempt Events : 0
                            Preempted Events : 0
Mesg Intvl Discards : 0
                            Mesg Intvl Errors : 0
```

7750 SR OS Router Configuration Guide

```
Addr List Discards : 0
                         Addr List Errors : 0
Auth Type Mismatch : 0
                         Auth Failures : 0
                         Invalid Pkt Type : 0
Invalid Auth Type : 0
Total Discards : 0
                         Pkt Length Errors : 0
_____
*A:ALA-A#
*A:ALA-A# show router vrrp instance interface n2 vrid 1 ipv6
_____
VRRP Instance 1 for interface "n2"
_____
No Matching Entries
_____
*A:ALA-A#
*A:ALA-A# show router vrrp instance interface n2 vrid 10 ipv6
_____
VRRP Instance 10 for interface "n2"
_____
                         VRRP State : Master
Owner
           : No
Primary IP of Master: FE80::1 (Self)
       : FE80::1
Primary IP
                         Standby-Forwarding: Disabled
VRRP Backup Addr : 5::10
            : FE80::10

        Admin State
        : Up
        Oper State
        : Up

        Up Time
        : 09/23/2004 06:55:12 Virt MAC Addr
        : 00:00:5e:00:02:0a

Config Mesg Intvl : 1.0
                         In-Use Mesg Intvl : 1.0
Master Inherit Intvl: Yes
Base Priority : 100
                         In-Use Priority : 100
        : n/a
                         Preempt Mode : Yes
Policy ID
Ping Reply
           : No
                          Telnet Reply
                                     : No
                          Traceroute Reply : No
            : 0
Init Delay
                         Init Timer Expires: 0.000 sec
Creation State
           : Active
_____
Master Information
_____
Primary IP of Master: FE80::1 (Self)
Addr List Mismatch : No
                         Master Priority : 100
           : 09/23/2004 06:55:16
Master Since
_____
Masters Seen (Last 32)
_____
Primarv IP of Master
             Last Seen
                          Addr List Mismatch Msg Count
_____
FE80··1
              09/23/2004 06:55:16 No
                                               0
_____
Statistics
_____
Master Transitions : 1
                         Discontinuity Time: 09/09/2004 01:57*
                         Adv Received : 0
Adv Sent
            : 23
Pri Zero Pkts Sent : 0
                         Pri Zero Pkts Rcvd: 0
Preempt Events : 0
                         Preempted Events : 0
Mesg Intvl Discards : 0
                        Mesg Intvl Errors : 0
                         Addr List Errors : 0
Total Discards : 0
```

 Auth Failures
 : 0
 Invalid Pkt Type
 : 0

 IP TTL Errors
 : 0
 Pkt Length Errors
 : 0

 * indicates that the corresponding row element may have been truncated.

policy

Syntax	policy [vrrp-policy-id [event event-type specific-qualifier]]		
Context	show>vrrp	show>vrrp	
Description	This command displays VRRP priority control policy information.		
	If no command line options are specified, a summary of the VRRP priority control event policies dis plays.		
Parameters	vrrp-policy-id —	- Displays information on the specified priority control policy ID.	
	Default	All VRRP policies IDs	
	Values	1 — 9999	
	event <i>event-type</i> — Displays information on the specified VRRP priority control event within the policy ID.		
	Default	All event types and qualifiers	
	Values	port-down port-id lag-port-down lag-id host-unreachable host-ip-addr route-unknown route-prefix/mask	
	specific-qualifie	r — Display information about the specified qualifier.	
	Values	port-id, lag-id, host-ip-addr, route-prefix/mask	

Output VRRP Policy Output — The following table describes the VRRP policy command output fields.

Label	Description
Policy Id	The VRRP priority control policy associated with the VRRP virtual router instance.
	A value of 0 indicates that no control policy policy is associated with the virtual router instance.
Current Priority	& Effects
Current Explicit	When multiple explicitly defined events associated with the priority control policy happen simultaneously, the lowest value of all the cur- rent explicit priorities will be used as the in-use priority for the virtual router.

Label	Description (Continued)
Current Delta Sum	The sum of the priorities of all the delta events when multiple delta events associated with the priority control policy happen simultane- ously. This sum is subtracted from the base priority of the virtual router to give the in-use priority.
Delta Limit	The delta-in-use-limit for a VRRP policy. Once the total sum of all delta events has been calculated and subtracted from the base-priority of the virtual router, the result is compared to the delta-in-use-limit value. If the result is less than this value, the delta-in-use-limit value is used as the virtual router in-use priority value. If an explicit priority control event overrides the delta priority control events, the delta-in-use-limit has no effect.
	If the delta-in-use-limit is 0, the sum of the delta priority control events to reduce the virtual router's in-use-priority to 0 can prevent it from becoming or staying master.
Current Priority	The configured delta-in-use-limit priority for a VRRP priority control policy or the configured delta or explicit priority for a priority control event.
Applied	The number of virtual router instances to which the policy has been applied. The policy cannot be deleted unless this value is 0.
Description	A text string which describes the VRRP policy.
Event Type & ID	A delta priority event is a conditional event defined in a priority con- trol policy that subtracts a given amount from the base priority to give the current in-use priority for the VRRP virtual router instances to which the policy is applied.
	An explicit priority event is a conditional event defined in a priority control policy that explicitly defines the in-use priority for the VRRP virtual router instances to which the policy is applied.
	Explicit events override all delta Events. When multiple explicit events occur simultaneously, the event with the lowest priority value defines the in-use priority.
Event Oper State	The operational state of the event.
Hold Set Remaining	The amount of time that must pass before the set state for a VRRP pri- ority control event can transition to the cleared state to dampen flap- ping events.
Priority & Effect	Delta — The <i>priority-level</i> value is subtracted from the associated virtual router instance's base priority when the event is set and no explicit events are set. The sum of the priority event <i>priority-level</i> values on all set delta priority events are subtracted from the virtual router base priority to derive the virtual router instance in-use priority value. If the delta priority event is cleared, the <i>priority-level</i> is no longer used
	If the delta priority event is cleared, the <i>priority-level</i> is no longer used in the in-use priority calculation.

Label	Description (Continued)
	Explicit — The <i>priority-level</i> value is used to override the base priority of the virtual router instance if the priority event is set and no other explicit priority event is set with a lower <i>priority-level</i> .
	The set explicit priority value with the lowest <i>priority-level</i> determines the actual in-use protocol value for all virtual router instances associated with the policy.
In Use	Specifies whether or not the event is currently affecting the in-use pri- ority of some virtual router.

Sample Output

A:ALA-A# show vrrp policy

VRRP Poli	cies						
Policy	Current	Current	Current	Delta	Appl	ied	
Id	Priority & Effect						
1	None	None	None	1	Yes		
2	None	None	None	1	No		
A:ALA-A#							
A:ALA-A#	show vrrp policy 1						
VRRP Poli	cy 1						
Descripti	on : 10.10.200.2	53 reachabil	lity				
Current P	riority: None	Ap	pplied	: No			
Current E	xplicit: None	Cu	urrent Delta S	Sum : None			
Delta Lim	Delta Limit : 1						
Applied To		VR C	Opr Base	In-use	Master	Is	
Interface	Name	Id	Pri	Pri	Pri	Master	
None							
-	Control Events						
Event Typ	e & ID	Event Op	per State			-	
					ing &Effe		
Host Unreach 10.10.200.252				Expired	d 201 d 101	Del No	
Host Unreach 10.10.200.253		n/a					
		n/a		Expired	d 1 H	Exp No	
A • AT A _ A#							

A:ALA-A#

VRRP Policy Event Output — The following table describes a specific event VRRP policy command output fields.

Label	Description
Description	A text string which describes the VRRP policy.
Policy Id	The VRRP priority control policy associated with the VRRP virtual router instance.
	A value of 0 indicates that no control policy is associated with the virtual router instance.
Current Priority	The base router priority for the virtual router instance used in the mas- ter election process.
Current Explicit	When multiple explicitly defined events associated with the priority control policy happen simultaneously, the lowest value of all the cur- rent explicit priorities will be used as the in-use priority for the virtual router.
Applied	The number of virtual router instances to which the policy has been applied. The policy cannot be deleted unless this value is 0.
Current Delta Sum	The sum of the priorities of all the delta events when multiple delta events associated with the priority control policy happen simultane- ously. This sum is subtracted from the base priority of the virtual router to give the in-use priority.
Delta Limit	The delta-in-use-limit for a VRRP policy. Once the total sum of all delta events has been calculated and subtracted from the base-priority of the virtual router, the result is compared to the delta-in-use-limit value. If the result is less than this value, the delta-in-use-limit value is used as the virtual router in-use priority value. If an explicit priority control event overrides the delta priority control events, the delta-in-use-limit has no effect.
	If the delta-in-use-limit is 0, the sum of the delta priority control events to reduce the virtual router's in-use-priority to 0 can prevent it from becoming or staying master.
Applied to Inter- face Name	The interface name where the VRRP policy is applied.
VR ID	The virtual router ID for the IP interface.
Opr	Up – Indicates that the operational state of the VRRP instance is up.
	Down - Indicates that the operational state of the VRRP instance is down.
Base Pri	The base priority used by the virtual router instance.
InUse Priority	The current in-use priority associated with the VRRP virtual router instance.

Label	Description (Continued)
Master Priority	The priority of the virtual router instance which is the current master.
Priority	The base priority used by the virtual router instance.
Priority Effect	Delta – A delta priority event is a conditional event defined in a priority control policy that subtracts a given amount from the base priority to give the current in-use priority for the VRRP virtual router instances to which the policy is applied.
	Explicit – A conditional event defined in a priority control pol- icy that explicitly defines the in-use priority for the VRRP virtual router instances to which the policy is applied.
	Explicit events override all delta events. When multiple explicit events occur simultaneously, the event with the lowest priority value defines the in-use priority.
Current Priority	The configured delta-in-use-limit priority for a VRRP priority control policy or the configured delta or explicit priority for a priority control event.
Event Oper State	The operational state of the event.
Hold Set Remaining	The amount of time that must pass before the set state for a VRRP pri- ority control event can transition to the cleared state to dampen flap- ping events.
Priority	The base priority used by the virtual router instance.
Priority Effect	Delta — The <i>priority-level</i> value is subtracted from the associated virtual router instance's base priority when the event is set and no explicit events are set. The sum of the priority event <i>priority-level</i> values on all set delta priority events are subtracted from the virtual router base priority to derive the virtual router instance in-use priority value.
	If the delta priority event is cleared, the <i>priority-level</i> is no longer used in the in-use priority calculation.
	Explicit — The <i>priority-level</i> value is used to override the base priority of the virtual router instance if the priority event is set and no other explicit priority event is set with a lower <i>priority-level</i> .
	The set explicit priority value with the lowest <i>priority-level</i> determines the actual in-use protocol value for all virtual router instances associated with the policy.
Hold Set Config	The configured number of seconds that the hold set timer waits after an event enters a set state or enters a higher threshold set state, depending on the event type.
Value In Use	Yes $-$ The event is currently affecting the in-use priority of some virtual router.

Label	Description (Continued)	
	NO - The event is not affecting the in-use priority of some virtual router.	
# trans to Set	The number of times the event has transitioned to one of the 'set' states.	
Last Transition	The time and date when the operational state of the event last changed.	

Sample Output

A:ALA-A#show vrrp policy 1 event port-down _____ VRRP Policy 1, Event Port Down 1/1/1 _____ : Description Current Priority: None Applied : Yes Current Explicit: None Current Delta Sum : None Delta Limit : 1 _____ VR Opr Applied To Base In-use Master Is Pri Pri Pri Interface Name Id Master _____ 1 Down 100 100 0 ies301backup No _____ Priority Control Event Port Down 1/1/1 _____ Priority : 30 Priority Effect : Delta Hold Set Config : 0 sec Hold Set Remaining: Expired Value In Use : No Current State : Cleared # trans to Set : 6 : Set-down Previous State Last Transition : 04/13/2007 04:54:35 _____ A:ALA-A# A:ALA-A# show vrrp policy 1 event host-unreachable _____ VRRP Policy 1, Event Host Unreachable 10.10.200.252 Description : 10.10.200.253 reachability Applied Current Priority: None : No Current Explicit: None Current Delta Sum : None Delta Limit : 1 _____ VR Opr Base In-use Master Is Id Pri Pri Pri Mas Applied To Id Interface Name Pri Pri Pri Master _____ None _____ Priority Control Event Host Unreachable 10.10.200.252 _____ Priority : 20 Interval : 1 sec Drop Count : 3 Priority Effect : Delta Timeout : 1 sec Hold Set Config : 0 sec Hold Set Remaining: Expired

7750 SR OS Router Configuration Guide

Page 325

```
Value In Use : No Current State : n/a
# trans to Set : 0
                     Previous State : n/a
Last Transition : 04/13/2007 23:10:24
_____
A:ALA-A#
A:ALA-A# show vrrp policy 1 event route-unknown
VRRP Policy 1, Event Route Unknown 10.10.100.0/24
_____
Description : 10.10.200.253 reachability
Current Priority: None Applied
                               : No
Current Explicit: None
                     Current Delta Sum : None
Delta Limit
        : 1
_____
            VR Opr Base In-use Master Is
Applied To
                         Pri Pri Pri Master
Interface Name
                 Id
_____
None
_____
Priority Control Event Route Unknown 10.10.100.0/24
_____
                    Priority Effect : Explicit
Priority : 1
Less Specific : No
                    Default Allowed : No
Next Hop(s) : None
Protocol(s) : None
Hold Set Config : 0 secHold Set Remaining: ExpiredValue In Use : NoCurrent State : n/a# torrer to Cat0
                     Previous State : n/a
# trans to Set : 0
Last Transition : 04/13/2007 23:10:24
_____
A:ALA-A#
```

statistics

Syntax	statistics
Context	show>router>vrrp
Description	This command displays statistics for VRRP instance.
Output	VRRP Statistics Output — The following table describes the VRRP statistics output fields.

Table 6: Show VRRP Statistics Output

Label	Description	
VR Id Errors	Displays the number of virtual router ID errors.	
Version Errors	Displays the number of version errors.	
Checksum Errors	Displays the number of checksum errors.	

7750 SR OS Router Configuration Guide

Sample Output

A:ALA-48# show router vrrp statistics			
VRRP Global Statistics			
VR Id Errors	: 0 V	Version Errors : 0	
Checksum Errors	: 0		
A:ALA-48#			

Monitor Commands

instance

Syntax	instance interface interface-name vr-id virtual-router-id [ipv6] [interval seconds] [repeat repeat] [absolute rate]		
Context	monitor>router>vrrp		
Description	Monitor statistics for a VRRP instance.		
Parameters	interface-name — The name of the existing IP interface on which VRRP is configured.		
	vr-id <i>virtual-router-id</i> — The virtual router ID for the existing IP interface, expressed as a decimal integer.		
	interval seconds — Configures the interval for each display in seconds.		
	Default 5 seconds		
	Values	3 — 60	
	repeat <i>repeat</i> — Configures how many times the command is repeated.		
	Default	10	
	Values	1 — 999	

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

ipv6 — Specifies to monitor IPv6 instances.

Sample Output

*A:ALA-A# monitor router vrrp instance interface n2 vr-id 1					
Monitor statistics f	Monitor statistics for VRRP Instance 1 on interface "n2"				
At time $t = 0$ sec (E	(Base Statistics)				
Become Master	: 1	Master Changes	: 1		
Adv Sent	: 1439	Adv Received	: 0		
Pri Zero Pkts Sent	: 0	Pri Zero Pkts Rcvd	: 0		
Preempt Events	: 0	Preempted Events	: 0		
Mesg Intvl Discards	s : O	Mesg Intvl Errors	: 0		
Addr List Discards	: 0	Addr List Errors	: 0		
Auth Type Mismatch	: 0	Auth Failures	: 0		
Invalid Auth Type	: 0	Invalid Pkt Type	: 0		
IP TTL Errors	: 0	Pkt Length Errors	: 0		
Total Discards	: 0				

7750 SR OS Router Configuration Guide

*A:ALA-A#

A:ALA-A# monitor router vrrp instance interface n2 vr-id 10 ipv6 _____ Monitor statistics for VRRP Instance 10 on interface "n2" _____ -----At time t = 0 sec (Base Statistics) _____ Discontinuity Time: 09/09/2004 01:57 Master Transitions : 1 Discontinuity Time: 09 Adv Received : 0 Pri Zero Pkts Rcvd: 0 Preempted Events : 0 Mesg Intvl Errors : 0 Addr List Errors : 0 Adv Sent : 1365 Pri Zero Pkts Sent : 0 Preempt Events : 0 Mesq Intvl Discards : 0 Addr List Errors : 0 Invalid Pkt Type : 0 Pkt Length Errors : 0 Total Discards : 0 Auth Failures: 0IP TTL Errors: 0 _____

*A:ALA-A#

Clear Commands

interface

Syntax	interface ip-int-name [vrid virtual-router-id] interface ip-int-name vrid virtual-router-id ipv6		
Context	clear>router>vrrp		
Description	This command resets VRRP protocol instances on an IP interface.		
Parameters	<i>ip-int-name</i> — The IP interface to reset the VRRP protocol instances.		
	vrid <i>vrid</i> — Resets the VRRP protocol instance for the specified VRID on the IP interface.		
	Default All VRIDs on the IP interface.		
	Values 1 – 255		
	in the second		

ipv6 — Clears IPv6 information for the specified interface.

statistics

Syntax	statistics [policy policy-id]		
Context	clear>router>vrrp		
Description	This command enables the context to clear and reset VRRP entities.		
Parameters	policy <i>policy-id</i> — Clears statistics for the specified policy.		
	Values 1 — 9999		

statistics

Syntax	statistics interface interface-name [vrid virtual-router-id] statistics statistics interface interface-name vrid virtual-router-id ipv6	
Context	clear>router>vrrp	
Description	This command clears statistics for VRRP instances on an IP interface or VRRP priority control poli- cies.	
Parameters	interface <i>ip-int-name</i> — Clears the VRRP statistics for all VRRP instances on the specified IP inter- face.	

vrid *virtual-router-id* — Clears the VRRP statistics for the specified VRRP instance on the IP interface.

Default All VRRP instances on the IP interface.

Values 1 — 255

policy [*vrrp-policy-id*] — Clears VRRP statistics for all or the specified VRRP priority control policy.

Default All VRRP policies.

Values 1 — 9999

ipv6 — Clears IPv6 statistics for the specified interface.

VRRP Debug Commands

events

Syntax	events events interface <i>ip-int-name</i> [vrid virtual-router-id] events interface <i>ip-int-name</i> vrid virtual-router-id ipv6 no events no events interface <i>ip-int-name</i> vrid virtual-router-id ipv6 no events interface <i>ip-int-name</i> [vrid virtual-router-id]	
Context	debug>router>vrrp	
Description	This command enables debugging for VRRP events. The no form of the command disables debugging.	
Parameters	<i>ip-int-name</i> — Displays the specified interface name. vrid <i>virtual-router-id</i> — Displays the specified VRID. ipv6 — Debugs the specified IPv6 VRRP interface.	

packets

Syntax	packets interface <i>ip-int-name</i> [vrid virtual-router-id] packets no packets interface <i>ip-int-name</i> [vrid virtual-router-id] [ipv6] no packets	
Context	debug>router>vrrp	
Description	This command enables debugging for VRRP packets.	
	The no form of the command disables debugging.	
Parameters	<i>ip-int-name</i> — Displays the specified interface name.	
	vrid virtual-router-id — Displays the specified VRID.	

Filter Policies

In This Chapter

This chapter provides information about filter policies and management.

Topics in this chapter include:

- Filter Policy Configuration Overview on page 334
 - → Service and Network Port-Based Filtering on page 334
 - \rightarrow Filter Policy Entities on page 335
 - \rightarrow Redirect Policies on page 337
- Creating and Applying Policies on page 340
- Configuration Notes on page 352

Filter Policy Configuration Overview

Filter policies, also referred to as Access Control Lists (ACLs), are templates applied to services or network ports to control network traffic into (ingress) or out of (egress) a service access port (SAP) or networkport based on IP, IPv6, and MAC matching criteria. Filters are applied to services to look at packets entering or leaving a SAP or network interface. Filters can be used on several interfaces. The same filter can be applied to ingress traffic, egress traffic, or both. Ingress filters affect only inbound traffic destined for the routing complex, and egress filters affect only outbound traffic sent from the routing complex.

Configuring an entity with a filter policy is optional. If an entity such as a service or network port is not configured with filter policies, then all traffic is allowed on the ingress and egress interfaces. By default, there are no filters associated with services or interfaces. They must be explicitly created and associated. When you create a new filter, default values are provided although you must specify a unique filter ID value to each new filter policy as well as each new filter entry and associated actions. The filter entries specify the filter matching criteria.

Only one ingress IP or MAC filter policy and one egress IP or MAC filter policy can be applied to a Layer 2 SAP. Only one ingress IP filter policy and one egress IP filter policy can be applied to a Layer 3 SAP or network interface. Only one ingress IPv6 filter policy and one egress IPv6 filter policy can be applied to a Layer 3 SAP or network interface but this can be in combination with an IP filter policy.

Network filter policies control the forwarding and dropping of packets based on IP or MAC match criteria. Note that non-IP packets are not hitting the IP filter policy, so the default action in the filter policy will not apply to these packets.

Service and Network Port-Based Filtering

IP, IPv6, and MAC filter policies specify either a forward or a drop action for packets based on information specified in the match criteria. You can create up to 2047 IPv6 and 2047 MAC filter policies per node although your network can handle up to 65535 policies including policies pushed out globally or to specific nodes. Within each filter policy, you can create up to 16384 entries.

Filter entry matching criteria can be as general or specific as you require, but all conditions in the entry must be met in order for the packet to be considered a match and the specified entry action performed. The process stops when the first complete match is found and executes the action defined in the entry, either to drop or forward packets that match the criteria.

Filter Policy Entities

A filter policy compares the match criteria specified within a filter entry to packets coming through the system, in the order the entries are numbered in the policy. When a packet matches all the parameters specified in the entry, the system takes the specified action to either drop or forward the packet. If a packet does not match the entry parameters, the packet continues through the filter process and is compared to the next filter entry, and so on. If the packet does not match any of the entries, then system executes the default action specified in the filter policy. Each filter policy is assigned a unique filter ID. Each filter policy is defined with:

- Scope
- Default action
- Description
- At least one filter entry

Each filter entry contains:

- Match criteria
- An action

Applying Filter Policies

Filter policies can be associated with the following entities:

Table 7: Applying Filter Policies

IP Filter	MAC Filter	IPv6 Filter
Security CPM filter	N/A	Security CPM filter
CRON TOD-suite	CRON TOD-suite	CRON TOD-suite
Router interface	N/A	Router interface
Egress multicast group	Egress multicast group	Egress multicast group
VLL SAP, spoke SDP	VLL SAP, spoke SDP	VLL SAP, spoke SDP
IES interface SAP, subscriber-interface	N/A	IES interface SAP, subscriber-interface
Ipipe SAP, spoke SDP	N/A	N/A
VPLS mesh/spoke SDP, SAP	VPLS mesh/spoke SDP, SAP	VPLS mesh/spoke SDP, SAP

IP Filter	MAC Filter	IPv6 Filter	
VPRN interface SAP, spoke SDP, subscriber-interface	N/A	VPRN interface SAP	
Epipe SAP, spoke SDP	Epipe SAP, spoke SDP	Epipe SAP, spoke SDP	
Fpipe SAP, spoke SDP	Fpipe SAP, spoke SDP	Fpipe SAP, spoke SDP	
Ipipe SAP, spoke SDP	Ipipe SAP, spoke SDP	Ipipe SAP, spoke SDP	
Pseudowire template	Pseudowire template	Pseudowire template	

Table 7: Applying Filter Policies (Continued)

Filter policies can be applied to specific service types:

- Epipe Both MAC and IP filters are supported on an Epipe SAP and spoke SDPs.
- IES Only IP and IPv6 filters are supported on an IES IP interface and spoke SDPs.
- VPLS Both MAC and IP filters are supported on a VPLS SAP and mesh and spoke SDPs.
- VPRN Only IP filters are supported on VPRN interface SAPS and spoke SDPs.

Filter policies are applied to the following service entities:

- SAP ingress IP and MAC filter policies applied on the SAP ingress define the Service Level Agreement (SLA) enforcement of service packets as they ingress a SAP according to the filter policy match criteria.
- SAP egress Filter policies applied on SAP egress define the Service Level Agreement (SLA) enforcement for service packets as they egress on the SAP according to the filter policy match criteria.
- IES interfaces
- Network ingress IP filter policies are applied to network ingress IP interfaces.
- Network egress IP filter policies are applied to network egress IP interfaces.

Redirect Policies

Redirect policies define one or more cache server destinations and provides a method to determine which destination is used. Redirection policies are used to identify cache servers (or other redirection target destinations) and define health check test methods used to validate the ability for the destination to receive redirected traffic. This destination monitoring greatly diminishes the likelihood of a destination receiving packets it cannot process.

Redirection identifies packets to be redirected and specifies the method to reach the web cache server. Packets are identified by IP filter entries. The redirection action is accomplished and supported with Policy Based Routing. Only IP routed frames can be redirected. Bridged IP packets that match the entry criteria will not be redirected.

Redirection policies can contain multiple destinations. Each destination is assigned an initial or base priority describing its relative importance within the policy. The destination with the highest priority value is selected.

There are no default redirect policies. Each redirect policy must be explicitly configured and specified in an IP filter entry.

To facilitate redirection based on a redirection policy, an IP filter must be created and applied to the appropriate ingress or egress IP interfaces where redirection is required. The entry criteria for the filter entry must specify a redirect policy to enable the appropriate IP packets to be redirected from the normal IP routing next hop. If packets do not meet any of the defined match criteria, then those packets are routed normally through the destination-based routing process.

The redirection policy is referenced within the action context for an IP filter entry, binding the filter entry to the policy and the IP destinations managed by the policy. The policy specifies the destination IP address where the packets matching the filter entry will be redirected. When the policy determines the destination for packets matching the filter, the action on the filter entry is similar to provisioning that destination IP address as an indirect next hop Policy Based Route (PBR) action.

Web Redirection (Captive Portal)

Redirection policies can be configured on 7750 SR devices. Redirection policies were designed for testing purposes. The new redirection policy can now block a customer's request from an intended recipient and force the customer to connect to the service's portal server. 255 unique entries with http-redirect are allowed.

Traffic Flow

The following example provides a brief scenario of a customer connection with web redirection.

- 1. The customer gets an IP address using DHCP (if the customer is trying to set a static IP he will be blocked by the anti-spoofing filter).
- 2. The customer tries to connect to a website.
- 3. The router intercepts the HTTP GET request and blocks it from the network
- 4. The router then sends the customer a HTTP 302 (service temporarily unavailable/moved). The target URL should then include the customer's IP and MAC addresses as part of the portal's URL.
- 5. The customer's web browser will then close the original connection and open a new connection to the web portal.
- 6. The web portal updates the ACL (directly or through SSC) to remove the redirection policy.
- 7. The customer connects to the original site.




Figure 13: Web Redirect Traffic Flow

Starred entries (*) are items the router performs masquerading as the destination, regardless of the destination IP address or type of service.

Information needed by the filter that may be sent to the portal:

- Customer's IP address
- Customer's MAC address
- Original requested URL
- Customer's SAP
- Customer's subscriber identification string

Note that the subscriber identification string is available only when used with subscriber management. Refer to the subscriber management section of the 7750 SR OS Triple Play Guide and the 7750 SR OS Router Configuration Guide.

Since most web sites are accessed using the domain name the router allows either DNS queries or responds to DNS with the portal's IP address.

Creating and Applying Policies

Figure 14 displays the process to create redirect policies and apply them to a service SAP or router interface.




Figure 14: Filter Creation and Implementation Flow

Figure 15 displays the process to create filter policies and apply them to a service or network port.




Figure 15: Creating and Applying Filter Policies

Packet Matching Criteria

Up to 65535 IP and 65535 MAC filter IDs (unique filter policies) can be defined. A maximum of 16384 filter entries can be defined in one filter at the same time. Each filter ID can contain up to 65535 filter entries. A maximum of 16384 filter entries can be defined in 1 filter at the same time. As few or as many match parameters can be specified as required, but all conditions must be met in order for the packet to be considered a match and the specified action performed. The process stops when the first complete match is found and then executes the action defined in the entry, either to drop or forward packets that match the criteria.

IP filter policies match criteria that associate traffic with an ingress or egress SAP. Matching criteria to drop or forward IP traffic include:

• Source IP address and mask

Source IP address and mask values can be entered as search criteria. The IP Version 4 addressing scheme consists of 32 bits expressed in dotted decimal notation (X.X.X.X).

Address ranges are configured by specifying mask values, the 32-bit combination used to describe the address portion which refers to the subnet and which portion refers to the host. The mask length is expressed as an integer (range 1 to 32).

The IP Version 6 (IPv6) addressing scheme consists of 128 bits expressed in compressed representation of IPv6 addresses (RFC 1924, *A Compact Representation of IPv6 Addresses*).

- Destination IP address and mask Destination IP address and mask values can be entered as search criteria.
- Protocol Entering a protocol ID (such as TCP, UDP, etc.) allows the filter to search for the protocol specified in this field.
- Protocol For IPv6: entering a next header allows the filter to match the first next header following the IPv6 header.
- Source port/range Entering the source port number or port range allows the filter to search for matching TCP or UDP port and range values.
- Destination port/range Entering the destination port number or port range allows the filter to search for matching TCP or UDP values.
- DSCP marking Entering a DSCP marking enables the filter to search for the DSCP marking specified in this field. See Table 8, DSCP Name to DSCP Value Table, on page 346.
- ICMP code Entering an ICMP code allows the filter to search for matching ICMP code in the ICMP header.
- ICMP type Entering an ICMP type allows the filter to search for matching ICMP types in the ICMP header.

- Fragmentation IPv4 only: Enable fragmentation matching. A match occurs if packets have either the MF (more fragment) bit set or have the Fragment Offset field of the IP header set to a non-zero value.
- Option value Entering an option value enables the first filter to search for a specific IP option. See Table 9, IP Option Values, on page 348.
- Option present Enabling the option presence allows the filter to search for presence or absence of IP options in the packet. Padding and EOOL are also considered as IP options.
- TCP-ACK/SYN flags Entering a TCP-SYN/TCP-ACK flag allows the filter to search for the TCP flags specified in these fields.

MAC filter policies match criteria that associate traffic with an ingress or egress SAP. Matching criteria to drop or forward MAC traffic include:

• Frame type

Entering the frame type allows the filter to match for a specific type of frame format; for example, Ethernet-II will match for only ethernet-II frames.

• Source MAC address and mask

Entering the source MAC address range allows the filter to search for matching a source MAC address and/or range. Enter the source MAC address and mask in the form of xx:xx:xx:xx:xx or xx-xx-xx-xx; for example, 00:dc:98:1d:00:00.

• Destination MAC address and mask

Entering the destination MAC address range allows the filter to search for matching a destination MAC address and/or range. Enter the destination MAC address and mask in the form of xx:xx:xx:xx:xx:xx or xx-xx-xx-xx-xx; for example, 02:dc:98:1d:00:01.

• Dot1p and mask

Entering an IEEE 802.1p value or range allows the filter to search for matching 802.1p frame. The Dot1p and mask accepts decimal, hex, or binary in the range of 0 to 7.

• Ethertype

Entering an Ethernet type II Ethertype value to be used as a filter match criterion. The Ethernet type field is a two-byte field used to identify the protocol carried by the Ethernet frame. The Ethertype accepts decimal, hex, or binary in the range of 1536 to 65535.

• IEEE 802.2 LLC SSAP

Specifying an Ethernet 802.2 LLC DSAP value allows the filter to match a source access point on the network node designated in the source field of a packet. The SSAP and mask accepts decimal, hex, and binary in the range of 0 to 255.

• IEEE 802.2 LLC DSAP

Specifying an Ethernet 802.2 LLC DSAP value allows the filter to match a destination access point on the network node designated in the destination field of a packet. The DSAP and mask accepts decimal, hex, and binary in the range of 0 to 255.

• IEEE 802.3 LLC SNAP PID

Specifying an Ethernet IEEE 802.3 LLC SNAP PID allows the filter to match the two-byte protocol ID that follows the three-byte OUI field. The DSAP and mask accepts decimal and hex in the range of 0 to 65535.

• IEEE 802.1ag ISID from the I-TAG – allows the filter to match the 24 bits ISID value from the PBB I-TAG. This match criteria is mutually exclusive with all the other match criteria under a particular mac-filter list. The resulting mac-filter can be applied as required on a BVPLS SAP or PW basis just in the egress direction. A new **mac-filter type** attribute is defined to control the use of ISID match criteria and must be set to **isid** to allow

the use of isid match criteria. The ISID tag is identified using the PBB ethertype provisioned under config>port>ethernet>pbb-etype.

DSCP Values

DSCP Name	Decimal DSCP Value	Hexadecimal DSCP Value	Binary DSCP Value
default	0	*	
cp1	1		
cp2	2		
cp3	3		
cp4	4		
cp5	5		
ср6	6		
cp7	7	*	
cs1	8		
cp9	9		
af10	10	*	
af11	11	*	
af12	12	*	
cp13	13		
cp14	14		
cp15	15		
cs2	16	*	
cp17	17		
af21	18	*	
cp19	19		
af22	20	*	
cp21	21		
af23	22	*	
cp23	23		
cs3	24	*	
cp25	25		
af31	26	*	
cp27	27		
af32	28	*	
cp29	29		

Table 8: DSCP Name to DSCP Value Table

DSCP Name	Decimal DSCP Value	Hexadecimal DSCP Value	Binary DSCP Value
af33	30	*	
cp21	31		
cs4	32	*	
cp33	33		
af41	34	*	
cp35	35		
af42	36	*	
cp37	37		
af43	38	*	
cp39	39		
cs5	40	*	
cp41	41		
cp42	42		
cp43	43		
cp44	44		
cp45	45		
ef	46	*	
cp47	47		
nc1	48	*	(cs6)
cp49	49		
cp50	50		
cp51	51		
cp52	52		
cp53	53		
cp54	54		
cp55	55		
cp56	56		
cp57	57		
nc2	58	*	(cs7)
cp60	60		
cp61	61		
cp62	62		

Table 8: DSCP Name to DSCP Value Table (Continued)

7750 SR OS Router Configuration Guide

IP Option Values

Table 9: IP Option Values

Сору	Class	Number	Value	Name	Description
0	0	0	0	EOOL	End of options list
0	0	1	1	NOP	No operation
0	0	7	7	RR	Record route
0	0	10	10	ZSU	Experimental measurement
0	0	11	11	MTUP	MTU probe
0	0	12	12	MTUR	MTU reply
0	0	15	15	ENCODE	
0	2	4	68	TS	Time stamp
0	2	18	82	TR	Traceroute
1	0	2	130	SEC	Security
1	0	3	131	LSR	Loose source router
1	0	5	133	E-SEC	Extended security
1	0	6	134	CIPSO	Commercial security
1	0	8	136	SID	Stream id
1	0	9	137	SSR	Strict source route
1	0	14	142	VISA	Experimental Access Control [Estrin]
1	0	16	144	IMITD	IMI Traffic Descriptor
1	0	17	145	EIP	Extended Internet Protocol
1	0	19	147	ADDEXT	Address Extension
1	0	20	148	RTRALT	Router alert
1	0	21	149	SDB	Selective directed broadcast
1	0	22	150	NSAPA	NSAP addresses
1	0	23	151	DPS	Dynamic packet state
1	0	24	152	UMP	Upstream multicast packet
1	2	13	205	FINN	Experimental flow control

Ordering Filter Entries

When entries are created, they should be arranged sequentially from the most explicit entry to the least explicit. Filter matching ceases when a packet matches an entry. The entry action is performed on the packet. 7750 SR supports either drop or forward action. To be considered a match, the packet must meet all the conditions defined in the entry.

Packets are compared to entries in a filter policy in an ascending entry ID order. To reorder entries in a filter policy, edit the entry ID value; for example, to reposition entry ID 6 to a more explicit location, change the entry ID 6 value to entry ID 2.

When a filter consists of a single entry, the filter executes actions as follows:

- If a packet matches all the entry criteria, the entry's specified action is performed (drop or forward).
- If a packet does not match all of the entry criteria, the policy's default action is performed.

If a filter policy contains two or more entries, packets are compared in ascending entry ID order (1, 2, 3 or 10, 20, 30, etc.):

- Packets are compared with the criteria in the first entry ID.
- If a packet matches all the properties defined in the entry, the entry's specified action is executed.
- If a packet does not completely match, the packet continues to the next entry, and then subsequent entries.
- If a packet does not completely match any subsequent entries, then the default action is performed.

Figure 16 displays an example of several packets forwarded upon matching the filter criteria and several packets traversing through the filter entries and then dropped.




Figure 16: Filtering Process Example

Applying Filters

After filters are created, they can be applied to the following entities:

- Applying a Filter to a SAP on page 351
- Applying a Filter to a Network Port on page 351

Applying a Filter to a SAP

During the SAP creation process, ingress and egress filters are selected from a list of qualifying IP and MAC filters. When ingress filters are applied to a SAP, packets received at the SAP are checked against the matching criteria in the filter entries. If the packet completely matches all criteria in an entry, the checking stops and an entry action is preformed. If permitted, the traffic is forwarded according to the specification of the action. If the packets do not match, the default filter action is applied. If permitted, the traffic is forwarded.

When egress filters are applied to a SAP, packets received at the egress SAP are checked against the matching criteria in the filter entries. If the packet completely matches all criteria in an entry, the checking stops. If permitted, the traffic is transmitted. If denied, the traffic is dropped. If the packets do not match, the default filter action is applied.

Filters can be added or changed to an existing SAP configuration by modifying the SAP parameters. Filter policies are not operational until they are applied to a SAP and the service enabled.

Applying a Filter to a Network Port

An IP filter can be applied to a network port. Packets received on the interface are checked against the matching criteria in the filter entries. If the packet completely matches all criteria in an entry, the checking stops. If permitted, the traffic is forwarded. If the packets do not match, they are discarded or forwarded based on the default action specified in the policy.

Configuration Notes

The following information describes filter implementation caveats:

- Creating a filter policy is optional.
- Associating a service with a filter policy is optional.
- When a filter policy is configured, it should be defined as having either an *exclusive* scope for one-time use, or a *template* scope meaning that the filter can be applied to multiple SAPs.
- A specific filter must be explicitly associated with a specific service in order for packets to be matched.
- Each filter policy must consist of at least one filter entry. Each entry represents a collection of filter match criteria. When packets enter the ingress or egress ports, packets are compared to the criteria specified within the entry or entries.
- When a large (complex) filter is configured, it may take a few seconds to load the filter policy configuration and be instantiated.
- The action keyword must be entered for the entry to be active. Any filter entry without the action keyword will be considered incomplete and be inactive.

MAC Filters

- If a MAC filter policy is created with an entry and entry action specified but the packet matching criteria is not defined, then all packets processed through this filter policy entry will pass and take the action specified. There are no default parameters defined for matching criteria.
- MAC filters cannot be applied to network interfaces, routable VPLS or IES services.
- Some of the MAC match criteria fields are exclusive to each other, based on the type of Ethernet frame. Use the following table to determine the exclusivity of fields.

Frame Format	Etype	LLC – Header (ssap & dsap)	SNAP-OUI	SNAP- PID
Ethernet – II	Yes	No	No	No
802.3	No	Yes	No	No
802.3 – snap	No	No ^a	Yes	Yes

Table 10: MAC Match Criteria Exclusivity Rules

a. When snap header is present, this is always set to AA-AA.

IP Filters

- Define filter entry packet matching criteria If a filter policy is created with an entry and entry action specified but the packet matching criteria is not defined, then all packets processed through this filter policy entry will pass and take the action specified. There are no default parameters defined for matching criteria.
- Action An action parameter must be specified for the entry to be active. Any filter entry without an action parameter specified will be considered incomplete and be inactive.
- When you configure a filter policy which is intended for filter-based mirroring, you must specify that the scope is *exclusive*.

IPv6 Filters

- Define filter entry packet matching criteria If a filter policy is created with an entry and entry action specified but the packet matching criteria is not defined, then all packets processed through this filter policy entry will pass and take the action specified. There are no default parameters defined for matching criteria.
- Action An action parameter must be specified for the entry to be active. Any filter entry without an action parameter specified will be considered incomplete and be inactive.

Log Filter

- Summarization logging is the collection and summarization of log messages for 1 specific log-id within a period of time.
- Filter log can be applied to different filters or CPM hardware filters.
- The implementation of the feature applies to filter logs with destination syslog.
- In case of VPLS scenario both Layer 2 & Layer 3 are applicable.
 - \rightarrow Layer 2: Source MAC or optionally destination MAC
 - \rightarrow Layer 3: Source IPv6 or optionally destination IPv6 for Layer 3 filters.
- The summarization interval is 100 seconds.
- Upon activation of a summary, a mini-table with src/dst-address and count is created for each type (IP/IPv6/MAC).
- Every received log packet (due to filter hit) is examined for source or destination address. If the log packet (source/destination address) matches a source/destination address entry in the mini-table a packet received previously), the summary counter of the matching address is incremented.

Configuration Notes

- If source or destination address of the log messages does not match an entry already present in the table, the source/destination address is stored in a free entry in the mini-table.
- In case the mini-table has no more free entries, only total counter is incremented.
- At expiry of the summarization interval, the mini-table for each type is flushed to the syslog destination.

Configuring Filter Policies with CLI

This section provides information to configure filter policies using the command line interface.

Topics in this section include:


- Basic Configuration on page 356
- Common Configuration Tasks on page 357
 - → Creating an IP Filter Policy on page 357
 - → Creating an IPv6 Filter Policy on page 362
 - → Creating a MAC Filter Policy on page 364
 - → Creating Filter Log Policies on page 368
 - → Applying Filter Policies on page 369
 - → Apply Filter Policies to a Network Port on page 372
 - → Creating a Redirect Policy on page 374
 - → Configuring Policy-Based Forwarding for Deep Packet Inspection in VPLS on page 375
- Filter Management Tasks on page 378
 - → Renumbering Filter Policy Entries on page 378
 - \rightarrow Modifying an IP Filter Policy on page 380
 - \rightarrow Deleting a Filter Policy on page 384
 - \rightarrow Deleting a Filter Policy on page 384
 - \rightarrow Copying Filter Policies on page 391

Basic Configuration

The most basic IP, IPv6 and MAC filter policies must have the following:

- A filter ID
- Template scope, either *exclusive* or *template*
- Default action, either drop or forward
- At least one filter entry
 - \rightarrow Specified action, either drop or forward
 - \rightarrow Specified matching criteria

The following example displays a sample configuration of an IP filter policy. The configuration blocks all incoming TCP session except Telnet and allows all outgoing TCP sessions from IP net 10.67.132.0/24. Figure 17 depicts the interface to apply the filter.



OSRG007

Figure 17: Applying an IP Filter to an Ingress Interface

Common Configuration Tasks

This section provides a brief overview of the tasks that must be performed for both IP and MAC filter configurations and provides the CLI commands.

To configure a filter policy, perform the following tasks:

- Creating an IP Filter Policy on page 357
- Creating an IPv6 Filter Policy on page 362
- Creating a MAC Filter Policy on page 364
- Creating Filter Log Policies on page 368
- Applying Filter Policies on page 369
- Apply Filter Policies to a Network Port on page 372

Creating an IP Filter Policy

Configuring and applying filter policies is optional. Each filter policy must have the following:

- The filter type specified (IP)
- A filter policy ID
- A default action, either drop or forward
- Filter policy scope specified, either *exclusive* or *template*
- At least one filter entry with matching criteria specified

IP Filter Policy

The following displays an exclusive filter policy configuration example:

```
A:ALA-7>config>filter# info

...

ip-filter 12 create

description "IP-filter"

scope exclusive

exit

...

A:ALA-7>config>filter#
```

7750 SR OS Router Configuration Guide

IP Filter Entry

Within a filter policy, configure filter entries which contain criteria against which ingress, egress, or network traffic is matched. The action specified in the entry determine how the packets are handled, either dropped or forwarded.

- Enter a filter entry ID. The system does not dynamically assign a value.
- Assign an action, either drop or forward.
- Specify matching criteria.

Use the following CLI syntax to create an IP filter entry:

```
CLI Syntax: config>filter# ip-filter filter-id [create]
        entry entry-id [time-range time-range-name] [create]
        description description-string
```

The following displays an IP filter entry configuration example.

```
A:ALA-7>config>filter>ip-filter# info

description "filter-main"

scope exclusive

entry 10 create

description "no-91"

match

exit

no action

exit

A:ALA-7>config>filter>ip-filter#
```

Configuring the HTTP-Redirect Option

If http-redirect is specified as an action, a corresponding forward entry must be specified before the redirect. Note that http-redirect is not supported on 7750 SR-1 or 7450 ESS-1 models.

The following displays an http-redirect configuration example:

```
A:ALA-48>config>filter>ip-filter# info
_____
         description "filter-main"
         scope exclusive
          entry 10 create
            description "no-91"
             match
                dst-ip 10.10.10.91/24
                src-ip 10.10.0.100/24
             exit
             no action
          exit
          entry 20 create
             match protocol tcp
                dst-ip 100.0.0.2/32
                dst-port eq 80
             exit
             action forward
          exit
          entry 30 create
             match protocol tcp
                dst-ip 10.10.10.91/24
                dst-port eq 80
             exit
             action http-redirect "http://100.0.0.2/login.cgi?mac=$MAC$sap=$S
AP&ip=$IP&orig_url=$URL"
        exit
-----
A:ALA-48>config>filter>ip-filter#
```

Filter Sampling

Within a filter entry, you can specify that traffic matching the associated IP filter entry is sampled. if the IP interface is set to cflowd ip-filter mode. Enabling filter-sample enables the cflowd tool.

The following displays an IP filter entry configuration example.

```
A:ALA-7>config>filter>ip-filter# info

description "filter-main"

scope exclusive

entry 10 create

description "no-91"

filter-sample

interface-disable-sample

match

exit

action forward redirect-policy redirect1

exit

A:ALA-7>config>filter>ip-filter#
```

IP Entry Matching Criteria

Use the following CLI syntax to configure IP filter matching criteria:

The following displays an IP filter matching configuration.

```
*A:ALA-48>config>filter>ip-filter# info
_____
         description "filter-mail"
        scope exclusive
         entry 10 create
            description "no-91"
            filter-sample
            interface-disable-sample
            match
               dst-ip 10.10.10.91/24
               src-ip 10.10.10.103/24
            exit
            action forward redirect-policy redirect2
         exit
-----
*A:ALA-48>config>filter>ip-filter#
```

Creating an IPv6 Filter Policy

Configuring and applying IPv6 filter policies is optional. Each filter policy must have the following:

- The IPv6 filter type specified
- An IPv6 filter policy ID
- A default action, either drop or forward.
- Template scope specified, either *exclusive* or *template*
- At least one filter entry with matching criteria specified

IPv6 Filter Policy

Use the following CLI syntax to create an IPv6 filter policy:

The following displays an IPv6 filter policy configuration example:

A:ALA-49>config>filter>ipv6-filter# info description "New IPv6 filter info" scope exclusive exit A:ALA-49>config>filter>ipv6-filter# tree detail

IPv6 Filter Entry

Within an IPv6 filter policy, configure filter entries which contain criteria against which ingress, egress, or network traffic is matched. The action specified in the entry determine how the packets are handled, either dropped or forwarded.

- Enter an IPv6 filter entry ID. The system does not dynamically assign a value.
- Assign an action, either drop or forward.
- Specify matching criteria.

The following displays an IPv6 filter entry configuration example.

A:ALA-49>config>filter>ipv6-filter# info description "New IPv6 filter info" scope exclusive entry 1 create match dst-ip 11::12/128 src-ip 13::14/128 exit action drop exit A:ALA-49>config>filter>ipv6-filter#

Creating a MAC Filter Policy

Configuring and applying filter policies is optional. Each filter policy must have the following:

- The filter type specified (MAC).
- A filter policy ID.
- A default action, either drop or forward.
- Filter policy scope, either *exclusive* or *template*.
- At least one filter entry.
- Matching criteria specified.

MAC Filter Policy

The following displays an MAC filter policy configuration example:

```
A:ALA-7>config>filter# info
....
mac-filter 90 create
description "filter-west"
scope exclusive
exit
A:ALA-7>config>filter#
```

Creating an ISID Filter

The following displays an ISID filter configuration example:

```
A;ALA-7>config>filter# info
-----
mac-filter 90 create
   description "filter-wan-man"
   scope template
    entry 1 create
       description "drop-local-isids"
        match
           isid 100 to 1000
       exit
       action drop
    exit
    entry 2 create
       description "allow-wan-isids"
       match
           isid 150
       exit
       action forward
    exit
```

MAC Filter Entry

Within a filter policy, configure filter entries which contain criteria against which ingress, egress, or network traffic is matched. The action specified in the entry determine how the packets are handled, either dropped or forwarded.

- Enter a filter entry ID. The system does not dynamically assign a value.
- Assign an action, either drop or forward.
- Specify matching criteria.

The following displays a MAC filter entry configuration example:

```
A:siml>config>filter# info

mac-filter 90 create

entry 1 create

description "allow-104"

match

exit

action drop

exit

exit

A:siml>config>filter#
```

MAC Entry Matching Criteria

The following displays a filter matching configuration example.

Creating Filter Log Policies

The following displays a filter matching configuration example.

```
A:ALA-48>config>filter>log# info detail
description "Test filter log."
destination memory 1000
wrap-around
no shutdown
A:ALA-48>config>filter>log#
```

Applying Filter Policies

Filter policies can be associated with the following entities:

Table 11: Applying Filter Policies

IP Filter	MAC Filter	IPv6 Filter
Epipe SAP, spoke SDP	Epipe SAP, spoke SDP	N/A
Fpipe SAP, spoke SDP	N/A	N/A
IES interface SAP	N/A	IES interface SAP
Ipipe SAP, spoke SDP	N/A	N/A
VPLS mesh SDP, spoke SDP, SAP	VPLS mesh SDP, spoke SDP, SAP	N/A
VPRN interface SAP, spoke SDP	N/A	N/A

Apply IP and MAC Filter Policies

The following example shows an example of applying an IP and a MAC filter policy to an Epipe service:

```
CLI Syntax: config>service# epipe service-id
sap sap-id
egress
filter { ip ip-filter-id | mac mac-filter-id}
ingress
filter { ip ip-filter-id | mac mac-filter-id}
spoke-sdp sdp-id:vc-id [vc-type { ether | vlan }]
egress
filter { ip ip-filter-id | mac-filter-id}
ingress
filter { ip ip-filter-id | mac-filter-id}
```

The following output displays IP and MAC filters assigned to an ingress and egress SAP and spoke SDP:

A:ALA-48>config>service>epipe# info sap 1/1/1.1.1 create

7750 SR OS Router Configuration Guide

```
ingress
             filter ip 10
            exit
            egress
            filter mac 92
           exit
         exit
         spoke-sdp 8:8 create
           ingress
              filter ip 10
           exit
           egress
            filter mac 91
           exit
        exit
        no shutdown
-----
A:ALA-48>config>service>epipe#
```

Apply an IPv6 Filter Policy to an IES SAP

The following output displays an IPv6 filters assigned to an IES service interface:

```
A:ALA-48>config>service>ies# info
-----
       interface "testA" create
          address 192.22.1.1/24
          sap 2/1/3:0 create
          exit
           ipv6
           ingress
             filter ipv6 100
           egress
            filter ipv6 100
          exit
        exit
. . .
-----
```

A:ALA-48>config>service>ies#

Apply Filter Policies to a Network Port

IP filter policies can be applied to network IP interfaces. MAC filters cannot be applied to network IP interfaces or to routable IES services. IPv6 filter policies can be applied to network IP interfaces in the IPv6 context within the interface configuration.

Apply an IP Interface

CLI Syntax: config>router# interface *ip-int-name*

The following displays an IP filter applied to an interface at ingress.

```
A:ALA-48>config>router# info
#-----
# IP Configuration
#-----
. . .
     interface "to-104"
       address 10.0.0.103/24
       port 1/1/1
       ingress
          filter ip 10
       exit
       egress
          filter ip 10
       exit
     exit
. . .
#-----
A:ALA-48>config>router#
```

Apply an IPv6 Interface

The following displays IPv6 filters applied to an interface at ingress and egress.

```
A:config>router>if# info
-----
       port 1/1/1
       ipv6
         address 3FFE::101:101/120
       exit
       ingress
          filter ip 2
          filter ipv6 1
        exit
        egress
          filter ip 2
          filter ipv6 1
       exit
-----
A:config>router>if#
```

Creating a Redirect Policy

Configuring and applying redirect policies is optional. Each redirect policy must have the following:

- A destination IP address
- A priority (default is 100)
- At least one of the following tests must be enabled:
 - \rightarrow Ping test
 - \rightarrow SNMP test
 - \rightarrow URL test

The following displays a redirection policy configuration:

```
A:ALA-7>config>filter# info
-----
      redirect-policy "redirect1" create
          destination 10.10.10.104 create
             description "SNMP to 104"
             priority 105
             snmp-test "SNMP-1"
                interval 30
                 drop-count 30 hold-down 120
             exit
             no shutdown
          exit
          destination 10.10.10.105 create
             priority 95
             ping-test
                 timeout 30
                 drop-count 5
             exit
             no shutdown
          exit
          destination 10.10.10.106 create
             priority 90
             url-test "URL to 106"
                 url "http://aww.alcatel.com/ipd/"
                 interval 60
                 return-code 2323 4567 raise-priority 96
             exit
             no shutdown
          exit
. . .
_____
```

A:ALA-7>config>filter#

Configuring Policy-Based Forwarding for Deep Packet Inspection in VPLS

The purpose policy-based forwarding is to capture traffic from a customer and perform a deep packet inspection (DPI) and forward traffic, if allowed, by the DPI.

In the following example, the split horizon groups are used to prevent flooding of traffic. Traffic from customers enter at SAP 1/1/5:5. Due to the mac-filter 100 that is applied on ingress, all traffic with dot1p 07 marking will be forwarded to SAP 1/1/22:1, which is the DPI.

DPI performs packet inspection/modification and either drops the traffic or forwards the traffic back into the box through SAP 1/1/21:1. Traffic will then be sent to spoke-sdp 3:5.

SAP 1/1/23:5 is configured to see if the VPLS service is flooding all the traffic. If flooding is performed by the router then traffic would also be sent to SAP 1/1/23:5 (which it should not).

Figure 18 shows an example to configure policy-based forwarding for deep packet inspection on a VPLS service. For information about configuring services, refer to the 7750 SR OS Services Guide.




Figure 18: Policy-Based Forwarding for Deep Packet Inspection

```
*A:ALA-48>config>service# info
_____
. . .
      vpls 10 customer 1 create
         service-mtu 1400
          split-horizon-group "dpi" residential-group create
          exit
          split-horizon-group "split" create
          exit
          stp
             shutdown
          exit
          sap 1/1/21:1 split-horizon-group "split" create
             disable-learning
             static-mac 00:00:00:31:11:01 create
          exit
          sap 1/1/22:1 split-horizon-group "dpi" create
             disable-learning
             static-mac 00:00:00:31:12:01 create
          exit
          sap 1/1/23:5 create
             static-mac 00:00:00:31:13:05 create
          exit
          no shutdown
      exit
. . .
-----
*A:ALA-48>config>service#
```

The following displays a VPLS service configuration with DPI example:

The following displays a MAC filter configuration example:

```
*A:ALA-48>config>filter# info
                        -----
. . .
      mac-filter 100 create
         default-action forward
         entry 10 create
            match
                dot1p 7 7
            exit
            log 101
            action forward sap 1/1/22:1
         exit
      exit
. . .
-----
*A:ALA-48>confiq>filter#
```

The following displays the MAC filter added to the VPLS service configuration:

```
*A:ALA-48>config>service# info
-----
. . .
       vpls 10 customer 1 create
          service-mtu 1400
          split-horizon-group "dpi" residential-group create
          exit
          split-horizon-group "split" create
          exit
          stp
              shutdown
          exit
          sap 1/1/5:5 split-horizon-group "split" create
              ingress
                 filter mac 100
              exit
              static-mac 00:00:00:31:15:05 create
          exit
          sap 1/1/21:1 split-horizon-group "split" create
              disable-learning
              static-mac 00:00:00:31:11:01 create
          exit
          sap 1/1/22:1 split-horizon-group "dpi" create
             disable-learning
              static-mac 00:00:00:31:12:01 create
          exit
          sap 1/1/23:5 create
             static-mac 00:00:00:31:13:05 create
          exit
          spoke-sdp 3:5 create
          exit
          no shutdown
       exit
. . . .
-----
*A:ALA-48>config>service#
```

Filter Management Tasks

This section discusses the following filter policy management tasks:

- Renumbering Filter Policy Entries on page 378
- Modifying an IP Filter Policy on page 380
- Modifying an IPv6 Filter Policy on page 382
- Modifying a MAC Filter Policy on page 383
- Deleting a Filter Policy on page 384
- Modifying a Redirect Policy on page 389
- Deleting a Redirect Policy on page 390
- Copying Filter Policies on page 391

Renumbering Filter Policy Entries

The system exits the matching process when the first match is found and then executes the actions in accordance with the specified action. Because the ordering of entries is important, the numbering sequence can be rearranged. Entries should be numbered from the most explicit to the least explicit.

Use the following CLI syntax to renumber existing MAC or IP filter entries to re-sequence filter entries:

CLI Syntax:	config>filter
	ip-filter <i>filter-id</i>
	renum old-entry-number new-entry-number
	mac-filter filter-id
	renum old-entry-number new-entry-number
Example:	config>filter>ip-filter# renum 10 15 config>filter>ip-filter# renum 20 10 config>filter>ip-filter# renum 40 1

A:ALA-7>config>filter# info A:ALA-7>config>filter# info _____ _____ ip-filter 11 create ip-filter 11 create description "filter-main" description "filter-main" scope exclusive scope exclusive entry 10 create entry 1 create description "no-91" match filter-sample dst-ip 10.10.10.91/24 interface-disable-sample src-ip 10.10.10.106/24 match exit dst-ip 10.10.10.91/24 action drop src-ip 10.10.10.103/24 exit entry 10 create exit action forward redirect-policy redirect1 match dst-ip 10.10.10.91/24 exit entry 20 create src-ip 10.10.0.100/24 match exit dst-ip 10.10.10.91/24 action drop src-ip 10.10.0.100/24 exit exit entry 15 create description "no-91" action drop exit filter-sample entry 30 create interface-disable-sample match match dst-ip 10.10.10.91/24 dst-ip 10.10.10.91/24 src-ip 10.10.0.200/24 src-ip 10.10.10.103/24 exit exit action forward action forward redirect-policy exit redirect1 entry 40 create exit entry 30 create match dst-ip 10.10.10.91/24 match src-ip 10.10.10.106/24 dst-ip 10.10.10.91/24 exit src-ip 10.10.0.200/24 action drop exit exit action forward exit. exit exit -----A:ALA-7>config>filter# A:ALA-7>config>filter#

The following displays the original filter entry order on the left side and the reordered filter entries on the right side:

Modifying an IP Filter Policy

To access a specific IP filter, you must specify the filter ID. Use the no form of the command to remove the command parameters or return the parameter to the default setting.

```
Example: config>filter>ip-filter# description "New IP filter info"
config>filter>ip-filter# entry 2 create
config>filter>ip-filter>entry$ description "new entry"
config>filter>ip-filter>entry# action drop
config>filter>ip-filter>entry# match dst-ip 10.10.10.104/32
config>filter>ip-filter>entry# exit
config>filter>ip-filter>entry# exit
```

The following output displays the modified IP filter output:

```
A:ALA-7>config>filter# info
. . .
       ip-filter 11 create
           description "New IP filter info"
           scope exclusive
           entry 1 create
               match
                  dst-ip 10.10.10.91/24
                   src-ip 10.10.10.106/24
               exit
               action drop
            exit
            entry 2 create
               description "new entry"
               match
                   dst-ip 10.10.10.104/32
               exit
               action drop
            exit
            entry 10 create
               match
                  dst-ip 10.10.10.91/24
                   src-ip 10.10.0.100/24
               exit
               action drop
            exit
            entry 15 create
               description "no-91"
               match
                   dst-ip 10.10.10.91/24
                   src-ip 10.10.10.103/24
               exit.
               action forward
            exit
            entry 30 create
               match
```

dst-ip 10.10.10.91/24 src-ip 10.10.0.200/24 exit action forward exit exit -----

A:ALA-7>config>filter#

••

Modifying an IPv6 Filter Policy

To access a specific IPv6 filter, you must specify the filter ID. Use the no form of the command to remove the command parameters or return the parameter to the default setting.

The following output displays the modified IPv6 filter output:

```
A:ALA-49>config>filter>ipv6-filter# info

description "IPv6 filter for Customer 1"

scope exclusive

entry 1 create

description "Fwds matching packets"

match

dst-ip 11::12/128

src-ip 13::14/128

exit

action forward

exit

A:ALA-49>config>filter>ipv6-filter#
```

Modifying a MAC Filter Policy

To access a specific MAC filter, you must specify the filter ID. Use the no form of the command to remove the command parameters or return the parameter to the default setting.

The following output displays the modified MAC filter output:

```
A:ALA-7>config>filter# info
_____
      mac-filter 90 create
          description "New filter info"
          scope exclusive
          entry 1 create
             description "New entry info"
              match
                 src-mac 00:dc:98:1d:00:00 ff:ff:ff:ff:ff
                 dst-mac 02:dc:98:1d:00:01 ff:ff:ff:ff:ff
              exit
              action forward
          exit
          entry 2 create
              match
                 dot1p 7 7
             exit
             action drop
          exit
       exit
. . .
                  _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _
A:ALA-7>config>filter#
```

Deleting a Filter Policy

Before you can delete a filter, you must remove the filter association from the applied ingress and egress SAPs and network interfaces.

- From an Ingress SAP on page 384
- From an Egress SAP on page 384
- From a Network Interface on page 385
- From the Filter Configuration on page 388

From an Ingress SAP

To remove a filter from an ingress SAP, enter the following CLI commands:

<pre>config>service# [epipe ies vpls] service-id</pre>
<pre>sap port-id[:encap-val]</pre>
ingress
no filter
config>service# epipe 5
config>service>epipe# sap 1/1/2:3
config>service>epipe>sap# ingress
config>service>epipe>sap>ingress# no filter

From an Egress SAP

To remove a filter from an egress SAP, enter the following CLI commands:

CLI Syntax:	<pre>config>service# [epipe ies vpls] service-id sap port-id[:encap-val] egress</pre>
	no filter
Example:	config>service# epipe 5 config>service>epipe# sap 1/1/2:3 config>service>epipe>sap# egress config>service>epipe>sap>egress# no filter

From a Network Interface

To delete a filter from a network interface, enter the following CLI commands:

IP and IPv6 filters can be assigned and deleted together or separately. To delete both IP and IPv6 filter associations, consider the following examples:

```
A:ALA-49>config>router>if# info
_____
        port 1/1/1
        ipv6
          address 3FFE::101:101/120
        exit
        ingress
          filter ip 2
          filter ipv6 1
        exit
        egress
          filter ip 2
          filter ipv6 1
        exit
_____
A:ALA-49>config>router>if#
CLI Syntax: config>router>if#
         config>router>if# ingress no filter
A:ALA-49>config>router>if# info
-----
        port 1/1/1
        ipv6
           address 3FFE::101:101/120
        exit
        egress
          filter ip 2
          filter ipv6 1
        exit
A:ALA-49>config>router>if#
```

CLI Syntax: config>router>if# egress no filter ip 2

A:ALA-49>config>router>if# info

7750 SR OS Router Configuration Guide

```
-----
       port 1/1/1
       ipv6
          address 3FFE::101:101/120
        exit
       egress
          filter ipv6 1
       exit
A:ALA-49>config>router>if#
CLI Syntax: config>router>if# ingress filter ip 2
         config>router>if# ingress filter ipv6 1
A:ALA-49>config>router>if# info
               port 1/1/1
       ipv6
          address 3FFE::101:101/120
        exit
        ingress
          filter ip 2
          filter ipv6 1
        exit
        eqress
          filter ipv6 1
       exit
_____
A:ALA-49>config>router>if#
```

CLI Syntax: config>router>if# ingress no filter ipv6 1

```
A:ALA-49>config>router>if# info

port 1/1/1

ipv6

address 3FFE::101:101/120

exit

ingress

filter ip 2

exit

egress

filter ipv6 1

exit

A:ALA-49>config>router>if#

CLI Syntax: config>router>if# ingress no filter
```

```
A:ALA-49>config>router>if#
port 1/1/1
```

```
ipv6
address 3FFE::101:101/120
exit
egress
filter ipv6 1
exit
A:ALA-49>config>router>if#
```

CLI Syntax: config>router>if# egress no filter

A:ALA-49>config>router>if# port 1/1/1 ipv6 address 3FFE::101:101/120 exit

A:ALA-49>config>router>if#

From the Filter Configuration

After you have removed the filter from the SAP, use the following CLI syntax to delete the filter.

CLI Syntax: config>filter# no ip-filter filter-id CLI Syntax: config>filter# no mac-filter filter-id CLI Syntax: config>filter# no ipv6-filter filter-id Example: config>filter# no ip-filter 11 config>filter# no mac-filter 13 config>filter# no ipv6-filter 100

Modifying a Redirect Policy

To access a specific redirect policy, you must specify the policy name. Use the no form of the command to remove the command parameters or return the parameter to the default setting.

```
Example: config>filter# redirect-policy redirect1
      config>filter>redirect-policy# description "New redirect info"
      config>filter>redirect-policy# destination 10.10.10.106
      confiq>filter>redirect-policy>dest# no url-test "URL to 106"
      config>filter>redirect-policy>dest# url-test "URL to Proxy"
      confiq>filter>redirect-policy>dest>url-test$ url http://
                   www.alcatel.com
      confiq>filter>redirect-policy>dest>url-test# interval 10
      config>filter>redirect-policy>dest>url-test# timeout 10
      config>filter>redirect-policy>dest>url-test# return-code 1
                   4294967295 raise-priority 255
A:ALA-7>config>filter# info
_____
. . .
      redirect-policy "redirect1" create
          description "New redirect info"
          destination 10.10.10.104 create
             description "SNMP to 104"
             priority 105
             snmp-test "SNMP-1"
                interval 30
                drop-count 30 hold-down 120
             exit
             no shutdown
          exit
          destination 10.10.10.105 create
             priority 95
             ping-test
                timeout 30
                drop-count 5
             exit
             no shutdown
          exit
          destination 10.10.10.106 create
             priority 90
             url-test "URL to Proxy"
                url "http://www.alcatel.com"
                interval 10
                timeout 10
                return-code 1 4294967295 raise-priority 255
             exit
             no shutdown
          exit
         no shutdown
      exit
. . .
```

A:ALA-7>config>filter#

7750 SR OS Router Configuration Guide

Deleting a Redirect Policy

Before you can delete a redirect policy from the filter configuration, you must remove the policy association from the IP filter.

The following example shows the command usage to replace the configured redirect policy (**redirect1**) with a different redirect policy (**redirect2**) and then removing the **redirect1** policy from the filter configuration.

```
Example:config>filter>ip-filter 11
       config>filter>ip-filter# entry 1
       config>filter>ip-filter>entry# action forward redirect-policy
redirect2
       config>filter>ip-filter>entry# exit
       config>filter>ip-filter# exit
       config>filter# no redirect-policy redirect1
A:ALA-7>config>filter>ip-filter# info
            ------
                               -----
_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _
         description "This is new"
          scope exclusive
          entry 1 create
           filter-sample
           interface-disable-sample
             match
                dst-ip 10.10.10.91/24
                src-ip 10.10.10.106/24
             exit
             action forward redirect-policy redirect2
          exit
          entry 2 create
             description "new entry"
_____
A:ALA-7>config>filter>ip-filter#
```

Copying Filter Policies

When changes are made to an existing filter policy, they are applied immediately to all services where the policy is applied. If numerous changes are required, the policy can be copied so you can edit the "work in progress" version without affecting the filtering process. When the changes are completed, you can overwrite the work in progress version with the original version.

New filter policies can also be created by copying an existing policy and renaming the new filter.

CLI Syntax: config>filter# copy filter-type src-filter-id [src-entry srcentry-id] to dst-filter-id [dst-entry dst-entry-id] [overwrite]

The following displays the command usage to copy an existing IP filter (11) to create a new filter policy (12).

Example: config>filter# copy ip-filter 11 to 12

```
A:ALA-7>confiq>filter# info
     . . .
      ip-filter 11 create
         description "This is new"
         scope exclusive
         entry 1 create
             match
                dst-ip 10.10.10.91/24
                src-ip 10.10.10.106/24
             exit
             action drop
          exit
          entry 2 create
. . .
      ip-filter 12 create
         description "This is new"
          scope exclusive
          entry 1 create
             match
                dst-ip 10.10.10.91/24
                src-ip 10.10.10.106/24
             exit
             action drop
          exit
         entry 2 create
. . .
_____
A:ALA-7>config>filter#
```


Filter Management Tasks

Filter Command Reference

Command Hierarchies

- Log Commands on page 393
- IP Filter Policy Commands on page 393
- IPv6 Filter Policy Commands on page 395
- MAC Filter Policy Commands on page 396
- Redirect Policy Configuration Commands on page 397
- Generic Filter Commands on page 398
- Show Commands on page 398
- Clear Commands on page 398
- Monitor Commands on page 398

Configuration Commands



filter
ip-filter filter-id [create]
no ip-filter filter-id
default-action {drop | forward}
description description-string
no description
renum old-entry-id new-entry-id
scope {exclusive | template}
no scope

7750 SR OS Router Configuration Guide

- entry entry-id [time-range time-range-name] [create]
- no entry entry-id
 - action [drop]
 - action forward [next-hop {ip-address | indirect ip-address | interface ip-int-name}]
 - action forward [redirect-policy policy-name]
 - action forward [sap sap-id | sdp sdp-id]
 - action http-redirect url
 - action nat
 - no action
 - **description** *description-string*
 - no description
 - [no] filter-sample
 - [no] interface-disable-sample
 - log log-id
 - no log
 - match [protocol protocol-id]
 - no match
 - dscp dscp-name
 - no dscp
 - **____dst-ip** {*ip-address/mask* | *ip-address netmask*}
 - no dst-ip
 - **dst-port** {**lt** | **gt** | **eq**} *dst-port-number*
 - **dst-port** range *start* end
 - no dst-port
 - **fragment** {true | false}
 - no fragment
 - icmp-code icmp-code
 - no icmp-code
 - icmp-type icmp-type
 - no icmp-type
 - **ip-option** *ip-option-value* [*ip-option-mask*]
 - no ip-option
 - multiple-option {true | false}
 - no multiple-option
 - option-present {true | false}
 - no option-present
 - src-ip{ip-address/mask | ip-address netmask}
 - no src-ip
 - **src-port** {{**lt** | **gt** | **eq**} *src-port-number*
 - **src-port** range *start* end}
 - no src-port
 - tcp-ack {true | false}
 - no tcp-ack
 - tcp-syn {true | false}
 - no tcp-syn

IPv6 Filter Policy Commands

config

— filter

- **ipv6-filter** *ipv6-filter-id* [**create**]
- **no ipv6-filter** ipv6-filter-id
 - default-action {drop | forward}
 - **description** *description-string*
 - no description
 - **entry** *entry-id* [**time-range** *time-range-name*]
 - no entry entry-id
 - action {drop | forward}
 - no action
 - **description** description-string
 - no description
 - log log-id
 - no log
 - match [next-header next-header]
 - no match
 - dscp dscp-name
 - no dscp
 - **dst-ip** [*ipv6-address/prefix-length*]
 - no dst-ip
 - dst-port {lt | gt | eq} dst-port-number
 - dst-port range start end
 - no dst-port
 - icmp-code icmp-code
 - no icmp-code
 - icmp-type icmp-type
 - no icmp-type
 - src-ip{ipv6-address/prefix-length}
 - no src-ip
 - **src-port** {**lt** | **gt** | **eq**} *src-port-number*
 - src-port range start end}
 - no src-port
 - tcp-ack {true | false}
 - no tcp-ack
 - tcp-syn {true | false}

— no tcp-syn

- renum old-entry-id new-entry-id
- **— scope** {exclusive | template}
- no scope

MAC Filter Policy Commands

config

— filter

- mac-filter filter-id [create]
- **no mac-filter** *filter-id*
 - **description** *description-string*
 - no description
 - default-action {drop | forward}
 - renum old-entry-id new-entry-id
 - **scope** {exclusive | template}
 - no scope
 - **type** *filter-type*
 - entry entry-id [time-range time-range-name]
 - no entry entry-id [create]
 - description description-string
 - no description
 - action [drop]
 - **action forward** [sap *sap-id* | sdp *sdp-id*]
 - **action** http-redirect *url*
 - no action
 - log log-id
 - no log
 - match [frame-type {802dot3 | 802dot2-llc | 802dot2-snap |
 - ethernet_II}] — no match
 - **dot1p** dot1p-value [dot1p-mask]
 - no dot1p
 - **dsap** *dsap-value* [*dsap-mask*]
 - no dsap
 - **dst-mac** *ieee-address* [*ieee-address-mask*]
 - no dst-mac
 - etype 0x0600..0xffff
 - no etype
 - isid value | value to higher-value
 - no isid
 - snap-oui {zero | non-zero}
 - no snap-oui
 - **snap-pid** snap-pid
 - no snap-pid
 - **ssap** ssap-value [ssap-mask]
 - no ssap
 - **src-mac** *ieee-address* [*ieee-address-mask*]
 - no src-mac

— type {normal | isid}

Redirect Policy Configuration Commands

config

— filter

- redirect-policy redirect-policy-name [create]
- no redirect-policy redirect-policy-name
 - description description-string
 - no description
 - [no] shutdown
 - destination *ip-address* [create]
 - no destination *ip-address*
 - description description-string
 - no description
 - **priority** [priority]
 - no priority
 - [no] shutdown
 - [no] ping-test
 - **drop-count** consecutive-failures [**hold-down** seconds]
 - no drop-count
 - interval seconds
 - no interval
 - **timeout** seconds
 - no timeout
 - **snmp-test** *test-name* [**create**]
 - no snmp-test test-name
 - **drop-count** consecutive-failures [hold-down seconds]
 - no drop-count
 - interval seconds
 - no interval
 - **oid** oid-string **community** community-string
 - no <mark>oid</mark>
 - return-value return-value type return-type [disable | lowerpriority priority | raise-priority priority]
 - no **return-value** *return-value* type *return-type*
 - timeout seconds
 - no timeout
 - url-test test-name [create]
 - **no url-test** test-name
 - **drop-count** consecutive-failures [hold-down seconds]
 - no drop-count
 - interval seconds
 - no interval
 - return-code return-code-1 [return-code-2] [disable | lowerpriority priority | raise-priority priority]
 - **no return-code** *return-code-1* [*return-code-2*]
 - timeout seconds
 - no timeout
 - **url** url-string [http-version version-string]
 - no url

Generic Filter Commands

config

— filter

— copy ip-filter | ipv6-filter | mac-filter src-filter-id [src-entry src-entry-id] to dst-filter-id [dst-entry dst-entry-id] [overwrite]

Show Commands

show — filter

— download-failed

- **ip** [*ip-filter-id* [**entry** *entry-id*] [**association** | **counters**]
- **ipv6** [*ipv6-filter-id* [**entry** *entry-id*] [**association** | **counters**]]
- log [bindings]
- log log-id [match string]
- mac {mac-filter-id [entry entry-id] [association | counters]}
- redirect-policy {redirect-policy-name [dest ip-address] [association]}

Clear Commands

clear

— filter

- **ip** *filter-id* [**entry** *entry-id*] [**ingress** | **egress**]
- **ipv6** *filter-id* [**entry** *entry-id*] [**ingress** | **egress**]
- log log-id
- mac filter-id [entry entry-id] [ingress | egress]

Monitor Commands

monitor

- filter ip ip-filter-id entry entry-id [interval seconds] [repeat repeat] [absolute | rate]
- filter ipv6 ipv6-filter-id entry entry-id [interval seconds] [repeat repeat] [absolute | rate]
- filter mac mac-filter-id entry entry-id [interval seconds] [repeat repeat] [absolute | rate]

Configuration Commands

Generic Commands

description

Syntax	description string no description
Context	config>filter>ip-filter config>filter>ip-filter>entry config>filter>ipv6-filter config>filter>log config>filter>mac-filter config>filter>mac-filter config>filter>mac-filter>entry config>filter>redirect-policy config>filter>redirect-policy>destination
Description	This command creates a text description stored in the configuration file for a configuration context.
	The description command associates a text string with a configuration context to help identify the context in the configuration file.
	The no form of the command removes any description string from the context.
Default	none
Parameters	<i>string</i> — The description character string. Allowed values are any string up to 80 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

Global Filter Commands

ip-filter

Syntax	[no] ip-filter filter-id [create]
Context	config>filter
Description	This command creates a configuration context for an IP filter policy.
	IP-filter policies specify either a forward or a drop action for packets based on the specified match criteria.
	The IP filter policy, sometimes referred to as an access control list (ACL), is a template that can be applied to multiple services or multiple network ports as long as the scope of the policy is template.
	Any changes made to the existing policy, using any of the sub-commands, will be applied immediately to all services where this policy is applied. For this reason, when many changes are required on an ip-filter policy, it is recommended that the policy be copied to a work area. That work-in-progress policy can be modified until complete and then written over the original filter policy. Use the config filter copy command to maintain policies in this manner.
	The no form of the command deletes the IP filter policy. A filter policy cannot be deleted until it is removed from all SAPs or network ports where it is applied.
Parameters	<i>filter-id</i> — Specifies the IP filter policy ID number.
	Values 1 — 65535
	create — Keyword required when first creating the configuration context. Once the context is created, one can navigate into the context without the create keyword.
6-filtor	

ipv6-filter

Syntax	[no] ipv6-filter ipv6-filter-id [create]	
Context	config>filter	
Description	This command creates a configuration context for an IPv6 filter policy.	
Parameters	<i>ipv6-filter-id</i> — specifies the IPv6 filter policy ID number.	
	Values 1 — 16384	
	create — Keyword required when first creating the configuration context. Once the context is	

created, one can navigate into the context without the create keyword.

mac-filter

Syntax	[no] mac-filter filter-id [create]
Context	config>filter
Description	This command enables the context for a MAC filter policy.
	The mac-filter policy specifies either a forward or a drop action for packets based on the specified match criteria.
	The mac-filter policy, sometimes referred to as an access control list, is a template that can be applied to multiple services as long as the scope of the policy is template.
	Note it is not possible to apply a MAC filter policy to a network port or an IES service.
	Any changes made to the existing policy, using any of the sub-commands, will be applied immediately to all services where this policy is applied. For this reason, when many changes are required on a mac-filter policy, it is recommended that the policy be copied to a work area. That work-in-progress policy can be modified until complete and then written over the original filter policy. Use the config filter copy command to maintain policies in this manner.
	The no form of the command deletes the mac-filter policy. A filter policy cannot be deleted until it is removed from all SAP where it is applied.
Parameters	<i>filter-id</i> — The MAC filter policy ID number.
	Values 1 — 65535
	create — Keyword required when first creating the configuration context. Once the context is created, one can navigate into the context without the create keyword.

redirect-policy

Syntax	[no] redirect-policy redirect-policy-name	
Context	config>filter	
Description	This command configures redirect policies.	
	The no form of the command removes the redirect policy from the filter configuration only if the policy is not referenced in an IP filter and the IP filter is not in use (applied to a service or network interface).	
Default	none	
Parameters	<i>redirect-policy-name</i> — Specifies the redirect policy name. Allowed values are any string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes. There is no limit to the number of redirect policies that can be configured.	

Filter Log Destination Commands

destination

Syntax	destination memory <i>num-entries</i> destination syslog syslog-id no destination
Context	config>filter>log
Description	This command configures the destination for filter log entries for the filter log ID.
	Filter logs can be sent to either memory (memory) or to an existing Syslog server definition (server).
	If the filter log destination is memory , the maximum number of entries in the log must be specified.
	The no form of the command deletes the filter log association.
Default	no destination
Parameters	memory <i>num-entries</i> — Specifies the destination of the filter log ID is a memory log. The <i>num-entries</i> value is the maximum number of entries in the filter log expressed as a decimal integer.
	Values 10 — 50000
	syslog <i>syslog-id</i> — Specifies the destination of the filter log ID is a Syslog server. The <i>syslog-id</i> parameter is the number of the Syslog server definition.
	Values 1 — 10

log

Syntax	log log-id [create] no log	
Context	config>filter	
Description	This command enables the context to create a filter log policy.	
	The no form of the command deletes the filter log ID. The log cannot be deleted if there are filter entries configured to write to the log. All filter entry logging associations need to be removed before the log can be deleted.	
Special Cases	Filter log 101 — Filter log 101 is the default log and is automatically created by the system. Filte log 101 is always a memory filter log and cannot be changed to a Syslog filter log. The log size defaults to 1000 entries. The number of entries and wrap-around behavior can be edited.	
Default	log 101	
Parameters	log-id — The filter log ID destination expressed as a decimal integer.	
	Values 101 — 199	

shutdown

Syntax	[no] shutdown
Context	config>filter>log config>filter>log>summary config>filter>redirect-policy config>filter>redirect-policy>destination
	Administratively enables/disabled (AdminUp/AdminDown) an entity. Downing an entity does not change, reset or remove any configuration settings or statistics. Many objects must be shutdown before they may be deleted.
	The shutdown command administratively downs an entity. Administratively downing an entity changes the operational state of the entity to down and the operational state of any entities contained within the administratively down entity.
	Unlike other commands and parameters where the default state will not be indicated in the configuration file, shutdown and no shutdown are always indicated in system generated configuration files.
	The no form of the command puts an entity into the administratively enabled state.
Default	no shutdown

summary

Syntax	summary
Context	config>filter>log
Description	This command enables the context to configure log summarization. These settings will only be taken into account when syslog is the log destination. Note that summary settings will only be taken into account in case the log destination is syslog.
Parameters	none

summary-crit

Syntax	summary-crit dst-addr
	summary-crit src-addr
	no summary-crit

- **Context** config>filter>log>summary
- **Description** This command defines the the key of the index of the minitable. If key information is changed while summary is in no shutdown, the filter summary minitable is flushed and recreated with different key information. Log packets received during the reconfiguration time will be handled as if summary was not active.

The **no** form of the command reverts to the default parameter.

Default dst-addr

Parameters dst-addr — Specifies that received log packets are summarized based on the destination IP, IPv6, or MAC address.

src-addr — Specifies that received log packets are summarized based on the source IP, IPv6 or MAC address.

wrap-around

Syntax	[no] wrap-around	
Context	config>filter>log	
Description	This command configures a memory filter log to log until full or to store the most recent log entrie (circular buffer).	
	Specifying wrap-around configures the memory filter log to store the most recent filter log entries (circular buffer). When the log is full, the oldest filter log entries are overwritten with new entries.	
	The no form of the command configures the memory filter log to accept filter log entries until full. When the memory filter log is full, filter logging for the log filter ID ceases.	
Default	wrap-around	

Filter Policy Commands

default-action

Syntax	default-action {drop forward}
Context	config>filter>ip-filter config>filter>ipv6-filter config>filter>mac-filter
Description	This command specifies the action to be applied to packets when the packets do not match the specified criteria in all of the IP filter entries of the filter.
	When multiple default-action commands are entered, the last command will overwrite the previous command.
Default	drop
Parameters	drop — Specifies all packets will be dropped unless there is a specific filter entry which causes the packet to be forwarded.
	forward — Specifies all packets will be forwarded unless there is a specific filter entry which causes the packet to be dropped.

scope

Syntax	scope {exclusive template} no scope		
Context	config>filter>ip-filter config>filter>ipv6-filter config>filter>mac-filter		
Description	This command configures the filter policy scope as exclusive or template. If the scope of the policy is template and is applied to one or more services or network interfaces, the scope cannot be changed.		
	The no form of the command sets the scope of the policy to the default of template .		
Default	template		
Parameters	exclusive — When the scope of a policy is defined as exclusive, the policy can only be applied to a single entity (SAP or network port). Attempting to assign the policy to a second entity will result in an error message. If the policy is removed from the entity, it will become available for assignment to another entity.		
	template — When the scope of a policy is defined as template, the policy can be applied to multiple SAPs or network ports.		

Filter Policy Commands

type

Syntax	type {normal isid}		
Context	config>filter>mac-filter		
Description	This command configures the type of mac-filter as regular or isid types. This command is required because using the ISID value for flitering is exclusive with any other match criteria. In other words, when the isid option is used only ISID match criteria is allowed. When normal option is used ISID match is not allowed.		
Default	normal		
Parameters	normal — Regular match criteria are allowed; ISID match not allowed.		
	isid — Only ISID match criteria are allowed.		

General Filter Entry Commands

entry

log

Syntax	entry entry-id [time-range time-range-name] [create] no entry entry-id		
Context	config>filter>ip-filter config>filter>ipv6-filter config>filter>mac-filter		
Description	This command creates or edits an IP, IPv6, or MAC filter entry. Multiple entries can be created us unique entry-id numbers within the filter. The implementation exits the filter on the first match fou and executes the actions in accordance with the accompanying action command. For this reason, entries must be sequenced correctly from most to least explicit.		
	An entry may not have any match criteria defined (in which case, everything matches) but must have at least the keyword action for it to be considered complete. Entries without the action keyword will be considered incomplete and hence will be rendered inactive.		
	The no form of the command removes the specified entry from the IP or MAC filter. Entries removed from the IP or MAC filter are ediately removed from all services or network ports where that filter is applied.		
Default	none		
Parameters	<i>entry-id</i> — An entry-id uniquely identifies a match criteria and the corresponding action. It is recommended that multiple entries be given <i>entry-ids</i> in staggered increments. This allows users to insert a new entry in an existing policy without requiring renumbering of all the existing entries.		
	Values 1 – 65535		
	time-range <i>time-range-name</i> — Specifies the time range name to be associated with this filter entry up to 32 characters in length. The time-range name must already exist in the config>cron context.		
	create — Keyword required when first creating the configuration context. Once the context is created, one can navigate into the context without the create keyword.		
Syntax	log log-id no log		
Context	config>filter>ip-filter>entry config>filter>ipv6-filter>entry config>filter>mac-filter>entry		

Description This command creates the context to enable filter logging for a filter entry and specifies the

7750 SR OS Router Configuration Guide

	destination filter log ID.		
	The filter log ID must exist before a filter entry can be enabled to use the filter log ID.		
	The no form of the command disables logging for the filter entry.		
Default	no log		
Parameters	log-id — The filter log ID destination expressed as a decimal integer.		
	Values 101 — 199		

IP Filter Entry Commands

action

Syntax	action [drop] action forward [next-hop { <i>ip-address</i> indirect <i>ip-address</i> interface <i>ip-int-name</i> }] action forward [redirect-policy <i>policy-name</i>] action forward [sap <i>sap-id</i> sdp <i>sdp-id</i>] action http-redirect <i>url</i> action nat no action		
Context	config>filter>ip-filter>entry		
Description	This command specifies to match packets with a specific IP option or a range of IP options in the first option of the IP header as an IP filter match criterion. The action keyword must be entered and a keyword specified in order for the entry to be active.		
	Note that action forward next-hop cannot be applied to multicast traffic.		
	Multiple action statements entered will overwrite previous actions parameters when defined.		
	The no form of the command removes the specified action statement. The filter entry is considered incomplete and hence rendered inactive without the action keyword.		
Default	none		
Parameters	drop — Specifies packets matching the entry criteria will be dropped.		
	forward — Specifies packets matching the entry criteria will be forwarded.		
	If neither drop nor forward is specified, the filter action is No-Op and the filter entry is inactive.		
	next-hop <i>ip-address</i> — The IP address of the direct next-hop to which to forward matching packets in dotted decimal notation.		
	indirect <i>ip-address</i> — The IP address of the indirect next-hop to which to forward matching packets in dotted decimal notation. The direct next-hop IP address and egress IP interface are determined by a route table lookup.		
	If the next hop is not available, then a routing lookup will be performed and if a match is found the packet will be forwarded to the result of that lookup. If no match is found a "ICMP destination unreachable" message is send back to the origin.		
	interface <i>ip-int-name</i> — The name of the egress IP interface where matching packets will be forwarded from. This parameter is only valid for unnumbered point-to-point interfaces. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.		
	redirect <i>policy-name</i> — Specifies the redirect policy configured in the config>filter>redirect-policy context.		

sap sap-id — Specifies the physical port identifier portion of the SAP definition. Only Ethernet SAPs are supported (including q-in-q, BCP, bridged Ethernet in Frame Relay or ATM).Refer to Common CLI Command Descriptions on page 517 for SAP CLI command syntax and parameter descriptions.

http-redirect *url* — Specifies the HTTP web address that will be sent to the user's browser. Note that http-redirect is not supported on 7750 SR-1 or 7450 ESS-1 models.

Values 255 characters maximum

action

Syntax	action {drop forward} no action	
Context	config>filter>ipv6-filter>entry	
Description	This command specifies the action to take for packets that match this filter entry. The action keyword must be entered and a keyword specified in order for the entry to be active.	
	Multiple action statements entered will overwrite previous actions parameters when defined.	
	The no form of the command removes the specified action statement. The filter entry is considered incomplete and hence rendered inactive without the action keyword.	
Default	drop	
Parameters	drop — Specifies packets matching the entry criteria will be dropped.	
	forward — Specifies packets matching the entry criteria will be forwarded.	

filter-sample

Syntax	[no] filter-sample
Context	config>filter>ip-filter>entry
Description	Specifies that traffic matching the associated IP filter entry is sampled if the IP interface is set to cflowd acl .
	If the cflowd is either not enabled or set to cflowd interface mode, this command is ignored.
	The no form removes this command for the system configuration, disallowing the sampling of packets if the ingress interface is in cflowd acl mode.
Default	no filter-sample

interface-disable-sample

Syntax	[no] interface-disable-sample	
Context	config>filter>ip-filter>entry	
Description	Specifies that traffic matching the associated IP filter entry is not sampled if the IP interface is set to cflowd interface mode.	
	If the cflowd is either not enabled or set to cflowd acl mode, this command is ignored.	
	The no form of this command enables sampling.	
Default	no interface-disable-sample	

match

Syntax	match [protocol protocol-id] no match			
Context	config>filter>ip	config>filter>ip-filter>entry		
Description	This command enables the context to enter match criteria for the filter entry. When the match criteria have been satisfied the action associated with the match criteria is executed.			
			hin one match statement) are configured then all criteria must be action associated with the match is executed.	
	A match contex entered per entry	•	ltiple match criteria, but multiple match statements cannot be	
	The no form of	the command remov	ves the match criteria for the <i>entry-id</i> .	
Parameters	protocol — The protocol keyword configures an IP protocol to be used as an IP filter match criterion. The protocol type such as TCP or UDP is identified by its respective protocol number			
	<i>protocol-id</i> — Configures the decimal value representing the IP protocol to be used as an IP filter match criterion. Well known protocol numbers include ICMP(1), TCP(6), UDP(17). The no form the command removes the protocol from the match criteria.			
	Values 0 — 255 (values can be expressed in decimal, hexidecimal, or binary - DHB) keywords: none, crtp, crudp, egp, eigrp, encap, ether-ip, gre, icmp, idrp, igmp, igp, ip, ipv6, ipv6-frag, ipv6-icmp, ipv6-no-nxt, ipv6-opts, ipv6-route, isis, iso-ip l2tp, ospf-igp, pim, pnni, ptp, rdp, rsvp, stp, tcp, udp, vrrp * — udp/tcp wildcard			
	Protocol	Protocol ID	Description	
	icmp	1	Internet Control Message	
	igmp	2	Internet Group Management	
	ip	4	IP in IP (encapsulation)	

Protocol	Protocol ID	Description	
tcp	6	Transmission Control	
egp	8	Exterior Gateway Protocol	
igp	9	Any private interior gateway (used by Cisco for IGRP)	
udp	17	User Datagram	
rdp	27	Reliable Data Protocol	
ipv6	41	IPv6	
ipv6-route	43	Routing Header for IPv6	
ipv6-frag	44	Fragment Header for IPv6	
idrp	45	Inter-Domain Routing Protocol	
rsvp	46	Reservation Protocol	
gre	47	General Routing Encapsulation	
ipv6-icmp	58	ICMP for IPv6	
ipv6-no-nxt	59	No Next Header for IPv6	
ipv6-opts	60	Destination Options for IPv6	
iso-ip	80	ISO Internet Protocol	
eigrp	88	EIGRP	
ospf-igp	89	OSPFIGP	
ether-ip	97	Ethernet-within-IP Encapsulation	
encap	98	Encapsulation Header	
pnni	102	PNNI over IP	
pim	103	Protocol Independent Multicast	
vrrp	112	Virtual Router Redundancy Protocol	
l2tp	115	Layer Two Tunneling Protocol	
stp	118	Spanning Tree Protocol	
ptp	123	Performance Transparency Protocol	
isis	124	ISIS over IPv4	
crtp	126	Combat Radio Transport Protocol	
crudp	127	Combat Radio User Datagram	

match

Syntax	match [next-header next-header] no match		
Context	config>filter>ip	v6-filter>entry	
Description	ion This command enables the context to enter match criteria for the filter entry. When have been satisfied the action associated with the match criteria is executed.		
	If more than one match criteria (within one match statement) are configured then all criteria must be satisfied (AND function) before the action associated with the match is executed.		
	A match contex entered per entry	t may consist of multiple match criteria, but multiple match statements cannot be y.	
	The no form of	the command removes the match criteria for the <i>entry-id</i> .	
Parameters	s <i>next-header</i> — Specifies the IPv6 next header to match. Note that this parameter is a protocol parameter used in IP-Filter match criteria.		
	Values	[0 — 42 45 — 49 52 — 59 61 — 255] — protocol numbers accepted in decimal, hexidecimal, or binary - DHB keywords : none, crtp, crudp, egp, eigrp, encap, ether-ip, gre, icmp, idrp, igmp, igp, ip, ipv6, ipv6-icmp, ipv6-no-nxt, isis, iso-ip, l2tp, ospf-igp, pim, pnni, ptp, rdp, rsvp, stp, tcp, udp, vrrp * — udp/tcp wildcard	

MAC Filter Entry Commands

action

Syntax	action drop action forward [sap sap-id sdp sdp-id] action http-redirect <i>url</i> no action		
Context	config>filter>mac-filter>entry		
Description	This command configures the action for a MAC filter entry. The action keyword must be entered for the entry to be active. Any filter entry without the action keyword will be considered incomplete and will be inactive.		
	If neither drop nor forward is specified, this is considered a No-Op filter entry used to explicitly set a filter entry inactive without modifying match criteria or removing the entry itself.		
	Multiple action statements entered will overwrite previous actions parameters when defined. To remove a parameter, use the no form of the action command with the specified parameter.		
	The no form of the command removes the specified action statement. The filter entry is considered incomplete and hence rendered inactive without the action keyword.		
Default	none		
Parameters	drop — Specifies packets matching the entry criteria will be dropped.		
	forward — Specifies packets matching the entry criteria will be forwarded. Only Ethernet SAPs are supported (including q-in-q, BCP, bridged Ethernet in Frame Relay or ATM).		
	If neither drop nor forward is specified, the filter action is no-op and the filter entry is inactive.		
	sap sap-id — Specifies the physical port identifier portion of the SAP definition. Refer to Common CLI Command Descriptions on page 517 for SAP CLI command syntax and parameter descriptions.		

Port Type	Encap-Type	Allowed Values	Comments
Ethernet	Null	0	The SAP is identified by the port.
Ethernet	Dot1q	0 — 4094	The SAP is identified by the 802.1Q tag on the port. Note that a 0 qtag1 value also accepts untagged packets on the dot1q port.
Ethernet	QinQ	qtag1: 0 — 4094 qtag2: 0 — 4094	The SAP is identified by two 802.1Q tags on the port. Note that a 0 qtag1 value also accepts untagged packets on the dot1q port.

SONET/SDH	IPCP	-	The SAP is identified by the channel. No BCP is deployed and all traffic is IP.
SONET/SDH TDM	BCP-Null	0	The SAP is identified with a single service on the channel. Tags are assumed to be part of the customer packet and not a service delimiter.
SONET/SDH TDM	BCP-Dot1q	0 — 4094	The SAP is identified by the 802.1Q tag on the channel.
SONET/SDH TDM	Frame Relay	16 — 991	The SAP is identified by the data link connection identifier (DLCI).
SONET/SDH ATM	ATM	vpi (NNI) 0 — 4095 vpi (UNI) 0 — 255 vci 1, 2, 5 — 65535	The SAP is identified by port or by PVPC or PVCC identifier (vpi, vpi/vci, or vpi range)

sdp-id — The SDP identifier.

Values 1 — 17407

vc-id — The virtual circuit identifier. This value is used to validate the VC ID portion of each mesh SDP binding defined in the service. The default value of this object is equal to the service ID.

Values 1 — 4294967295

http-redirect url — Specifies the HTTP web address that will be sent to the user's browser.

Values 255 characters maximum

match

Syntax	match [frame-type 802dot3 802dot2-llc 802dot2-snap ethernet_ll] no match		
Context	config>filter>mac-filter>entry		
Description	This command creates the context for entering/editing match criteria for the filter entry and specifies an Ethernet frame type for the entry. When the match criteria have been satisfied the action associated with the match criteria is executed.		
	If more than one match criteria (within one match statement) are configured then all criteria must be satisfied (AND function) before the action associated with the match will be executed.		
	A match context may consist of multiple match criteria, but multiple match statements cannot be entered per entry.		
	The no form of the command removes the metal criterio for the entry id		

The **no** form of the command removes the match criteria for the *entry-id*.

 Parameters
 frame-type keyword — The frame-type keyword configures an Ethernet frame type to be used for the MAC filter match criteria.

Default802dot3Values802dot3, 802dot2-llc, 802dot2-snap, ethernet_II802dot3 — Specifies the frame type is Ethernet IEEE 802.3.802dot2-llc — Specifies the frame type is Ethernet IEEE 802.2 LLC.802dot2-snap — Specifies the frame type is Ethernet IEEE 802.2 SNAP.ethernet_II — Specifies the frame type is Ethernet Type II.

IP Filter Match Criteria

dscp

Syntax	dscp dscp-na no dscp	me	
Context	config>filter>ip-filter>entry>match config>filter>ipv6-filter>entry>match		
Description	This command configures a DiffServ Code Point (DSCP) name to be used as an IP filter match criterion.		
	The no form of the command removes the DSCP match criterion.		
Default	no dscp		
Parameters	<i>dscp-name</i> — Configure a dscp name that has been previously mapped to a value using the dscp-name command. The DiffServ code point may only be specified by its name.		
	Values	be, cp1, cp2, cp3, cp4, cp5, cp6, cp7, cs1, cp9, af11, cp11, af12, cp13, af13, cp15, cs2, cp17, af21, cp19, af22, cp21, af23, cp23	

dst-ip

Syntax	dst-ip { <i>ip-addr</i> no dst-ip	ess[Imask]} [netmask]	
Context	config>filter>ip	-filter>entry>match	
Description	This command c	configures a destination IP address range to be used as an IP filter match criterion.	
		destination IP address, specify the address and its associated mask, e.g. 10.1.0.0/16. I notation of 10.1.0.0 255.255.0.0 may also be used.	
	The no form of t	the command removes the destination IP address match criterion.	
Default	none		
Parameters	<i>ip-prefix</i> — The IP prefix for the IP match criterion in dotted decimal notation.		
	Values	0.0.00 - 255.255.255.255	
	mask — The subnet mask length expressed as a decimal integer.		
	Values	0 — 32	
	netmask — Any	mask epressed in dotted quad notation.	
	Values	0.0.00 - 255.255.255.255	

7750 SR OS Router Configuration Guide

dst-ip

Syntax	dst-ip [<i>ipv6-address/prefix-length</i>] no dst-ip
Context	config>filter>ipv6-filter>entry>match
Description	This command matches a destination IPv6 address.
	To match on the destination IPv6 address, specify the address and prefix length, for example, 11::12/128.
	The no form of the command removes the destination IP address match criterion.
Default	none
Parameters	<i>ipv6-prefix</i> — The IPv6 prefix for the IP match criterion in dotted decimal notation.
	Values ipv6-address x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:x:d.d.d.d x: [0FFFF]H d: [0255]D
	prefix-length — The IPv6 prefix length for the ipv6-address expressed as a decimal integer.
	Values 1 – 128

dst-port

Syntax	dst-port {It gt eq} dst-port-number dst-port range start end no dst-port
Context	config>filter>ip-filter>entry>match config>filter>ipv6-filter>entry>match
Description	This command configures a destination TCP or UDP port number or port range for an IP filter match criterion.
	The no form of the command removes the destination port match criterion.
Default	none
Parameters	It gt eq — Specifies the operator to use relative to <i>dst-port-number</i> for specifying the port number match criteria.
	It specifies all port numbers less than <i>dst-port-number</i> match.
	gt specifies all port numbers greater than dst-port-number match.
	eq specifies that <i>dst-port-number</i> must be an exact match.
	 eq — Specifies the operator to use relative to <i>dst-port-number</i> for specifying the port number match criteria. The eq keyword specifies that <i>dst-port-number</i> must be an exact match.

dst-port-number — The destination port number to be used as a match criteria expressed as a decimal integer.

Values 1 — 65535

range *start end* — Specifies an inclusive range of port numbers to be used as a match criteria. The destination port numbers *start-port* and *end-port* are expressed as decimal integers.

Values 1 — 65535

fragment

Syntax	fragment {true false} no fragment
Context	config>filter>ip-filter>entry>match
Description	Configures fragmented or non-fragmented IP packets as an IP filter match criterion.
	The no form of the command removes the match criterion.
Default	false
Parameters	true — Configures a match on all fragmented IP packets. A match will occur for all packets that have either the MF (more fragment) bit set OR have the Fragment Offset field of the IP header set to a non-zero value.
	false — Configures a match on all non-fragmented IP packets. Non-fragmented IP packets are packets that have the MF bit set to zero and have the Fragment Offset field also set to zero.

icmp-code

Syntax	icmp-code icmp-code no icmp-code
Context	config>filter>ip-filter>entry>match config>filter>ipv6-filter>entry>match
Description	Configures matching on ICMP code field in the ICMP header of an IP or IPv6 packet as a filter match criterion.
	This option is only meaningful if the protocol match criteria specifies ICMP (1).
	The no form of the command removes the criterion from the match entry.
Default	no icmp-code
Parameters	<i>icmp-code</i> — The ICMP code values that must be present to match.
	Values 0 — 255

7750 SR OS Router Configuration Guide

icmp-type

Syntax	icmp-type icmp-type no icmp-type		
Context	config>filter>ip-filter>entry>match config>filter>ipv6-filter>entry>match		
Description	This command configures matching on the ICMP type field in the ICMP header of an IP or IPv6 packet as a filter match criterion.		
	This option is only meaningful if the protocol match criteria specifies ICMP (1).		
	The no form of the command removes the criterion from the match entry.		
Default	no icmp-type		
Parameters	<i>icmp-type</i> — The ICMP type values that must be present to match.		
	Values 0 – 255		

ip-option

Syntax	ip-option ip-option-value ip-option-mask no ip-option			
Context	config>filter>ip-filter>entry>match			
Description	This command configures matching packets with a specific IP option or a range of IP options in the first option of the IP header as an IP filter match criterion.			
	The option-type octet contains 3 fields:			
	1 bit copied flag (copy options in all fragments)			
	2 bits option class			
	5 bits option number			
	The no form of the command removes the match criterion.			
Default	none			
Parameters	<i>ip-option-value</i> — Enter the 8 bit option-type as a decimal integer. The mask is applied as an AND to the option byte, the result is compared with the option-value.			
	The decimal value entered for the match should be a combined value of the eight bit option type field and not just the option number. Thus to match on IP packets that contain the Router Alert option (option number = 20), enter the option type of 148 (10010100).			
	Values 0 – 255			
	<i>ip-option-mask</i> — This is optional and may be used when specifying a range of option numbers to use as the match criteria.			

This 8 bit mask can be configured using the following formats:

Format	Style	Format Syntax	Example	
Decimal		DDD	20	
Hexadecimal		0xHH	0x14	
Binary		0bbbbbbbbbbbbbbbbbbbbbbbbbbbbbbbbbbbbb	0b0010100	
Default	255 (deci	mal) (exact match)		
Values	1 — 255	(decimal)		

multiple-option

Syntax	multiple-option {true false} no multiple-option			
Context	config>filter>ip-filter>entry>match			
Description	This command configures matching packets that contain one or more than one option fields in the IP header as an IP filter match criterion.			
	The no form of the command removes the checking of the number of option fields in the IP header as a match criterion.			
Default	no multiple-option			
Parameters	true — Specifies matching on IP packets that contain more than one option field in the header.			
	false — Specifies matching on IP packets that do not contain multiple option fields present in the header.			

option-present

Syntax	option-present {true false} no option-present
Context	config>filter>ip-filter>entry>match
Description This command configures matching packets that contain the option field or have an op zero in the IP header as an IP filter match criterion.	
	The no form of the command removes the checking of the option field in the IP header as a match criterion.
Parameters	true — Specifies matching on all IP packets that contain the option field in the header. A match will occur for all packets that have the option field present. An option field of zero is considered as no option present.

false — Specifies matching on IP packets that do not have any option field present in the IP header (an option field of zero). An option field of zero is considered as no option present.

src-ip

Syntax	<pre>src-ip {ip-address[/mask]} [netmask] no src-ip</pre>				
Context	config>filter>ip-filter>entry>match				
Description	This command configures a source IP address range to be used as an IP filter match criterion.				
	To match on the source IP address, specify the address and its associated mask, e.g. 10.1.0.0/16. The conventional notation of 10.1.0.0 255.255.0.0 may also be used.				
	The no form of the command removes the source IP address match criterion.				
Default	no src-ip				
Parameters	<i>ip-address</i> — The IP prefix for the IP match criterion in dotted decimal notation.				
	Values 0.0.0.0 — 255.255.255				
	mask — The subnet mask length expressed as a decimal integer.				
	Values 0 — 32				
	netmask — Any mask epressed in dotted quad notation.				
	Values 0.0.0.0 — 255.255.255				

src-ip

Syntax	src-ip [<i>ipv6-address/prefix-length</i>] no src-ip			
Context	config>filter>ipv6-filter>entry>match			
Description	This command configures a source IPv6 address range to be used as an IP filter match criterion.			
	The no form of the command removes the source IPv6 address match criterion.			
Default	no src-ip			
Parameters	<i>ipv6-address</i> — The IP prefix for the IP match criterion in dotted decimal notation.			
	Values x:x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:x:d.d.d.d x $[0FFFF]H$ d $[0 - 255]D$			
	prefix-length — The IPv6 mask value for the IPv6 filter entry.			
	Values 1 – 28			

src-port

Syntax	src-port {It gt eq} src-port-number src-port range start end no src-port				
Context	config>filter>ip-filter>entry>match config>filter>ipv6-filter>entry>match				
Description	This command configures a source TCP or UDP port number or port range for an IP filter match criterion.				
	The no form of the command removes the source port match criterion.				
Default	no src-port				
Parameters	It gt eq — Specifies the operator to use relative to <i>src-port-number</i> for specifying the port number match criteria.				
It specifies all port numbers less than <i>src-port-number</i> match.					
	gt specifies all port numbers greater than src-port-number match.				
	eq specifies that <i>src-port-number</i> must be an exact match.				
	<i>src-port-number</i> — The source port number to be used as a match criteria expressed as a decimal integer.				
	Values 1 — 65535				
	range start end — Specifies an inclusive range of port numbers to be used as a match criteria. The source port numbers start-port and end-port are expressed as decimal integers.				
	Values 1 – 65535				

tcp-ack

Syntax	tcp-ack {true false} no tcp-ack			
Context	config>filter>ip-filter>entry>match config>filter>ipv6-filter>entry>match			
Description	This command configures matching on the ACK bit being set or reset in the control bits of the Te header of an IP packet as an IP filter match criterion.			
	The no form of the command removes the criterion from the match entry.			
Default	no tcp-ack			
Parameters	true — Specifies matching on IP packets that have the ACK bit set in the control bits of the TCP header of an IP packet.			
	false — Specifies matching on IP packets that do not have the ACK bit set in the control bits of the TCP header of the IP packet.			

tcp-syn

Syntax	tcp-syn {true false} no tcp-syn			
Context	config>filter>ip-filter>entry>match config>filter>ipv6-filter>entry>match			
Description	This command configures matching on the SYN bit being set or reset in the control bits of the TCP header of an IP packet as an IP filter match criterion.			
	The SYN bit is normally set when the source of the packet wants to initiate a TCP session with the specified destination IP address.			
	The no form of the command removes the criterion from the match entry.			
Default	no tcp-syn			
Parameters	true — Specifies matching on IP packets that have the SYN bit set in the control bits of the TCP header.			
	false — Specifies matching on IP packets that do not have the SYN bit set in the control bits of the TCP header.			

MAC Filter Match Criteria

dot1p

Syntax	dot1p ip-value [mask] no dot1p					
Context	config>filter>mac-filter>ei	config>filter>mac-filter>entry				
Description	Configures an IEEE 802.1p value or range to be used as a MAC filter match criterion.					
	When a frame is missing the 802.1p bits, specifying an dot1p match criterion will fail for the frame and result in a non-match for the MAC filter entry.					
	The no form of the comman	nd removes the criterion from the	ne match entry.			
Special Cases	SAP Egress — Egress dot1p value matching will only match if the customer payload contains the 802.1p bits. For example, if a packet ingresses on a null encapsulated SAP and the customer packet is IEEE 802.1Q or 802.1p tagged, the 802.1p bits will be present for a match evaluation. On the other hand, if a customer tagged frame is received on a dot1p encapsulated SAP, the tag will be stripped on ingress and there will be no 802.1p bits for a MAC filter match evaluation; in this case, any filter entry with a dot1p match criterion specified will fail.					
Default	no dot1p					
Parameters	<i>ip-value</i> — The IEEE 802.1p value in decimal.					
	Values $0 - 7$ mask — This 3-bit mask can be configured using the following formats:					
	Format Style Format Syntax Example					
	Decimal	D	4			
	Hexadecimal	0xH	0x4			

To select a range from 4 up to 7 specify *p*-value of 4 and a mask of 0b100 for value and mask.

0b100

0bBBB

Default	7 (decimal)

Values 1 - 7 (decimal)

dsap

Syntaxdsap dsap-value [mask]
no dsapContextconfig>filter>mac-filter>entry>match

7750 SR OS Router Configuration Guide

Binary

Description Configures an Ethernet 802.2 LLC DSAP value or range for a MAC filter match criterion.

This is a one-byte field that is part of the 802.2 LLC header of the IEEE 802.3 Ethernet Frame.

The snap-pid field, etype field, ssap and dsap fields are mutually exclusive and may not be part of the same match criteria. MAC Match Criteria Exclusivity Rules on page 352 describes fields that are exclusive based on the frame format.

Use the **no** form of the command to remove the dsap value as the match criterion.

Default no dsap

Parameters *dsap-value* — The 8-bit dsap match criteria value in hexadecimal.

Values 0x00 - 0xFF (hex)

mask — This is optional and may be used when specifying a range of dsap values to use as the match criteria.

This 8 bit mask can be configured using the following formats:

Format	Style	Format Syntax	Example	
Decimal		DDD	240	
Hexadecimal		0×HH	0xF0	
Binary		0bBBBBBBBB	0b11110000	
Default	FF (hex) (exact match)		
Values	0x00 — 0x	FF		

dst-mac

Syntax	dst-mac ieee-address [mask] no dst-mac			
Context	config>filter>mac-filter>entry			
Description	Configures a destination MAC address or range to be used as a MAC filter match criterion.			
	The no form of the command removes the destination mac address as the match criterion.			
Default	no dst-mac			
Parameters	<i>ieee-address</i> — The MAC address to be used as a match criterion.			
	Values HH:HH:HH:HH:HH:HH or HH-HH-HH-HH-HH where H is a hexadecimal digit			

mask — A 48-bit mask to match a range of MAC address values.

This 48-bit mask can be configured using the following formats:

Format Style	Format Syntax	Example	
Decimal	ססססססססססססס	281474959933440	
Hexadecimal	0хннннннннннн	0xFFFFFF000000	
Binary	0bBBBBBBBB	0b11110000B	

To configure so that all packets with a source MAC OUI value of 00-03-FA are subject to a match condition then the entry should be specified as: 0003FA000000 0x0FFFFF000000

etype

etype ethernet-type no etype
config>filter>mac-filter>entry
Configures an Ethernet type II Ethertype value to be used as a MAC filter match criterion.
The Ethernet type field is a two-byte field used to identify the protocol carried by the Ethernet frame. For example, 0800 is used to identify the IPv4 packets.
The Ethernet type field is used by the Ethernet version-II frames. IEEE 802.3 Ethernet frames do not use the type field. For IEEE 802.3 frames, use the dsap, ssap or snap-pid fields as match criteria.
The snap-pid field, etype field, ssap and dsap fields are mutually exclusive and may not be part of the same match criteria. Table 10, MAC Match Criteria Exclusivity Rules, on page 352 describes fields

	that are exclusive based on the frame format.		
	The no form of the command removes the previously entered etype field as the match criteria.		
Default	no etype		
Parameters	<i>ethernet-type</i> — The Ethernet type II frame Ethertype value to be used as a match criterion expressed in hexadecimal.		
	Values $0x0600 - 0xFFFF$		
isid			
Syntax	isid value value to higher-value no isid		
Context	config>filter>mac-filter>entry>match		
Description	This command configures an ISID value or a range of ISID values to be matched by the mac-filter parent. The pbb-etype value for the related SAP (inherited from the ethernet port configuration) or for the related SDP binding (inherited from SDP configuration) will be used to identify the ISID tag. When an isid statement is used in a match criteria the corresponding mac-filter can be applied only on the egress side of a SAP/SDP binding. In order to be able to use an isid match criteria one needs to set the mac-filter type attribute to isid. Once this configuration is performed only ISID match criteria are allowed in the mac-filter.		
	The no form of this command removes the ISID match criterion.		
Default	no isid		
	<i>value or higher-value</i> — Specifies the ISID value, 24 bits. When just one present identifies a particular ISID to be used for matching.		
	value to higher-value — Identifies a range of ISIDs to be used as matching criteria.		
snap-oui			

Syntax	snap-oui [zero non-zero] no snap-oui
Context	config>filter>mac-filter>entry
Description	This command configures an IEEE 802.3 LLC SNAP Ethernet Frame OUI zero or non-zero value to be used as a MAC filter match criterion.
	The no form of the command removes the criterion from the match criteria.
Default	no snap-oui
Parameters	zero — Specifies to match packets with the three-byte OUI field in the SNAP-ID set to zero.
	non-zero — Specifies to match packets with the three-byte OUI field in the SNAP-ID not set to zero.

snap-pid

Syntax	snap-pid <i>pid-value</i> no snap-pid
Context	config>filter>mac-filter>entry
Description	Configures an IEEE 802.3 LLC SNAP Ethernet Frame PID value to be used as a MAC filter match criterion.
	This is a two-byte protocol id that is part of the IEEE 802.3 LLC SNAP Ethernet Frame that follows the three-byte OUI field.
	The snap-pid field, etype field, ssap and dsap fields are mutually exclusive and may not be part of the same match criteria. MAC Match Criteria Exclusivity Rules on page 352 describes fields that are exclusive based on the frame format.
	Note: The snap-pid match criterion is independent of the OUI field within the SNAP header. Two packets with different three-byte OUI fields but the same PID field will both match the same filter entry based on a snap-pid match criteria.
	The no form of the command removes the snap-pid value as the match criteria.
Default	no snap-pid
Parameters	pid-value — The two-byte snap-pid value to be used as a match criterion in hexadecimal.
	Values 0x0000 — 0xFFFF

src-mac

Syntax	<pre>src-mac ieee-address [ieee-address-mask] no src-mac</pre>		
Context	config>filter>mac-filter>entry		
Description	Configures a source MAC address or range to be used as a MAC filter match criterion.		
	The no form of the command removes the source mac as the match criteria.		
Default	no src-mac		
Parameters	<i>ieee-address</i> — Enter the 48-bit IEEE mac address to be used as a match criterion.		
	Values HH:HH:HH:HH:HH or HH-HH-HH-HH-HH where H is a hexadecimal digit		

ieee-address-mask — This 48-bit mask can be configured using:

Format Style	Format Syntax	Example	
Decimal	ססססססססססססססס	281474959933440	
Hexadecimal	0хННННННННННН	0x0FFFFF000000	

Format	Style Format Syntax	Example	
Binary	0bBBBBBBBB	0b11110000B	
U	e so that all packets with a source MA ition then the entry should be specified	C OUI value of 00-03-FA are subject to as: 003FA000000 0xFFFFFF000000	a
Default	0xFFFFFFFFFFFFF (exact match)		
Values	0x0000000000000 — 0xFFFFFFF	FFFF	

ssap

Syntax	ssap ssap-value [ssap-mask] no ssap			
Context	config>filter>mac-filter>entry			
Description	This command c criterion.	configures an Ethe	ernet 802.2 LLC SSAI	P value or range for a MAC filter match
	This is a one-by	te field that is par	t of the 802.2 LLC hea	ader of the IEEE 802.3 Ethernet Frame.
	same match crite	• •	Criteria Exclusivity R	nutually exclusive and may not be part of the cules on page 352 describes fields that are
	The no form of	the command rem	oves the ssap match c	riterion.
Default	no ssap			
Parameters	ssap-value — The 8-bit ssap match criteria value in hex.			ζ.
	Values	0x00 — 0xFF		
	<i>ssap-mask</i> — This is optional and may be used when specifying a range of ssap values to use as the match criteria.			
	This 8 bit mask can be configured using the following formats:			
	Format Style Format Syntax Example			
	Decimal	•	DDD	240
	Hexadecimal		0×HH	0×F0
	Binary		0bBBBBBBBB	0b11110000
	Default	none		
	Values	0x00 — 0xFF		

Policy and Entry Maintenance Commands

сору

Syntax	copy {ip-filter ipv6-filter mac-filter} source-filter-id dest-filter-id dest-filter-id [overwrite]		
Context	config>filter		
Description	This command copies existing filter list entries for a specific filter ID to another filter ID. The copy command is a configuration level maintenance tool used to create new filters using existing filters. It also allows bulk modifications to an existing policy with the use of the overwrite keyword. If overwrite is not specified, an error will occur if the destination policy ID exists.		
Parameters	ip-filter — Indicates that the <i>source-filter-id</i> and the <i>dest-filter-id</i> are IP filter IDs.		
	ipv6-filter — This keyword indicates that the <i>source-filter-id</i> and the <i>dest-filter-id</i> are IPv6 filter IDs.		
	mac-filter — Indicates that the <i>source-filter-id</i> and the <i>dest-filter-id</i> are MAC filter IDs.		
	source-filter-id — The source-filter-id identifies the source filter policy from which the copy command will attempt to copy. The filter policy must exist within the context of the preceding keyword (ip-filter, ipv6-filter or mac-filter).		
	<i>dest-filter-id</i> — The <i>dest-filter-id</i> identifies the destination filter policy to which the copy command will attempt to copy. If the overwrite keyword does not follow, the filter policy ID cannot already exist within the system for the filter type the copy command is issued for. If the overwrite keyword is present, the destination policy ID may or may not exist.		
	overwrite — The overwrite keyword specifies that the destination filter ID may exist. If it does, everything in the existing destination filter ID will be completely overwritten with the contents of the source filter ID. If the destination filter ID exists, either overwrite must be specified or an error message will be returned. If overwrite is specified, the function of copying from source to destination occurs in a 'break before make' manner and therefore should be handled with care.		
renum			
Syntax	renum old-entry-id new-entry-id		
Context	config>filter>ip-filter config>filter>ipv6-filter config>filter>mac-filter		
Description	This command renumbers existing MAC or IP filter entries to properly sequence filter entries. This may be required in some cases since the OS exits when the first match is found and executes the actions according to the accompanying action command. This requires that entries be sequenced correctly from most to least explicit.		

Parameters *old-entry-id* — Enter the entry number of an existing entry.

Values 1 — 65535

 $\mathit{new-entry-id}$ — Enter the new entry-number to be assigned to the old entry.

Values 1 – 65535

Redirect Policy Commands

destination

Syntax	[no] destination ip-address	
Context	config>filter>redirect-policy	
Description	This command defines a cache server destination in a redirect policy. More than one destination can be configured. Whether a destination IP address will receive redirected packets depends on the effective priority value after evaluation.	
Default	none	
Parameters	<i>ip-address</i> — Specifies the IP address to send the redirected traffic.	

ping-test

Syntax	[no] ping-test	
Context	config>filter>destination>ping-test config>filter>destination>snmp-test	
Description	This command configures parameters to perform connectivity ping tests to validate the ability for the destination to receive redirected traffic.	
Default	none	

drop-count

Syntax	drop-count consecutive-failures [hold-down seconds] no drop-count	
Context	config>filter>destination>ping-test config>filter>destination>snmp-test config>filter>destination>url-test	
Description	This command specifies the number of consecutive requests that must fail for the destination to be declared unreachable.	
Default	drop-count 3 hold-down 0	
Parameters	<i>consecutive-failures</i> — Specifies the number of consecutive ping test failures before declaring the destination down.	
	Values 1 – 60	

hold-down *seconds* — The amount of time, in seconds, that the system should be held down if any of the test has marked it unreachable.

Values 0 — 86400

interval

Syntax	interval seconds no interval	
Context	config>filter>destination>ping-test config>filter>destination>snmp-test config>filter>destination>url-test	
Description	This command specifies the amount of time, in seconds, between consecutive requests sent to the far end host.	
Default	1	
Parameters	<i>seconds</i> — Specifies the amount of time, in seconds, between consecutive requests sent to the far end host.	
	Values 1 — 60	

timeout

Syntax	timeout seconds no timeout	
Context	config>filter>destination>snmp-test config>filter>destination>url-test	
Description	Specifies the amount of time, in seconds, that is allowed for receiving a response from the far-end host. If a reply is not received within this time the far-end host is considered unresponsive.	
Default	1	
Parameters	<i>seconds</i> — Specifies the amount of time, in seconds, that is allowed for receiving a response from the far end host.	
	Values 1 – 60	

priority

Syntax	priority priority no priority
Context	config>filter>destination

Description	Redirect policies can contain multiple destinations. Each destination is assigned an initial or base priority which describes its relative importance within the policy. If more than one destination is specified, the destination with the highest effective priority value is selected.	
Default	100	
Parameters	<i>priority</i> — The priority, expressed as a decimal integer, used to weigh the destination's rela importance within the policy.	
	Values 1 – 255	

snmp-test

Syntax	snmp-test test-name		
Context	config>filter>redirect-policy>destination		
Description	This command enables the context to configure SNMP test parameters.		
Default	none		
Parameters	<i>test-name</i> — specifies the name of the SNMP test. Allowed values are any string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.		

oid

Syntax	oid oid-string community community-string	
Context	config>filter>redirect-policy>destination>snmp-test	
Description	This command specifies the OID of the object to be fetched from the destination.	
Default	none	
Parameters	oid-string — Specifies the object identifier (OID) in the OID field.	
	community <i>community-string</i> — The SNMP v2 community string or the SNMP v3 context nam used to conduct this SNMP test.	

return-value

Syntax	return-value return-value type return-type [disable lower-priority priority raise-priority priority]	
Context	config>filter>redirect-policy>destination>snmp-test	
Description	This command specifies the criterion to adjust the priority based on the test result. Multiple criteria can be specified with the condition that they are not conflicting or overlap. If the returned value is	

	within the speci	fied range, the priority can be disabled, lowered or raised.
Default	none	
Parameters	return-value — Specifies the SNMP value against which the test result is matched.	
	Values	A maximum of 256 characters.
	return-type — Specifies the SNMP object type against which the test result is matched.	
	Values	integer, unsigned, string, ip-address, counter, time-ticks, opaque
	disable — The keyword that specifies that the destination may not be used for the amount of time specified in the hold-time command when the test result matches the criterion.	
	lower-priority _l	priority — Specifies the amount to lower the priority of the destination.
	Values	1 — 255
	raise-priority p	<i>riority</i> — Specifies the amount to raise the priority of the destination.
	Values	1 — 255

url-test

Syntax	url-test test-name	
Context	config>filter>redirect-policy>destination	
Description	The context to enable URL test parameters. IP filters can be used to selectively cache some web sites.	
Default	none	
Parameters	test-name — The name of the URL test. Allowed values are any string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.	

return-code

Syntaxreturn-code return-code-1 [return-code-2] [disable | lower-priority priority | raise-priority
priority]
no return-code return-code-1 [return-code-2]Contextconfig>filter>redirect-policy>destination>url-testDescriptionReturn codes are returned when the URL test is performed. Values for the specified range are the
return codes which can be given back to the system as a result of the test been performed.
For example, error code 401 for HTTP is "page not found." If, while performing this test, the URL is
not reachable, you can lower the priority by 10 points so that other means of reaching this destination
are prioritized higher than the older one.

Default	none	
Parameters	<i>return-code-1, return-code-2</i> — Specifies a range of return codes. When the URL test return-code falls within the specified range, the corresponding action is performed.	
	Values return-code-1: 1 — 4294967294 return-code-2: 2 — 4294967295	
	disable — Specifies that the destination may not be used for the amount of time specified in the hold-time command when the return code falls within the specified range.	
	lower-priority <i>priority</i> — Specifies the amount to lower the priority of the destination when the return code falls within the specified range.	
	raise-priority <i>priority</i> — Specifies the amount to raise the priority of the destination when the return code falls within the specified range.	
Syntax	url url-string [http-version version-string]	
Context	config>filter>redirect-policy>destination>url-test	

- **Description** This command specifies the URL to be probed by the URL test.
 - Default none

url

Parameters *url-string* — Specify a URL up to 255 characters in length.

http-version version-string — Specifies the HTTP version, 80 characters in length.

Redirect Policy Commands

Show Commands

download-failed

Syntax	download-failed
Context	show>filter
Description	This command shows all filter entries for which the download has failed.
Output	download-failed Output — The following table describes the filter download-failed output.

Label	Description
Filter-type	Displays the filter type.
Filter-ID	Displays the ID of the filter.
Filter-Entry	Displays the entry number of the filter.

Sample Output

```
A:ALA-48# show filter download-failed

Filter entries for which download failed

Filter-type Filter-Id Filter-Entry

ip 1 10

A:ALA-48#
```

ip

Syntax	ip [ip-filter-id] [entry entry-id] [association counters]	
Context	show>filter	
Description	This command shows IP filter information.	
Parameters	<i>ip-filter-id</i> — Displays detailed information for the specified filter ID and its filter entries.	
	Values 1 — 65535	
	entry entry-id — Displays information on the specified filter entry ID for the specified filter ID only.	
	Values 1 — 65535	
	associations — Appends information as to where the filter policy ID is applied to the detailed filter policy ID output.	

7750 SR OS Router Configuration Guide

- **counters** Displays counter information for the specified filter ID. Note that egress counters count the packets without Layer 2 encapsulation. Ingress counters count the packets with Layer 2 encapsulation.
- **Output** Show Filter (no filter-id specified) The following table describes the command output for the command when no filter ID is specified.

Label	Description
Filter Id	The IP filter ID
Scope	Template – The filter policy is of type template.
	Exclusive – The filter policy is of type exclusive.
Applied	No - The filter policy ID has not been applied.
	Yes – The filter policy ID is applied.
Description	The IP filter policy description.

```
A:ALA-49# show filter ip
```

```
IP Filters

Filter-Id Scope Applied Description

1 Template Yes

3 Template Yes

6 Template Yes

10 Template No

11 Template No

11 Template No

A:ALA-49#
```

Output Show Filter (with filter-id specified) — The following table describes the command output for the command when a filter ID is specified.

Label	Description
Filter Id	The IP filter policy ID.
Scope	Template – The filter policy is of type template.
	Exclusive – The filter policy is of type exclusive.
Entries	The number of entries configured in this filter ID.
Description	The IP filter policy description.

Label	Description (Continued)
Applied	No – The filter policy ID has not been applied.
	Yes $-$ The filter policy ID is applied.
Def. Action	Forward – The default action for the filter ID for packets that do not match the filter entries is to forward.
	Drop – The default action for the filter ID for packets that do not match the filter entries is to drop.
Filter Match Criteria	IP – Indicates the filter is an IP filter policy.
Entry	The filter ID filter entry ID. If the filter entry ID indicates the entry is (Inactive), then the filter entry is incomplete as no action has been specified.
Log Id	The filter log ID.
Src. IP	The source IPv6 address and prefix length match criterion.
Dest. IP	The destination IPv6 address and prefix length match criterion.
Next-header	The next header ID for the match criteria. Undefined indicates no next-header specified.
ІСМР Туре	The ICMP type match criterion. Undefined indicates no ICMP type specified.
Fragment	Off – Configures a match on all non-fragmented IP packets.
	On – Configures a match on all fragmented IP packets.
Sampling	Off – Specifies that traffic sampling is disabled.
	On - Specifies that traffic matching the associated IP filter entry is sampled.
IP-Option	Specifies matching packets with a specific IP option or a range of IP options in the IP header for IP filter match criteria.
TCP-syn	Off – Specifies that the SYN bit is disabled.
	On – Specifies that the SYN bit is set.
Match action	Default – The filter does not have an explicit forward or drop match action specified. If the filter entry ID indicates the entry is Inactive, the filter entry is incomplete, no action was specified.
	Drop – Drop packets matching the filter entry.
	Forward – The explicit action to perform is forwarding of the packet.
Ing. Matches	The number of ingress filter matches/hits for the filter entry.

Label	Description (Continued)
Src. Port	The source TCP or UDP port number or port range.
Dest. Port	The destination TCP or UDP port number or port rangee.
Dscp	The DiffServ Code Point (DSCP) name.
ICMP Code	The ICMP code field in the ICMP header of an IP packet.
Option-present	Off – Specifies not to search for packets that contain the option field or have an option field of zero.
	On - Matches packets that contain the option field or have an option field of zero be used as IP filter match criteria.
Int. Sampling	Off – Interface traffic sampling is disabled.
	On – Interface traffic sampling is enabled.
Multiple Option	Off – The option fields are not checked.
	On - Packets containing one or more option fields in the IP header will be used as IP filter match criteria.
TCP-ack	Off – No matching of the ACK bit.
	On - Matches the ACK bit being set or reset in the control bits of the TCP header of an IP packet.
Egr. Matches	The number of egress filter matches/hits for the filter entry.

A:ALA-49>config>filter# show filter ip 3			
IP Filter			
Filter Id	: 3	Applied	: Yes
Scope	: Template	Def. Action	: Drop
Entries	: 1		
Filter Match	Criteria : IP		
Entry	: 10		
Log Id	: n/a		
Src. IP	: 10.1.1.1/24	Src. Port	: None
Dest. IP	: 0.0.0.0/0	Dest. Port	: None
Protocol	: 2	Dscp	: Undefined
ІСМР Туре	: Undefined	ICMP Code	: Undefined
TCP-syn	: Off	TCP-ack	: Off
Match action	: Drop		
Ing. Matches	: 0	Egr. Matches	: 0
A:ALA-49>config>filter#			

A:ALA-49# show filter ip 10			
IP Filter			
Filter Id	: 10	Applied	: No
Scope		Def. Action	: Drop
Entries	: 2		
Filter Match	Criteria : IP		
Entry			
time-range	: day	Cur. Status	: Inactive
Log Id	: n/a		
Src. IP		Src. Port	
Dest. IP	: 10.10.100.1/24	Dest. Port	: None
Protocol	: Undefined		: Undefine
ICMP Type	: Undefined	ICMP Code	: Undefine
Fragment		Option-present	: Off
Sampling IP-Option	: Off	Int. Sampling	: On
IP-Option	: 0/0	Multiple Optior	n: Off
TCP-syn	: Off	TCP-ack	: Off
Match action	: Forward		
Next Hop	: 138.203.228.28		
Ing. Matches	: 0	Egr. Matches	: 0
Entry			
time-range	-	Cur. Status	: Active
Log Id			
Src. IP	: 0.0.0.0/0 : 10.10.1.1/16	Src. Port Dest. Port	: None
		Dest. Port	: None
Protocol	: Undefined	Dscp	: Undefine
ІСМР Туре	: Undefined	ICMP Code	: Undefine
Fragment	: Off	Option-present	: Off
Sampling	: Off	Int. Sampling	: On
IP-Option	: 0/0	Multiple Optior	n: Off
TCP-syn	: Off	TCP-ack	: Off
Match action	: Forward		
Next Hop	: 172.22.184.101		
Ing. Matches	: 0	Eqr. Matches	: 0

Output Show Filter (with time-range specified) — If a time-range is specified for a filter entry, it is **Output** Show Filter Associations — The following table describes the fields that display when the associations keyword is specified.

Label	Description
Filter Id	The IP filter policy ID.
Scope	Template - The filter policy is of type Template.
	Exclusive – The filter policy is of type Exclusive.
Entries	The number of entries configured in this filter ID.
Applied	No - The filter policy ID has not been applied.
	Yes – The filter policy ID is applied.
Def. Action	Forward $-$ The default action for the filter ID for packets that do not match the filter entries is to forward.
	Drop – The default action for the filter ID for packets that do not match the filter entries is to drop.
Service Id	The service ID on which the filter policy ID is applied.
SAP	The Service Access Point on which the filter policy ID is applied.
(Ingress)	The filter policy ID is applied as an ingress filter policy on the inter- face.
(Egress)	The filter policy ID is applied as an egress filter policy on the interface.
Туре	The type of service of the service ID.
Entry	The filter ID filter entry ID. If the filter entry ID indicates the entry is Inactive, the filter entry is incomplete as no action was specified.
Log Id	The filter log ID.
Src. IP	The source IP address and mask match criterion. 0.0.0/0 indicates no criterion specified for the filter entry.
Dest. IP	The destination IP address and mask match criterion. 0.0.0/0 indi- cates no criterion specified for the filter entry.
Protocol	The protocol ID for the match criteria. Undefined indicates no proto- col specified.
ІСМР Туре	The ICMP type match criterion. Undefined indicates no ICMP type specified.
Fragment	Off – Configures a match on all non-fragmented IP packets.
	On – Configures a match on all fragmented IP packets.

Label	Description (Continued)
Sampling	Off – Specifies that traffic sampling is disabled.
	On - Specifies that traffic matching the associated IP filter entry is sampled.
IP-Option	Specifies matching packets with a specific IP option or a range of IP options in the IP header for IP filter match criteria.
TCP-syn	Off – Specifies that the SYN bit is disabled.
	On – Specifies that the SYN bit is set.
Match action	Default – The filter does not have an explicit forward or drop match action specified. If the filter entry ID indicates the entry is Inactive, the filter entry is incomplete (no action was specified).
	Drop – Drop packets matching the filter entry.
	Forward – The explicit action to perform is forwarding of the packet. If the action is Forward, then if configured the nexthop information should be displayed, including Nexthop: <ip address="">, Indirect: <ip address=""> or Interface: <ip interface="" name="">.</ip></ip></ip>
Ing. Matches	The number of ingress filter matches/hits for the filter entry.
Src. Port	The source TCP or UDP port number or port range.
Dest. Port	The destination TCP or UDP port number or port range.
Dscp	The DiffServ Code Point (DSCP) name.
ICMP Code	The ICMP code field in the ICMP header of an IP packet.
Option-present	Off - Specifies not to search for packets that contain the option field or have an option field of zero.
	On - Matches packets that contain the option field or have an option field of zero be used as IP filter match criteria.
Int. Sampling	Off – Interface traffic sampling is disabled.
	On – Interface traffic sampling is enabled.
Multiple Option	Off – The option fields are not checked.
	On - Packets containing one or more option fields in the IP header will be used as IP filter match criteria.
TCP-ack	Off – No matching of the ACK bit.
	On - Matches the ACK bit being set or reset in the control bits of the TCP header of an IP packet.
Egr. Matches	The number of egress filter matches/hits for the filter entry.

```
A:ALA-49# show filter ip 1 associations
_____
IP Filter
_____
Filter Id : 1
                         Applied : Yes
Scope : Template
Entries : 1
                         Def. Action : Drop
_____
Filter Association : IP
------
           -----
Service Id : 1001
                         Туре
                                 : VPLS
- SAP 1/1/1:1001 (Ingress)
Service Id : 2000
                         Type : IES
- SAP 1/1/1:2000 (Ingress)
_____
Filter Match Criteria : IP
_____
      : 10
Entrv
Log Id
      : n/a
Src. IP
      : 10.1.1.1/24
                         Src. Port
                                 : None
Dest. IP
                         Dest. Port
      : 0.0.0.0/0
                                 : None
Protocol
                         Dscp
                                 : Undefined
      : 2
                         ICMP Code : Undefined
ICMP Type : Undefined
Fragment : Off
                         Option-present : Off
Sampling
      : Off
                         Int. Sampling : On
IP-Option : 0/0
                         Multiple Option: Off
TCP-syn : Off
                         TCP-ack : Off
Match action : Drop
Ing. Matches : 0
                         Egr. Matches : 0
A:ALA-49#
```

Output Show Filter Associations (with TOD-suite specified) — If a filter is referred to in a TOD Suite assignment, it is displayed in the show filter associations command output:

```
A:ALA-49# show filter ip 160 associations
_____
TP Filter
_____
                  Applied : No
Filter Id : 160
   : Template
                   Def. Action : Drop
Scope
Entries
    : 0
        _____
Filter Association : IP
_____
Tod-suite "english_suite"
- ingress, time-range "day" (priority 5)
A:ALA-49#
```

Label	Description
IP Filter Filter Id	The IP filter policy ID.
Scope	Template – The filter policy is of type Template.
	Exclusive – The filter policy is of type Exclusive.
Applied	NO - The filter policy ID has not been applied.
	Yes – The filter policy ID is applied.
Def. Action	Forward $-$ The default action for the filter ID for packets that do not match the filter entries is to forward.
	Drop – The default action for the filter ID for packets that do not match the filter entries is to drop.
Filter Match Criteria	IP - Indicates the filter is an IP filter policy.
Entry	The filter ID filter entry ID. If the filter entry ID indicates the entry is (Inactive), then the filter entry is incomplete as no action has been specified.
Ing. Matches	The number of ingress filter matches/hits for the filter entry.
Egr. Matches	The number of egress filter matches/hits for the filter entry.
	Note that egress counters count the packets without Layer 2 encapsula- tion. Ingress counters count the packets with Layer 2 encapsulation.

Output Show Filter Counters — The following table describes the output fields when the counters keyword is specified..

Sample Output

*A:ALA-48# show filter ipv6 100 counters			
IPv6 Filter			
Filter Id	: 100	Applied	: No
Scope	: Template	Def. Action	: Forward
Entries	: 1		
Description	Description : IPv6 filter configuration		
Filter Match Criteria : IPv6			
Entry	: 10		
Ing. Matches	: 9788619 pkts (978861900 bytes)		
Egr. Matches	: 9788619 pkts (978861900 bytes)		
*A:ALA-48#			

ipv6

Syntax	ipv6 {ipv6-filter-id [entry entry-id] [association counters]}
Context	show>filter
Description	This command shows IPv6 filter information.
Parameters	<i>ipv6-filter-id</i> — Displays detailed information for the specified IPv6 filter ID and filter entries.
	Values 1 — 65535
	entry entry-id — Displays information on the specified IPv6 filter entry ID for the specified filter ID.
	Values 1 — 9999
	associations — Appends information as to where the IPv6 filter policy ID is applied to the detailed filter policy ID output.
	counters — Displays counter information for the specified IPv6 filter ID. Note that egress counters count the packets without Layer 2 encapsulation. Ingress counters count the packets with Layer 2 encapsulation.

Output Show Filter (no filter-id specified) — The following table describes the command output for the command when no filter ID is specified.

Label	Description
Filter Id	The IP filter ID
Scope	Template – The filter policy is of type template.
	Exclusive – The filter policy is of type exclusive.
Applied	No – The filter policy ID has not been applied.
	Yes – The filter policy ID is applied.
Description	The IP filter policy description.

Sample Output

A:ALA-48# show filter ipv6			
IP Filter	s		
Filter-Id	Scope	Applied	Description
100	Template	Yes	test
200	Exclusive	Yes	
Num IPv6 filters: 2			
A:ALA-48#			

Output Show Filter (with filter-id specified) — The following table describes the command output for the command when a filter ID is specified.

Label	Description
Filter Id	The IP filter policy ID.
Scope	Template – The filter policy is of type template.
	Exclusive – The filter policy is of type exclusive.
Entries	The number of entries configured in this filter ID.
Description	The IP filter policy description.
Applied	No - The filter policy ID has not been applied.
	Yes $-$ The filter policy ID is applied.
Def. Action	Forward $-$ The default action for the filter ID for packets that do not match the filter entries is to forward.
	Drop – The default action for the filter ID for packets that do not match the filter entries is to drop.
Filter Match Criteria	IP – Indicates the filter is an IP filter policy.
Entry	The filter ID filter entry ID. If the filter entry ID indicates the entry is (Inactive), then the filter entry is incomplete as no action has been specified.
Log Id	The filter log ID.
Src. IP	The source IP address and mask match criterion. 0.0.0.0/0 indicates no criterion specified for the filter entry.
Dest. IP	The destination IP address and mask match criterion. 0.0.0/0 indi- cates no criterion specified for the filter entry.
Protocol	The protocol ID for the match criteria. Undefined indicates no proto- col specified.
ІСМР Туре	The ICMP type match criterion. Undefined indicates no ICMP type specified.
Fragment	Off – Configures a match on all non-fragmented IP packets.
	On – Configures a match on all fragmented IP packets.
Sampling	Off – Specifies that traffic sampling is disabled.
	On – Specifies that traffic matching the associated IP filter entry is sampled.

Label	Description (Continued)
IP-Option	Specifies matching packets with a specific IP option or a range of IP options in the IP header for IP filter match criteria.
TCP-syn	Off – Specifies that the SYN bit is disabled.
	On – Specifies that the SYN bit is set.
Match action	Default — The filter does not have an explicit forward or drop match action specified. If the filter entry ID indicates the entry is (Inactive), then the filter entry is incomplete as no action has been specified.
	Drop – Drop packets matching the filter entry.
	Forward – The explicit action to perform is forwarding of the packet. If the action is Forward, then if configured the nexthop information should be displayed, including Nexthop: <ip address="">, Indirect: <ip address=""> or Interface: <ip interface="" name="">.</ip></ip></ip>
Ing. Matches	The number of ingress filter matches/hits for the filter entry.
Src. Port	The source TCP or UDP port number or port range.
Dest. Port	The destination TCP or UDP port number or port range.
Dscp	The DiffServ Code Point (DSCP) name.
ICMP Code	The ICMP code field in the ICMP header of an IP packet.
Option-present	Off - Specifies not to search for packets that contain the option field or have an option field of zero.
	On - Matches packets that contain the option field or have an option field of zero be used as IP filter match criteria.
Int. Sampling	Off – Interface traffic sampling is disabled.
	On – Interface traffic sampling is enabled.
Multiple Option	Off – The option fields are not checked.
	On - Packets containing one or more option fields in the IP header will be used as IP filter match criteria.
TCP-ack	Off – No matching of the ACK bit.
	On - Matches the ACK bit being set or reset in the control bits of the TCP header of an IP packet.
Egr. Matches	The number of egress filter matches/hits for the filter entry.

```
A:ALA-48# show filter ipv6 100
_____
IPv6 Filter
_____
Filter Id : 100
                            Applied : Yes
Scope : Template
Entries : 1
                            Def. Action : Forward
Description : test
_____
Filter Match Criteria : IPv6
_____
Entry : 10
Log Id : 101
Src. IP : ::/0
Dest. IP : ::/0
                            Src. Port : None
Dest. Port : None
                         Dscp : Undefined
ICMP Code : Undefined
TCP-ack : Off
Next Header : Undefined
ICMP Type : Undefined
TCP-syn : Off
Match action : Drop
Ing. Matches : 0
                            Egr. Matches : 0
_____
A:ALA-48#
```

Output Show Filter Associations — The following table describes the fields that display when the associations keyword is specified.

Label	Description
Filter Id	The IPv6 filter policy ID.
Scope	Template – The filter policy is of type Template.
	Exclusive – The filter policy is of type Exclusive.
Entries	The number of entries configured in this filter ID.
Applied	No – The filter policy ID has not been applied.
	Yes $-$ The filter policy ID is applied.
Def. Action	Forward – The default action for the filter ID for packets that do not match the filter entries is to forward.
	Drop – The default action for the filter ID for packets that do not match the filter entries is to drop.
Service Id	The service ID on which the filter policy ID is applied.
SAP	The Service Access Point on which the filter policy ID is applied.
(Ingress)	The filter policy ID is applied as an ingress filter policy on the inter- face.
(Egress)	The filter policy ID is applied as an egress filter policy on the interface.

Label	Description (Continued)
Туре	The type of service of the service ID.
Entry	The filter ID filter entry ID. If the filter entry ID indicates the entry is Inactive, the filter entry is incomplete, no action was specified.
Log Id	The filter log ID.
Src. IP	The source IP address and mask match criterion. 0.0.0.0/0 indicates no criterion specified for the filter entry.
Dest. IP	The destination IP address and mask match criterion. 0.0.0.0/0 indi- cates no criterion specified for the filter entry.
Protocol	The protocol ID for the match criteria. Undefined indicates no proto- col specified.
ІСМР Туре	The ICMP type match criterion. Undefined indicates no ICMP type specified.
Fragment	Off – Configures a match on all non-fragmented IP packets.
	On – Configures a match on all fragmented IP packets.
Sampling	Off – Specifies that traffic sampling is disabled.
	On - Specifies that traffic matching the associated IP filter entry is sampled.
IP-Option	Specifies matching packets with a specific IP option or a range of IP options in the IP header for IP filter match criteria.
TCP-syn	Off – Specifies that the SYN bit is disabled.
	On – Specifies that the SYN bit is set.
Match action	Default – The filter does not have an explicit forward or drop match action specified. If the filter entry ID indicates the entry is Inactive, the filter entry is incomplete, no action was specified.
	Drop – Drop packets matching the filter entry.
	Forward – The explicit action to perform is forwarding of the packet. If the action is Forward, then if configured the nexthop information should be displayed, including Nexthop: <ip address="">, Indirect: <ip address=""> or Interface: <ip interface="" name="">.</ip></ip></ip>
Ing. Matches	The number of ingress filter matches/hits for the filter entry.
Src. Port	The source TCP or UDP port number or port range.
Dest. Port	The destination TCP or UDP port number or port range.
Dscp	The DiffServ Code Point (DSCP) name.

Label	Description (Continued)
ICMP Code	The ICMP code field in the ICMP header of an IP packet.
Option-present	Off - Specifies not to search for packets that contain the option field or have an option field of zero.
	On - Matches packets that contain the option field or have an option field of zero be used as IP filter match criteria.
Int. Sampling	Off – Interface traffic sampling is disabled.
	On – Interface traffic sampling is enabled.
Multiple Option	Off – The option fields are not checked.
	On - Packets containing one or more option fields in the IP header will be used as IP filter match criteria.
TCP-ack	Off – No matching of the ACK bit.
	On - Matches the ACK bit being set or reset in the control bits of the TCP header of an IP packet.
Egr. Matches	The number of egress filter matches/hits for the filter entry.

A:ALA-48# show filter ipv6 1 associations			
IPv6 Filter			
Filter Id : 1 Scope : Template Entries : 1	Applied Def. Action	: Drop	
Filter Association : IPv6			
Service Id : 2000 Type : IES - SAP 1/1/1:2000 (Ingress)			
Filter Match Criteria : IPv6			
Entry : 10 Log Id : 101 Src. IP : ::/0 Dest. IP : ::/0 Next Header : Undefined ICMP Type : Undefined	Src. Port Dest. Port Dscp ICMP Code	: None : None : Undefined : Undefined	
TCP-syn : Off Match action : Drop Ing. Matches : 0	TCP-ack Egr. Matches		
 A:ALA-48#	-		

7750 SR OS Router Configuration Guide

Output Show Filter Counters — The following table describes the output fields when the counters keyword is specified..

Label	Description
IP Filter Filter Id	The IP filter policy ID.
Scope	Template – The filter policy is of type template.
	Exclusive – The filter policy is of type exclusive.
Applied	No – The filter policy ID has not been applied.
	Yes $-$ The filter policy ID is applied.
Def. Action	Forward $-$ The default action for the filter ID for packets that do not match the filter entries is to forward.
	Drop – The default action for the filter ID for packets that do not match the filter entries is to drop.
Filter Match Criteria	IP – Indicates the filter is an IP filter policy.
Entry	The filter ID filter entry ID. If the filter entry ID indicates the entry is (Inactive), then the filter entry is incomplete as no action has been specified.
Ing. Matches	The number of ingress filter matches/hits for the filter entry.
Egr. Matches	The number of egress filter matches/hits for the filter entry.
	Note that egress counters count the packets without Layer 2 encapsulation. Ingress counters count the packets with Layer 2 encapsulation.

Sample Output

```
A:ALA-48# show filter ipv6 8 counters
_____
IPv6 Filter
_____
Filter Id : 8
                  Applied : Yes
Scope : Template
Entries : 4
                     Def. Action : Forward
Description : Description for Ipv6 Filter Policy id # 8
Filter Match Criteria : IPv6
_____
Entry
    : 5
Ing. Matches : 0 pkts
Egr. Matches : 0 pkts
```

7750 SR OS Router Configuration Guide

log

Syntax	log log-id [match string] [bindings]	
Context	show>filter	
Description	This command shows the contents of a memory-based or a file-based filter log.	
	If the optional keyword match and <i>string</i> parameter are given, the command displays the given filter log from the first occurence of the given string.	
Parameters	log-id — The filter log ID destination expressed as a decimal integer.	
	Values 101 — 199	
	match string — Specifies to start displaying the filter log entries from the first occurence of string.	
	bindings — Displays the number of filter logs currently instantiated.	
Output	Log Message Formatting — Each filter log entry contains the following information in case summary log feature is not active (as appropriate).	

Label	Description
yyyy/mm/dd hh:mm:ss	The date and timestamp for the log filter entry where <i>yyyy</i> is the year, <i>mm</i> is the month, <i>dd</i> is the day, <i>hh</i> is the hour, <i>mm</i> is the minute and <i>ss</i> is the second.
Filter	The filter ID and the entry ID which generated the filter log entry in the form <i>Filter_ID</i> : <i>Entry_ID</i> .
Desc	The description of the filter entry ID which generated the filter log entry.
Interface	The IP interface on which the filter ID and entry ID was associated which generated the filter log entry.
Action	The action of the filter entry on the logged packet.

Label	Description (Continued)
Src MAC	The source MAC address of the logged packet.
Dst MAC	The destination MAC of the logged packet.
EtherType	The Ethernet type of the logged Ethernet type II packet.
Src IP	The source IP address of the logged packet. The source port will be displayed after the IP address as appropriate separated with a colon.
Dst IP	The destination IP address of the logged packet. The source port will be displayed after the IP address as appropriate separated with a colon.
Flags (IP flags)	M – The more fragments IP flag is set in the logged packet. DF – The do not fragment IP flag is set in the logged packet.
TOS	The TOS byte value in the logged packet.
Protocol	The IP protocol of the logged packet (TCP, UDP, ICMP or a protocol number in hex).
Flags (TCP flags)	 URG – Urgent bit set. ACK – Acknowledgement bit set. RST – Reset bit set. SYN – Synchronize bit set. FIN – Finish bit set.
HEX	If an IP protocol does not have a supported decode, the first 32 bytes following the IP header are printed in a hex dump. Log entries for non-IP packets include the Ethernet frame information and a hex dump of the first 40 bytes of the frame after the Ethernet header.
Total Log Instances (Allowed)	Specifies the maximum allowed instances of filter logs allowed on the system.
Total Log Instances (In Use)	Specifies the instances of filter logs presently existing on the system.
Total Log Bindings	Specifies the count of the filter log bindings presently existing on the system.
Туре	The type of service of the service ID.
Filter ID	Uniquely identifies an IP filter as configured on the system.
Entry ID	The identifier which uniquely identifies an entry in a filter table.
Log	Specifies an entry in the filter log table.
Instantiated	Specifies if the filter log for this filter entry has or has not been instan- tiated.

If the packet being logged does not have a source or destination MAC address (i.e., POS) then the MAC information output line is omitted from the log entry.

In case log summary is active, the filter log mini-tables contain the following information..

Label	Description
Summary Log LogID	Displays the log ID.
Crit1	Summary criterion that is used as index into the mini-tables of the log.
TotCnt	The total count of logs.
ArpCnt	Displays the total number of ARP messages logged for this log ID.
Src Dst	The address type indication of the key in the mini-table.
count	The number of messages logged with the specified source/destination address.
address	The address for which count messages where received.

Sample Filter Log Output

2007/04/13 16:23:09 Filter: 100:100 Desc: Entry-100 Interface: to-ser1 Action: Forward Src MAC: 04-5b-01-01-00-02 Dst MAC: 04-5d-01-01-00-02 EtherType: 0800 Src IP: 10.10.0.1:646 Dst IP: 10.10.0.4:49509 Flags: TOS: c0 Protocol: TCP Flags: ACK 2007/04/13 16:23:10 Filter: 100:100 Desc: Entry-100 Interface: to-ser1 Action: Forward Src MAC: 04-5b-01-01-00-02 Dst MAC: 04-5d-01-01-00-02 EtherType: 0800 Src IP: 10.10.0.1:646 Dst IP: 10.10.0.3:646 Flags: TOS: c0 Protocol: UDP 2007/04/13 16:23:12 Filter: 100:100 Desc: Entry-100 Interface: to-ser1 Action: Forward Src MAC: 04-5b-01-01-00-02 Dst MAC: 01-00-5e-00-00-05 EtherType: 0800 Src IP: 10.10.13.1 Dst IP: 224.0.0.5 Flags: TOS: c0 Protocol: 89 Hex: 02 01 00 30 0a 0a 00 01 00 00 00 00 ba 90 00 00

A:ALA-A>config# show filter log bindings Filter Log Bindings Total Log Instances (Allowed) : 2046 Total Log Instances (In Use) : 0 Total Log Bindings : 0 Type FilterId EntryId Log Instantiated No Instances found A:ALA-A>config#

Note: A summary log will be printed only in case TotCnt is different from 0. Only the address types with at least 1 entry in the minitable will be printed.

A:ALA-A>config# show filter log 190		
Summary	Log[190]	Crit1: SrcAddr TotCnt: 723 ArpCnt: 83
Mac	8	06-06-06-06-06
Mac	8	06-06-06-06-05
Mac	8	06-06-06-06-06-04
Mac	8	06-06-06-06-03
Mac	8	06-06-06-06-02
Ip	16	6.6.6.1
Ip	16	6.6.2
Ip	16	6.6.3
Ip	16	6.6.4
Ip	8	6.6.5
Ipv6	8	3FE:1616:1616:1616:1616::
Ipv6	8	3FE:1616:1616:1616:1616:FFFF:FFFF
Ipv6	8	3FE:1616:1616:1616:1616:FFFF:FFFE
Ipv6	8	3FE:1616:1616:1616:1616:FFFF:FFFD
Ipv6	8	3FE:1616:1616:1616:1616:FFFF:FFFC
A:ALA-A		

mac

Syntax	mac [mac-filter-id [associations counters] [entry entry-id]]		
Context	show>filter	show>filter	
Description	This command displays M	AC filter information.	
Parameters	mac-filter-id — Displays detailed information for the specified filter ID and its filter entries.		
	Values 1—655	535	
	associations — Appends information as to where the filter policy ID is applied to the detailed filter policy ID output.		
	counters — Displays counter information for the specified filter ID.		
	entry entry-id — Display	s information on the specified filter entry ID for the specified filter ID only.	
	Values 1 — 65	535	
Output	No Parameters Specified — When no parameters are specified, a brief listing of IP filters is produced. The following table describes the command output for the command.		
	Label	Description	
	Filter Id	The IP filter ID	

Label	Description (Continued)
Scope	Template - The filter policy is of type Template.
	Exclusiv – The filter policy is of type Exclusive.
Applied	NO - The filter policy ID has not been applied.
	Yes – The filter policy ID is applied.
Description	The MAC filter policy description.

Filter ID Specified — When the filter ID is specified, detailed filter information for the filter ID and its entries is produced. The following table describes the command output for the command.

Label	Description
MAC Filter Filter Id	The MAC filter policy ID.
Scope	Template – The filter policy is of type Template.
	Exclusiv – The filter policy is of type Exclusive.
Description	The IP filter policy description.
Applied	NO - The filter policy ID has not been applied.
	Yes $-$ The filter policy ID is applied.
Def. Action	Forward – The default action for the filter ID for packets that do not match the filter entries is to forward.
	Drop – The default action for the filter ID for packets that do not match the filter entries is to drop.
Filter Match Criteria	MAC – Indicates the filter is an MAC filter policy.
Entry	The filter ID filter entry ID. If the filter entry ID indicates the entry is (Inactive), then the filter entry is incomplete as no action has been specified.
Description	The filter entry description.
FrameType	Ethernet – The entry ID match frame type is Ethernet IEEE 802.3. Ethernet II – The entry ID match frame type is Ethernet Type II.
Src MAC	The source MAC address and mask match criterion. When both the MAC address and mask are all zeroes, no criterion specified for the filter entry.
Dest MAC	The destination MAC address and mask match criterion. When both the MAC address and mask are all zeroes, no criterion specified for the filter entry.
Dot1p	The IEEE 802.1p value for the match criteria. Undefined indicates no value is specified.
Ethertype	The Ethertype value match criterion.
DSAP	The DSAP value match criterion. Undefined indicates no value specified.
SSAP	SSAP value match criterion. Undefined indicates no value specified.

Label	Description (Continued)
Snap-pid	The Ethernet SNAP PID value match criterion. Undefined indicates no value specified.
Esnap-oui-zero	Non-Zero – Filter entry matches a non-zero value for the Ethernet SNAP OUI. Zero – Filter entry matches a zero value for the Ethernet SNAP OUI. Undefined – No Ethernet SNAP OUI value specified.
Match action	Default – The filter does not have an explicit forward or drop match action specified. If the filter entry ID indicates the entry is Inactive, the filter entry is incomplete, no action was specified. Drop – Packets matching the filter entry criteria will be dropped. Forward – Packets matching the filter entry criteria is forwarded.
Ing. Matches	The number of ingress filter matches/hits for the filter entry.
Egr. Matches	The number of egress filter matches/hits for the filter entry.

Sample Detailed Output

Mac Filter : 200		
Filter Id Scope Description :	: 200	Applied : No D. Action : Drop
Filter Match	Criteria : Mac	
Entry Description	: 200 : Not Available	FrameType : 802.2SNAP
	: 00:00:5a:00:00:00 ff:ff:ff:00 : 00:00:00:00:00:00 00:00:00:00	
Dot1p	: Undefined	Ethertype : 802.2SNAP
DSAP		SSAP : Undefined
Snap-pid		ESnap-oui-zero : Undefined
Match action	: Forward	
Ing. Matches		Egr. Matches : 0
-	: 300 (Inactive)	FrameType : Ethernet
-	: Not Available	
	: 00:00:00:00:00:00 00:00:00:00	
	: 00:00:00:00:00:00 00:00:00:00	
Dot1p		Ethertype : Ethernet
DSAP		SSAP : Undefined
Snap-pid		ESnap-oui-zero : Undefined
Match action		
Ing. Matches	: 0	Egr. Matches : 0

Filter Associations — The associations for a filter ID will be displayed if the **associations** keyword is specified. The association information is appended to the filter information. The following table describes the fields in the appended associations output.

Label	Description
Filter Associa- tion	Mac – The filter associations displayed are for a MAC filter policy ID.
Service Id	The service ID on which the filter policy ID is applied.
SAP	The Service Access Point on which the filter policy ID is applied.
Туре	The type of service of the Service ID.
(Ingress)	The filter policy ID is applied as an ingress filter policy on the inter- face.
(Egress)	The filter policy ID is applied as an egress filter policy on the interface.

Sample Output

A:ALA-49# show filter mac 3 associations _____ Mac Filter _____ Applied : Yes Def. Action : Drop Filter ID: 3 Scope : Template Entries : 1 _____ Filter Association : Mac _____ Service Id: 1001 Type : VPLS - SAP 1/1/1:1001 (Egress) _____ A:ALA-49#

Filter Entry Counters Output — When the **counters** keyword is specified, the filter entry output displays the filter matches/hit information. The following table describes the command output for the command.

Filter Policies

Label	Description
Mac Filter Filter Id	The MAC filter policy ID.
Scope	Template - The filter policy is of type Template.
	Exclusive – The filter policy is of type Exclusive.
Description	The MAC filter policy description.
Applied	NO - The filter policy ID has not been applied.
	Yes – The filter policy ID is applied.
Def. Action	Forward – The default action for the filter ID for packets that do not match the filter entries is to forward.
	Drop – The default action for the filter ID for packets that do not match the filter entries is to drop.
Filter Match Criteria	Mac – Indicates the filter is an MAC filter policy.
Entry	The filter ID filter entry ID. If the filter entry ID indicates the entry is (Inactive), then the filter entry is incomplete as no action has been specified.
FrameType	Ethernet – The entry ID match frame type is Ethernet IEEE 802.3.
	802.2LLC - The entry ID match frame type is Ethernet IEEE 802.2 LLC.
	802.2SNAP – The entry ID match frame type is Ethernet IEEE 802.2 SNAP.
	Ethernet II – The entry ID match frame type is Ethernet Type II.
Ing. Matches	The number of ingress filter matches/hits for the filter entry.
Egr. Matches	The number of egress filter matches/hits for the filter entry.

Sample Output

A:ALA-49# show filter mac 8 counters Mac Filter Filter Id : 8 Applied : Yes Scope : Template Def. Action : Forward Entries : 2 Description : Description for Mac Filter Policy id # 8 Filter Match Criteria : Mac

7750 SR OS Router Configuration Guide

redirect-policy

Syntax	redirect-policy {redirect-policy-name [dest ip-address] [association]}
Context	show>filter
Description	This command shows redirect filter information.
Parameters	redirect-policy-name — Displays information for the specified redirect policy.
	dest <i>ip-address</i> — Directs the router to use a specified IP address for communication.
	association — Appends association information.

Output Redirect Policy Output — The following table describes the fields in the redirect policy command output.

Label	Description
Redirect Policy	Specifies a specific redirect policy.
Applied	Specifies whether the redirect policy is applied to a filter policy entry.
Description	Displays the user-provided description for this redirect policy.
Active Destina- tion	ip address – Specifies the IP address of the active destination. none – Indicates that there is currently no active destination.
Destination	Specifies the destination IP address.
Oper Priority	Specifies the operational value of the priority for this destination. The highest operational priority across multiple destinations is used as the preferred destination.
Admin Priority	Specifies the configured base priority for the destination.
Admin State	Specifies the configured state of the destination.
	Out of Service – Tests for this destination will not be conducted.
Oper State	Specifies the operational state of the destination.
Ping Test	Specifies the name of the ping test.

Label	Description (Continued)
Timeout	Specifies the amount of time in seconds that is allowed for receiving a response from the far-end host. If a reply is not received within this time the far-end host is considered unresponsive.
Interval	Specifies the amount of time in seconds between consecutive requests sent to the far end host.
Drop Count	Specifies the number of consecutive requests that must fail for the des- tination to declared unreachable.
Hold Down	Specifies the amount of time in seconds that the system should be held down if any of the test has marked it unreachable.
Hold Remain	Specifies the amount of time in seconds that the system will remain in a hold down state before being used again.
Last Action at	Displays a time stamp of when this test received a response for a probe that was sent out.
SNMP Test	Specifies the name of the SNMP test.
URL Test	Specifies the name of the URL test.

```
A:ALA-A>confiq>filter# show filter redirect-policy
_____
Redirect Policies
_____
             Applied Description
Redirect Policy
wccp
             Yes
redirect1
             Yes
                New redirect info
               Test test test test
             Yes
redirect2
_____
ALA-A>config>filter#
```

```
ALA-A>config>filter# show filter redirect-policy redirect1
_____
Redirect Policy
_____
Redirect Policy: redirect1
                         Applied : Yes
Description : New redirect info
Active Dest : 10.10.10.104
Destination : 10.10.10.104
_____
Description : SNMP_to_104
Admin Priority : 105
                          Oper Priority: 105
Admin State : Up
                          Oper State : Up
SNMP Test: SNMP-1Interval: 30
                          Timeout : 1
```

Drop Count : 30 Hold Down : 120 Hold Remain : 0 Last Action at : None Taken Destination : 10.10.10.105 _____ Description : another test Admin Priority : 95 Oper Priority: 105 Admin State : Up Oper State : Down Ping Test Interval Timeout : 30 : 1 Drop Count : 5 : 0 Hold Down Hold Remain : 0 Last Action at : 03/19/2007 00:46:55 Action Taken : Disable _____ Destination : 10.10.10.106 -----_____ Description : (Not Specified) Admin Priority : 90 Oper Priority: 90 Admin State : Up Oper State : Down URL Test : URL_to_Proxy Interval : 10 : 10 Timeout : 10 : 3 : 0 Drop Count Hold Down Hold Remain : 0 Last Action at : 03/19/2007 05:04:15 Action Taken : Disable Priority Change: 0 Return Code : 0 _____ A:ALA-A>config>filter# A:ALA-A>show filter redirect-policy redirect1 dest 10.10.10.106 _____ Redirect Policy Redirect Policy: redirect1 Applied : Yes Description : New redirect info Active Dest : 10.10.10.104 _____ Destination : 10.10.10.106 ----------Description : (Not Specified) Admin Priority : 90 Oper Priority: 90 Admin State : Up Oper State : Down URL Test : URL_to_Proxy : 10 Timeout Interval : 10 Drop Count : 3 Hold Down Hold Remain : 0 : 0 Last Action at : 03/19/2007 05:04:15 Action Taken : Disable Priority Change: 0 Return Code : 0 _____ ALA-A#

Clear Commands

ip

Syntax	ip ip-filter-id [entry entry-id] [ingress egress]
Context	clear>filter
Description	Clears the counters associated with the IP filter policy.
	By default, all counters associated with the filter policy entries are reset. The scope of which counters are cleared can be narrowed using the command line parameters.
Default	clears all counters associated with the IP filter policy entries.
Parameters	<i>ip-filter-id</i> — The IP filter policy ID.
	Values 1 — 65535
	<i>entry-id</i> — Specifies that only the counters associated with the specified filter policy entry will be cleared.
	Values 1 — 65535
	ingress — Specifies to only clear the ingress counters.
	egress — Specifies to only clear the egress counters.

ipv6

Syntax	ipv6 ip-filter-id [entry entry-id] [ingress egress]
Context	clear>filter
Description	Clears the counters associated with the IPv6 filter policy.
	By default, all counters associated with the filter policy entries are reset. The scope of which counters are cleared can be narrowed using the command line parameters.
Default	Clears all counters associated with the IPv6 filter policy entries.
Parameters	<i>ip-filter-id</i> — The IP filter policy ID.
	Values 1 – 65535
	<i>entry-id</i> — Specifies that only the counters associated with the specified filter policy entry will be cleared.
	Values 1 – 65535
	ingress — Specifies to only clear the ingress counters.

7750 SR OS Router Configuration Guide

egress — Specifies to only clear the egress counters.

log

Syntax	log log-id
Context	clear
Description	Clears the contents of a memory or file based filter log.
	This command has no effect on a syslog based filter log.
Parameters	log-id — The filter log ID destination expressed as a decimal integer.
	Values 101 — 199

mac

Syntax	mac mac-filter-id [entry entry-id] [ingress egress]
Context	clear>filter
	Clears the counters associated with the MAC filter policy.
	By default, all counters associated with the filter policy entries are reset. The scope of which counters are cleared can be narrowed using the command line parameters.
Default	Clears all counters associated with the MAC filter policy entries
Parameters	<i>mac-filter-id</i> — The MAC filter policy ID.
	Values 1 – 65535
	<i>entry-id</i> — Specifies that only the counters associated with the specified filter policy entry will be cleared.
	Values 1 – 65535
	ingress — Specifies to only clear the ingress counters.

egress — Specifies to only clear the egress counters.

Monitor Commands

filter

Syntax	filter ip ip-filter-id entry entry-id [interval seconds] [repeat repeat] [absolute rate]		
Context	monitor		
Description	This command monitors the counters associated with the IP filter policy.		
Parameters	<i>ip-filter-id</i> — The IP filter policy ID.		
	Values 1 – 65535		
	<i>entry-id</i> — Specifies that only the counters associated with the specified filter policy entry will be monitored.		
	Values 1 — 65535		
	interval — Configures the interval for each display in seconds.		
	Default 10 seconds		
	Values 3 – 60		
	repeat — Configures how many times the command is repeated.		
	Default 10		
	Values 1 — 999		
	absolute — When the absolute keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.		
	rate — When the rate keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.		
filter			
Syntax	filter ipv6 ipv6-filter-id entry entry-id [interval seconds] [repeat repeat] [absolute rate]		
Context	monitor		
Description	This command monitors the counters associated with the IPv6 filter policy.		
Parameters	<i>ipv6-filter-id</i> — The IP filter policy ID.		
	Values 1 — 65535		
	<i>entry-id</i> — Specifies that only the counters associated with the specified filter policy entry will be moniitored.		

Values 1 — 65535

7750 SR OS Router Configuration Guide

interval — Configures the interval for each display in seconds.			
Default	5 seconds		
Values	3 — 60		
repeat <i>repeat</i> — Configures how many times the command is repeated.			
Default	10		
Values	1 — 999		

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

filter

Syntax	filter mac mac-filter-id entry entry-id [interval seconds] [repeat repeat] [absolute rate]		
Context	monitor		
Description	This command monitors the counters associated with the MAC filter policy.		
Parameters	<i>mac-filter-id</i> — The MAC filter policy ID.		
	Values 1 – 65535		
	<i>entry-id</i> — Specifies that only the counters associated with the specified filter policy entry will be cleared.		
	Values 1 – 65535		
	interval — Configures the interval for each display in seconds.		
	Default 5 seconds		
	Values 3 – 60		
	repeat <i>repeat</i> — Configures how many times the command is repeated.		
	Default 10		
	Values 1 — 999		
	abalate Willing the abalate bernood is an effect the new statistics are displayed without we		

absolute — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

rate — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

Cflowd

In This Chapter

This chapter provides information to configure Cflowd.

Topics in this chapter include:

- Cflowd Overview on page 472
 - \rightarrow Operation on page 473
 - → Cflowd Filter Matching on page 477
- Cflowd Configuration Process Overview on page 478
- Configuration Notes on page 479

Cflowd Overview

Cflowd is a tool used to sample IP

IPv4 and MPLS traffic traffic data flows through a router. Cflowd enables traffic sampling and analysis by ISPs and network engineers to support capacity planning, trends analysis, and characterization of workloads in a network service provider environment.

Cflowd is also useful for Web host tracking, accounting, network planning and analysis, network monitoring, developing user profiles, data warehousing and mining, as well as security-related investigations. Collected information can be viewed several ways such as in port, AS, or network matrices, and pure flow structures. The amount of data stored depends on the cflowd configurations.

Cflowd maintains a list of data flows through a router. A flow is a uni-directional traffic stream defined by several characteristics such as source and destination IP addresses, source and destination ports, inbound interface, IP protocol and TOS bits.

When a router receives a packet for which it currently does not have a flow entry, a flow structure is initialized to maintain state information regarding that flow, such as the number of bytes exchanged, IP addresses, port numbers, AS numbers, etc. Each subsequent packet matching the same parameters of the flow contribute to the byte and packet count of the flow until the flow is terminated and exported to a collector for storage.

Cflowd is not supported on the 7750 SR-1 chassis.

Cflowd

Operation

Figure 19 depicts the basic operation of the cflowd feature. This sample flow is only used to describe the basic steps that are performed. It is not intended to specify implementation.




Figure 19: Basic Cflowd Steps

- 1. As a packet ingresses a port, a decision is made to forward or drop the packet.
- 2. If the packet is forwarded, it is then decided if the packet should be sampled for cflowd.
- 3. If a new flow is found, a new entry is added to the cache. If the flow already exists in the cache, the flow statistics are updated.
- 4. If a new flow is detected and the maximum number of entries are already in the flow cache, the earliest expiry entry is removed. The earliest expiry entry/flow is the next flow that will expire due to the active or inactive timer expiration.
- 5. If a flow has been inactive for a period of time equal to or greater then the inactive timer (default 15 seconds), then the entry is removed from the flow cache.
- 6. If a flow has been active for a period of time equal to or greater than the active timer (default 30 minutes), then the entry is removed from the flow cache.

When a flow is exported from the cache, the collected data is sent to an external collector which maintains an accumulation of historical data flows that network operators can use to analyze traffic patterns.

Data is exported in one of the following formats:

- Version 5 Generates a fixed export record for each individual flow captured.
- Version 8 Aggregates multiple individual flows into a fixed aggregate record.
- Version 9 Generates a variable export record, depending on user configuration and sampled traffic type (IPv4 or MPLS), for each individual flow captured.

There are several different aggregate flow types including:

- AS matrix
- Destination prefix matrix
- Source prefix matrix
- Prefix matrix
- Protocol/port matrix.

V8 is an aggregated export format. As individual flows are aged out of the raw flow cache, the data is added to the aggregate flow cache for each configured aggregate type. Each of these aggregate flows are also aged in a manner similar to the method the active flow cache entries are aged. When an aggregate flow is aged out, it is sent to the external collector in the V8 record format.




Figure 20 depicts Version 5, Version 8 and Version 9 flow processing.

Figure 20: V5, V8 and Flow Processing

- 1. As flows are expired from the active flow cache, the export format must be determined, either Version 5, Version 8 and Version 9.
- 2. If the export format is Version 5 or Version 9, no further processing is performed and the flow data is accumulated to be sent to the external collector.
- 3. If the export format is Version 8, then the flow entry is added to one or more of the configured aggregation matrices.

As the entries within the aggregate matrices are aged out, they are accumulated to be sent to the external flow collector in Version 8 format.

The sample rate and cache size are configurable values. The cache size default is 64K flow entries.

A flow terminates when one of the following conditions is met:

- When the inactive timeout period expires (default: 15 seconds). A flow is considered terminated when no packets are seen for the flow for N seconds.
- When an active timeout expires default: 30 seconds). A flow terminates according to the time duration regardless of whether or not there are packets coming in for the flow.
- When the user executes a **clear cflowd** command.

• When other measures are met that apply to aggressively age flows as the cache becomes too full (such as overflow *percent*).

Version 9

The Version 9 format is a more flexible format and allows for different templates or sets of cflowd data to be sent based on the type of traffic being sampled and the template set configured.

Version 9 is interoperable with RFC 3954, Cisco Systems NetFlow Services Export Version 9.

Cflowd Filter Matching

In the filter-matching process, normally, every packet is matched against filter (access list) criteria to determine acceptability. With cflowd, only the first packet of a flow is checked. If the first packet is forwarded, an entry is added to the cflowd cache. Subsequent packets in the same flow are then forwarded without needing to be matched against the complete set of filters. Specific performance varies depending on the number and complexity of the filters.

Cflowd Configuration Process Overview

Figure 21 displays the process to configure Cflowd parameters.




Figure 21: Cflowd Configuration and Implementation Flow

There are three modes in which cflowd can be enabled to sample traffic on a given interface:

- Cflowd interface, where all traffic entering a given port will be subjected to sampling as the configured sampling rate
- Cflowd interface plus the definition of IP filters which specify an action of interfacedisable-sample, in which traffic that matches these filter entries will not be subject to cflowd sampling.
- Cflowd ACL, where IP filters must be created with entries containing the action filtersampled. In this mode only traffic matching these filter entries will be subject to the cflowd sampling process.

Configuration Notes

The following cflowd components must be configured for cflowd to be operational:

- Cflowd is enabled globally.
- At least one collector must be configured and enabled.
- A cflowd option must be specified and enabled on a router interface.
- Sampling must be enabled on either:
 - \rightarrow An IP filter which is applied to a port or service.
 - \rightarrow An interface on a port or service.

Configuration Notes

Configuring Cflowd with CLI

This section provides information to configure cflowd using the command line interface.

Topics in this section include:

- Cflowd Configuration Overview on page 482
 - \rightarrow Traffic Sampling on page 482
 - \rightarrow Collectors on page 483
 - \rightarrow Aggregation on page 483
- Basic Cflowd Configuration on page 485
- Common Configuration Tasks on page 486
 - \rightarrow Enabling Cflowd on page 488
 - → Configuring Global Cflowd Parameters on page 489
 - → Configuring Cflowd Collectors on page 490
 - \rightarrow Dependencies on page 495
 - → Enabling Cflowd on Interfaces and Filters on page 491
 - → Specifying Cflowd Options on an IP Interface on page 492
 - → Specifying Sampling Options in Filter Entries on page 494
- Cflowd Configuration Management Tasks on page 497
 - → Modifying Global Cflowd Components on page 497
 - → Modifying Cflowd Collector Parameters on page 498

Cflowd Configuration Overview

The 7750 SR OS implementation of cflowd supports the option to analyze traffic flow. The implementation also supports the use of traffic/access list (ACL) filters to limit the type of traffic that is analyzed. Traffic blocked (dropped) by ACL filters is not sent to cflowd for analysis.

Cflowd is not supported on the 7750 SR-1 chassis.

Traffic Sampling

Traffic sampling does not examine all packets received by a router. Command parameters allow the rate at which traffic is sampled and sent for flow analysis to be modified. The default sampling rate is every 1000th packet. Excessive sampling over an extended period of time, for example, more than every 1000th packet, can burden router processing resources.

The following data is maintained for each individual flow in the raw flow cache:

- Source IP address
- Destinations IP address
- Source port
- Destination port
- Input interface
- Output interface
- IP protocol
- TCP flags
- First timestamp (of the first packet in the flow)
- Last timestamp (timestamp of last packet in the flow prior to expiry of the flow)
- Source AS number for peer and origin (taken from BGP)
- Destination AS number for peer and origin (taken from BGP)
- IP next hop
- BGP next hop
- ICMP type and code
- IP version
- Source prefix (from routing)
- Destination prefix (from routing)
- MPLS label stack from label 1 to 6

Within the raw flow cache, the following characteristics are used to identify an individual flow:

- Ingress interface
- Source IP address
- Destination IP address
- Source transport port number
- Destination transport port number
- IP protocol type
- IP TOS byte
- Virtual router id
- ICMP type and code
- MPLS labels

The 7750 SR OS implementation allows you to enable cflowd either at the interface level or as an action to a filter. By enabling cflowd at the interface level, all IP packets forwarded by the interface are subject to cflowd analysis. By setting cflowd as an action in a filter, only packets matching the specified filter are subject to cflowd analysis. This provides the network operator greater flexibility in the types of flows that are captured.

Collectors

A collector defines the data flow for exporting sampled data from the cache. A maximum of 5 collectors can be configured. Each collector is identified by a unique IP address and UDP port value. Each collector can only export traffic in one version type, either V5, V8 or V9.

The parameters within a collector configuration can be modified or the defaults retained.

The autonomous-system-type command defines whether the autonomous system information to be included in the flow data is based on the originating AS or external peer AS of the flow.

Aggregation

V8 aggregation allows for flow data to be aggregated into larger, less granular flows. Use aggregation commands to specify the type of data to be collected.

The following aggregation schemes are supported:

 AS matrix — Flows are aggregated based on source and destination AS and ingress and egress interface.

- Protocol-port Flows are aggregated based on the IP protocol, source port number, and destination port number.
- Source prefix Flows are aggregated based on source prefix and mask, source AS, and ingress interface.
- Destination prefix Flows are aggregated based on destination prefix and mask, destination AS, and egress interface.
- Source-destination prefix Flows are aggregated based on source prefix and mask, destination prefix and mask, source and destination AS, ingress interface and egress interface.
- Raw Flows are not aggregated and are sent to the collector in a V5 record.

Basic Cflowd Configuration

This section provides information to configure cflowd and configuration examples of common configuration tasks. In order to sample traffic, the minimal cflowd parameters that need to be configured are:

- Cflowd must be enabled.
- At least one collector must be configured and enabled.
- Sampling must be enabled on either:
 - \rightarrow An IP filter entry and applied to a service or an port.
 - \rightarrow An interface applied to a port.

The following example displays a cflowd configuration.

```
A:ALA-1>config>cflowd# info detail
```

```
_____
       active-timeout 30
       cache-size 65536inactive-timeout 15
        overflow 1
        rate 1000
        collector 10.10.10.103:2055 version 9
          no aggregation
          autonomous-system-type origin
          description "V9 collector"
          no shutdown
        exit
        template-retransmit 330
        exit
       no shutdown
_____
A:ALA-1>config>cflowd#
```

Common Configuration Tasks

This section provides a brief overview of the tasks that must be performed to configure cflowd and provides the CLI commands. In order to begin traffic flow sampling, cflowd must be enabled and at least one collector must be configured.

Global Cflowd Components

The components common (global) to all instances of cflowd include the following parameters:

- Active timeout
- Inactive timeout
- Cache size
- Overflow
- Rate
- Template retransmit

Configuring Cflowd

Use the CLI syntax displayed below to perform the following tasks:

- Enabling Cflowd on page 488
- Configuring Global Cflowd Parameters on page 489
- Configuring Cflowd Collectors on page 490
- Enabling Cflowd on Interfaces and Filters on page 491

```
CLI Syntax: config>cflowd#
            active-timeout minutes
            cache-size num-entries
            inactive-timeout seconds
            template-retransmit seconds
            overflow percent
            rate sample-rate
            collector ip-address[:port] {version [5 | 8 | 9]}
               aggregation
                  as-matrix
                  destination-prefix
                  protocol-port
                  raw
                  source-destination-prefix
                  source-prefix
               template-set {basic | mpls-ip}
               autonomous-system-type [origin | peer]
               description description-string
               no shutdown
            no shutdown
```

Enabling Cflowd

Cflowd is disabled by default. Executing the command configure cflowd will enable cflowd, by default cflowd is not shutdown but must be configured including at least one collector to be active.

Use the following CLI syntax to enable cflowd:

CLI Syntax: config# cflowd no shutdown

The following example displays the default values when cflowd is initially enabled. No collectors or collector options are configured.

Configuring Global Cflowd Parameters

The following cflowd parameters apply to all instances where cflowd (traffic sampling) is enabled.

Use the following CLI commands to configure cflowd parameters:

```
CLI Syntax: config>cflowd#
    active-timeout minutes
    cache-size num-entries
    inactive-timeout seconds
    overflow percent
    rate sample-rate
    template-retransmit seconds
    no shutdown
```

The following example displays a common cflowd component configuration:

Configuring Cflowd Collectors

To configure cflowd collector parameters, enter the following commands:

```
CLI Syntax: config>cflowd#
    collector ip-address[:port] [version version]
    aggregation
        as-matrix
        destination-prefix
        protocol-port
        raw
        source-destination-prefix
        source-prefix
        autonomous-system-type [origin | peer]
        description description-string
        no shutdown
        template-set {basic | mpls-ip}
```

The following example displays a basic cflowd configuration:

```
A:ALA-1>config>cflowd# info
active-timeout 20
      inactive-timeout 10
      overflow 10
      rate 100
      collector 10.10.10.1:2000 version 8
          aggregation
             as-matrix
             raw
          exit
          description "AS info collector"
      exit
      collector 10.10.10.2:5000 version 8
          aggregation
             protocol-port
             source-destination-prefix
          exit
         autonomous-system-type peer
         description "Neighbor collector"
      exit
                A:ALA-1>config>cflowd#
```

Enabling Cflowd on Interfaces and Filters

This section discusses the following cflowd configuration management tasks:

- Dependencies on page 495
- Specifying Cflowd Options on an IP Interface on page 492
 - \rightarrow Interface Configurations on page 492
 - \rightarrow Service Interfaces on page 493
- Specifying Sampling Options in Filter Entries on page 494
 - \rightarrow Interface Configurations on page 492

Specifying Cflowd Options on an IP Interface

When cflowd is enabled on an interface, all packets forwarded by the interface are subject to analysis according to the global cflowd configuration and sorted according to the collector configuration(s).

Refer to Table 12, Cflowd Configuration Dependencies, on page 496 for configuration combinations.

To enable for filter traffic sampling, the following requirements must be met:

- 1. Cflowd must be enabled globally.
- 2. At least one cflowd collector must be configured and enabled.
- 3. On the IP interface being used, the interface>cflowd acl option must be selected. (See Interface Configurations on page 492.) For configuration information, refer to the IP Router Configuration Overview sections of the 7750 SR OS Router Configuration Guide.
- 4. On the IP filter being used, the entry>filter-sample option must be explicitly enabled. The default is no filter-sample. (See Filter Configurations on page 494.)
- 5. The filter must be applied to a service or a port. The service or port must be enabled and operational.

Interface Configurations

```
CLI Syntax: config>router>if#
cflowd {acl|interface}
no cflowd
```

Depending on the option selected, either acl or interface, cflowd extracts traffic flow samples from an IP filter or an interface for analysis. All packets forwarded by the interface are analyzed according to the cflowd configuration.

The acl option must be selected in order to enable traffic sampling on an IP filter. Cflowd (filter-sample) must be enabled in at least one IP filter entry.

The interface option must be selected in order to enable traffic sampling on an interface. If cflowd is not enabled (no cflowd) then traffic sampling will not occur on the interface.

Service Interfaces

CLI Syntax: config>service>vpls *service-id*# interface *ip-int-name* cflowd {acl|interface}

When enabled on a service interface, cflowd collects routed traffic flow samples through a router for analysis. Cflowd is supported on IES and VPRN services interfaces only. Layer 2 traffic is excluded. All packets forwarded by the interface are analyzed according to the cflowd configuration. On the interface level, cflowd can be associated with a filter (ACL) or an IP interface.

Specifying Sampling Options in Filter Entries

Packets are matched against filter entries to determine acceptability. With cflowd, only the first packet of a flow is compared. If the first packet matches the filter criteria, then an entry is added to the cflowd cache. Subsequent packets in the same flow are also sampled based on the cache entry.

Since a filter can be applied to more than one interface (when configured with a **scope template**), the **interface-disable-sample** option is intended to enable or disable traffic sampling on an interface-by-interface basis. The command can be enabled or disabled as needed instead creating numerous filter versions.

When the **cflowd interface** option is configured in the **config>router>interface** context, the following requirements must be met in order to enable traffic sampling on the specific interface:

- 1. Cflowd must be enabled.
- 2. At least one cflowd collector must be configured and enabled.
- The interface>cflowd interface option must be selected. For configuration information, refer to the Filter Policy Overview sections of the 7750 SR OS Router Configuration Guide.
- 4. The **config>filter>ip-filter>entry>interface-disable-sample** option must be enabled (the default, **no interface-disable-sample**, must be explicitly modified to **interface-disable-sample**).
- 5. The filter must be applied to a service or a port.

Filter Configurations

CLI Syntax: config>filter>ip-filter>entry# [no] filter-sample [no] interface-disable-sample

When a filter policy is applied to a service or port, sampling can be configured so that traffic matching the associated IP filter entry is sampled when the IP interface is set to cflowd ACL mode and the **filter-sample** command is enabled. If cflowd is either not enabled (**no filter-sample**) or set to the **cflowd interface** mode, then sampling does not occur.

When the **interface-disable-sample** command is enabled, then traffic matching the associated IP filter entry is not sampled if the IP interface is set to cflowd ACL mode.

Dependencies

In order for cflowd to be operational, the following requirements must be met:

- Cflowd must be enabled on a global level. If cflowd is disabled, any traffic sampling instances are also disabled.
- At least one collector must be configured and enabled in order for traffic sampling to occur on an enabled entity.
- If a specific collector UDP port is not identified then, by default, flows are sent to port 2055.

Cflowd can also be dependent on the following entity configurations:

- Interface Configurations on page 492
- Service Interfaces on page 493
- Filter Configurations on page 494

Depending on the combination of interface and filter entry configurations determine if and when flow sampling occurs. Table 12 displays the expected results when specific features are enabled and disabled.

Table 12: Cflowd Configuration Dependencies

Interface Setting	router>interface cflowd [acl interface] Setting	Command ip-filter entry	Expected Results
IP-filter mode	ACL	filter-sampled	Traffic matching is sampled at specified rate.
IP-filter mode	ACL	no filter-sampled	No traffic is sampled on this interface.
IP-filter mode or cflowd not enabled on interface	ACL	interface- disable-sample	Command is ignored. No sampling occurs.
Interface mode	interface	interface- disable-sample	Traffic matching this IP filter entry is not sampled.
Interface mode	interface	none	All IP traffic ingressing the interface is subject to sampling.
Interface mode	interface	filter sampled	Filter level action is ignored. All traffic ingressing the interface is subject to sampling.

Cflowd Configuration Management Tasks

This section discusses the following cflowd configuration management tasks:

- Modifying Global Cflowd Components on page 497
- Modifying Cflowd Collector Parameters on page 498

Modifying Global Cflowd Components

Cflowd parameter modifications apply to all instances where cflowd or traffic sampling is enabled. Changes are applied immediately. Use the following cflowd commands to modify global cflowd parameters:

```
CLI Syntax: config>cflowd#
    active-timeout minutes
    no active-timeout
    cache-size num-entries
    no cache-size
    inactive-timeout seconds
    no inactive-timeout
    overflow percent
    no overflow
    rate sample-rate
    no rate
    [no] shutdown
    template-retransmit seconds
    no template-retransmit
```

The following example displays the cflowd command usage to modify configuration parameters:

Example: config>cflowd# active-timeout 60
 config>cflowd# no inactive-timeout
 config>cflowd# overflow 2
 config>cflowd# rate 10

The following example displays the common cflowd component configuration:

7750 SR OS Router Configuration Guide

Modifying Cflowd Collector Parameters

Use the following commands to modify cflowd collector and aggregation parameters:

```
CLI Syntax: config>cflowd#
    collector ip-address[:port] [version version]
    no collector ip-address[:port]
        [no] aggregation
        [no] as-matrix
        [no] destination-prefix
        [no] protocol-port
        [no] raw
        [no] source-destination-prefix
        [no] source-prefix
        [no] autonomous-system-type [origin | peer]
        [no] description description-string
        [no] shutdown
        template-set {basic | mpls-ip}
```

If a specific collector UDP port is not identified then, by default, flows are sent to port 2055.


The following displays basic cflowd modifications:

```
A:ALA-1>config>cflowd# info
                          _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _
    active-timeout 60
       overflow 2
        rate 10
        collector 10.10.10.1:2000 version 5
           description "AS info collector"
        exit
        collector 10.10.10.2:5000 version 8
           aggregation
               source-prefix
               raw
           exit
           description "Test collector"
       exit
                    A:ALA-1>confiq>cflowd#
```

Cflowd Command Reference

Command Hierarchies

Configuration Commands



— status

Clear Commands

clear — cflowd Cflowd Command Reference

Cflowd Configuration Commands

Global Commands

cflowd

Syntax	[no] cflowd
Context	config>cflowd
Description	This command creates the context to configure cflowd.
	The no form of this command removes all configuration under cflowd including the deletion of all configured collectors. This can only be executed if cflowd is in a shutdown state.
Default	no cflowd
active-timeout	
Syntax	active-timeout <i>minutes</i> no active-timeout
Context	config>cflowd
Description	This command configures the maximum amount of time before an active flow is aged out of the active cache. If an individual flow is active for this amount of time, the flow is aged out and a new flow will be created on the next packet sampled for that flow.
	Note : Existing flows do not inherit the new active-timeout value if this parameter is changed while cflowd is active. The active-timeout value for a flow is set when the flow is first created in the active cache table and does not change dynamically.
	The no form of this command resets the inactive timeout back to the default value.
Default	30
Parameters	minutes — The value expressed in minutes before an active flow is exported.
	Values 1 – 600

cache-size

Syntax	cache-size num-entries no cache-size	
Context	config>cflowd	
Description	This command specifies the maximum number of active flows to maintain in the flow cache table.	
	The no form of this command resets the number of active entries back to the default value.	
Default	65536 (64K)	
Parameters	num-entries — The number of entries maintained in the cflowd cache.	
	Values 1000 - 250000 (SF/CPM3 and 7750 SR-c12/4) 1000 - 128k (all other platforms)	

collector

Syntax	collector ip-ac no collector	ddress[:port] {version [5 8 9]}	
Context	config>cflowd		
Description	This command defines a flow data collector for cflowd data. The IP address of the flow collector must be specified. The UDP port number is an optional parameter. If it is not set, the default of 2055 is used. The version must be specified. A maximum of 5 collectors can be configured.		
	The no form of this command removes the flow collector definition from the config and stops t export of data to the collector. The collector needs to be shutdown to be deleted.		
Default	none		
Parameters	<i>ip-addr</i> — The IP address of the flow data collector in dotted decimal notation.		
	<i>port</i> — The UDP port of flow data collector.		
	Values	1—65535	
	Default	2055	
	version — The v	version of the flow data collector.	
	Values	5, 8, 9	
	Default	5	

aggregation

Syntax	[no] aggregation
Context	config>cflowd>collector
Description	This command configures the type of aggregation scheme to be exported.

7750 SR OS Router Configuration Guide

Specifies the type of data to be aggregated and to the collector.
 To configure aggregation, you must decide which type of aggregation scheme to configure: autonomous system, destination prefix, protocol port, raw, source destination, or source prefix. This can only be configured if the collector version is configured as V8. The no form of this command removes all aggregation types from the collector configuration.
 Default no aggregation

as-matrix

Syntax	[no] as-matrix
Context	config>cflowd>collector>aggregation
Description	This command specifies that the aggregation data should be based on autonomous system (AS) information. An AS matrix contains packet and byte counters for traffic from either source-destination autonomous systems or last-peer to next-peer autonomous systems.
	The no form of this command removes this type of aggregation from the collector configuration.
Default	no as-matrix

destination-prefix

Syntax	[no] destination-prefix	
Context	config>cflowd>collector>aggregation	
Description	This command specifies that the aggregation data is based on destination prefix information.	
	The no form removes this type of aggregation from the collector configuration.	
Default	none	

protocol-port

Syntax	[no] protocol-port
Context	config>cflowd>collector>aggregation
Description	This command specifies that flows be aggregated based on the IP protocol, source port number, and destination port number.
	The no form of this command removes this type of aggregation from the collector configuration.
Default	none

raw

Syntax	[no] raw	
Context	config>cflowd>collector>aggregation	
Description	This command configures raw (unaggregated) flow data to be sent in Version 5.	
	The no form of this command removes this type of aggregation from the collector configuration.	
Default	none	

source-destination-prefix

Syntax	[no] source-destination-prefix
Context	config>cflowd>collector>aggregation
Description	This command configures cflowd aggregation based on source and destination prefixes.
	The no form of this command removes this type of aggregation from the collector configuration.
Default	none

source-prefix

Syntax	[no] source-prefix
Context	config>cflowd>collector>aggregation
Description	This command configures cflowd aggregation based on source prefix information.
	The no form of this command removes this type of aggregation from the collector configuration.
Default	none

autonomous-system-type

Syntax	autonomous-system-type {origin peer} no autonomous-system-type
Context	config>cflowd>collector
Description	This command defines whether the autonomous system (AS) information included in the flow data is based on the originating AS or external peer AS of the routes.
	This option is only allowed if the collector is configured as Version 5 or Version 8.
	The no form of this command resets the AS type to the default value.
Default	autonomous-system-type origin

Parametersorigin — Specifies that the AS information included in the flow data is based on the originating AS.peer — Specifies that the AS information included in the flow data is based on the peer AS.

description

Syntax	description description-string no description				
Context	config>cflowd>collector				
Description	This command creates a text description stored in the configuration file for a configuration context.				
	The no form of this command removes the description string from the context.				
Default	No description is associated with the configuration context.				
Parameters	<i>description-string</i> — The description character string. Allowed values are any string up to 80 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.				

shutdown

Syntax	[no] shutdown
Context	config>cflowd config>cflowd>collector
Description	This command administratively disables an entity. When disabled, an entity does not change, reset, or remove any configuration settings or statistics.
	The operational state of the entity is disabled as well as the operational state of any entities contained within. Many objects must be shut down before they may be deleted.
	The no form of this command administratively enables an entity.
	Unlike other commands and parameters where the default state is not indicated in the configuration file. The shutdown and no shutdown states are always indicated in system generated configuration files.
template-set	
Syntax	template-set {basic mpls-ip}
Context	config>cflowd>collector
Description	This command specifies the set of templates sent to the collector when using cflowd Version 9.
Default	basic

Parameters basic — Basic flow data is sent.

7750 SR OS Router Configuration Guide

mpls-ip — Extended flow data is sent that includes IP and MPLS information.

inactive-timeout

Syntax	inactive-timeout seconds no inactive-timeout					
Context	config>cflowd					
Description	This command specifies the amount of time, in seconds, that must elapse without a packet matching a flow in order for the flow to be considered inactive.					
	The no form of this command resets the inactive timeout back to the default of 15 seconds.					
	Note : Existing flows will not inherit the new inactive-timeout value if this parameter is changed while cflowd is active. The inactive-timeout value for a flow is set when the flow is first created in the active cache table and does not change dynamically.					
Default	15					
Parameters	<i>seconds</i> — Specifies the amount of time, in seconds, that must elapse without a packet matching a flow in order for the flow to be considered inactive.					
	Values 10 — 600					

overflow

Syntax	overflow percent no overflow					
Context	config>cflowd					
Description	This command specifies the percentage of the flow cache entries removed when the maximum number of entries is exceeded. The entries removed are the entries that have not been updated for the longest amount of time.					
	The no form of this command resets the number of entries cleared from the flow cache on overflow to the default value.					
Default	1 %					
Parameters	<i>percent</i> — Specifies the percentage of the flow cache entries removed when the maximum number of entries is exceeded.					
	Values $1 - 50$ percent					

rate

Syntax	rate sample-rate no rate				
Context	config>cflowd				
Description	This command specifies the rate (N) at which traffic is sampled and sent for flow analysis. A packet is sampled every N packets; for example, when <i>sample-rate</i> is configured as 1, then all packets are sent to the cache. When <i>sample-rate</i> is configured as 100, then every 100th packet is sent to the cache. The no form of this command resets the sample rate to the default value.				
Default	1000				
Parameters	sample-rate — Specifies the rate at which traffic is sampled.				
	Values 1 – 10000				

template-retransmit

Syntax	template-retransmit seconds no template-retransmit					
Context	config>cflowd					
Description	This command specifies the interval for sending template definitions.					
Default	600					
Parameters	seconds — The value expressed in seconds before sending template definitions.					
	Values 10 — 600					

Cflowd Configuration Commands

Show Commands

collector

Syntax	collector [ip-addr[:port]] [detail]					
Context	show>cflowd	show>cflowd				
Description	This command c	lisplays administrative and operational status of data collector configuration.				
Parameters	<i>ip-addr</i> — Displ	<i>ip-addr</i> — Display only information about the specified collector IP address.				
	Default all collectors					
	:port — Display only information the collector on the specified UDP port.					
	Default all UDP ports					
	Values 1 – 65535					
	detail — Displays details about either all collectors or the specified collector.					
• • •						

Output cflowd Collector Output — The following table describes the show cflowd collector output fields:

Label	Description				
Host Address	The IP address of a remote Cflowd collector host to receive the exported Cflowd data.				
Port	The UDP port number on the remote Cflowd collector host to receive the exported Cflowd data.				
AS Type	The style of AS reporting used in the exported flow data.				
	origin – Reflects the endpoints of the AS path which the flow is following.				
	peer - Reflects the AS of the previous and next hops for the flow.				
Version	Specifies the configured version for the associated collector.				
Admin	The desired administrative state for this Cflowd remote collector host.				
Oper	The current operational status of this Cflowd remote collector host.				
Recs Sent	The number of Cflowd records that have been transmitted to this remote collector host.				
Collectors	The total number of collectors using this IP address.				

Table 13: Show Cflowd Collector Output Fields

Sample Output

A:R51-CfmA# show cflowd collector

Cflowd Collectors						
Host Address	Dort	Voraion		Admin	Oper	Sent.
HOSE AUGLESS		version	АЗ туре	AGIII 11	oper	
138.120.135.103	2055	v5	peer	up	up	1380 records
138.120.135.103	9555	v8	origin	up	up	90 records
138.120.135.103	9996	v9	-	up	up	0 packets
138.120.214.224	2055	v5	origin	up	up	1380 records
Collectors : 4						

Label Description				
Address	The IP address of a remote Cflowd collector host to receive the exported Cflowd data.			
Port	The UDP port number on the remote Cflowd collector host to receive the exported Cflowd data.			
Description	A user-provided descriptive string for this Cflowd remote collector host.			
Version	The version of the flow data sent to the collector.			
AS Type	The style of AS reporting used in the exported flow data.			
	origin – Reflects the endpoints of the AS path which the flow is following.			
	peer - Reflects the AS of the previous and next hops for the flow.			
Admin State	The desired administrative state for this Cflowd remote collector host.			
Oper State	The current operational status of this Cflowd remote collector host.			
Records Sent	The number of Cflowd records that have been transmitted to this remote collector host.			
Last Changed	The time when this row entry was last changed.			
Last Pkt Sent	The time when the last Cflowd packet was sent to this remote collector host.			

Table 14: Show Cflowd Collector Detailed Output Fields

Label	Description
Aggregation Type	The bit mask which specifies the aggregation scheme(s) used to aggre- gate multiple individual flows into an aggregated flow for export to this remote host collector.
	none $-$ No data will be exported for this remote collector host.
	raw – Flow data is exported without aggregation in version 5 format.
	All other aggregation types use version 8 format to export the flow data to this remote host collector.
Collectors	The total number of collectors using this IP address.

Table 14: Show Cflowd Collector Detailed Output Fields (Continued)

A:R51-CfmA# show cflowd collector detail

Cflowd Collectors (detail)				
Address Port Description Version AS Type Admin State Oper State Records Sent Last Changed Last Pkt Sent	: 138.120.13 : 2055 : Test v5 Co : 5 : peer : up : up : 1260 : 09/03/2009 : 09/03/2009	5.103 llector 17:24:04		
		Sent	Open	Errors
		42	0	0
Port Description Version AS Type Admin State Oper State Records Sent Last Changed Last Pkt Sent	: 138.120.13 : 9555 : Test v8 Co : 8 : origin : up : up : 82 : 09/03/2009 : 09/03/2009	17:24:04 18:06:41		
Aggregation Type	Status	Sent	Open	Errors
as-matrix protocol-port source-prefix destination-prefix source-destination-prefix raw	Disabled Disabled Enabled Enabled	0 0 21 21 0 0	0 0 0 0 0 0	0 0 0 0 0 0
Address Port	: 138.120.13 : 9996	======================================		

Description	: Test v9 Col	llector		
Version	: 9			
Admin State	: up			
Oper State	: up			
Packets Sent	: 51			
Last Changed	: 09/03/2009	17:24:04		
Last Pkt Sent	: 09/03/2009	: 09/03/2009 18:07:10		
Template Set	: Basic			
Traffic Type	Template Sent	Sent	Open	Errors
IPv4	09/03/2009 18:07:29	51	1	0
MPLS	No template sent	0	0	0
A:R51-CfmA#				

interface

Syntax	interface [ip-addr ip-int-name]		
Context	show>cflowd		
Description	Displays the administrative and operational status of the interfaces with cflowd enabled.		
Parameters	<i>ip-addr</i> — Display only information for the IP interface with the specified IP address.		
	Default all interfaces with cflowd enabled.		
	<i>ip-int-name</i> — Display only information for the IP interface with the specified name.		
	Default all interfaces with cflowd enabled.		

Output cflowd Interface Output — The following table describes the show cflowd interface output fields.

Label	Description
Interface	Displays the physical port identifier.
IP Address	Displays the IP address.
Mode	Displays the mode.
Admin	Displays the administrative state of the interface.
Oper	Displays the operational state of the interface.

Sample Output

B:sr-002# show cflowd interface				
Cflowd Interfaces				
Interface	IP Address	Mode	Admin Oper	

Cflowd

To_Sr1	1.10.1.2/24	Interface	Up	Up
To_C2	1.12.1.2/24	Interface	Up	Up
To_Cisco_7600	1.13.1.2/24	Interface	Up	Up
To_E	1.11.1.2/24	Interface	Up	Up
To_G2	150.153.1.1/24	Interface	Up	Up
To_Sr1_Sonet	150.140.1.2/24	Interface	Up	Down
Main	120.1.1.1/24	Filter	Down	Down
New	120.2.1.1/24	Filter	Up	Up
Interfaces : 8				
B:sr12-002#				

status

Syntax	status
Context	show>cflowd
Description	This command displays basic information regarding the administrative and operational status of cflowd.
Output	cflowd Status Output — The following table describes the show cflowd status output fields:

Table 15: Show Cflowd Status Output Fields

Label	Description
Cflowd Admin Status	The desired administrative state for this Cflowd remote collector host.
Cflowd Oper Status	The current operational status of this Cflowd remote collector host.
Active Timeout	The maximum amount of time, in minutes, before an active flow will be exported. If an individual flow is active for this amount of time, the flow is exported and a new flow is created.
Inactive Timeout	Inactive timeout in seconds.
Template Retransmit	The time in seconds before template definitions are sent.
Cache Size	The maximum number of active flows to be maintained in the flow cache table.
Overflow	The percentage number of flows to be flushed when the flow cache size has been exceeded.
Sample Rate	The rate at which traffic is sampled and forwarded for Cflowd analysis. one (1) - All packets are analyzed. 1000 (default) - Every 1000th packet is analyzed.
Active Flows	The current number of active flows being collected.

Label	Description
Total Pkts Rcvd	The rate at which traffic is sampled and forwarded for Cflowd analysis.
Total Pkts Dropped	The total number of packets dropped.
Aggregation Info:	
Туре	The type of data to be aggregated and to the collector.
Status	enabled – Specifies that the aggregation type is enabled.
	disabled – Specifies that the aggregation type is disabled.

Table 15: Show Cflowd Status Output Fields (Continued)

Sample Output

Cflowd Status					
Cflowd Admin Status	: Enabled				
Cflowd Oper Status	: Enabled				
Active Timeout	: 1 minutes				
Inactive Timeout	: 30 seconds				
Template Retransmit	: 60 seconds				
Cache Size	: 65536 entrie	S			
Overflow	: 1%				
Sample Rate	: 1				
Active Flows	: 34				
Total Pkts Rcvd	: 801600				
Total Pkts Dropped	: 0				
Version Info					
Version	Status	Sent	Open	Errors	
5	Enabled		0	0	
8	Enabled	46	0	0	
9	Enabled		1	0	
10	Disabled	0	0	0	

Clear Commands

cflowd

Syntax	cflowd
Context	clear
Description	Clears the raw and aggregation flow caches which are sending flow data to the configured collectors. This action will trigger all the flows to be discarded. The cache restarts flow data collection from a fresh state. This command also clears global stats collector stats listed in the cflowd show commands.

Clear Commands

Common CLI Command Descriptions

In This Chapter

This section provides information about common Command Line Interface (CLI) syntax and command usage.

Topics in this chapter include:

• SAP syntax on page 518

Common Service Commands

sap

Syntax	[no] sap sap-id	
Description	This command specifies the physical port identifier portion of the SAP definition.	
Parameters	sap-id — Specifies the physical port identifier portion of the SAP definition.	
	The <i>sap-id</i> can be configured in one of the following formats:	

Туре	Syntax	Example
port-id	slot/mda/port[.channel]	1/1/5
null	[port-id bundle-id/ bpgrp-id lag-id / aps-id]	<i>port-id</i> : 1/1/3 <i>bundle-id</i> : bundle-ppp-1/1.1 <i>bpgrp-id</i> : bpgrp-ima-1 <i>lag-id</i> : lag-63 <i>aps-id</i> : aps-1
dot1q	[port-id bundle-id/ bpgrp-id lag-id / aps-id]:qtag1	port-id:qtag1: 1/1/3:100 bundle-id: bundle-ppp-1/1.1 bpgrp-id: bpgrp-ima-1 lag-id:qtag1:lag-61:102 aps-id:qtag1: aps-1:27
qinq	[port-id bundle-id bpgrp-id lag-id]:qtag1.qtag2	<i>port-id</i> :qtag1.qtag2: 1/1/3:100.10 <i>bundle-id</i> : bundle-ppp-1/1.1 <i>bpgrp-id</i> : bpgrp-ima-1 <i>lag-id</i> :qtag1.qtag2:lag-10:
atm	[<i>port-id</i> <i>aps-id</i> <i>bundle-id</i> <i>bpgrp-id</i>][:vpi/vci vpi vpi1.vpi2]	port-id: 1/1/1 aps-id: aps-1 bundle-id: bundle-ima-1/1.1 bundle-ppp-1/1.1 bpgrp-id: bpgrp-ima-1 vpi/vci: 16/26 vpi: 16 vpi1.vpi2: 16.200
frame- relay	[port-id aps-id]:dlci	<i>port-id</i> : 1/1/1:100 <i>aps-id</i> : aps-1 <i>dlci</i> : 16
cisco-hdlc	slot/mda/port.channel	port-id: 1/1/3.1

Values: sap-id	null dot1q qinq atm frame cisco-hdlc	[port-id bundle-id bpgrp-id lag-id aps-id] [port-id bundle-id bpgrp-id lag-id aps-id]:qtag1 [port-id bundle-id bpgrp-id lag-id]:qtag1.qtag2 [port-id aps-id][:vpi/vci vpi vpi1.vpi2] [port-id aps-id]:dlci slot/mda/port.channel slot/mda/port.channel [bundle-id[:vpi/vci vpi1.vpi2] slot/mda/port[.channel] bundle-type-slot/mda.bundle-num		
	cem			
	ima-grp			
	port-id			
	bundle-id			
		bundle	keyword	
		type	ima, fr, ppp	
			bundle-num 1 — 336	
	bpgrp-id	bpgrp-type-bpgrp-num		
		bpgrp	keyword	
		type	ima, fr, ppp	
	ana id		1 — 2000	
	aps-id		<i>id</i> [<i>.channel</i>] keyword	
		aps group-id	1 — 64	
	ccag-id	ccag-id.path-id[cc-type]:cc-id		
	ceag la	ccag	keyword	
		id	1-8	
		path-id	a, b	
		cc-type	.sap-net, .net-sap	
		cc-id	0 - 4094	
	lag-id	lag-id		
		lag	keyword	
		id	1 - 200	
	qtag1	0 — 4094		
	qtag2	*, 0 — 4094 NNI: 0 — 4095		
	vpi			
	UNI: 0 — 255			
	vci	1, 2, 5 — 65535 16 — 1022 ipsec- <i>id</i> .[private public]: <i>tag</i>		
	dlci			
	ipsec-id			
		ipsec id	keyword 1 — 4	
			1 - 4 0 - 4094	
		tag	0 - +02+	

bundle-id — Specifies the multilink bundle to be associated with this IP interface. The **bundle** keyword must be entered at the beginning of the parameter.

The command syntax must be configured as follows:

bundle-id: **bundle***-type-slot-id/mda-slot.bundle-num bundle-id* value range: 1 — 336

For example:

7750 SR OS Router Configuration Guide

*A:ALA-12>config# port bundle-ppp-5/1.1
*A:ALA-12>config>port# multilink-bundle

bgprp-id — Specifies the bundle protection group ID to be associated with this IP interface. The **bpgrp** keyword must be entered at the beginning of the parameter.

The command syntax must be configured as follows:

bpgrp-id:	bpgrp-type-bpgrp-num
type:	ima
bpgrp-num value range:	1 - 2000

For example:

```
*A:ALA-12>config# port bpgrp-ima-1
*A:ALA-12>config>service>vpls$ sap bpgrp-ima-1
```

qtag1, *qtag2* — Specifies the encapsulation value used to identify the SAP on the port or sub-port. If this parameter is not specificially defined, the default value is 0.

Values	qtag1:	* 0 4094
	qtag2 :	* 0 - 4094

The values depends on the encapsulation type configured for the interface. The following table describes the allowed values for the port and encapsulation types.

Port Type	Encap-Type	Allowed Values	Comments
Ethernet	Null	0	The SAP is identified by the port.
Ethernet	Dot1q	0 — 4094	The SAP is identified by the 802.1Q tag on the port. Note that a 0 qtag1 value also accepts untagged packets on the dot1q port.
Ethernet	QinQ	qtag1: 0 — 4094 qtag2: 0 — 4094	The SAP is identified by two 802.1Q tags on the port. Note that a 0 qtag1 value also accepts untagged packets on the Dot1q port.
SONET/SDH	IPCP	-	The SAP is identified by the channel. No BCP is deployed and all traffic is IP.
SONET/SDH TDM	BCP-Null	0	The SAP is identified with a single service on the channel. Tags are assumed to be part of the customer packet and not a service delimiter.
SONET/SDH TDM	BCP-Dot1q	0 — 4094	The SAP is identified by the 802.1Q tag on the channel.
SONET/SDH TDM	Frame Relay	16 — 991	The SAP is identified by the data link connection identifier (DLCI).
SONET/SDH ATM	ATM	vpi (NNI) 0 — 4095 vpi (UNI) 0 — 255 vci 1, 2, 5 — 65535	The SAP is identified by port or by PVPC or PVCC identifier (vpi, vpi/vci, or vpi range)

sap ipsec-*id.***private**|**public***:tag* — This parameter associates an IPSec group SAP with this interface. This is the public side for an IPSec tunnel. Tunnels referencing this IPSec group in the private side may be created if their local IP is in the subnet of the interface subnet and the routing context specified matches with the one of the interface.

This context will provide a SAP to the tunnel. The operator may associate an ingress and egress QoS policies as well as filters and virtual scheduling contexts. Internally this creates an Ethernet SAP that will be used to send and receive encrypted traffic to and from the MDA. Multiple tunnels can be associated with this SAP. The "tag" will be a dot1q value. The operator may see it as an identifier. The range is limited to 1 - 4095.

Common CLI Command Descriptions

Standards and Protocol Support

Standards Compliance

IEEE 802.1ab-REV/D3 Station and Media Access Control Connectivity Discovery IEEE 802.1d Bridging IEEE 802.1p/Q VLAN Tagging IEEE 802.1s Multiple Spanning Tree IEEE 802.1w Rapid Spanning Tree Protocol IEEE 802.1x Port Based Network Access Control IEEE 802.1ad Provider Bridges IEEE 802.1ah Provider Backbone Bridges IEEE 802.1ag Service Layer OAM IEEE 802.3ah Ethernet in the First Mile IEEE 802.1ak Multiple MAC **Registration Protocol** IEEE 802.3 10BaseT IEEE 802.3ad Link Aggregation IEEE 802.3ae 10Gbps Ethernet IEEE 802.3ah Ethernet OAM IEEE 802.3u 100BaseTX IEEE 802.3x Flow Control IEEE 802.3z 1000BaseSX/LX ITU-T Y.1731 OAM functions and mechanisms for Ethernet based networks ITU-T G.8031 Ethernet linear protection switching

Protocol Support

OSPF

- RFC 1765 OSPF Database Overflow
- RFC 2328 OSPF Version 2
- RFC 2370 Opaque LSA Support
- RFC 2740 OSPF for IPv6 (OSPFv3) draft-ietf-ospf-ospfv3-update-14.txt
- RFC 3101 OSPF NSSA Option
- RFC 3137 OSPF Stub Router
- Advertisement
- RFC 3623 Graceful OSPF Restart GR helper
- RFC 3630 Traffic Engineering (TE) Extensions to OSPF Version 2

RFC 4203 for Shared Risk Link Group (SRLG) sub-TLV

BGP

RFC 1397 BGP Default Route Advertisement RFC 1772 Application of BGP in the Internet RFC 1965 Confederations for BGP **RFC 1997 BGP Communities Attribute RFC 2385 Protection of BGP Sessions** via MD5 RFC 2439 BGP Route Flap Dampening RFC 2547bis BGP/MPLS VPNs RFC 2918 Route Refresh Capability for BGP-4 RFC 3107 Carrying Label Information in BGP-4 RFC 3392 Capabilities Advertisement with BGP4 RFC 4271 BGP-4 (previously RFC 1771) **RFC 4360 BGP Extended Communities** Attribute RFC 4364 BGP/MPLS IP Virtual Private Networks (VPNs) (previously RFC 2547bis BGP/MPLS VPNs) RFC 4456 BGP Route Reflection: Alternative to Full-mesh IBGP (previously RFC 1966 & 2796) RFC 4724 Graceful Restart Mechanism for BGP — GR helper RFC 4760 Multi-protocol Extensions for

BGP

RFC 4893 BGP Support for Four-octet AS Number Space

RFC 5065 Confederations for BGP (obsoletes 3065)

IS-IS

RFC 1142 OSI IS-IS Intra-domain Routing Protocol (ISO 10589)

RFC 1195 Use of OSI IS-IS for routing in TCP/IP & dual environments

RFC 2763 Dynamic Hostname Exchange for IS-IS

- RFC 2966 Domain-wide Prefix Distribution with Two-Level IS-IS
- RFC 2973 IS-IS Mesh Groups
- RFC 3373 Three-Way Handshake for Intermediate System to Intermediate System (IS-IS) Point-to-Point Adjacencies
- RFC 3567 Intermediate System to Intermediate System (ISIS) Cryptographic Authentication
- RFC 3719 Recommendations for Interoperable Networks using IS-IS
- RFC 3784 Intermediate System to Intermediate System (IS-IS) Extensions for Traffic Engineering (TE)
- RFC 3787 Recommendations for Interoperable IP Networks
- RFC 3847 Restart Signaling for IS-IS GR helper
- RFC 4205 for Shared Risk Link Group (SRLG) TLV
- draft-ietf-isis-igp-p2p-over-lan-05.txt

LDP

- RFC 3036 LDP Specification RFC 3037 LDP Applicability RFC 3478 Graceful Restart Mechanism for LDP — GR helper RFC 5283 LDP extension for Inter-Area LSP
- draft-jork-ldp-igp-sync-03

IPSec

- RFC 2401 Security Architecture for the Internet Protocol
- RFC 2409 The Internet Key Exchange (IKE)
- RFC 3706 IKE Dead Peer Detection
- RFC 3947 Negotiation of NAT-Traversal in the IKE
- RFC 3948 UDP Encapsulation of IPsec ESP Packets
- draft-ietf-ipsec-isakmp-xauth-06.txt Extended Authentication within ISAKMP/Oakley (XAUTH)

draft-ietf-ipsec-isakmp-modecfg-05.txt — The ISAKMP Configuration Method

IPv6

- RFC 1981 Path MTU Discovery for IPv6
- RFC 2375 IPv6 Multicast Address Assignments
- RFC 2460 Internet Protocol, Version 6 (IPv6) Specification
- RFC 2461 Neighbor Discovery for IPv6
- RFC 2462 IPv6 Stateless Address Auto configuration
- RFC 2463 Internet Control Message Protocol (ICMPv6) for the Internet Protocol Version 6 Specification
- RFC 2464 Transmission of IPv6 Packets over Ethernet Networks
- RFC 2529 Transmission of IPv6 over IPv4 Domains without Explicit Tunnels
- RFC 2545 Use of BGP-4 Multiprotocol Extension for IPv6 Inter-Domain Routing
- RFC 2710 Multicast Listener Discovery (MLD) for IPv6
- RFC 2740 OSPF for IPv6
- RFC 3306 Unicast-Prefix-based IPv6 Multicast Addresses
- RFC 3315 Dynamic Host Configuration Protocol for IPv6
- RFC 3587 IPv6 Global Unicast Address Format
- RFC3590 Source Address Selection for the Multicast Listener Discovery (MLD) Protocol
- RFC 3810 Multicast Listener Discovery Version 2 (MLDv2) for IPv6
- RFC 4007 IPv6 Scoped Address Architecture
- RFC 4193 Unique Local IPv6 Unicast Addresses
- RFC 4291 IPv6 Addressing Architecture
- RFC 4552 Authentication/Confidentiality for OSPFv3
- RFC 4659 BGP-MPLS IP Virtual Private Network (VPN) Extension for IPv6 VPN
- RFC 5072 IP Version 6 over PPP
- RFC 5095 Deprecation of Type 0 Routing Headers in IPv6

draft-ietf-isis-ipv6-05

draft-ietf-isis-wg-multi-topology-xx.txt

Multicast

- RFC 1112 Host Extensions for IP Multicasting (Snooping)
- RFC 2236 Internet Group Management Protocol, (Snooping)
- RFC 3376 Internet Group Management Protocol, Version 3 (Snooping)
- RFC 2362 Protocol Independent Multicast-Sparse Mode (PIMSM)
- RFC 3618 Multicast Source Discovery Protocol (MSDP)

RFC 3446 Anycast Rendevous Point (RP) mechanism using Protocol Independent Multicast (PIM) and Multicast Source Discovery Protocol (MSDP)

RFC 4601 Protocol Independent Multicast - Sparse Mode (PIM-SM): Protocol Specification (Revised)

RFC 4604 Using IGMPv3 and MLDv2 for Source-Specific Multicast

- RFC 4607 Source-Specific Multicast for IP
- RFC 4608 Source-Specific Protocol Independent Multicast in 232/8
- RFC 4610 Anycast-RP Using Protocol Independent Multicast (PIM)
- draft-ietf-pim-sm-bsr-06.txt
- draft-rosen-vpn-mcast-08.txt
- draft-ietf-mboned-msdp-mib-01.txt
- draft-ietf-13vpn-2547bis-mcast-07: Multicast in MPLS/BGP IP VPNs
- draft-ietf-l3vpn-2547bis-mcast-bgp-05: BGP Encodings and Procedures for Multicast in MPLS/BGP IP VPNs
- RFC 3956: Embedding the Rendezvous Point (RP) Address in an IPv6 Multicast Address

MPLS

- RFC 3031 MPLS Architecture
- RFC 3032 MPLS Label Stack
- Encoding (REV3443))
- RFC 4379 Detecting Multi-Protocol Label Switched (MPLS) Data Plane Failures
- RFC 4182 Removing a Restriction on the use of MPLS Explicit NULL
- RFC 5332 MPLS Multicast Encapsulations

RIP

RFC 1058 RIP Version 1

RFC 2082 RIP-2 MD5 Authentication RFC 2453 RIP Version 2

RSVP-TE

- RFC 2430 A Provider Architecture DiffServ & TE
- RFC 2702 Requirements for Traffic Engineering over MPLS
- RFC2747 RSVP Cryptographic Authentication
- RFC3097 RSVP Cryptographic Authentication
- RFC 3209 Extensions to RSVP for Tunnels
- RFC 3564 Requirements for Diff-Servaware TE
- RFC 4090 Fast reroute Extensions to RSVP-TE for LSP Tunnels
- RFC 4124 Protocol Extensions for Support of Diffserv-aware MPLS Traffic Engineering
- RFC 4125 Maximum Allocation Bandwidth Constraints Model for Diffserv-aware MPLS Traffic Engineering
- RFC 4875 Extensions to Resource Reservation Protocol - Traffic Engineering (RSVP-TE) for Pointto-Multipoint TE Label Switched Paths (LSPs)
- draft-ietf-mpls-soft-preemption-14 MPLS Traffic Engineering Soft Preemption
- draft-ietf-ccamp-mpls-gracefulshutdown-06 Graceful Shutdown in GMPLS Traffic Engineering Networks
- draft-ietf-mpls-p2mp-lsp-ping-06 Graceful Shutdown in GMPLS Traffic Engineering Networks

DIFFERENTIATED SERVICES

- RFC 2474 Definition of the DS Field the IPv4 and IPv6 Headers (Rev)
- RFC 2597 Assured Forwarding PHB Group (rev3260)
- RFC 2598 An Expedited Forwarding PHB
- RFC 3140 Per-Hop Behavior Identification Codes

TCP/IP

RFC 768 UDP RFC 1350 The TFTP Protocol (Rev.

Standards and Protocols

RFC 791 IP RFC 792 ICMP RFC 793 TCP RFC 826 ARP RFC 854 Telnet RFC 951 BootP (rev) RFC 1519 CIDR RFC 1542 Clarifications and Extensions for the Bootstrap Protocol RFC 1812 Requirements for IPv4 Routers RFC 2347 TFTP option Extension **RFC 2328 TFTP Blocksize Option** RFC 2349 TFTP Timeout Interval and Transfer Size option RFC 2401 Security Architecture for Internet Protocol draft-ietf-bfd-mib-00.txtBidirectional Forwarding Detection Management Information Base draft-ietf-bfd-base-05.txt Bidirectional Forwarding Detection draft-ietf-bfd-v4v6-1hop-06.txt BFD IPv4 and IPv6 (Single Hop) draft-ietf-bfd-multihop-06.txt BFD for Multihop Paths

VRRP

RFC 2787 Definitions of Managed Objects for the Virtual Router Redundancy Protocol

RFC 3768 Virtual Router Redundancy Protocol

draft-ietf-vrrp-unified-spec-02: Virtual Router Redundancy Protocol Version 3 for IPv4 and IPv6

PPP

- RFC 1332 PPP IPCP
- RFC 1377 PPP OSINLCP
- RFC 1638/2878PPP BCP
- RFC 1661 PPP (rev RFC2151)
- RFC 1662 PPP in HDLC-like Framing RFC 1877 PPP Internet Protocol Control
- Protocol Extensions for Name Server Addresses
- RFC 1989 PPP Link Quality Monitoring
- RFC 1990 The PPP Multilink Protocol (MP) RFC 1994 PPP Challenge Handshake
- RFC 1994 PPP Challenge Handshake Authentication Protocol (CHAP)

RFC 2516 A Method for Transmitting PPP Over EthernetRFC 2615 PPP over SONET/SDH

RFC 2686 The Multi-Class Extension to Multi-Link PPP

Frame Relay

- FRF.1.2 PVC User-to-Network Interface (UNI) Implementation Agreement
- FRF.5 Frame Relay/ATM PVC Network Interworking Implementation
- ANSI T1.617 Annex D, DSS1 Signalling Specification For Frame Relay Bearer Service.
- FRF2.2 -PVC Network-to- Network Interface (NNI) Implementation Agreement.
- FRF.12 Frame Relay Fragmentation Implementation Agreement
- FRF.16.1 Multilink Frame Relay UNI/ NNI Implementation Agreement
- ITU-T Q.933 Annex A-Additional procedures for Permanent Virtual Connection (PVC) status management

ATM

- RFC 1626 Default IP MTU for use over ATM AAL5
- RFC 2514 Definitions of Textual Conventions and OBJECT_IDENTITIES for ATM Management
- RFC 2515 Definition of Managed Objects for ATM Management RFC 2684 Multiprotocol Encapsulation over ATM Adaptation Layer 5
- AF-TM-0121.000 Traffic Management Specification Version 4.1
- ITU-T Recommendation I.610 B-ISDN Operation and Maintenance Principles and Functions version 11/ 95
- ITU-T Recommendation I.432.1 BISDN user-network interface — Physical layer specification: General characteristics
- GR-1248-CORE Generic Requirements for Operations of ATM Network Elements (NEs). Issue 3
- GR-1113-CORE Bellcore, Asynchronous Transfer Mode (ATM) and ATM Adaptation Layer

(AAL) Protocols Generic Requirements, Issue 1

- AF-ILMI-0065.000 Integrated Local Management Interface (ILMI) Version 4.0
- AF-TM-0150.00 Addendum to Traffic Management v4.1 optional minimum desired cell rate indication for UBR
- AF-PHY-0086.001,Inverse Multiplexing for ATM (IMA) Specification Version 1.1

DHCP

- RFC 2131 Dynamic Host Configuration Protocol (REV)
- RFC 3046 DHCP Relay Agent Information Option (Option 82)
- RFC 1534 Interoperation between DHCP and BOOTP

VPLS

RFC 4762 Virtual Private LAN Services Using LDP draft-ietf-12vpn-vpls-mcast-reqts-04 draft-ietf-12vpn-signaling-08

PSEUDO-WIRE

RFC 3985 Pseudo Wire Emulation Edgeto-Edge (PWE3)

- RFC 4385 Pseudo Wire Emulation Edgeto-Edge (PWE3) Control Word for Use over an MPLS PSN
- RFC 3916 Requirements for Pseudo-Wire Emulation Edge-to-Edge (PWE3)
- RFC 4717 Encapsulation Methods for Transport ATM over MPLS Networks (draft-ietf-pwe3-atmencap-10.txt)
- RFC 4816 PWE3 ATM Transparent Cell Transport Service (draft-ietf-pwe3cell-transport-04.txt)
- RFC 4448 Encapsulation Methods for Transport of Ethernet over MPLS Networks (draft-ietf-pwe3-ethernetencap-11.txt)
- RFC 4619 Encapsulation Methods for Transport of Frame Relay over MPLS Networks (draft-ietf-pwe3frame-relay-07.txt)
- RFC 4446 IANA Allocations for PWE3

- RFC 4447 Pseudowire Setup and Maintenance Using LDP (draft-ietfpwe3-control-protocol-17.txt)
- RFC 5085, Pseudowire Virtual Circuit Connectivity Verification (VCCV):A Control Channel for Pseudowires

draft-ietf-l2vpn-vpws-iw-oam-02.txt draft-ietf-pwe3-oam-msg-map-05-txt draft-ietf-l2vpn-arp-mediation-04.txt draft-ietf-pwe3-ms-pw-arch-05.txt

- draft-ietf-pwe3-segmented-pw-11.txt draft-hart-pwe3-segmented-pw-vccv-02.txt
- draft-muley-dutta-pwe3-redundancy-bit-02.txt
- draft-muley-pwe3-redundancy-02.txt MFA Forum 9.0.0 The Use of Virtual trunks for ATM/MPLS Control
- Plane Interworking MFA Forum 12.0.0 Multiservice
- Interworking Ethernet over MPLS MFA forum 13.0.0 - Fault Management
- for Multiservice Interworking v1.0 MFA Forum 16.0.0 — Multiservice Interworking - IP over MPLS

ANCP/L2CP

draft-ietf-ancp-framework-01.txt draft-ietf-ancp-protocol-00.txt

CIRCUIT EMULATION

- RFC 4553 Structure-Agnostic Time Division Multiplexing (TDM) over Packet (SAToP)
- RFC 5086 Structure-Aware Time Division Multiplexed (TDM) Circuit Emulation Service over Packet Switched Network (CESoPSN)
- MEF-8 Implementation Agreement for the Emulation of PDH Circuits over Metro Ethernet Networks, October 2004
- RFC 5287 Control Protocol Extensions for the Setup of Time-Division Multiplexing (TDM) Pseudowires in MPLS Networks

SONET/SDH

- ITU-G.841 Telecommunication Standardization Section of ITU, Types and Characteristics of
- SDH Networks Protection Architecture, issued in October 1998 and as augmented by Corrigendum1 issued in July 2002

RADIUS

RFC 2865 Remote Authentication Dial In User Service RFC 2866 RADIUS Accounting

SSH

draft-ietf-secsh-architecture.txtSSH Protocol Architecture draft-ietf-secsh-userauth.txt SSH Authentication Protocol draft-ietf-secsh-transport.txt SSH Transport Layer Protocol draft-ietf-secsh-connection.txt SSH Connection Protocol draft-ietf-secsh- newmodes.txt SSH Transport Layer Encryption Modes

TACACS+

draft-grant-tacacs-02.txt

Timing

- GR-253-CORE SONET Transport Systems: Common Generic Criteria. Issue 3, September 2000
- ITU-T G.781 Telecommunication Standardization Section of ITU, Synchronization layer functions, issued 09/2008
- ITU-T G.813 Telecommunication Standardization Section of ITU, Timing characteristics of SDH equipment slave clocks (SEC), issued 03/2003.
- GR-1244-CORE Clocks for the Synchronized Network: Common Generic Criteria, Issue 3,May 2005
- ITU-T G.8261 Telecommunication Standardization Section of ITU, Timing and synchronization aspects in packet networks, issued 04/2008.
- ITU-T G.8262 Telecommunication Standardization Section of ITU, Timing characteristics of synchronous Ethernet equipment slave clock (EEC), issued 08/2007.

ITU-T G.8264 Telecommunication Standardization Section of ITU, Distribution of timing information through packet networks, issued 10/ 2008.

NETWORK MANAGEMENT

ITU-T X.721: Information technology-**OSI-Structure of Management** Information ITU-T X.734: Information technology-**OSI-Systems Management: Event** Report Management Function M.3100/3120 Equipment and Connection Models TMF 509/613 Network Connectivity Model RFC 1157 SNMPv1 RFC 1215 A Convention for Defining Traps for use with the SNMP RFC 1657 BGP4-MIB RFC 1724 RIPv2-MIB RFC 1850 OSPF-MIB RFC 1907 SNMPv2-MIB RFC 2011 IP-MIB RFC 2012 TCP-MIB RFC 2013 UDP-MIB RFC 2096 IP-FORWARD-MIB **RFC 2138 RADIUS** RFC 2206 RSVP-MIB RFC 2452 IPv6 Management Information Base for the Transmission Control Protocol RFC 2454 IPv6 Management Information Base for the User Datagram Protocol RFC 2465 Management Information Base for IPv6: Textual Conventions and General Group **RFC 2558 SONET-MIB RFC 2571 SNMP-FRAMEWORKMIB** RFC 2572 SNMP-MPD-MIB RFC 2573 SNMP-TARGET-&-NOTIFICATION-MIB RFC 2574 SNMP-USER-BASED-**SMMIB** RFC 2575 SNMP-VIEW-BASEDACM-MIB **RFC 2576 SNMP-COMMUNITY-MIB** RFC 2665 EtherLike-MIB RFC 2819 RMON-MIB RFC 2863 IF-MIB **RFC 2864 INVERTED-STACK-MIB**

RFC 2987 VRRP-MIB **RFC 3014 NOTIFICATION-LOGMIB** RFC 3019 IP Version 6 Management Information Base for The Multicast Listener Discovery Protocol RFC 3164 Syslog RFC 3273 HCRMON-MIB RFC 3411 An Architecture for Describing Simple Network Management Protocol (SNMP) Management Frameworks RFC 3412 - Message Processing and Dispatching for the Simple Network Management Protocol (SNMP) RFC 3413 - Simple Network Management Protocol (SNMP) Applications RFC 3414 - User-based Security Model (USM) for version 3 of the Simple Network Management Protocol (SNMPv3) RFC 3418 - SNMP MIB RFC 5101 - Specification of the IP Flow Information Export (IPFIX) Protocol for the Exchange of IP Traffic Flow Information draft-ietf-disman-alarm-mib-04.txt draft-ietf-ospf-mib-update-04.txt

draft-ietf-mpls-lsr-mib-06.txt draft-ietf-mpls-te-mib-04.txt draft-ietf-mpls-ldp-mib-07.txt draft-ietf-isis-wg-mib-05.txt IANA-IFType-MIB IEEE8023-LAG-MIB

Proprietary MIBs

TIMETRA-APS-MIB.mib TIMETRA-ATM-MIB.mib TIMETRA-BGP-MIB.mib TIMETRA-BSX-NG-MIB.mib TIMETRA-CAPABILITY-7750-V4v0.mib TIMETRA-CFLOWD-MIB.mib TIMETRA-CHASSIS-MIB.mib TIMETRA-CLEAR-MIB.mib TIMETRA-FILTER-MIB.mib TIMETRA-GLOBAL-MIB.mib TIMETRA-IGMP-MIB.mib TIMETRA-ISIS-MIB.mib TIMETRA-LAG-MIB.mib TIMETRA-LDP-MIB.mib TIMETRA-LOG-MIB.mib

TIMETRA-MIRROR-MIB.mib TIMETRA-MPLS-MIB.mib TIMETRA-NG-BGP-MIB.mib TIMETRA-OAM-TEST-MIB.mib TIMETRA-OSPF-NG-MIB.mib TIMETRA-OSPF-V3-MIB.mib TIMETRA-PIM-NG-MIB.mib TIMETRA-PORT-MIB.mib TIMETRA-PPP-MIB.mib TIMETRA-QOS-MIB.mib TIMETRA-RIP-MIB.mib TIMETRA-ROUTE-POLICY-MIB.mib TIMETRA-RSVP-MIB.mib TIMETRA-SECURITY-MIB.mib TIMETRA-SERV-MIB.mib TIMETRA-SUBSCRIBER-MGMTMIB.mib TIMETRA-SYSTEM-MIB.mib TIMETRA-TC-MIB.mib TIMETRA-VRRP-MIB.mib TIMETRA-VRTR-MIB.mib

Standards and Protocols

Index

С

Cflowd overview 472 collectors 472 filter matching 477 operation 473 V5 and V8 flow processing 475 configuring basic 485 collectors 483, 490 enabling 488 global parameters 489 interfaces and filters 491 IP interfaces 492 overview 482 sampling options 494 management tasks 497 command reference 499

F

Filters overview 334 applying filter to network ports 351 to SAP 351 entities 336 entries 335 filter entry ordering 349 filter types **IP** 334, 342 **IPv6** 334 MAC 334, 344, 352 matching criteria **DSCP** values 346 **IP** 342 IP option values 348 MAC 344 packets 342 policies 335 policy entries 335 port-based filtering 334 redirect policies 337

scope 352 services 336 configuring basic 356 IP filter policy 357, 362 MAC filter policy 364 redirect policy 374 applying to network ports 372 management tasks 378

I

IP Router overview 20 autonomous systems 25 confederations 26 interfaces 20 network 20 system 22 IP addresses 24 address range 24 Router ID 24 configuring autonomous systems 74 basic 47 command reference 79 confederations 72 interfaces 50 IP address range 67 network interface 46 overview 46 router ID 72 service management tasks 76 system interface 46 system name 48

V

VRRP overview 232 components 233 IP address owner 233 IP addresses 234

7750 SR OS Router Configuration Guide

Page 529

owner and non-owner 235 virtual router 233 virtual router backup 235 virtual router master 234 **VRID** 236 configuring basic 257 command reference 271 **IES** parameters 263 non-owner 263 owner 264 management tasks 267 overview 256 router interface 261, 265 non-owner 265 owner 266 VRRP policy parameters 262