



# 7210 SAS D, E OS Interface Configuration Guide

Software Version: 7210 SAS OS 5.0 Rev .01

October 2012

Document Part Number: 93-0415-01-01



---

This document is protected by copyright. Except as specifically permitted herein, no portion of the provided information can be reproduced in any form, or by any means, without prior written permission from Alcatel-Lucent.

Alcatel, Lucent, Alcatel-Lucent and the Alcatel-Lucent logo are trademarks of Alcatel-Lucent. All other trademarks are the property of their respective owners.

The information presented is subject to change without notice.

Alcatel-Lucent assumes no responsibility for inaccuracies contained herein.

Copyright 2011 Alcatel-Lucent. All rights reserved.

# TABLE OF CONTENTS

<b>Preface</b> .....	9
<b>Getting Started</b> .....	13
Alcatel-Lucent 7210 SAS D, E-Series Switch Configuration Process .....	13
<b>7210 SAS-Series Interfaces</b>	
Configuration Overview .....	16
Chassis Slots and Cards .....	16
Digital Diagnostics Monitoring .....	17
Alcatel-Lucent SFPs and XFPs .....	20
Statistics Collection .....	20
Ports .....	21
Port Types .....	21
LAG Features .....	22
Link Layer Discovery Protocol (LLDP) .....	23
LLDP Protocol Features .....	26
Port loopback for Ethernet ports .....	28
Port loopback without MAC swap .....	28
Port loop back with MAC swap .....	28
LAG .....	29
LAG Features .....	29
Configuring LAGs .....	30
LAG Hashing .....	31
LAG and QoS Policies .....	35
Port Link Damping .....	36
LACP .....	36
Multi-Chassis LAG .....	36
G.8032 Protected Ethernet Rings .....	37
802.3ah OAM .....	41
OAM Events .....	42
Remote Loopback .....	43
802.3ah OAM PDU Tunneling for Epipe Service .....	43
MTU Configuration Guidelines .....	44
Deploying Preprovisioned Components .....	47
Configuration Notes .....	48
Configuring Physical Ports with CLI .....	49
Preprovisioning Guidelines .....	50
Predefining Entities .....	50
Preprovisioning a Port .....	51
Basic Configuration .....	52
Common Configuration Tasks .....	53
Configuring Ports .....	54
Configuring Ethernet Port Parameters .....	55
Ethernet Access Uplink Port .....	55

## Table of Contents

Ethernet Access Port .....	55
Configuring 802.1x Authentication Port Parameters .....	57
Configuring LAG Parameters .....	58
Service Management Tasks .....	59
Modifying a Card Type .....	60
Deleting a Card .....	61
Deleting Port Parameters .....	61
Card, MDA, and Port Command Reference .....	63
<b>Standards and Protocol Support (7210 SAS D) .....</b>	<b>197</b>
<b>Standards and Protocol Support (7210 SAS E) .....</b>	<b>199</b>
<b>Index .....</b>	<b>201</b>

# LIST OF TABLES

## Getting Started

Table 1: Configuration Process .....13

## 7210 SAS-Series Interfaces

Table 2: Real-Time DDM Information .....18  
Table 3: DDM Alarms and Warnings .....19  
Table 4: Hashing mechanism for services configured on 7210 SAS-E devices .....31  
Table 5: Hashing mechanism for services configured on 7210 SAS-D devices .....33  
Table 6: MTU Default Values .....44  
Table 7: MTU Configuration Example Values .....45  
Table 8: MTU Configuration Example Values .....46



# LIST OF FIGURES

## 7210 SAS-Series Interfaces

Figure 1:	LLDP Internal Architecture for a Network Node .....	24
Figure 2:	Generic Customer Use Case For LLDP .....	25
Figure 3:	LAG Configuration .....	30
Figure 4:	MTU Configuration Example .....	45



## About This Guide

This guide describes system concepts and provides configuration examples to provision input/output and ports

This document is organized into functional chapters and provides concepts and descriptions of the implementation flow, as well as Command Line Interface (CLI) syntax and command usage.

## Audience

This manual is intended for network administrators who are responsible for configuring the 7210 SAS-Series routers. It is assumed that the network administrators have an understanding of networking principles and configurations, routing processes, and protocols and standards, including:

- CLI concepts
- MDA and port configuration
- QoS policies
- Services

## List of Technical Publications

The 7210-SAS D, E OS documentation set is composed of the following books:

- 7210-SAS D, E OS Basic System Configuration Guide  
This guide describes basic system configurations and operations.
- 7210-SAS D, E OS System Management Guide  
This guide describes system security and access configurations as well as event logging and accounting logs.
- 7210-SAS D, E OS Interface Configuration Guide  
This guide describes card, Media Dependent Adapter (MDA), and port provisioning.
- 7210-SAS D, E OS OS Router Configuration Guide  
This guide describes logical IP routing interfaces and associated attributes such as an IP address, port, link aggregation group (LAG) as well as IP and MAC-based filtering.
- 7210-SAS D, E OS Services Guide  
This guide describes how to configure service parameters such as customer information and user services.
- 7210-SAS D, E OS OAM and Diagnostic Guide  
This guide describes how to configure features such as service mirroring and Operations, Administration and Management (OAM) tools.
- 7210-SAS D, E OS Quality of Service Guide  
This guide describes how to configure Quality of Service (QoS) policy management.

## Technical Support

If you purchased a service agreement for your 7210 SAS-series router and related products from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance. If you purchased an Alcatel-Lucent service agreement, contact your welcome center:

Web: [http://www1.alcatel-lucent.com/comps/pages/carrier\\_support.jhtml](http://www1.alcatel-lucent.com/comps/pages/carrier_support.jhtml)

# GETTING STARTED

---

## In This Chapter

This chapter provides process flow information to configure cards and ports.

---

## Alcatel-Lucent 7210 SAS D, E-Series Switch Configuration Process

[Table 1](#) lists the tasks necessary to provision and ports.

This guide is presented in an overall logical configuration flow. Each section describes a software area and provides CLI syntax and command usage to configure parameters for a functional area.

**Table 1: Configuration Process**

Area	Task	Chapter
Provisioning	Chassis slots and cards	<a href="#">Chassis Slots and Cards on page 16</a>
	Ports	<a href="#">Ports on page 21</a>
Reference	List of IEEE, IETF, and other proprietary entities.	<a href="#">Standards and Protocol Support on page 197</a>



# 7210 SAS-Series Interfaces

---

## In This Chapter

This chapter provides information about configuring chassis slots, cards, and ports. Topics in this chapter include:

- [Configuration Overview on page 16](#)
  - [Chassis Slots and Cards on page 16](#)
  - [Digital Diagnostics Monitoring on page 17](#)
  - [Ports on page 21](#)
    - [Port Types on page 21](#)
  - [LAG on page 29](#)
    - [Multi-Chassis LAG on page 36](#)
    - [802.1x Network Access Control on page 37](#)
  - [MTU Configuration Guidelines on page 44](#)
  - [Deploying Preprovisioned Components on page 47](#)
- [Configuration Notes on page 48](#)

## Configuration Overview

NOTE: This document uses the term pre-provisioning in the context of preparing or pre-configuring entities such as chassis slots, media dependent adapters (MDAs), ports, and interfaces, prior to initialization. These entities can be installed but not enabled. When the entity is in a **no shutdown** state (administratively enabled) then the entity is considered to be provisioned.

Alcatel- Lucent 7210 SAS devices are single chassis devices. The 7210 SAS devices do not accept any IOM cards.

The chassis slot is auto-provisioned at boot time with the appropriate line card type.

The following sections are discussed.

- [Chassis Slots and Cards on page 16](#)
  - [Ports on page 21](#)
- 

## Chassis Slots and Cards

The 7210 SAS E supports the following:

- 12 x 10/100/1000 SFP ports
- One Ethernet out of band management port
- One management console port
- 12 x 10/100/1000 BASE-T ports

The 7210 SAS D supports the following:

- 6 x 10/100/1000 SFP ports
- 4 x 10/100/1000 BASE-T ports
- One management console port

## Digital Diagnostics Monitoring

Some Alcatel-Lucent SFPs, XFPs, and the MSA DWDM transponder have Digital Diagnostics Monitoring (DDM) capability where the transceiver module maintains information about its working status in device registers including:

- Temperature
- Supply voltage
- Transmit (TX) bias current
- TX output power
- Received (RX) optical power

The transceiver is also programmed with warning and alarm thresholds for low and high conditions that can generate system events. These thresholds are programmed by the transceiver manufacturer.

There are no CLI commands required for DDM operations, however, the **show>port *port-id* detail** command displays DDM information in the Transceiver Digital Diagnostics Monitoring output section.

DDM information is populated into the router's MIBs, so the DDM data can be retrieved by Network Management using SNMP. Also, RMON threshold monitoring can be configured for the DDM MIB variables to set custom event thresholds if the factory-programmed thresholds are not at the desired levels.

The following are potential uses of the DDM data:

- Optics degradation monitoring — With the information returned by the DDM-capable optics module, degradation in optical performance can be monitored and trigger events based on custom or the factory-programmed warning and alarm thresholds.
- Link/router fault isolation — With the information returned by the DDM-capable optics module, any optical problem affecting a port can be quickly identified or eliminated as the potential problem source.

Supported real-time DDM features are summarized in [Table 2](#).

**Table 2: Real-Time DDM Information**

Parameter	User Units	SFP/XFP Units	SFP	XFP	MSA DWDM
Temperature	Celsius	C	Supported	Supported	Supported
Supply Voltage	Volts	$\mu$ V	Supported	Supported	Not supported
TX Bias Current	mA	$\mu$ A	Supported	Supported	Supported
TX Output Power	dBm (converted from mW)	mW	Supported	Supported	Supported
RX Received Optical Power4	dBm (converted from dBm) (Avg Rx Power or OMA)	mW	Supported	Supported	Supported
AUX1	parameter dependent (embedded in transceiver)	-	Not supported	Supported	Not supported
AUX2	parameter dependent (embedded in transceiver)	-	Not supported	Supported	Not supported

The factory-programmed DDM alarms and warnings that are supported are summarized in [Table 3](#).

**Table 3: DDM Alarms and Warnings**

Parameter	SFP/XFP Units	SFP	XFP	Required?	MSA DWDM
Temperature - High Alarm - Low Alarm - High Warning - Low Warning	C	Yes	Yes	Yes	Yes
Supply Voltage - High Alarm - Low Alarm - High Warning - Low Warning	$\mu$ V	Yes	Yes	Yes	No
TX Bias Current - High Alarm - Low Alarm - High Warning - Low Warning	$\mu$ A	Yes	Yes	Yes	Yes
TX Output Power - High Alarm - Low Alarm - High Warning - Low Warning	mW	Yes	Yes	Yes	Yes
RX Optical Power - High Alarm - Low Alarm - High Warning - Low Warning	mW	Yes	Yes	Yes	Yes
AUX1 - High Alarm - Low Alarm - High Warning - Low Warning	parameter dependent (embedded in transceiver)	No	Yes	Yes	No
AUX2 - High Alarm - Low Alarm - High Warning - Low Warning	parameter dependent (embedded in transceiver)	No	Yes	Yes	No

## Alcatel-Lucent SFPs and XFPs

The availability of the DDM real-time information and warning/alarm status is based on the transceiver. It may or may not indicate that DDM is supported. Although some Alcatel-Lucent SFPs support DDM, initial releases of 7210 SAS does not support DDM. Please contact Alcatel-Lucent representatives for information on the software release in which DDM functionality is supported. Non-DDM and DDM-supported SFPs are distinguished by a specific ICS value.

For Alcatel-Lucent SFPs that do not indicate DDM support in the ICS value, DDM data is available although the accuracy of the information has not been validated or verified.

For non-Alcatel-Lucent transceivers, DDM information may be displayed, but Alcatel-Lucent is not responsible for formatting, accuracy, etc.

---

## Statistics Collection

The DDM information and warnings/alarms are collected at one minute intervals, so the minimum resolution for any DDM events when correlating with other system events is one minute.

Note that in the Transceiver Digital Diagnostic Monitoring section of the **show port *port-id* detail** command output:

- If the present measured value is higher than the either or both High Alarm, High Warn thresholds; an exclamation mark “!” displays along with the threshold value.
- If the present measured value is lower than the either or both Low Alarm, Low Warn thresholds; an exclamation mark “!” displays along with the threshold value.

```
B:SR7-101# show port 2/1/6 detail
.....
=====
Transceiver Digital Diagnostic Monitoring (DDM), Internally Calibrated
=====
                Value High Alarm  High Warn   Low Warn  Low Alarm
-----
Temperature (C)      +33.0+98.0  +88.0      -43.0-45.0
Supply Voltage (V)   3.31 4.12   3.60       3.00 2.80
Tx Bias Current (mA)5.7 60.0   50.00.1  0.0
Tx Output Power (dBm) -5.45 0.00  -2.00     -10.50  -12.50
Rx Optical Power (avg dBm) -0.65-3.00! -4.00!    -19.51  -20.51
=====
```

# Ports

---

## Port Types

Before a port can be configured, the slot must be provisioned with a card type and MDA type specified.

The Alcatel-Lucent 7210 SAS routers support the following port types:

- Ethernet — Supported Ethernet port types include 10/100/1000 BaseT and 100/1000 fiber ports. Access uplink ports must be configured as access uplink. The default is access.
  - Access ports — Configured for customer facing traffic on which services are configured. If a Service Access Port (SAP) is to be configured on the port, it must be configured as an access port. When a port is configured for access mode, the appropriate encapsulation type must be configured to distinguish the services on the port. Once a port has been configured for access mode, one or more services can be configured on the port depending on the encapsulation value.
  - Access uplink ports — Configured for network facing traffic. These ports participate in the service provider transport or infrastructure network. QinQ is supported on access uplink ports. These ports are similar to network mode ports configured in the Alcatel-Lucent's 7750 SR, 7710 SR, and 7450 ESS service routers, and in some aspects, like ingress QoS policies apply per port for access uplink ports.

Note: 10/100/1000 Base-T Copper SFPs can be used in any of the SFP ports. It supports all speeds.

## LAG Features

- [LAG on page 29](#)
- [802.1x Network Access Control on page 37](#)


## Link Layer Discovery Protocol (LLDP)

The IEEE 802.1ab Link Layer Discovery Protocol (LLDP) standard defines protocol and management elements suitable for advertising information to stations attached to the same IEEE 802 LAN. The protocol facilitates the identification of stations connected by IEEE 802 LANs or MANs, their points of interconnection, and access points for management protocols.

The LLDP helps the network operators to discover topology information. This information is used to detect and resolve network problems and inconsistencies in the configuration.

Listed below is the information included in the protocol defined by the IEEE 802.1ab standard:

- Connectivity and management information about the local station to adjacent stations on the same IEEE 802 LAN is advertised.
- Network management information from adjacent stations on the same IEEE 802 LAN is received.
- Operates with all IEEE 802 access protocols and network media.
- Network management information schema and object definitions that suitable for storing connection information about adjacent stations is established.
- Provides compatibility with a number of MIBs. Refer to [Figure 1](#).




OSSG262

**Figure 1: LLDP Internal Architecture for a Network Node**

In order to detect and address network problems and inconsistencies in the configuration, the network operators can discover the topology information using LLDP. The Standard-based tools address the complex network scenarios where multiple devices from different vendors are interconnected using Ethernet interfaces.

The example displayed in [Figure 2](#) depicts a MPLS network that uses Ethernet interfaces in the core or as an access/handoff interfaces to connect to different kind of Ethernet enabled devices such as service gateway/routers, QinQ switches DSLAMs or customer equipment.

The topology information of the network in [Figure 2](#) can be discovered if, IEEE 802.1ab LLDP is running on each of the Ethernet interfaces in network.



OSSG263

**Figure 2: Generic Customer Use Case For LLDP**

## LLDP Protocol Features

The IEEE 802.1ab Link Layer Discovery Protocol (LLDP) is a uni-directional protocol that uses the MAC layer to transmit specific information related to the capabilities and status of the local device. The LLDP can send as well as receive information from a remote device stored in the related MIB(s).

The LLDP does not contain a mechanism to solicit information received from other LLDP agents. The protocol also does not provide means to confirm the receipt of information. LLDP provides the flexibility of enabling a transmitter and receiver separately, therefore the following LLDP configurations are allowed:

- An LLDP agent can only transmit information.
- An LLDP agent can only receive information.
- An LLDP agent can transmit and receive information.

The information fields in each LLDP frame are contained in an LLDP Data Unit (LLDPDU) as a sequence of variable length information elements. Each information element includes Type, Length, and Value fields (TLVs).

- Type indicates the nature of information being transmitted.
- Length indicates the length of the information string in octets.
- Value is the actual information that is transmitted. (For example, a binary bit map or an alphanumeric string that can contain one or more fields).

Each LLDPDU contains four mandatory TLVs and optional TLVs selected by the Network Management. Below is the format of a LLDPDU:

- Chassis ID TLV
- Port ID TLV
- Time To Live TLV
- Zero or more optional TLVs, depending on the maximum size of the LLDPDU allowed.
- End Of LLDPDU TLV

An LLDP agent or port is identified by a concatenated string formed by the Chassis ID TLV and the Port ID TLV. This string is used by a recipient to identify an LLDP port or agent. The combination of the Port ID and Chassis ID TLVs remains unchanged until the port or agent is operational.

The TTL (Time To Live) field of an Time-To-Live TLV can be either zero or a non-zero value. A zero value in the TTL field notifies the receiving LLDP agent to immediately discard all information related to the sending LLDP agent. A non-zero value in the TTL field indicates the time duration for which the receiving LLDP agent should retain the sending LLDP agent's

information. The receiving LLDP agent discards all information related to the sending LLDP agent after the time interval indicated in the TTL field is complete.

**Note:** A TTL value of zero can be used to signal that the sending LLDP port has initiated a port shutdown procedure.

The End Of LLDPDU TLV indicates the end of the LLDPDU.

## Port loopback for Ethernet ports

7210 devices support port loopback for ethernet ports. There are two flavors of port loopback commands - port loopback without mac-swap and port loopback with mac-swap. Both these commands are helpful for testing the service configuration and measuring performance parameters such as throughput, delay, and jitter on service turn-up. Typically, a third-party external test device is used to inject packets at desired rate into the service at a central office location.

The following sections describe the port loopback functionality

### Port loopback without MAC swap

When the Port loopback command is enabled, the system enables PHY/MAC loopback on the specified port. All the packets are sent out the port configured for loopback and received back by the system. On ingress to the system after the loopback, the node processes the packets as per the service configuration for the SAP.

This flavor is recommended for use with only VLL services. This command affects all the services configured on the port, therefore the user is advised to ensure all the configuration guidelines mentioned for this feature in the command description are followed.

### Port loop back with MAC swap

**Note:** The port loopback with MAC swap functionality is not supported on 7210 SAS-E devices.

The 7210 SAS provides port loop back support with MAC swap. When the Port loopback command is enabled, the system enables PHY/MAC loopback on the specified port. All the packets are sent out the port configured for loopback and received back by the system. On ingress to the system after the loopback, the node swaps the MAC addresses for the specified SAP and the service. It only processes packets that match the specified source MAC address and destination MAC address, while dropping packets that do not match. It processes these packets as per the service configuration for the SAP.

This flavor is recommended for use with only VPLS and VLL services. This command affects all the services configured on the port, therefore the user is advised to ensure all the configuration guidelines mentioned for this feature in the command description are followed

# LAG

Based on the IEEE 802.3ax standard (formerly 802.3ad), Link Aggregation Groups (LAGs) can be configured to increase the bandwidth available between two network devices, depending on the number of links installed. LAG also provides redundancy in the event that one or more links participating in the LAG fail. All physical links in a given LAG links combine to form one logical interface.

Packet sequencing must be maintained for any given session. The hashing algorithm deployed by Alcatel-Lucent routers is based on the type of traffic transported to ensure that all traffic in a flow remains in sequence while providing effective load sharing across the links in the LAG.

LAGs must be statically configured or formed dynamically with Link Aggregation Control Protocol (LACP). The optional marker protocol described in IEEE 802.3ax is not implemented. LAGs can be configured on access uplink and access ports.

---

## LAG Features

Hardware capabilities:

- The LAG load sharing is executed in hardware, which provides line rate forwarding for all port types.

Software capabilities:

- Conforms to the IEEE LAG implementation.

## Configuring LAGs

LAG configuration guidelines include:

- A maximum of 6 LAGs, 2 ports in each, can be configured on the 7210 SAS-Series.
- Ports can be added or removed from the LAG while the LAG and its ports (other than the port being removed) remain operational. When ports to and/or from the LAG are added or removed, the hashing algorithm is adjusted for the new port count.
- The **show** commands display physical port statistics on a port-by-port basis or the entire LAG can be displayed.
- LAG is supported on Ethernet ports.
- Ports of a particular LAG can be of different types but they must be the same speed and duplex. To guarantee the same port speed is used for all ports in a LAG, autonegotiation must be disabled or in limited mode to ensure only a specific speed is advertised.

Figure 3 displays traffic routed between ALA-1 and ALA-2 as a LAG consisting of four ports.




Figure 3: LAG Configuration

## LAG Hashing

When a requirement exists to increase the available bandwidth for a logical link that exceeds the physical bandwidth or add redundancy for a physical link, typically Link Aggregation (LAG) one of the methods is applied. The supports up to 16 equal cost routes in ECMP and up to two ports per LAG.

The Alcatel-Lucent implementation supports per flow hashing used to achieve uniform loadspreading and per service hashing designed to provide consistent per service forwarding. Depending on the type of traffic that needs to be distributed into LAG, different variables are used as input to the hashing algorithm that determines the next hop selection.

In the tables below, it is assumed that the traffic flows from “A” to “B” (A and B represent SAPs, SDPs or IP interfaces) and it summarizes the variables used for different services and traffic types.

**Table 4: Hashing mechanism for services configured on 7210 SAS-E devices**

Services	Traffic Type	A	B	Hashing
E- pipe	IP or non-IP traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination MAC address</li> <li>• Port ID</li> </ul>
VPLS	Learnt non-IP traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination MAC address</li> <li>• Ether type</li> <li>• VLAN ID</li> <li>• Port ID</li> </ul>
VPLS	Learnt IP traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination IP address</li> <li>• Source or destination L4 ports</li> <li>• Port ID</li> </ul>

**Table 4: Hashing mechanism for services configured on 7210 SAS-E devices**

<b>Services</b>	<b>Traffic Type</b>	<b>A</b>	<b>B</b>	<b>Hashing</b>
VPLS	Broadcast or Unlearned or Multicast traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination MAC address</li> <li>• Port ID</li> </ul>
IES	IP traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination IP address and Source or destination L4 ports</li> <li>• Port ID</li> </ul>
IES	IPv4 Traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination IP address and Source or destination L4 ports</li> <li>• Port ID</li> </ul>

**NOTE:**

1. VLAN ID is considered for Learnt non-IP traffic in VPLS only for the traffic ingressing at dot1q, Q.\* and Q1.Q2 SAPS.
2. Only outer VLAN tag is considered for hashing.

**Table 5: Hashing mechanism for services configured on 7210 SAS-D devices**

<b>Services</b>	<b>Traffic Type</b>	<b>A</b>	<b>B</b>	<b>Hashing</b>
E- pipe	Non-IP traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination MAC address</li> <li>• Ether type</li> <li>• VLAN ID</li> </ul>
E- pipe	IP traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination IP address</li> <li>• Source or destination L4 ports</li> </ul>
VPLS	Unlearned Non-IP traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination MAC address,</li> <li>• Ether type</li> <li>• VLAN ID</li> <li>• Port ID</li> </ul>
E-pipe	Non-IP traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination MAC address</li> <li>• Ether type and VLAN ID</li> <li>• Port ID</li> </ul>
E-pipe	IP traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination IP address</li> <li>• Source or destination L4 ports</li> <li>• Port ID</li> </ul>

**NOTE:**

1. VLAN ID is considered for Learnt non-IP traffic in VPLS only for the traffic ingressing at dot1q, Q.\* and Q1.Q2 SAPS.
2. Only outer VLAN tag is considered for hashing.

**Table 5: Hashing mechanism for services configured on 7210 SAS-D devices**

<b>Services</b>	<b>Traffic Type</b>	<b>A</b>	<b>B</b>	<b>Hashing</b>
VPLS	Unlearnt non-IP traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination MAC address</li> <li>• Ether type</li> <li>• VLAN ID</li> <li>• Port ID</li> </ul>
VPLS	Unlearnt IP traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination IP address</li> <li>• Source or destination L4 ports</li> <li>• Port ID</li> </ul>
VPLS	Learnt non-IP traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination MAC address</li> <li>• Ether type</li> <li>• VLAN ID</li> </ul>

**NOTE:**

1. VLAN ID is considered for Learnt non-IP traffic in VPLS only for the traffic ingressing at dot1q, Q.\* and Q1.Q2 SAPS.
2. Only outer VLAN tag is considered for hashing.

**Table 5: Hashing mechanism for services configured on 7210 SAS-D devices**

Services	Traffic Type	A	B	Hashing
VPLS	Learnt IP traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination IP address</li> <li>• Source or destination L4 ports</li> </ul>
IES	IP traffic Port ID	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination IP address and Source or destination L4 ports</li> </ul>
IES	IPv4 traffic	SAP	SAP	<ul style="list-style-type: none"> <li>• Source or destination IP address and Source or destination L4, and Port ID</li> </ul>

**LAG and QoS Policies**

In the 7210 SAS E, an ingress QoS policy is applied to the aggregate traffic that enters the traffic through all the ports of the system. For example, if an ingress policy is configured with a policier of PIR 100Mb, for a SAP configured on a LAG with two ports, then the policier limits the traffic entering the system through the two ports to a maximum of 100Mb.

In the 7210 SAS E, egress QoS policy shaper parameters are applied to all the ports that are members of the LAG (all ports get the full SLA). For example, if an egress policy is configured with a policier of PIR 100Mb, each port would get a PIR of 100 Mb. The advantage of this method over a scheme where the PIR is divided equally among all the member ports of the LAG, is that a single flow can consume the entire SLA. The disadvantage is that the overall SLA can be exceeded if the flows span multiple ports.

## Port Link Damping

Hold time controls enable port link damping timers that reduce the number of link transitions reported to upper layer protocols.

The 7210 SAS OS port link damping feature guards against excessive port transitions. Any initial port transition is immediately advertised to upper layer protocols, but any subsequent port transitions are not advertised to upper layer protocols until a configured timer has expired.

An “up” timer controls the dampening timer for link up transitions, and a “down” timer controls the dampening timer for link down transitions.

---

## LACP

Generally, link aggregation is used for two purposes: provide an increase in bandwidth and/or provide redundancy. Both aspects are addressed by aggregating several Ethernet links in a single LAG.

LACP enhancements allow active lag-member selection based on particular constrains. The mechanism is based on the IEEE 802.3ax standard so interoperability is ensured.

---

## Multi-Chassis LAG

This section describes the Multi-Chassis LAG (MC-LAG) concept. MC-LAG is an extension of a LAG concept that provides node-level redundancy in addition to link-level redundancy provided by “regular LAG”.

Typically, MC-LAG is deployed in a network-wide scenario providing redundant connection between different end points. The whole scenario is then built by combination of different mechanisms (for example, MC-LAG and redundant pseudowire to provide e2e redundant p2p connection or dual homing of DSLAMs in Layer 2/3 TPSDA).

The 7210 SAS supports the capability which enables it to connect to an MC-LAG-enabled node. In particular, the 7210 SAS, allows for provisioning of links into sub-groups in a LAG and supports active/standby links. Note that the MC-LAG solution can be achieved with or without subgroups configured.

NOTE: The 7210 SAS cannot peer with an MC-LAG-enabled node since it does not implement MC-LAG protocol.

## G.8032 Protected Ethernet Rings

Ethernet ring protection switching offers ITU-T G.8032 specification compliance to achieve resiliency for Ethernet Layer 2 networks. G.8032 (Eth-ring) is built on Ethernet OAM and often referred to as Ring Automatic Protection Switching (R-APS).

For further information on Ethernet rings, see G.8032 Protected Ethernet Rings section in the Services Guide.

---

### 802.1x Network Access Control

The Alcatel-Lucent 7210 SAS supports network access control of client devices (PCs, STBs, etc.) on an Ethernet network using the IEEE. 802.1x standard. 802.1x is known as Extensible Authentication Protocol (EAP) over a LAN network or EAPOL.

---

### 802.1x Modes

The Alcatel-Lucent 7210 SAS supports port-based network access control for Ethernet ports only. Every Ethernet port can be configured to operate in one of three different operation modes, controlled by the port-control parameter:

- **force-auth** — Disables 802.1x authentication and causes the port to transition to the authorized state without requiring any authentication exchange. The port transmits and receives normal traffic without requiring 802.1x-based host authentication. This is the default setting.
- **force-unauth** — Causes the port to remain in the unauthorized state, ignoring all attempts by the hosts to authenticate. The switch cannot provide authentication services to the host through the interface.
- **auto** — Enables 802.1x authentication. The port starts in the unauthorized state, allowing only EAPOL frames to be sent and received through the port. Both the router and the host can initiate an authentication procedure as described below. The port will remain in unauthorized state (no traffic except EAPOL frames is allowed) until the first client is authenticated successfully. After this, traffic is allowed on the port for all connected hosts.

### 802.1x Basics

- The supplicant — This is the end-user device that requests access to the network.
- The authenticator — Controls access to the network. Both the supplicant and the authenticator are referred to as Port Authentication Entities (PAEs).
- The authentication server — Performs the actual processing of the user information.

The authentication exchange is carried out between the supplicant and the authentication server, the authenticator acts only as a bridge. The communication between the supplicant and the authenticator is done via the Extended Authentication Protocol (EAP) over LANs (EAPOL). On the back end, the communication between the authenticator and the authentication server is done with the RADIUS protocol. The authenticator is thus a RADIUS client, and the authentication server a RADIUS server.

The router will initiate the procedure when the Ethernet port becomes operationally up, by sending a special PDU called EAP-Request/ID to the client. The client can also initiate the exchange by sending an EAPOL-start PDU, if it doesn't receive the EAP-Request/ID frame during bootup. The client responds on the EAP-Request/ID with a EAP-Response/ID frame, containing its identity (typically username + password).

After receiving the EAP-Response/ID frame, the router will encapsulate the identity information into a RADIUS AccessRequest packet, and send it off to the configured RADIUS server.

The RADIUS server checks the supplied credentials, and if approved will return an Access Accept message to the router. The router notifies the client with an EAP-Success PDU and puts the port in authorized state.

## 802.1x Timers

The 802.1x authentication procedure is controlled by a number of configurable timers and scalars. There are two separate sets, one for the EAPOL message exchange and one for the RADIUS message exchange.

EAPOL timers:

- *transit-period* — Indicates how many seconds the Authenticator will listen for an EAP-Response/ID frame. If the timer expires, a new EAP-Request/ID frame will be sent and the timer restarted. The default value is 60. The range is 1-3600 seconds.
- *supplicant-timeout* — This timer is started at the beginning of a new authentication procedure (transmission of first EAP-Request/ID frame). If the timer expires before an EAP-Response/ID frame is received, the 802.1x authentication session is considered as having failed. The default value is 30. The range is 1 — 300.
- *quiet-period* — Indicates number of seconds between authentication sessions It is started after logoff, after sending an EAP-Failure message or after expiry of the supplicant-timeout timer. The default value is 60. The range is 1 — 3600.

RADIUS timer and scalar:

- *max-auth-req* — Indicates the maximum number of times that the router will send an authentication request to the RADIUS server before the procedure is considered as having failed. The default value is value 2. The range is 1 — 10.
- *server-timeout* — Indicates how many seconds the authenticator will wait for a RADIUS response message. If the timer expires, the access request message is sent again, up to *max-auth-req* times. The default value is 60. The range is 1 — 3600 seconds.

The router can also be configured to periodically trigger the authentication procedure automatically. This is controlled by the *enable re-authentication* and *reauth-period* parameters. *Reauth-period* indicates the period in seconds (since the last time that the authorization state was confirmed) before a new authentication procedure is started. The range of *reauth-period* is 1 — 9000 seconds (the default is 3600 seconds, one hour). Note that the port stays in an authorized state during the re-authentication procedure.

## 802.1x Configuration and Limitations

Configuration of 802.1x network access control on the router consists of two parts:

- Generic parameters, which are configured under **config>security>dot1x**
- Port-specific parameters, which are configured under **config>port>ethernet>dot1x**

801.x authentication:

- Provides access to the port for any device, even if only a single client has been authenticated.
- Can only be used to gain access to a pre-defined Service Access Point (SAP). It is not possible to dynamically select a service (such as a VPLS service) depending on the 802.1x authentication information.

## 802.3ah OAM

802.3ah Clause 57 (EFM OAM) defines the Operations, Administration, and Maintenance (OAM) sub-layer, which provides mechanisms useful for monitoring link operation such as remote fault indication and remote loopback control. In general, OAM provides network operators the ability to monitor the health of the network and quickly determine the location of failing links or fault conditions. EFM OAM described in this clause provides data link layer mechanisms that complement applications that may reside in higher layers.

OAM information is conveyed in slow protocol frames called OAM protocol data units (OAMPDUs). OAMPDUs contain the appropriate control and status information used to monitor, test and troubleshoot OAM-enabled links. OAMPDUs traverse a single link, being passed between peer OAM entities, and as such, are not forwarded by MAC clients (like bridges or switches).

The following EFM OAM functions are supported:

- EFM OAM capability discovery.
- Active and passive modes.
- Remote failure indication — Handling of critical link events (for example, link fault, critical event, dying gasp)
- Loopback — A mechanism is provided to support a data link layer frame-level loopback mode. Both remote and local loopback modes are supported.
- Generation of dying gasp message on access uplink ports on power failure.
- EFM OAMPDU tunneling.
- Timer for EFM OAM in 500ms interval (minimum).

## OAM Events

EFM OAM defines a set of events that may impact link operation. The following events are supported:

- Critical link events (defined in 802.3ah clause 57.2.10.1)
  - Link fault: the PHY has determined a fault has occurred in the receive direction of the local DTE.
  - Dying gasp: an unrecoverable local failure condition has occurred.
  - Critical event: an unspecified critical event has occurred.

These critical link events are signaled to the remote DTE by the flag field in OAM PDUs.

The 7210 does not generate EFM OAM PDUs with these flags except for the dying gasp flag. However, it supports processing of these flags in EFM OAM PDUs received from the peer.

## Remote Loopback

EFM OAM provides a link-layer frame loopback mode that can be remotely controlled.

To initiate remote loopback, the local EFM OAM client sends a loopback control OAM PDU by enabling the OAM remote-loopback command. After receiving the loopback control OAM PDU, the remote OAM client puts the remote port into local loopback mode.

To exit remote loopback, the local EFM OAM client sends a loopback control OAM PDU by disabling the OAM remote-loopback command. After receiving the loopback control OAM PDU, the remote OAM client puts the port back into normal forwarding mode.

Note that during remote loopback test operation, all frames except EFM OAM PDUs are dropped at the local port for the receive direction, where remote loopback is enabled. If local loopback is enabled, then all frames except EFM OAM PDUs are dropped at the local port for both the receive and transmit directions. This behavior may result in many protocols (such as STP or LAG) resetting their state machines.

Note that when a port is in loopback mode, service mirroring will not work if the port is a mirror-source or a mirror-destination.

---

## 802.3ah OAM PDU Tunneling for Epipe Service

The 7210 SAS routers support 802.3ah. Customers who subscribe to Epipe service treat the Epipe as a wire, so they demand the ability to run 802.3ah between their devices which are located at each end of the Epipe.

Note: This feature only applies to port-based Epipe SAPs because 802.3ah runs at port level not VLAN level. Hence, such ports must be configured as null encapsulated SAPs.

When OAM PDU tunneling is enabled, 802.3ah OAM PDUs received at one end of an Epipe are forwarded through the Epipe. 802.3ah can run between devices that are located at each end of the Epipe. When OAM PDU tunneling is disabled (by default), OAM PDUs are dropped or processed locally according to the **efm-oam** configuration (**shutdown** or **no shutdown**).

Note that by enabling 802.3ah for a specific port and enabling OAM PDU tunneling for the same port are mutually exclusive.

## MTU Configuration Guidelines

Observe the following general rules when planning your physical MTU configurations:

The 7210 SAS must contend with MTU limitations at many service points. The physical (access and access uplink) port, MTU values must be individually defined.

- Identify the ports that are designated as access uplink ports as these are intended to carry service traffic.
- MTU values should not be modified frequently.
- MTU values must conform to the following conditions:
  - The access uplink port MTU must be greater than or equal to the access port MTU plus the overhead added by the system (for example, typically 4 bytes of VLAN tag are added when a packet is transmitted using the QinQ access uplink).

### Default MTU Values

[Table 6](#) displays the default MTU values which are dependent upon the (sub-) port type, mode, and encapsulation.

**Table 6: MTU Default Values**

Port Type	Mode	Encap Type	Default (bytes)
Ethernet	access	null	1514
Ethernet	access	dot1q	1518
Fast Ethernet	uplink	—	1522
Other Ethernet	uplink	—	9212*

\*The default MTU for Ethernet ports other than Fast Ethernet is actually the lesser of 9212 and any MTU limitations imposed by hardware which is typically 9728 bytes.

## Modifying MTU Defaults


MTU parameters can be modified on the port level.

- The port-level MTU parameters configure the maximum payload MTU size for an Ethernet port that is part of a multilink bundle or LAG.

The default MTU values should be modified to ensure that packets are not dropped due to frame size limitations.

## Configuration Example

In order for the maximum length service frame to successfully travel from a local ingress SAP to a remote egress SAP, the MTU values configured on the port on which the local ingress SAP is provisioned and the port on which egress SAP is provisioned must be coordinated to accept the maximum frame size the service can forward. For example, the targeted MTU values to configure for an Epipe service (ALA-A and ALA-B) are displayed in [Figure 4](#).



**Figure 4: MTU Configuration Example**

Since ALA-A uses Dot1q encapsulation, the port 1/1/1 MTU must be set to 1518 to be able to accept a 1514-byte service frame (see [Table 7](#) for MTU default values). Each of the access uplink port's MTU must be set to at least 1518 as well. Finally, the MTU of ALA-B's SAP (access port 1/1/2) must be at least 1514, as it uses null encapsulation.

**Table 7: MTU Configuration Example Values**

	ALA-A		ALA-B	
	Access (SAP)	Access Uplink (SAP)	Access Uplink (SAP)	Access (SAP)
Port (slot/MDA/port)	1/1/1	1/1/24	1/1/18	1/1/2
Mode type	access (dot1q)	access-uplink (QinQ)	access-uplink (QinQ)	access (null)
MTU	1518	1518	1518	1514

Instead, if ALA-A uses a dot1p-preserve SAP on port 1/1/1, then port 1/1/1 MTU must be set to 1518 to be able to accept a 1514-byte service frame (see [Table 8](#) for MTU default values). Each of the access uplink port's MTU must be set to at least 1522 as well. Finally, the MTU of ALA-B's SAP (access port 1/1/2) must be at least 1518, as it uses Dot1q encapsulation.

**Table 8: MTU Configuration Example Values**

	ALA-A		ALA-B	
	Access (SAP)	Access Uplink (SAP)	Access Uplink (SAP)	Access (SAP)
Port (slot/MDA/port)	1/1/1	1/1/24	1/1/18	1/1/2
Mode type	access (dot1q-preserve)	access-uplink (QinQ)	access-uplink (QinQ)	access (dot1q-preserve)
MTU	1518	1522	1522	1518

## Deploying Preprovisioned Components

Cards and MDAs are auto-provisioned by the system and does not need to be provisioned by the user.

## Configuration Notes

The following information describes provisioning caveats:

- Ports can be provisioned without provisioning slot, card and MDA type, since these are auto-provisioned.

## Configuring Physical Ports with CLI

This section provides information to configure cards, MDAs, and ports.

Topics in this section include:

- [Preprovisioning Guidelines on page 50](#)
  - [Predefining Entities on page 50](#)
  - [Preprovisioning a Port on page 51](#)
- [Basic Configuration on page 52](#)
- [Common Configuration Tasks on page 53](#)
  - [Configuring Ports on page 54](#)
- [Common Configuration Tasks on page 53](#)
  - [Configuring Ports on page 54](#)
    - [Configuring Ethernet Port Parameters on page 55](#)
  - [Configuring LAG Parameters on page 58](#)
- [Service Management Tasks on page 59](#)
  - [Modifying a Card Type on page 60](#)
  - [Deleting a Card on page 61](#)
  - [Deleting Port Parameters on page 61](#)

## Preprovisioning Guidelines

7210 SAS routers have a console port to connect terminals to the router. The 7210 SAS does not support a management port.

Configure parameters from a system console connected to a console port, using Telnet to access a 7210 SAS remotely or SSH to open a secure shell connection.

---

## Predefining Entities

The 7210 SAS auto-provisions card and MDA types.

In order to initialize a card, the chassis slot, line card type, and MDA type must match the preprovisioned parameters. In this context, *preprovisioning* means to configure the entity type (such as the line card type, MDA type, port, and interface) that is planned for a chassis slot, line card, or MDA. Preprovisioned entities can be installed but not enabled or the slots can be configured but remain empty until populated. *Provisioning* means that the preprovisioned entity is installed and enabled.

You can:

- Pre-provision ports and interfaces after the line card and MDA types are specified.
- Install line cards in slots with no preconfiguration parameters specified. Once the card is installed, the card and MDA types must be specified.
- Install a line card in a slot provisioned for a different card type (the card will not initialize). The existing card and MDA configuration must be deleted and replaced with the current information.

## Preprovisioning a Port

Some recommendations to configure a port include:

- Ethernet
  - Configure an access port for customer facing traffic on which services are configured.  
An encapsulation type may be specified in order to distinguish services on the port or channel. Encapsulation types are not required for network ports.  
To configure an Ethernet access port, refer to [on page 55](#).

## Basic Configuration

The most basic configuration must have the following:

- Identify chassis slot.
- Specify line card type (must be an allowed card type).
- Identify MDA slot.
- Specify MDA type (must be an allowed MDA type).
- Identify specific port to configure.

## Common Configuration Tasks

The following sections are basic system tasks that must be performed.

- [Configuring Ports on page 54](#)
  - [Configuring Ethernet Port Parameters on page 55](#)
- [Configuring LAG Parameters on page 58](#)
- [Service Management Tasks on page 59](#)

## Configuring Ports

- [Configuring Ethernet Port Parameters on page 55](#)

The following example displays the default port pool configurations.

```
*A:card-1>config>port# info detail
-----
description "10/100/Gig Ethernet SFP"
access
  egress
    pool default
    resv-cbs default
    slope-policy "default"
  exit
exit
uplink
  egress
    pool default
    resv-cbs default
    slope-policy "default"
  exit
exit
exit
exit
...
-----
*A:card-1>config>port#
```

## Configuring Ethernet Port Parameters

---

### Ethernet Access Uplink Port

An access uplink port is network facing and participates in the service provider transport or infrastructure network processes. This is similar to a network port concept, except that the 7210 SAS E does not allow IP interfaces nor runs routing protocols.

A SAP can be created when a port is configured in access uplink mode. When a port is configured in access uplink mode, then the encapsulation type of the port is set to QinQ.

The following example displays a network port configuration:

```
A:ALA-B>config>port# info
-----
description "Ethernet Access Uplink port"
-----
    ethernet
        mode access uplink
    exit
    no shutdown
-----
A:ALA-B>config>port#
```

---

### Ethernet Access Port

Services are configured on access ports used for customer-facing traffic. If a Service Access Port (SAP) is to be configured on a port, it must be configured as access mode or access uplink mode. When a port is configured for access mode, the appropriate encapsulation type can be specified to distinguish the services on the port. Once a port has been configured for access mode, multiple services may be configured on the port.

The following example displays an Ethernet access port configuration (For 7210 SAS-D):

```
*A:7210-SAS>config>port# info
-----
    ethernet
        mode access
        access
            egress
        exit
    exit
    encap-type dot1q
    mtu 9212
    loopback internal service 1 sap 1/1/1:2 src-mac 00:00:00:22:22:22 dst-mac
00:00:00:11:11:11
```

## Configuring Ports

```
exit
no shutdown
```

```
-----
*A:7210-SAS>config>port# show service id 1 sap 1/1/1:2 detail
```

The following example displays an Ethernet access port configuration (For 7210 SAS-E):

```
A:ALA-A>config>port# info
```

```
-----
description "Ethernet access port"
access
  egress
    pool
      slope-policy "slopePolicy1"
    exit
  exit
exit
ethernet
  mode access
  encaps-type dot1q
exit
no shutdown
```

```
-----
A:ALA-A>config>port#
```

---

## Configuring 802.1x Authentication Port Parameters

The following example displays an 802.1x port configuration:

```
A:ALA-A>config>port>ethernet>dot1x# info detail
-----
      port-control auto
      radius-plcy dot1xpolicy
      re-authentication
      re-auth-period 3600
      max-auth-req 2
      transmit-period 30
      quiet-period 60
      supplicant-timeout 30
      server-timeout 30
-----
```

## Configuring LAG Parameters

LAG configurations should include at least two ports. Other considerations include:

- A maximum of two ports can be included in a LAG. All ports in the LAG must share the same characteristics (speed, duplex, hold-timer, etc.). The port characteristics are inherited from the primary port.
- Autonegotiation must be disabled or set limited mode for ports that are part of a LAG to guarantee a specific port speed.
- Ports in a LAG must be configured as full duplex.

The following example displays LAG configuration output:

```
A:ALA-A>config>lag# info detail
-----
description "LAG2"
mac 04:68:ff:00:00:01
port 1/1/1
port 1/3/1
-----
A:ALA-A>config>lag#
```

## Service Management Tasks

This section discusses basic procedures of the following service management tasks:

- [Modifying a Card Type on page 60](#)
- [Deleting a Card on page 61](#)
- [Deleting Port Parameters on page 61](#)

To change an MDA type already provisioned for a specific slot/card, first you must shut down the slot/MDA/port configuration and then delete the MDA from the configuration. Modify and delete operations can be performed only on the MDAs that are not auto equipped or auto provisioned.

Use the following CLI syntax to modify an MDA:

**CLI Syntax:** `config> port port-id  
shutdown`

**CLI Syntax:** `config> card slot-number  
shutdown  
[no] mda mda-number  
[no] mda-type mda-type  
shutdown`

## **Modifying a Card Type**

The modify operation cannot be performed on an IOM card that is auto equipped and auto provisioned during bootup and is fixed.

## Deleting a Card

The delete operation cannot be performed on an IOM card that is auto equipped and auto provisioned during bootup and is fixed.

---

## Deleting Port Parameters

Use the following CLI syntax to delete a port provisioned for a specific card:

**CLI Syntax:** `config>port port-id`  
`shutdown`  
`no port port-id`



---

## Card, MDA, and Port Command Reference

---

### Command Hierarchies

#### Card and MDA Configuration Commands

- [Hardware Commands on page 64](#)
- [Card Commands on page 64](#)[Port Configuration Commands on page 65](#)
- [Ethernet Commands on page 67](#)
- [LAG Commands on page 69](#)
- [Ethernet Ring Commands on page 70](#)
- [Show Commands on page 71](#)
- [Clear Commands on page 72](#)
- [Debug Commands on page 72](#)

## Hardware Commands

- config**
- **[no] card** *slot-number*
- **card-type** *card-type*
- **[no] mda** *mda-slot*
  - **mda-type** *mda-type*
  - **no mda-type**
  - **[no] shutdown**
  - **[no] sync-e**
- **[no] shutdown**

## Port Configuration Commands

```
config
  — port
  — no port
    — access
      — egress
        — [no] pool [name]
          — slope-policy name
          — no slope-policy
      — uplink
        — egress
          — [no] pool [name]
            — slope-policy name
            — no slope-policy
    — description long-description-string
    — no description
    — ethernet
    — [no] shutdown
    — split-horizon-group group-name
    — split-horizon-group group-name
```

## Port Loopback Commands

**configure**

— **system**

- **loopback-no-svc-port** {**mac-swap** | **mirror**} *port-id* [ **NOTE: applicable only for 7210 SAS-E**]
- **no loopback-no-svc-port**

## Ethernet Commands

```

config
  — [no] port {port-id}
    — ethernet
      — access
        — accounting-policy acct-policy-id
        — no accounting-policy
        — [no] collect-stats
        — egress
          — qosqos
          — qos policy-id
          — no qos
        — uplink
          — accounting-policy acct-policy-id
          — no accounting-policy
          — [no] collect-stats
          — qos policy-id
          — no qos
          — queue-policy name
          — no queue-policy
      — autonegotiate [limited]
      — [no] autonegotiate
      — dot1x
        — tmax-auth-req max-auth-request
        — port-control {auto | force-auth | force-unauth}
        — quiet-period seconds
        — [no] radius-ply name
        — re-auth-period seconds
        — [no] re-authentication
        — server-timeout seconds
        — no server-timeout
        — supplicant-timeout seconds
        — no supplicant-timeout
        — transmit-period seconds
        — no transmit-period
      — down-when-looped
        — keep-alive timer
        — no keep-alive
        — retry-timeout timer
        — no retry-timeout
        — [no] shutdown
      — duplex {full | half}
      — efm-oam
        — [no] accept-remote-loopback
        — mode {active | passive}
        — [no] shutdown
        — [no] transmit-interval interval [multiplier multiplier]
        — [no] tunneling
      — egress-rate <sub-rate> [max-burst <size-in-kbits>]
      — no egress-rate
      — encap-type {dot1q | null}
      — no encap-type
      — hold-time {[up hold-time up] [down hold-time down]}

```

- **no hold-time**
- **no ip-mtu** *mtu-bytes* (supported only on 7210 SAS-E)
- **[no] lacp-tunnel** (supported only on 7210 SAS0-D)
- **lldp**
  - **[no] tunnel-nearest-bridge-dest-mac**(supported only on 7210 SAS-D)
  - **dest-mac** {nearest-bridge | nearest-non-tpmr | nearest-customer}
    - **admin-status** {rx | tx | tx-rx | disabled}
    - **[no] notification**
    - **tx-mgmt-address** [system]
    - **no tx-mgmt-address**
    - **tx-flvs** [port-desc] [sys-name] [sys-desc] [sys-cap]
    - **no tx-flvs**
- **no loopback** {internal} [service *svc-id* sap *sap-id* src-mac *SA* dst-mac *DA*]
- **mac** *ieee-address*
- **no mac**
- **mode** access [uplink]
- **no mode**
- **mtu** *mtu-bytes*
- **no mtu**
- **qinq-etype** *0x0600..0xffff*
- **no qinq-etype**
- **[no] port-clock** {master | slave} (Supported only on 7210 SAS-D ETR)
- **speed** {10 | 100 | 1000}
- **ssm** (Supported on 7210 SAS-D only)
  - **[no] shutdown**
  - **code-type** sonet | sdh
  - **[no] tx-dus**
- **statistics**
  - **egress**
    - **queue** *queue-id*
      - **[no] packets-forwarded-count**

## LAG Commands

- ```

config
  — [no] lag [lag-id]
    — description long-description-string
    — no description
    — encap-type { dot1q | null | qinq }
    — no encap-type
    — hold-time down hold-down-time
    — no hold-time
    — lacp [mode] [administrative-key admin-key] [system-id system-id][system-priority
      priority]
    — lacp-xmit-interval { slow | fast }
    — no lacp-xmit-interval
    — [no] lacp-xmit-stdby
    — mac ieee-address
    — no mac
    — mode access [uplink]
    — no mode
    — port port-id [port-id ... up to 4 total] [priority priority] [sub-group sub-group-id]
    — no port port-id [port-id ... up to 4 total]
    — port-threshold value [action { down }]
    — no port-threshold
    — selection-criteria [highest-count | highest-weight] [slave-to-partner]
    — no selection-criteria
    — [no] shutdown

```

## Ethernet Ring Commands

```
config
— eth-ring ring-id
— no eth-ring
— description long-description-string
— no description
— guard-time time
— revert-time time
— ccm-hold-time { down down-timeout | up up-timeout }
— [no] rpl-node { owner | nbr }
— node-id mac
— path { a | b } [ { port-id | lag-id } raps-tag qtag[qtag] ]
— description long-description-string
— [no] rpl-end
— eth-cfm
— [no] mep mep-id domain md-index association ma-index
— [no] ccm-enable
— [no] ccm-ltm-priority priority
— [no] control-mep
— [no] eth-test-enable
— [no] test-pattern { all-zeros | all-ones } [crc-enable]
— bit-error-threshold bit-errors
— mac-address mac-address
— one-way-delay-threshold seconds
— [no] shutdown
```

## Show Commands

- ```

show
— chassis [environment] [power-supply] ('environment' option not supported on 7210 SAS D)
— card [slot-number] [detail]
— card state
— pools <mda-id[/port]> [<access-app> [<pool-name>]][access-app [pool-name]]
— pools <mda-id[/port]> [<network-app> [<pool-name>]][access-app [pool-name]]
— lag [lag-id] [detail] [statistics]
— lag lag-id associations
— port port-id [count] [statistics] [detail]
— port port-id description
— port port-id associations
— port port-id dot1x [detail]
— port port-id ethernet [efm-oam | detail]
— port [A1] [detail] [statistics] [description] (Out-of-band Ethernet port is not supported on 7210 SAS
D devices)
— lldp [nearest-bridge | nearest-non-tpmr | nearest-customer] [remote-info] [detail]
—
— system
— internal-loopback-ports [detail]

```

## Monitor Commands

### Monitor

— **port** *port-id* [*port-id...*(up to 5 max)] [**interval** *seconds*] [**repeat** *repeat*] [**absolute** | **rate**]

## Clear Commands

### clear

— **lag** *lag-id* **statistics**  
— **port** *port-id* **statistics**

## Debug Commands

### debug

— **lag** [**lag-id** *lag-id* **port** *port-id*] [**all**]  
— **lag** [**lag-id** *lag-id* **port** *port-id*] [**sm**] [**pkt**] [**cfg**] [**red**] [**iom-upd**] [**port-state**] [**timers**] [**sel-logic**]  
— **no lag** [**lag-id** *lag-id*]

---

## Configuration Commands

- [Generic Commands on page 73](#)
- [Card Commands on page 75](#)
- [Interface QoS Commands on page 78](#)
- [General Port Commands on page 80](#)
- [Ethernet Port Commands on page 84](#)
- [802.1x Port Commands on page 97](#)
- [LAG Commands on page 107](#)
- [Ethernet Ring Commands on page 112](#)

---

## Generic Commands

### description

**Syntax**    **description** *description-string*  
**no description**

**Context**    config>port  
 config>lag  
 config>split-horizon-group

**Description**    This command creates a text description for a configuration context to help identify the content in the configuration file.

The **no** form of this command removes any description string from the context.

**Default**    No description is associated with the configuration context.

**Parameters**    *long-description-string* — The description character string. Strings can be up to 160 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

### shutdown

**Syntax**    [**no**] **shutdown**

**Context**    config>card  
 config>card>mda  
 config>port  
 config>port>ethernet

## Generic Commands

```
config>lag  
config>port>ethernet>ssm
```

### Description

This command administratively disables an entity. When disabled, an entity does not change, reset, or remove any configuration settings or statistics.

The operational state of the entity is disabled as well as the operational state of any entities contained within.

The **no** form of this command administratively enables an entity.

**card** — The default state for a card is **no shutdown**.

**mda** — The default state for a mda is **no shutdown**.

**lag** — The default state for a Link Aggregation Group (LAG) is **shutdown**.

**port** — The default state for a port is **shutdown**.

---

## Card Commands

### card

**Syntax** `card slot-number`

**Context** config

**Description** This mandatory command enables access to the chassis card Input/Output Module (IOM), slot, and MDA CLI context.

The **no** form of this command cannot be used on fixed IOM and MDA cards that are auto equipped and auto provisioned.

**Default** No cards are configured. The IOM card is equipped and provisioned for slot 1.

**Parameters** *slot-number* — The slot number of the card in the chassis.

### card-type

**Syntax** `card-type card-type`

**Context** config>card

**Description** This mandatory command adds an to the device configuration for the slot. The card type can be preprovisioned, meaning that the card does not need to be installed in the chassis.

A card must be provisioned before an MDA or port can be configured.

A card can only be provisioned in a slot that is vacant, meaning no other card can be provisioned (configured) for that particular slot.

A card can only be provisioned in a slot if the card type is allowed in the slot. An error message is generated if an attempt is made to provision a card type that is not allowed.

A high severity alarm is raised if an administratively enabled card is removed from the chassis. The alarm is cleared when the correct card type is installed or the configuration is modified. A low severity trap is issued when a card is removed that is administratively disabled.

An appropriate alarm is raised if a partial or complete card failure is detected. The alarm is cleared when the error condition ceases.

The **no** form of this command cannot be used as the card is fixed.

**Default** The card is equipped and preprovisioned for slot 1.

---

## MDA Commands

### mda

<b>Syntax</b>	<b>mda</b> <i>mda-slot</i> <b>no mda</b> <i>mda-slot</i>
<b>Context</b>	config>card
<b>Description</b>	This mandatory command enables access to a card's MDA CLI context to configure MDAs.
<b>Default</b>	1
<b>Parameters</b>	<i>mda-slot</i> — The MDA slot number to be configured. Fixed ports on the panel of the chassis belong to MDA 1.

### mda-type

<b>Syntax</b>	<b>mda-type</b> <i>mda-type</i> <b>no mda-type</b>
<b>Context</b>	config>card>mda
<b>Description</b>	<p>This mandatory command provisions a specific MDA type to the device configuration for the slot. The MDA can be preprovisioned but an MDA must be provisioned before ports can be configured. Ports can be configured once the MDA is properly provisioned.</p> <p>A maximum of three MDAs can be provisioned on an IOM. Only one MDA can be provisioned per IOM MDA slot. To modify an MDA slot, shut down all port associations.</p> <p>An alarm is raised if partial or complete MDA failure is detected. The alarm is cleared when the error condition ceases.</p> <p>MDA 1 does not need to be configured as is provisioned automatically during bootup.</p> <p>The <b>no</b> form of this command deletes the MDA from the configuration. The MDA must be administratively shut down before it can be deleted from the configuration. A fixed MDA that is auto equipped and auto provisioned cannot be deleted. An error message is shown in case the <b>no</b> form of command is performed on fixed MDAs.</p>
<b>Default</b>	MDA 1 is equipped and provisioned by default during bootup.
<b>Parameters</b>	<i>mda-type</i> — The type of MDA selected for the slot position.
<b>Values</b>	m4-tx+6-sfp

**sync-e****Syntax** [no] sync-e**Context** config>card>mda

**Description** This command enables Synchronous Ethernet on the Ethernet ports that support Synchronous Ethernet. When Synchronous Ethernet is enabled, the timing information is derived from the Ethernet ports.

Synchronous Ethernet is supported for both Ethernet SFP ports and fixed copper ports. It is highly recommended to use copper port only for distribution of synchronous ethernet and not as a reference. Refer to the 7210 SAS Basic System Configuration Guide for more information on Synchronous Ethernet.

**Default** no sync-e

---

## Interface QoS Commands

### access

**Syntax**     **access**

**Context**     config>card>mda  
              config>port

**Description**   This command enables the access context to configure egress and ingress pool policy parameters.

### uplink

**Syntax**     **uplink**

**Context**     config>port>access

**Description**   This command enables the network context to configure egress pool policy parameters.

### egress

**Syntax**     **egress**

**Context**     config>port>access  
              config>port>access>uplink

**Description**   This command enables the context to specify the slope policy that is configured in the **config>qos>slope-policy** context.

### pool

**Syntax**     [no] **pool** [*name*]

**Context**     config>port>access>egress  
              config>port>access>uplink>egress

**Description**   This command configures pool policies.

**Default**     default

**Parameters**   *name* — Specifies the pool name, a string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

## slope-policy

**Syntax** **slope-policy** *name*  
**no slope-policy**

**Context** config>port>access>egress>pool  
config>port>access uplink>egress>pool

**Description** This command specifies an existing slope policy which defines high and low priority RED slope parameters. The policy is defined in the **config>qos>slope-policy** context.

## qos

**Syntax** **qos** *policy-id*  
**no qos**

**Context** config>port>ethernet>access>egress  
config>port>ethernet>access>uplink

**Description** This command associates a QoS policy to the port.

**Parameters** *policy-id* — Specifies an existing QoS policy to be assigned to the port.

**Values** 1 — 65535

---

## General Port Commands

### port

<b>Syntax</b>	<b>port</b> <b>no port</b>
<b>Context</b>	config
<b>Description</b>	This command enables access to the context to configure ports. Before a port can be configured, the chassis slot must be provisioned with a valid card type and the MDA parameter must be provisioned with a valid MDA type. (See <b>card</b> and <b>mda</b> commands.)
<b>Default</b>	No ports are configured. All ports must be explicitly configured and enabled.
<b>Parameters</b>	<i>port-id</i> — Specifies the physical port ID in the <i>slot/mda/port</i> format.
	<b>Values</b>

### egress-scheduler-policy

<b>Syntax</b>	<b>egress-scheduler-policy</b> <i>port-scheduler-policy-name</i> <b>no egress-scheduler-policy</b>
<b>Context</b>	config>port>ethernet
<b>Description</b>	The default scheduling done for a port is strict scheduling. When a port-scheduler-policy is applied to the port, the scheduling behavior changes to the one specified in the policy (Strict, RR, WRR, WDRR, WRR/WDRR + Strict).  The <b>no</b> form of the command removes the policy from the port and makes the scheduling scheme of the port to strict.

### mode

<b>Syntax</b>	<b>mode access</b> [ <b>uplink</b> ] <b>no mode</b>
<b>Context</b>	config>port>ethernet
<b>Description</b>	This command configures an Ethernet port for <b>access</b> or <b>access uplink</b> mode operation.  An <b>access</b> port is used for customer facing traffic on which services are configured. A Service Access Point (SAP) can only be configured on an access port or channel. When a port is configured for access mode, the appropriate <b>encap-type</b> must be specified to distinguish the services on the port. Once an Ethernet port has been configured for access mode, multiple services can be configured on the Ethernet port.

The **no** form of this command restores the default.

**Default** **access** — Configures the Ethernet port for transport access use.

**Parameters** **access** — Configures the Ethernet port as service access.  
**access uplink** — Configures the Ethernet port for transport access uplink use.

## mac

**Syntax** **mac** *ieee-address*  
**no mac**

**Context** config>port>ethernet  
 config>lag  
 config>eth-tunnel

**Description** This command assigns a specific MAC address to an Ethernet port, Link Aggregation Group (LAG), Ethernet tunnel.

Only one MAC address can be assigned to a port. When multiple **mac** commands are entered, the last command overwrites the previous command. When the command is issued while the port is operational, IP will issue an ARP, if appropriate, and BPDU's are sent with the new MAC address.

The **no** form of this command returns the MAC address to the default value.

**Default** A default MAC address is assigned by the system from the chassis MAC address pool.

**Parameters** *ieee-address* — Specifies the 48-bit MAC address in the form aa:bb:cc:dd:ee:ff or aa-bb-cc-dd-ee-ff where aa, bb, cc, dd, ee and ff are hexadecimal numbers. Allowed values are any non-broadcast, non-multicast MAC and non-IEEE reserved MAC addresses.

## mtu

**Syntax** **mtu** *mtu-bytes*  
**no mtu**

**Context** config>port>ethernet

**Description** This command configures the maximum payload MTU size for an Ethernet port port. The Ethernet port level MTU parameter indirectly defines the largest physical packet the port can transmit or the far-end Ethernet port can receive. Packets received larger than the MTU will be discarded. Packets that cannot be fragmented at egress and exceed the MTU are discarded.

The value specified for the MTU includes the destination MAC address, source MAC address, the Ethertype or Length field and the complete Ethernet payload. The MTU value does not include the preamble, start of frame delimiter or the trailing CRC.

The **no** form of this command restores the default values.

**Default** The default MTU value depends on the (sub-)port type, mode and encapsulation and are listed in the following table:

## General Port Commands

Type	Mode	Encap Type	Default (Bytes)
10/100, Gig	Access	null	1514
10/100, Gig	Access	dot1q	1518
10/100, Gig	Access	q-in-q	1522

**Parameters** *mtu-bytes* — Sets the maximum allowable size of the MTU, expressed as an integer.

**Values** 512 — 9212

config>port>ethernet

**Range**

512 — 9212

---

## Port Loopback Commands

### loopback-no-svc-port

**Syntax** [ no ] loopback-no-svc-port {*mirror* | *mac-swap* }*port-id*

**Context** config>system

**Description** This command specifies the port to assign for system use when using port loopback with mac-swap OAM tool or for the mirroring OAM tool. The system utilizes the resources of the port and the port is not available for configuring services.

**NOTE:** This command is applicable only for the 7210 SAS-E device.

User cannot share a single port between both these tools/applications, if they intend to use both these two tools simultaneously. The system displays an error if the user tries to configure the same port for use with both these tools OR if the user tries to use the tool without first configuring the port resources to be used by the tool. User will have to execute the command twice, once for each OAM tool with a different port ID, if they intend to use both these tools simultaneously. Example: user can dedicate two ports for use, by executing the command loopback-no-svc-port mirror 1/1/1 for use with mirroring, followed by execution of the command loopback-no-svc-port mac-swap 1/1/2 again, for mac-swap OAM tool. For more information, see the platform specific note at the end of this CLI description.

The system verifies if any services are configured on the port specified with this command and if services are configured the command fails.

The no form of the command disables the use of this port by the specified OAM tool.

**NOTE:**

On 7210 SAS-E, this command must be used and the user needs to dedicate one front-panel port for use with the mirroring applications. Port loopback with mac-swap is not supported on 7210 SAS-E. On 7210 SAS-D (ETR and non-ETR variants), the system automatically uses the resources of the internal ports and hence this command is not supported.

**Default** None

**Parameters** *port-id* — Specifies the physical port ID in the slot/mda/port format.

*mac-swap* - Keyword not supported for 7210 SAS-E.

*mirror* — Specifies the port specified by the port-id is dedicated for use by the mirroring application/OAM tool.

## Ethernet Port Commands

### ethernet

**Syntax** ethernet

**Context** config>port

**Description** This command enables access to the context to configure access parameters.  
This context can only be used when configuring Ethernet LAN ports on an appropriate MDA.

### access

**Syntax** access

**Context** config>port>ethernet

**Description** This command configures Ethernet access port parameters.

### egress

**Syntax** egress

**Context** config>port>ethernet>access

**Description** This command configures Ethernet access egress port parameters.

### ingress

**Syntax** ingress

**Context** config>port>ethernet>access

**Description** This command configures Ethernet access ingress port parameters.

### autonegotiate

**Syntax** autonegotiate [limited]  
[no] autonegotiate

**Context** config>port>ethernet

<b>Description</b>	<p>This command enables speed and duplex autonegotiation on Fast Ethernet ports and enables far-end fault indicator support on gigabit ports.</p> <p>There are three possible settings for autonegotiation:</p> <ul style="list-style-type: none"> <li>• “on” or enabled with full port capabilities advertised</li> <li>• “off” or disabled where there are no autonegotiation advertisements</li> <li>• “limited” where a single speed/duplex is advertised.</li> </ul> <p>When autonegotiation is enabled on a port, the link attempts to automatically negotiate the link speed and duplex parameters. If autonegotiation is enabled, the configured duplex and speed parameters are ignored.</p> <p>When autonegotiation is disabled on a port, the port does not attempt to autonegotiate and will only operate at the <b>speed</b> and <b>duplex</b> settings configured for the port. Note that disabling autonegotiation on gigabit ports is not allowed as the IEEE 802.3 specification for gigabit Ethernet requires autonegotiation be enabled for far end fault indication.</p> <p>If the <b>autonegotiate limited</b> keyword option is specified the port will autonegotiate but will only advertise a specific speed and duplex. The speed and duplex advertised are the <b>speed</b> and <b>duplex</b> settings configured for the port. One use for limited mode is for multispeed gigabit ports to force gigabit operation while keeping autonegotiation enabled for compliance with IEEE 801.3.</p> <p>7210 SAS requires that autonegotiation be disabled or limited for ports in a Link Aggregation Group to guarantee a specific port speed.</p> <p>The <b>no</b> form of this command disables autonegotiation on this port.</p>
<b>Default</b>	autonegotiate
<b>Parameters</b>	<b>limited</b> — The Ethernet interface will automatically negotiate link parameters with the far end, but will only advertise the speed and duplex mode specified by the Ethernet <b>speed</b> and <b>duplex</b> commands.

## duplex

<b>Syntax</b>	<b>duplex {full   half}</b>
<b>Context</b>	config>port>ethernet
<b>Description</b>	<p>This command configures the duplex of a Fast Ethernet port when autonegotiation is disabled.</p> <p>This configuration command allows for the configuration of the duplex mode of a Fast Ethernet port. If the port is configured to autonegotiate this parameter is ignored.</p>
<b>Default</b>	<b>full</b>
<b>Parameters</b>	<p><b>full</b> — Sets the link to full duplex mode.</p> <p><b>half</b> — Sets the link to half duplex mode.</p>

### efm-oam

<b>Syntax</b>	<b>efm-oam</b>
<b>Context</b>	config>port>ethernet
<b>Description</b>	This command configures EFM-OAM attributes.

### accept-remote-loopback

<b>Syntax</b>	<b>[no] accept-remote-loopback</b>
<b>Context</b>	config>port>ethernet>efm-oam
<b>Description</b>	This command enables reactions to loopback control OAM PDUs from peers. The <b>no</b> form of this command disables reactions to loopback control OAM PDUs.
<b>Default</b>	no accept-remote-loopback

### mode

<b>Syntax</b>	<b>mode {active   passive}</b>
<b>Context</b>	config>port>ethernet>efm-oam
<b>Description</b>	This command configures the mode of OAM operation for this Ethernet port. These two modes differ in that active mode causes the port to continually send out efm-oam info PDUs while passive mode waits for the peer to initiate the negotiation process. A passive mode port cannot initiate monitoring activities (such as loopback) with the peer.
<b>Default</b>	active
<b>Parameters</b>	<b>active</b> — Provides capability to initiate negotiation and monitoring activities. <b>passive</b> — Relies on peer to initiate negotiation and monitoring activities.

### transmit-interval

<b>Syntax</b>	<b>[no] transmit-interval <i>interval</i> [<b>multiplier</b> <i>multiplier</i>]</b>
<b>Context</b>	config>port>ethernet>efm-oam
<b>Description</b>	This command configures the transmit interval of OAM PDUs.
<b>Default</b>	transmit-interval 10 multiplier 5
<b>Parameters</b>	<i>interval</i> — Specifies the transmit interval. <b>Values</b> 5 — 600 (in 100 milliseconds)

**multiplier** *multiplier* — Specifies the multiplier for transmit-interval to set local link down timer.

**Values** 2 — 5

## tunneling

**Syntax** [no] tunneling

**Context** config>port>ethernet>efm-oam

**Description** This command enables EFM OAM PDU tunneling. Enabling tunneling will allow a port mode Epipe SAP to pass OAM frames through the pipe to the far end.  
The **no** form of the command disables tunneling.

**Default** no tunneling

## egress-rate

**Syntax** egress-rate *sub-rate* [max-burst <*size-in-kbits*>]  
no egress-rate

**Context** config>port>ethernet

**Description** This command configures the rate of traffic leaving the network.  
The **no** form of this command returns the value to the default.

**Default** no egress-rate

**Parameters** *sub-rate* — The egress rate in Kbps.

**Values** 1 — 10000000

**max-burst** <*size-in-kbits*> — The maximum egress burst in kilobits (Kbits).

**Values** 32 — 16384

## encap-type

**Syntax** encap-type {dot1q | null| qinq}  
no encap-type

**Context** config>port>ethernet

**Description** This command configures the encapsulation method used to distinguish customer traffic on an Ethernet access port, or different VLANs on a port. In the 7210 SAS E, QinQ encap-type can be specified only for access uplink ports and null and the Dot1q encap-type can be specified only for access ports.

The **no** form of this command restores the default.

## Ethernet Port Commands

**Default** null

**Parameters** **dot1q** — Ingress frames carry 802.1Q tags where each tag signifies a different service.  
**null** — Ingress frames will not use any tags to delineate a service. As a result, only one service can be configured on a port with a null encapsulation type.  
**qinq** — This encapsulation type is specified for QinQ access SAPs.

## hold-time

**Syntax** **hold-time** {[**up** *hold-time up*] [**down** *hold-time down*]}  
**no hold-time**

**Context** config>port>ethernet

**Description** This command configures port link dampening timers which reduce the number of link transitions reported to upper layer protocols. The **hold-time** value is used to dampen interface transitions.  
When an interface transitions from an up state to a down state, it is immediately advertised to the rest of the system if the hold-time down interval is zero, but if the hold-time down interval is greater than zero, interface down transitions are not advertised to upper layers until the hold-time down interval has expired. Likewise, an interface is immediately advertised as up to the rest of the system if the hold-time up interval is zero, but if the hold-time up interval is greater than zero, up transitions are not advertised until the hold-time up interval has expired.  
The **no** form of this command reverts to the default values.

**Default** **down 0** seconds — No port link down dampening is enabled; link down transitions are immediately reported to upper layer protocols.  
**up 0** seconds — No port link up dampening is enabled; link up transitions are immediately reported to upper layer protocols.

**Parameters** **up** *hold-time up* — The delay, in seconds or centiseconds, to notify the upper layers after an interface transitions from a down state to an up state.  
**Values** 0 — 900  
**down** *hold-time down* — The delay, in seconds or centiseconds, to notify the upper layers after an interface transitions from an up state to a down state.  
**Values** 0 — 900

## ip-mtu

**Note:** This command is supported only on 7210 SAS-E devices. The **ip-mtu** command for 7210 SAS-D devices can be enabled using the CLI "config>service>ies>if> ip-mtu *octets*".

**Syntax** [**no**] **ip-mtu** *mtu-bytes*

**Context** config>port>ethernet

**Description** This command allows the user to configure the IP MTU value. This value is used by all IP interfaces created on the port. The IP MTU value specified must be smaller than the configured port MTU value. If the configured IP MTU value is greater than the port MTU value, the IP MTU is set equal to the port MTU value and the port MTU value is set to default. The MTU check is enforced on self-generated and forwarded packets. The system uses the configured IP MTU value to ensure that packets sent out of the IP interfaces configured on the port are lesser than or equal to the specified value. The IP packets which need to be forwarded but are greater than the configured IP MTU size are dropped. It is supported only on Ethernet ports.

On 7210 SAS-E devices the IES IP interfaces are created on access-uplink ports for In-band management. The IP MTU command allows the operator to specify the IP MTU size to be used for CPU generated IP packets (for example SNMP, FTP and so on). Additionally, it also allows the operators to specify different MTU sizes for service traffic and management traffic (a smaller MTU size value allowed) that share the same port.

**Note:** Use of ip-mtu command without specifying a value is equivalent to executing the no form of the ip-mtu command.

The **no** form of the command sets the IP MTU to default value

**Default** The IP MTU value is set to the port MTU value.

**Parameters** *mtu-bytes* — Specifies the IP MTU value in bytes.

**Values** 512 - 9000

## lACP-tunnel

**Syntax** [**no**] **lACP-tunnel**

**Context** config>port>ethernet

**Description** This command enables LACP packet tunneling for the Ethernet port. When tunneling is enabled, the port will not process any LACP packets but will tunnel them instead. The port cannot be added as a member to a LAG group.

The **no** form of the command disables LACP packet tunneling for the Ethernet port.

**Default** no lACP-tunnel

## qinq-etype

**Syntax** **qinq-etype** *0x0600..0xffff*  
**no qinq-etype**

**Context** config>port>ethernet

**Description** This command configures the Ethertype used for Q-in-Q encapsulation.  
The **no** form of this command reverts the qinq-etype value to the default.

## Ethernet Port Commands

**Parameters** The **no** form of the command sets the qinq-etype value to the default value. The default value is “0x8100”, it is not user configurable.

**Default** 0x8100

**Description** **0x0600..0xffff** — Specifies QinQ etype values.

**Values** 1536 — 65535, in hexadecimal or decimal notation. Ensure that the values do not match any of the IEEE reserved ethertype values such as 0x8a88, 0x9100, and 0x9200.

## statistics

**Syntax** **statistics**

**Context** config>port>ethernet

**Description** This command provides the context to configure the counters associated with the egress port.

## egress

**Syntax** **egress**

**Context** config>port>ethernet>statistics

**Description** This command provides the context to configure egress per queue statistics counter, it counts the total number of packets forwarded.

## queue

**Syntax** **queue** *queue-id*

**Context** config>port>ethernet>statistics>egress

**Description** This command enables the context to associate a counter with the egress queue identified by the queue-id.

**Default** none

**Parameters** *queue-id* — Identifies the queue with which the counter must be associated.

**Values** 1 — 8

## packets-forwarded-count

**Syntax** [**no**] **packets-forwarded-count**

**Context** config>port>ethernet>statistics>egress

<b>Description</b>	This command associates a counter with the specified queue and counts the number of packets forwarded through the queue.  The <b>no</b> form of the command stops the counter and disassociates the counter from the queue. Before issuing the <b>no</b> form of the command, ensure all accounting policies using the counter and associated with the port are removed from the configuration.
<b>Default</b>	none

## port-clock

**Note:** This command is supported only on 7210 SAS-D ETR devices.

**Syntax** **port-clock {master | slave}**

**Context** config>port>ethernet

<b>Description</b>	<p>With copper ports using 1G speed, the nodes need to determine who will be the master and slave with respect to clock used for transmission and reception. The master-slave relationship between the two ports of the nodes is determined during auto-negotiation of the link parameters and is automated; there is no management intervention in this process. Once this process is complete, the master port's transmit clock will be used for receiving the packets on the slave port. However, when syncE is in use, to maintain clock distribution hierarchy (for example, master will be synchronized to a stable reference and will distribute this clock to the slave) one needs to make sure that one of the ports behave as a master while the remote port of the link in question behaves as a slave.</p> <p>This command allows the user to force the copper port to be a master or slave. Using a value of master, ensures that the local node is the syncE master. A syncE master port, distributes the system timing over the copper port to the remote peer node. Using a value of slave, ensures that the local node is a syncE slave. A syncE slave port uses the incoming timing information.</p> <p>The no form of the command allows the node to automatically determine the master or slave status for the copper port based on the nodes capabilities exchanged during auto-negotiation. In other words, depending on the peer setting, the local end could end up as either a master or a slave when the no form of the command is used.</p> <p><b>Note:</b></p> <p>The following conditions must be met before using syncE on the fixed port copper ports:</p> <ol style="list-style-type: none"> <li>1. Auto-negotiation (or auto-negotiation limited) must be turned on.</li> <li>2. This command is required only when the copper port speed is set to 1Gbps.</li> <li>3. This CLI command is not supported for fiber ports or for fiber ports that use Copper SFPs.</li> </ol>
<b>Parameters</b>	<p><b>master</b> — This option ensures that the local node is the synchronous Ethernet master. A synchronous Ethernet master port, distributes the system timing over the copper port to the remote peer node.</p> <p><b>slave</b> — This option ensures that the local node is a synchronous Ethernet slave. A synchronous Ethernet slave port uses the incoming timing information.</p>

## Ethernet Port Commands

### speed

<b>Syntax</b>	<b>speed {10   100   1000}</b>
<b>Context</b>	config>port>ethernet
<b>Description</b>	This command configures the port speed of a Fast Ethernet port when autonegotiation is disabled. If the port is configured to autonegotiate this parameter is ignored. Speed cannot be configured for ports that are part of a Link Aggregation Group (LAG).
<b>Default</b>	<b>100</b>
<b>Parameters</b>	<b>10</b> — Sets the link to 10 mbps speed. <b>100</b> — Sets the link to 100 mbps speed. <b>1000</b> — Sets the link to 1000 mbps speed.

### loopback

Note : Port loopback with mac-swap is not supported on 7210 SAS-E devices.

<b>Syntax</b>	<b>[no] loopback {internal}[service svc-id sap sap-id src-mac SA dst-mac DA]</b>
<b>Context</b>	config>port>Ethernet
<b>Description</b>	<p>This command allows for configuration of simple port loopback and port loopback with MAC swap. The command when the optional parameter 'internal' is specified, provides the port loopback without the mac-swap functionality. It enables physical layer loopback of the packets that egress on the SAPs created on a ethernet port. The packets that egress are looped back into the node instead of being transmitted on to the line. After loopback, the packets ingress the system and are mapped to the same SAP from which they were egressed. The packets that are looped back are processed as per the service configuration of the SAP.</p> <p>The command when used with service-id and MAC address, provides the port loopback with mac-swap functionality. It enables a physical layer loopback, so that packets which egress on the SAPs created on an ethernet port are looped back into the system. After loopback, on ingress to the system, the MAC addresses in the Ethernet header are swapped (that is, the source MAC address and destination MAC address is exchanged with each other) by the system before being processed as per the service configuration of the SAP. System allocates a virtual port internally and uses the resources associated with it for this feature. No user configuration is needed. This port is associated with the index 1/1/11 on 7210 SAS-D and appears in the show port output. It is shown as a 'loopback' port in the display output (see example below). System ensures that no service entities are configured on this virtual port by failing any attempt to do so.</p>

```
=====
Ports on Slot 1
=====
Port Admin Link Port Cfg Oper LAG/ Port Port Port SFP/XFP/
Id   State State MTU MTU Bndl Mode Encp Type MDIMDX
-----
1/1/11 Down NoDown 9212 9212 - accs null xcme None(loopback)
```

**Note:** Port loopback without mac-swap does not require another port to be assigned for system use on any of the 7210 platforms.

The port loopback with mac-swap functionality is currently not supported on 7210 SAS-E devices.

Physical layer loopback is used with external third-party Ethernet test devices to diagnose provisioning issues and test end-to-end performance metrics of a service.

**Note: For Port loopback without mac-swap:**

- Use this command for testing VLL services.
- Enabling this command for testing VPLS services leads to rapid MAC address movement to another port, as source or destination MAC address swap is not performed.
- This command affects all services provisioned on the port.
- Before enabling this command, turn off all layer 2 and IP control protocols (such as LACP, EFM, 802.1x and so on) on the device and its peer to prevent errors such as protocol flaps due to timeout and so on. When port loopback feature is to be used for multicast traffic with IGMP snooping enabled in the service, the corresponding data path has to be statically created using static IGMP groups.
- For loop back to be functional, the following are not required:
  - >SFP or XFPs need not be inserted into the device.
  - >Ethernet cables need not be plugged in for copper ports.
- When the loop back command is enabled, ensure that Ethernet parameters such as, speed, duplex, auto-negotiation and so on are not modified.

**Notes: For port loopback with mac-swap:**

- This command is available for testing VLL services and VPLS services only.
- When enabled, the command affects all services provisioned on the port.
- Before enabling this command, turn off all layer 2 and IP control protocols (such as LACP, EFM, 802.1x and so on) on the device and its peer to prevent errors such as protocol flaps due to timeout and so on. When port loopback feature is to be used for multicast traffic with IGMP snooping enabled in the service, the corresponding data path has to be statically created using static IGMP groups.
- When port loopback with mac-swap enabled, for unicast and unknown-unicast packets, if the packet matches the configured source and destination MAC address it will be swapped and looped back in the service. For broadcast and multicast packets, if the packet matches the configured source MAC address, its source MAC address will be used as the destination MAC address and the system MAC address will be the source MAC address. The packet is looped back in the service as a unicast packet. All other packets sent to the loopback port will be dropped. Since forwarding of these packets after loopback can potentially cause network wide problems.
- For loop back to be functional, the following are not required:
  - >SFP or XFPs need not be inserted into the device.
  - >Ethernet cables need not be plugged in for copper ports.
- When the loop back is enabled, ensure that Ethernet parameters such as, speed, duplex, auto-negotiation and so on are not modified.
- When the loopback is enabled, ensure that service parameter and attributes such as ingress qos policy, accounting records, ingress/egress ACLs, and so on are not modified.
  - >With port loopback in use, the SAP ingress ACLs with IP-criteria is not recommended for use, since only MAC addresses are swapped.

The recommended procedure for using port loopback with mac-swap is:

- Configure the service and SAP on which loopback is to be enabled.
- Configure the assigned loopback port to be used.
- Send bi-directional learning frames on the SAP under test and spoke or uplink from a traffic tester or one can install static MAC for this purpose. Installing a static MAC is highly recommended, since the recommended procedure for enabling port loopback is to shutdown the port → enable loopback and then execute no shutdown the port.
- Enable port loopback and specify the service, SAP, and the source MAC address (SA) and the destination MAC address (DA). All packets with source Mac matching SA are the only ones processed in the context of the SAP on ingress after the loopback. Any other traffic, is dropped on ingress, to avoid issues due to mac movement and flooding issues in other services/SAPs, since the whole port is in loopback.
- When the port is in loopback, software disable learning and aging on the specified SAP. Once the loopback configuration is removed for the port, then the software enables learning and aging for specified SAP. Hence, port loopback with mac-swap cannot be used for learning or aging.
- It is not recommend to change the service parameters for the SAP and the service when loopback is active. Additionally use of commands which clears the FDB, and so on is highly discouraged.
- Remove the loopback on the sap port to bring the sap out of MAC swap with loopback mode.

The **no** form of the command disables physical layer loopback on the Ethernet port.

**Note:** The loop back command is not saved in the configuration file across a reboot.

Listed below is the recommended sequence of commands to be executed to perform loop back:

1. Disable the port, execute the command `config>port> shutdown`.
2. Enable loop back, execute the command `config >port>ethernet> loopback internal`
3. Enable the port, execute the command `config>port> no shutdown`.
4. Perform the required tests.
5. Disable the port, execute the command `config>port> shutdown`.
6. Disable loop back, execute the command `config >port>ethernet> no loopback internal`

Enable the port, execute the command `config>port> no shutdown`. Enable the required services. Listed below is the recommended sequence of commands to be executed to perform loop back when SFP or XFPs are inserted into the device :

1. Insert SFP or XFPs. SFP or XFPs are not required in case of fixed copper ports.
2. Enable the port and execute the command `config>port> [no] shutdown`.
3. Disable the port and execute the command `config>port> shutdown`. Enable loop back and execute the command `config >port>ethernet> loopback internal`
4. Enable the port and execute the command `config>port> no shutdown`. Perform the required tests.
5. Disable the port and execute the command `config>port> shutdown`. Disable loop back and execute the command `config >port>ethernet> no loopback internal`
6. Enable the port and execute the command `config>port> no shutdown`. Enable the required services.

Listed below is the sequence of commands to be executed to perform loop back when SFP or XFPs are changed :

1. Disable the port, execute the command `config>port> shutdown`.
2. Insert the new SFP or XFP.
3. Enable the port and execute the command `config>port> no shutdown`. Disable the port and execute the command `config>port> shutdown`. Enable loop back and execute the command `config >port>ethernet> loopback internal`.
4. Enable the port and execute the command `config>port> no shutdown`.
5. Perform the required tests.
6. Disable the port and execute the command `config>port> shutdown`.
7. Disable loop back and execute the command `config >port>ethernet> no loopback internal`.
8. Enable the port and execute the command `config>port> no shutdown`.
9. Enable the required services.
10. Enable loop back and execute the command `config >port>ethernet> loopback internal`.
11. Perform the required tests.
12. Disable loop back and execute the command `config >port>ethernet> no loopback internal`.
13. Enable the required services.

## Parameters

**service <service-id>** — The unique service identification number or string identifying the service in the service domain. This ID must be unique to this service and may not be used for any other service of any type. The service-id must be the same number used for every on which this service is defined.

**Values**      service-id      1 — 2147483648

**sap <sap-id>** — Specifies the physical port identifier portion of the SAP.

**Values**      sap-id null - <port-id>  
dot1q      - <port-id>:qtag1  
qinq      - <port-id>:qtag1.qtag2  
port-id      - slot/mda/port[.channel]  
qtag1      - [0..4094]  
qtag2      - [\*]1..4094

**src-mac <SA>** — Specifies the source MAC address.

**Values**      SA      6-byte unicast mac-address (xx:xx:xx:xx:xx:xx or xx-xx-xx-xx-xx-xx).

**dst-mac <DA>** — Specifies the destination MAC address.

**Values**      DA      6-byte unicast mac-address (xx:xx:xx:xx:xx:xx or xx-xx-xx-xx-xx-xx).

## SSM

**Syntax**      **ssm**

Note: SSM is supported only on 7210 SAS-D devices

## Ethernet Port Commands

**Context** config>port>ethernet

**Description** This command enables Ethernet Synchronous Status Message (SSM).

### code-type

**Syntax** code-type [sonet | sdh]

**Context** config>port>ethernet>ssm

**Description** This command configures the encoding of synchronous status messages, that is, to select either SDH or SONET set of values. Configuring the code-type is only applicable to Synchronous Ethernet ports. It is not configurable on TDM ports. For the code-type, SDH refers to ITU-T G.781 Option-1, while SONET refers to G.781 Option 2 (equivalent to Telcordia GR-253-CORE).

**Default** sdh

**Parameters** **sdh** — Specifies the values used on a G.781 Option 1 compliant network.

**sonet** — Specifies the values used on a G.781 Option 2 compliant network.

### tx-dus

**Syntax** [no] tx-dus

**Context** config>port>ethernet>ssm  
config>port>sonet-sdh

**Description** This command forces the QL value transmitted from the SSM channel of the SONET/SDH port or the Synchronous Ethernet port to be set to QL-DUS/QL-DNU. This capability is provided to block the use of the interface from the SR/ESS for timing purposes.

**Default** no tx-dus

---

## 802.1x Port Commands

### tmax-auth-req

<b>Syntax</b>	<b>max-auth-req</b> <i>max-auth-request</i>
<b>Context</b>	config>port>ethernet>dot1x
<b>Description</b>	This command configures the maximum number of times that the 7210 SAS will send an access request RADIUS message to the RADIUS server. If a reply is not received from the RADIUS server after the specified <i>number</i> attempts, the 802.1x authentication procedure is considered to have failed.  The <b>no</b> form of this command returns the value to the default.
<b>Default</b>	2
<b>Parameters</b>	<i>max-auth-request</i> — The maximum number of RADIUS retries.  <b>Values</b> 1 — 10

### port-control

<b>Syntax</b>	<b>port-control</b> [auto   force-auth   force-unauth]
<b>Context</b>	config>port>ethernet>dot1x
<b>Description</b>	This command configures the 802.1x authentication mode.  The <b>no</b> form of this command returns the value to the default.
<b>Default</b>	force-auth
<b>Parameters</b>	<b>force-auth</b> — Disables 802.1x authentication and causes the port to transition to the authorized state without requiring any authentication exchange. The port transmits and receives normal traffic without requiring 802.1x-based host authentication.  <b>force-unauth</b> — Causes the port to remain in the unauthorized state, ignoring all attempts by the hosts to authenticate. The switch cannot provide authentication services to the host through the interface.  <b>auto</b> — Enables 802.1x authentication. The port starts in the unauthorized state, allowing only EAPOL frames to be sent and received through the port. Both the 7210 SAS and the host can initiate an authentication procedure. The port will remain in un-authorized state (no traffic except EAPOL frames is allowed) until the first client is authenticated successfully. After this, traffic is allowed on the port for all connected hosts.

## quiet-period

<b>Syntax</b>	<b>quiet-period</b> <i>seconds</i> <b>no quiet-period</b>
<b>Context</b>	config>port>ethernet>dot1x
<b>Description</b>	This command configures the period between two authentication sessions during which no EAPOL frames are sent by the 7210 SAS.  The <b>no</b> form of this command returns the value to the default.
<b>Default</b>	30
<b>Parameters</b>	<i>seconds</i> — Specifies the quiet period in seconds.  <b>Values</b> 1 — 3600

## radius-plcy

<b>Syntax</b>	<b>radius-plcy</b> <i>name</i> <b>no radius-plcy</b>
<b>Context</b>	config>port>ethernet>dot1x
<b>Description</b>	This command configures the RADIUS policy to be used for 802.1x authentication. An 802.1x RADIUS policy must be configured (under config>security>dot1x) before it can be associated to a port. If the RADIUS policy-id does not exist, an error is returned. Only one 802.1x RADIUS policy can be associated with a port at a time.  The <b>no</b> form of this command removes the RADIUS policy association.
<b>Default</b>	no radius-plcy
<b>Parameters</b>	<i>name</i> — Specifies an existing 802.1x RADIUS policy name.

## re-auth-period

<b>Syntax</b>	<b>re-auth-period</b> <i>seconds</i> <b>no re-auth-period</b>
<b>Context</b>	config>port>ethernet>dot1x
<b>Description</b>	This command configures the period after which re-authentication is performed. This value is only relevant if re-authentication is enabled.  The <b>no</b> form of this command returns the value to the default.
<b>Default</b>	3600
<b>Parameters</b>	<i>seconds</i> — The re-authentication delay period in seconds.

**Values** 1 — 9000

## re-authentication

**Syntax** **[no] re-authentication**

**Context** config>port>ethernet>dot1x

**Description** This command enables / disables periodic 802.1x re-authentication.

When re-authentication is enabled, the 7210 SAS will re-authenticate clients on the port every re-auth-period seconds.

The **no** form of the command returns the value to the default.

**Default** re-authentication

## server-timeout

**Syntax** **server-timeout** *seconds*  
**no server-timeout**

**Context** config>port>ethernet>dot1x

**Description** This command configures the period during which the 7210 SAS waits for the RADIUS server to respond to its access request message. When this timer expires, the 7210 SAS will re-send the access request message, up to the specified number times.

The **no** form of this command returns the value to the default.

**Default** 30

**Parameters** *seconds* — The server timeout period in seconds.

**Values** 1 — 300

## supplicant-timeout

**Syntax** **supplicant-timeout** *seconds*  
**no supplicant-timeout**

**Context** config>port>ethernet>dot1x

**Description** This command configures the period during which the 7210 SAS waits for a client to respond to its EAPOL messages. When the supplicant-timeout expires, the 802.1x authentication session is considered to have failed.

The **no** form of this command returns the value to the default.

**Default** 30

## 802.1x Port Commands

**Parameters**    *seconds* — The server timeout period in seconds.

**Values**        1 — 300

### transmit-period

**Syntax**        **transmit-period** *seconds*  
**no transmit-period**

**Context**        config>port>ethernet>dot1x

**Description**    This command configures the period after which the 7210 SAS sends a new EAPOL request message. The **no** form of this command returns the value to the default.

**Default**        30

**Parameters**    *seconds* — The server transmit period in seconds.

**Values**        1 — 3600

### down-when-looped

**Syntax**        **down-when-looped**

**Context**        config>port>ethernet

**Description**    This command configures Ethernet loop detection attributes.

### dot1x

**Syntax**        **dot1x**

**Context**        config>port>ethernet

**Description**    This command enables access to the context to configure port-specific 802.1x authentication attributes. This context can only be used when configuring a Fast Ethernet, gigabit or 10Gig EthernetFast Ethernet, gigabit or 10Gig EthernetFast Ethernet or gigabit Ethernet LAN ports on an appropriate MDA.

### keep-alive

**Syntax**        **keep-alive** *timer*  
**no keep-alive**

**Context**        config>port>ethernet>dwl

**Description**    This command configures the time interval between keep-alive PDUs.

**Default** no keep-alive

**Parameters** *timer* — Specifies the time interval, in seconds, between keep-alive PDUs.

**Values** 1 — 120

## retry-timeout

**Syntax** **retry-timeout** timer  
**no retry-timeout**

**Context** config>port>ethernet>dwl

**Description** This command configures the minimum wait time before re-enabling port after loop detection.

**Default** no retry-timeout

**Parameters** *timer* — Specifies the minimum wait time before re-enabling port after loop detection.

**Values** 0, 10 — 160

---

## LLDP Port Commands

### lldp

<b>Syntax</b>	<b>lldp</b>
<b>Context</b>	config>port>ethernet
<b>Description</b>	This command enables the context to configure Link Layer Discovery Protocol (LLDP) parameters on the specified port.

### tunnel-nearest-bridge-dest-mac

<b>Syntax</b>	<b>[no] tunnel-nearest-bridge-dest-mac</b>
<b>Context</b>	config>port>ethernet>lldp
<b>Description</b>	This command allows user to configure tunneling for LLDP frames that use the nearest-bridge-dest-mac as destination MAC address. If enabled using the command tunnel-nearest-bridge-dest-mac, all frames received with the appropriate destination mac address are forwarded transparently to the remote end of the service. To forward these frames transparently the port on which tunneling is enabled must be configured with NULL SAP and the NULL SAP must be configured in an Epipe service. Tunneling is not supported for any other port encapsulation or when using any other service.

Note: This command is supported only on 7210 SAS-D.

Additionally, before enabling tunneling, admin status for LLDP dest-mac nearest-bridge must be set to disabled or Tx only, using the command admin-status available under configure> port> ethernet> lldp> dest-mac nearest-bridge. If admin-status for dest-mac nearest-bridge is set to receive and process nearest-bridge LLDPDUs (that is, if either rx or tx-rx is set) then it overrides the tunnel-nearest-bridge-dest-mac command. The following table lists the behavior for LLDP with different values set in use for admin-status and when tunneling is enabled or disabled:

Nearest-bridge mac Admin status	Tunneling Enabled	Tunneling Disabled
Rx	Process/Peer	Process/Peer
Tx	Tunnel	Drop
Rx-Tx	Process/Peer	Process/Peer
Disabled	Tunnel	Drop

**NOTE:** Transparent forwarding of LLDP frames can be achieved using the standard defined mechanism when using the either nearest-non-tmpr or the nearest-customer as the destination MAC address in the LLDP frames. It is recommended that the customers use these MAC address where possible to conform to

standards. This command allows legacy LLDP implementations that do not support these additional destinations MAC addresses to tunnel LLDP frames that use the nearest-bridge destination MAC address. The no form of the command disable LLDP tunneling for frames using nearest-bridge destination MAC address.

**Default** no tunnel-nearest-bridge-dest-mac

## dest-mac

**Syntax** **dest-mac** {*bridge-mac*}

**Context** config>port>ethernet>lldp

**Description** This command configures destination MAC address parameters.

**Parameters** **bridge-mac** — Specifies destination bridge MAC type to use by LLDP.

**Values** **nearest-bridge** — Specifies to use the nearest bridge.  
**nearest-non-tpmr** — Specifies to use the nearest non-Two-Port MAC Relay (TPMR) .  
**nearest-customer** — Specifies to use the nearest customer.

## admin-status

**Syntax** **admin-status** {*rx* | *tx* | *tx-rx* | **disabled**}

**Context** config>port>ethernet>lldp>dstmac

**Description** This command specifies the desired administrative status of the local LLDP agent.

**Parameters** **rx** — Specifies that the LLDP agent receives LLDP frames on this port, also indicates that the LLDP agent does not transmit LLDP frames.

**tx** — Specifies that the LLDP agent transmits LLDP frames on this port and does not store any information about the remote systems connected.

**tx-rx** — Specifies that the LLDP agent transmitw and receives LLDP frames on this port.

**disabled** — Specifies that the LLDP agent does not transmit or receive LLDP frames on this port. If there is remote systems information which is received on this port and stored in other tables, before the port's admin status becomes disabled, then the information will naturally age out.

## notification

**Syntax** [**no**] **notification**

**Context** config>port>ethernet>lldp>dstmac

## LLDP Port Commands

**Description** This command enables LLDP notifications.  
The **no** form of the command disables LLDP notifications.

### tx-mgmt-address

**Syntax** **tx-mgmt-address [system]**  
**no tx-mgmt-address**

**Context** config>port>ethernet>lldp>dstmac

**Description** This command specifies which management address to transmit.  
The no form of the command resets value to the default.

**Default** no tx-mgmt-address

**Parameters** **system** — Specifies to use the system IP address. Note that the system address will only be transmitted once it has been configured if this parameter is specified.

### tx-tlvs

**Syntax** **tx-tlvs [port-desc] [sys-name] [sys-desc] [sys-cap]**  
**no tx-tlvs**

**Context** config>port>ethernet>lldp>dstmac

**Description** This command specifies which LLDP TLVs to transmit. The **no** form of the command resets the value to the default.  
no tx-tlvs

**Parameters** **port-desc** — Indicates that the LLDP agent should transmit port description TLVs.  
**sys-name** — Indicates that the LLDP agent should transmit system name TLVs.  
**sys-desc** — Indicates that the LLDP agent should transmit system description TLVs.  
**sys-cap** — Indicates that the LLDP agent should transmit system capabilities TLVs.

---

## Access Uplink Port Commands

### uplink

**Syntax**    **uplink**

**Context**    config>port>access

**Description**    This command enables the context to configure access uplink egress port parameters.

### accounting-policy

**Syntax**    **accounting-policy** *policy-id*  
**no accounting-policy**

**Context**    config>port>ethernet>access>uplink  
config>port>ethernet>access

**Description**    This command configures an accounting policy that can apply to an interface.

An accounting policy must be configured before it can be associated to an interface. If the accounting *policy-id* does not exist, an error is returned.

Accounting policies associated with service billing can only be applied to SAPs. Accounting policies associated with network ports can only be associated with interfaces. Only one accounting policy can be associated with an interface at a time.

The **no** form of this command removes the accounting policy association from the network interface, and the accounting policy reverts to the default.

**Default**    No accounting policies are specified by default. You must explicitly specify a policy. If configured, the accounting policy configured as the default is used.

**Parameters**    *policy-id* — The accounting *policy-id* of an existing policy. Accounting policies record either service (access) or network information. A network accounting policy can only be associated with the network port configurations. Accounting policies are configured in the config>log>accounting-policy context.

**Values**    1 — 99

### collect-stats

**Syntax**    **[no] collect-stats**

**Context**    config>port>ethernet>access>uplink  
config>port>ethernet>access

## Access Uplink Port Commands

**Description** This command enables the collection of accounting and statistical data for the network interface. When applying accounting policies, the data, by default, is collected in the appropriate records and written to the designated billing file.

When the **no collect-stats** command is issued, the statistics are still accumulated by the IOM cards, however, the CPU does not obtain the results and write them to the billing file.

If the **collect-stats** command is issued again (enabled), then the counters written to the billing file will include the traffic collected while the **no collect-stats** command was in effect.

**Default** no collect-stats

## queue-policy

**Syntax** **queue-policy** *name*  
**no queue-policy**

**Context** config>port>ethernet>access>uplink

**Description** This command specifies the existing network queue policy which defines queue parameters such as CIR and PIR rates, as well as forwarding-class to queue mappings. The network-queue policy is defined in the **config>qos>network-queue** context.

A default CBS is defined for the queues and this is not configurable.

**Default** default

**Parameters** *name* — Specifies an existing network-queue policy name.

## line-impedance

**Syntax** **line-impedance** {75 | 100 | 120}

**Context** config>port>tdm

**Description** This command configures the line impedance of a port. Line impedance is set on a per-port basis and ports on the same card can have different values. Before changing the line impedance of a port, the port must be shut down.

**Default** 100 for DS1  
120 for E1

**Parameters** 100 for DS1  
120 or 75 for E1

---

## LAG Commands

### lag

**Syntax** [no] lag [*lag-id*]

**Context** config

**Description** This command creates the context for configuring Link Aggregation Group (LAG) attributes.

A LAG can be used to group up to two ports into one logical link. The aggregation of multiple physical links allows for load sharing and offers seamless redundancy. If one of the links fails, traffic will be redistributed over the remaining links. Up to 2 links can be supported in a single LAG, up to 6 LAGs can be configured on a node.

**NOTE:** All ports in a LAG group must have autonegotiation set to Limited or Disabled.

There are three possible settings for autonegotiation:

- “on” or enabled with full port capabilities advertised
- “off” or disabled where there is no autonegotiation advertisements
- “limited” where a single speed/duplex is advertised.

When autonegotiation is enabled on a port, the link attempts to automatically negotiate the link speed and duplex parameters. If autonegotiation is enabled, the configured duplex and speed parameters are ignored.

When autonegotiation is disabled on a port, the port does not attempt to autonegotiate and will only operate at the **speed** and **duplex** settings configured for the port. Note that disabling autonegotiation on gigabit ports is not allowed as the IEEE 802.3 specification for gigabit Ethernet requires autonegotiation be enabled for far end fault indication.

If the **autonegotiate limited** keyword option is specified the port will autonegotiate but will only advertise a specific speed and duplex. The speed and duplex advertised are the **speed** and **duplex** settings configured for the port. One use for limited mode is for multispeed gigabit ports to force gigabit operation while keeping autonegotiation is enabled for compliance with IEEE 801.3.

The system requires that autonegotiation be disabled or limited for ports in a LAG to guarantee a specific port speed.

The **no** form of this command deletes the LAG from the configuration. Deleting a LAG can only be performed while the LAG is administratively shut down. Any dependencies such as IP-Interfaces configurations must be removed from the configuration before issuing the **no lag** command.

**Default** No LAGs are defined.

**Parameters** *lag-id* — The LAG identifier, expressed as a decimal integer.

**Values** 1 — 6

## encap-type

**Syntax** **encap-type** {dot1q | null | qinq}  
**no encap-type**

**Context** config>lag

**Description** This command configures the encapsulation method used to distinguish customer traffic on a LAG. The encapsulation type is configurable on a LAG port. The LAG port and the port member encapsulation types must match when adding a port member.

If the encapsulation type of the LAG port is changed, the encapsulation type on all the port members will also change. The encapsulation type can be changed on the LAG port only if there is no interface associated with it. If the MTU is set to a non default value, it will be reset to the default value when the encap type is changed.

The **no** form of this command restores the default.

**Default** **null** — All traffic on the port belongs to a single service or VLAN.

**Parameters** **dot1q** — Ingress frames carry 802.1Q tags where each tag signifies a different service.

**null** — Ingress frames will not use any tags to delineate a service. As a result, only one service can be configured on a port with a null encapsulation type.

**qinq** — Specifies QinQ encapsulation.

## hold-time

**Syntax** **hold-time down** *hold-down-time*  
**no hold-time**

**Context** config>lag

**Description** This command specifies the timer, in tenths of seconds, which controls the delay between detecting that a LAG is down (all active ports are down) and reporting it to the higher levels.

A non-zero value can be configured, for example, when active/standby signalling is used in a 1:1 fashion to avoid informing higher levels during the small time interval between detecting that the LAG is down and the time needed to activate the standby link.

**Default** 0

**Parameters** **down** *hold-down-time* — Specifies the hold-time for event reporting

**Values** 0 — 2000

## lACP

**Syntax** **lACP** [*mode*] [**administrative-key** *admin-key*] [**system-id** *system-id*][**system-priority** *priority*]

**Context** config>lag

**Description** This command specifies the LACP mode for aggregated Ethernet interfaces only. This command enables the LACP protocol. Per the IEEE 802.3ax standard (formerly 802.3ad), the Link Aggregation Control Protocol (LACP) provides a standardized means for exchanging information between Partner Systems on a link to allow their Link Aggregation Control instances to reach agreement on the identity of the Link Aggregation Group to which the link belongs, move the link to that Link Aggregation Group, and enable its transmission and reception functions in an orderly manner. LACP can be enabled on a maximum of 256 ports.

**Default** no lacp

**Parameters** *mode* — Specifies the mode in which LACP will operate.

**Values** **passive** — Starts transmitting LACP packets only after receiving packets.  
**active** — Initiates the transmission of LACP packets.  
**power-off** — Disables transmitter of standby ports.

**administrative-key** *admin-key* — Specifies an administrative key value to identify the channel group on each port configured to use LACP. This value should be configured only in exceptional cases. If it is not specified, a random key is assigned.

**Values** 1 — 65535

## lacp-xmit-interval

**Syntax** **lacp-xmit-interval** {**slow** | **fast**}

**Context** config>lag

**Description** This command specifies the interval signaled to the peer and tells the peer at which rate it should transmit.

**Default** fast

**Parameters** **slow** — Transmits packets every 30 seconds.

**fast** — Transmits packets every second.

## lacp-xmit-stdby

**Syntax** [**no**] **lacp-xmit-stdby**

**Context** config>lag

**Description** This command enables LACP message transmission on standby links.

The **no** form of this command disables LACP message transmission. This command should be disabled for compatibility when using active/standby groups. This forces a timeout of the standby links by the peer. Use the **no** form if the peer does not implement the correct behavior regarding the lacp sync bit.

**Default** lacp-xmit-stdby

## port

<b>Syntax</b>	<b>port</b> <i>port-id</i> [ <i>port-id</i> ...up to 4 total] [ <b>priority</b> <i>priority</i> ] [ <b>subgroup</b> <i>sub-group-id</i> ] <b>no port</b> <i>port-id</i> [ <i>port-id</i> ...up to 4 total]
<b>Context</b>	config>lag <i>lag-id</i>
<b>Description</b>	<p>This command adds ports to a Link Aggregation Group (LAG).</p> <p>The port configuration of the first port added to the LAG is used as a basis to compare to subsequently added ports. If a discrepancy is found with a newly added port, that port will be not added to the LAG.</p> <p>Up to 16 (space separated) ports can be added or removed from the LAG link assuming the maximum of 16 ports is not exceeded.</p> <p>All ports, when added to a LAG, must share the same characteristics (speed, duplex, etc.). An error message will be displayed when adding ports that do not share the same characteristics. Hold-timers down must be 0. Ports that are part of a LAG must be configured with autonegotiate limited or disabled.</p> <p>The <b>no</b> form of this command removes ports from the LAG.</p>
<b>Default</b>	No ports are defined as members of a LAG.
<b>Parameters</b>	<p><i>port-id</i> — The port ID configured or displayed in the <i>slot/mda/port</i> format.</p> <p><b>priority</b> <i>priority</i> — Port priority used by LACP. The port priority is also used to determine the primary port. The port with the lowest priority is the primary port. In the event of a tie, the smallest port ID becomes the primary port.</p> <p><b>Values</b> 1 — 65535</p> <p><b>subgroup</b> <i>sub-group-id</i> — This parameter identifies a LAG subgroup. When using subgroups in a LAG, they should only be configured on one side of the LAG, not both. Only having one side perform the active/standby selection will guarantee a consistent selection and fast convergence. The active/standby selection will be signalled through LACP to the other side. The hold time should be configured when using subgroups to prevent the LAG going down when switching between active and standby links in case no links are usable for a short time, especially in case a subgroup consists of one member.</p> <p><b>Values</b> 1 — 8 identifies a LAG subgroup. The <b>auto-md</b> subgroup is defined based on the MDA.</p>

## port-threshold

<b>Syntax</b>	<b>port-threshold</b> <i>value</i> [ <b>action</b> {down}] <b>no port-threshold</b>
<b>Context</b>	config>lag <i>lag-id</i>
<b>Description</b>	<p>This command configures the behavior for the Link Aggregation Group (LAG) if the number of operational links is equal to or below a threshold level.</p> <p>The <b>no</b> form of this command reverts to the default values.</p>
<b>Default</b>	“0” action down

**Parameters** *value* — The decimal integer threshold number of operational links for the LAG at or below which the configured action will be invoked. If the number of operational links exceeds the port-threshold value, any action taken for being below the threshold value will cease.

**Values** 0 — 3

**action {down}** — Specifies the action to take if the number of active links in the LAG is at or below the threshold value.

If the number of operational links is equal to or less than the configured threshold value and action **down** is specified the LAG is brought to an operationally down state. The LAG is considered as operationally up only when the number of operational links exceeds the configured threshold value.

## selection-criteria

**Syntax** **selection-criteria [highest-count | highest-weight] [slave-to-partner]**  
**no selection-criteria**

**Context** config>lag

**Description** This command specifies which selection criteria should be used to select the active sub-group.

**Default** highest-count

**Parameters** **highest-count** — Specifies sub-group with the highest number of eligible members.

**highest-weight** — Specifies sub-group with the highest aggregate weight.

**best-port** — Selection criteria used with "power-off" mode of operation. The sub-group containing the port with highest priority port. In case of equal port priorities the sub-group containing the port with the lowest port-id is taken

**slave-to-partner** — The slave-to-partner keyword specifies that it, together with the selection criteria, should be used to select the active sub-group. An eligible member is a lag-member link which can potentially become active. This means it is operationally up (not disabled) for use by the remote side. The **slave-to-partner** parameter can be used to control whether or not this latter condition is taken into account.

## standby-signalling

**Syntax** **standby-signalling {lacp | power-off}**  
**no standby-signalling**

**Context** config>lag

**Description** This command specifies how the state of a member port is signalled to the remote side when the status corresponding to this member port has the **standby** value.

---

## Ethernet Ring Commands

### eth-ring

<b>Syntax</b>	<b>eth-ring</b> <i>ring-id</i> <b>no eth-ring</b>
<b>Context</b>	config
<b>Description</b>	This command configures a G.8032 protected Ethernet ring. G.8032 Rings may be configured as major rings with two paths (a&b).  The <b>no</b> form of this command deletes the Ethernet ring specified by the ring-id.
<b>Default</b>	no eth-ring
<b>Parameters</b>	<i>ring-id</i> — Specifies the ring ID.  <b>Values</b> 1—128

### description

<b>Syntax</b>	<b>description</b> <i>long-description-string</i> <b>no description</b>
<b>Context</b>	config>eth-ring
<b>Description</b>	This command adds a text description for the ring. The no form of this command removes the text description.
<b>Default</b>	“Eth ring”
<b>Parameters</b>	<i>string</i> — Specifies the text description up to 160 characters in length.

### guard-time

<b>Syntax</b>	<b>guard-time</b> <i>time</i> <b>no guard-time</b>
<b>Context</b>	config>eth-ring
<b>Description</b>	This command configures the guard time for an Eth-Ring. The guard timer is standard and is configurable from “x”ms to 2 seconds  The <b>no</b> form of this command restores the default guard-time.
<b>Default</b>	5 deciseconds

**Parameters** *value* — Specifies the guard-time.  
**Values** 1—20 deciseconds

## revert-time

**Syntax** **revert-time** *time*  
**no revert-time**

**Context** config>eth-ring

This command configures the revert time for an Eth-Ring. It ranges from 60 seconds to 720 second by 1 second intervals.

The no form of this command this command means non-revertive mode and revert time essentially is 0 meaning the revert timers are not set.

**Default** 300 seconds

**Parameters** *value* — Specifies the guard-time.  
**Values** 60 —720 seconds

## ccm-hold-time

**Syntax** **ccm-hold-time** {**down** *down-timeout* | **up** *up-timeout*}  
**no ccm-hold-time**

**Context** config>eth-ring

This command configures eth-ring dampening timers.

The **no** form of this command set the up and down timer to the default values.

## down

**Syntax** **down** *down-timeout*

**Context** config>eth-ring>ccm-hold-time

This command specifies the timer, which controls the delay between detecting that ring path is down and reporting it to the G.8032 protection module. If a non-zero value is configured, the CPM will wait for the time specified in the value parameter before reporting it to the G.8032 protection module.

**Note:** This parameter applies only to ring path CCM. It does NOT apply to the ring port link state. To damp ring port link state transitions, use hold-time parameter from the physical member port.

**Default** 0 - the fault will be reported immediately to the protection module.

**Parameters** *value* — Specifies the down timeout.

## Ethernet Ring Commands

**Values** 0 — 5000 deciseconds

### up

**Syntax** **up** *up-timeout*

**Context** config>eth-ring>ccm-hold-time

This command specifies the timer, which controls the delay between detecting that ring path is up and reporting it to the G.8032 protection module. If a non-zero value is configured, the CPM will wait for the time specified in the value parameter before reporting it to the G.8032 protection module.

**Note:** This parameter applies only to ring path CCM. It does NOT apply to the member port link state. To damp member port link state transitions, use hold-time parameter from the physical member port.

**Default** 20 deciseconds

**Parameters** *value* — Specifies the hold-time for reporting the recovery.

**Values** 0 — 5000 deciseconds

### rpl-node

**Syntax** **rpl-node** <owner | nbr>  
**no rpl-node**

**Context** config>eth-ring

This command configures the G.8032 ring protection link type as owner or neighbor. The no form of the command means this node is not connected to an RPL link. When RPL owner or neighbor is specified either the a or b path must be configured with the RPL end command. An owner is responsible for operation of the rpl link. Configuring the RPL as neighbor is optional (can be left as no rpl-node) but if the command is used the nbr is mandatory.

The **no** form of this command removes the RPL link.

**Default** no rpl-node

### node-id

**Syntax** **node-id** *mac*  
**no node-id**

**Context** config>eth-ring

This optional command configures the MAC address of the RPL control. The default is to use the chassis MAC for the ring control. This command allows the chassis MAC to be overridden with another MAC address.

The no form of this command removes the RPL link.

**Default** no node-id

**Parameters** *mac* — <xx:xx:xx:xx:xx:xx or xx-xx-xx-xx-xx-xx>

## path

**Syntax** **path {a | b} <portid> raps-tag <qtag [.qtag]>**  
**[no] path {a | b}**

**Context** config>eth-ring

**Description** This command assigns the ring (major or sub-ring) path to a port and defines the Ring APS tag. Rings typically have two paths a and b.

The no form of this command removes the path a or b.

**Default** no path

**Parameters** *raps-tag <qtag [.qtag]>* — Specifies the qtag.

**Values** Dot1q: 1—4094

**Values** QinQ: 1—4094.1—4094

## description

**Syntax** **description *long-description-string***  
**no description**

**Context** config>eth-ring>path

**Description** This command adds a text description for the ring path. The no form of this command removes the text description.

**Default** ""

**Parameters** *string* — Specifies the text description up to 160 characters in length.

## rpl-end

**Syntax** **rpl-end**  
**no rpl-end**

**Context** config>eth-ring>path

**Description** This command configures the G.8032 path as a ring protection link end. The ring should be declared as either a RPL owner or RPL neighbor for this command to be allowed. Only path a or path b can be declared an RPL-end.

The no form of this command sets the rpl-end to default no rpl-end.

## Ethernet Ring Commands

**Default** no rpl-end

### eth-cfm

**Syntax** eth-cfm

**Context** config>eth-ring>path

**Description** This command enables the context to configure ETH-CFM parameters.

### mep

**Syntax** [**no**] mep *mep-id* **domain** *md-index* **association** *ma-index*

**Context** config>eth-ring>path>eth-cfm

**Description** This command provisions an 802.1ag maintenance endpoint (MEP).  
The **no** form of the command reverts to the default values.

**Parameters** *mep-id* — Specifies the maintenance association end point identifier.

**Values** 1 — 81921

*md-index* — Specifies the maintenance domain (MD) index value.

**Values** 1 — 4294967295

*ma-index* — Specifies the MA index value.

**Values** 1 — 4294967295

### ccm-enable

**Syntax** [**no**] ccm-enable

**Context** config>eth-ring>path>eth-cfm>mep

**Description** This command enables the generation of CCM messages.  
The **no** form of the command disables the generation of CCM messages.

### ccm-ltm-priority

**Syntax** ccm-ltm-priority *priority*  
no ccm-ltm-priority

**Context** config>eth-ring>path>eth-cfm>mep

**Description** This command specifies the priority value for CCMs and LTMs transmitted by the MEP. The **no** form of the command removes the priority value from the configuration.

**Default** The highest priority on the bridge-port.

**Parameters** *priority* — Specifies the priority of CCM and LTM messages.

**Values** 0 — 7

## control-mep

**Syntax** **no control-mep**

**Context** config>eth-ring>path>eth-cfm>mep

**Description** This command enables the usage of the CC state by the Ethernet ring for consideration in the protection algorithm. The use of control-mep command is recommended if fast failure detection is required, especially when Link Layer OAM does not provide the required detection time.

The **no** form of this command disables the use of the CC state by the Ethernet ring.

**Default** no control-mep

**Values**

## eth-test-enable

**Syntax** [**no**] **eth-test-enable**

**Context** config>eth-ring>path>eth-cfm>mep

**Description** This command enables eth-test functionality on MEP. For this test to work, operators need to configure ETH-test parameters on both sender and receiver nodes. The ETH-test then can be done using the following OAM commands:

```
oam eth-cfm eth-test mac-address mep mep-id domain md-index association
ma-index [priority priority] [data-length data-length]
```

A check is done for both the provisioning and test to ensure the MEP is an Y.1731 MEP (MEP provisioned with domain format none, association format icc-based). If not, the operation fails. An error message in the CLI and SNMP will indicate the problem.

## test-pattern

**Syntax** **test-pattern {all-zeros | all-ones} [crc-enable]**  
**no test-pattern**

**Context** config>eth-ring>path>eth-cfm>mep>eth-test-enable

## Ethernet Ring Commands

- Description** This command configures the test pattern for eth-test frames.  
The **no** form of the command removes the values from the configuration.
- Parameters** **all-zeros** — Specifies to use all zeros in the test pattern.  
**all-ones** — Specifies to use all ones in the test pattern.  
**crc-enable** — Generates a CRC checksum.
- Default** all-zeros

### bit-error-threshold

- Syntax** **bit-error-threshold** *bit-errors*
- Context** config>eth-ring>path>eth-cfm>mep
- Description** This command specifies the lowest priority defect that is allowed to generate a fault alarm.
- Default** 1
- Parameters** *bit-errors* — Specifies the lowest priority defect.
- Values** 0 — 11840

### mac-address

- Syntax** **mac-address** *mac-address*  
**no mac-address**
- Context** config>eth-ring>path>eth-cfm>mep
- Description** This command specifies the MAC address of the MEP.  
The **no** form of this command reverts the MAC address of the MEP back to that of the port (if the MEP is on a SAP) or the bridge (if the MEP is on a spoke SDP).
- Parameters** *mac-address* — *Specifies the MAC address of the MEP.*
- Values** 6-byte unicast mac-address (xx:xx:xx:xx:xx:xx or xx-xx-xx-xx-xx-xx) of the MEP. Using the all zeros address is equivalent to the no form of this command.

### one-way-delay-threshold

- Syntax** **one-way-delay-threshold** *seconds*
- Context** config>eth-ring>path>eth-cfm>mep
- Description** This command enables one way delay threshold time limit.

**Default** 3 seconds

**Parameters** *priority* — Specifies the value for the threshold in seconds.

**Values** 0 — 600

## shutdown

**Syntax** [no] shutdown

**Context** config>eth-ring>path>eth-cfm>mep

**Description** This command administratively enables or disables the MEP.  
The **no** form of this command disables or enables the MEP.

**Default** shutdown

## shutdown

**Syntax** [no] shutdown

**Context** config>eth-ring>path  
config>eth-ring

**Description** This command administratively enables or disables the path.  
The **no** form of this command disables or enables the path.

**Default** shutdown

## shutdown

**Syntax** [no] shutdown

**Context** config>eth-ring

**Description** This command administratively enables/disables the ethernet ring.  
The **no** form of this command disables/enables the path.

**Default** shutdown

### description

<b>Syntax</b>	<b>description</b> <i>long-description-string</i> <b>no description</b>
<b>Context</b>	config>eth-tunnel
<b>Description</b>	This command adds a text description for the eth-tunnel. The <b>no</b> form of this command removes the text description.
<b>Default</b>	“Eth-tunnel”
<b>Parameters</b>	<i>string</i> — Specifies the text description up to 160 characters in length.

### split-horizon-group

<b>Syntax</b>	<b>split-horizon-group</b> <i>group-name</i> <b>no split-horizon-group</b>
<b>Context</b>	config>lag config>port
<b>Description</b>	This command associates a split horizon group to which this port or LAG belongs. For LAGs, all the member ports of the LAG are added to the split horizon group. The split-horizon-group must be configured in the <b>config</b> context.  The <b>no</b> form of this command removes the port or all member ports of the LAG from the split horizon group.  Configuring or removing the association of the port requires the following conditions to be satisfied: <ul style="list-style-type: none"><li>• There are no applications associated with the port/lag (like SAPs on the port, etc.).</li><li>• The port or LAG should be administratively shutdown.</li><li>• The port should not be part of a LAG.</li><li>• To change split horizon group of a port or LAG, the old split horizon group should be first removed from the port or LAG, and then the new split horizon group can be configured.</li></ul> The <b>no</b> form of this command removes the port or all member ports of the LAG from the split horizon group.
<b>Parameters</b>	<i>group-name</i> — Specifies the name of the split horizon group up to 32 characters in length. The string must be composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

### split-horizon-group

<b>Syntax</b>	[ <b>no</b> ] <b>split-horizon-group</b> <i>name-string</i>
<b>Context</b>	config

- Description** This command creates a split horizon group to be applied on ports and LAGs. The **no** form of the command removes the split horizon group. The user can remove a split horizon group only when there are no ports or LAGs associated with this split horizon group.
- Default** none
- Parameters** *name-string* — Creates the name of the split horizon group up to 32 characters in length. The string must be composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.



---

## Show Commands

---

### Hardware Commands

#### chassis

**Syntax** `chassis [environment] [power-supply]` (environment' option not supported on 7210 SAS D)

**Context** show

**Description** This command displays general chassis status information.

**Parameters** **environment** — Displays chassis environmental status information.

**Default** Displays all chassis information.

**power-supply** — Displays chassis power supply status information.

**Default** Displays all chassis information.

**Output** **Chassis Output** — The following table describes chassis output fields.

Label	Description
Name	The system name for the router.
Type	Displays the device model number.
Location	The system location for the device.
Coordinates	A user-configurable string that indicates the Global Positioning System (GPS) coordinates for the location of the chassis. For example: N 45 58 23, W 34 56 12 N37 37' 00 latitude, W122 22' 00 longitude N36*39.246' W121*40.121'
CLLI Code	The Common Language Location Identifier (CLLI) that uniquely identifies the geographic location of places and certain functional categories of equipment unique to the telecommunications industry.
Number of slots	The number of slots in this chassis that are available for plug-in cards. The total number includes the IOM slot(s) and the CPM slots.
Number of ports	The total number of ports currently installed in this chassis. This count does not include the Ethernet ports on the CPMs that are used for management access.

## Hardware Commands

Label	Description (Continued)
Critical LED state	The current state of the Critical LED in this chassis.
Major LED state	The current state of the Major LED in this chassis.
Minor LED state	The current state of the Minor LED in this chassis.
Base MAC address	The base chassis Ethernet MAC address.
Admin chassis mode	The configured chassis mode.
Oper chassis mode	The current chassis mode.
Part number	The CPM's part number.
CLEI code	The code used to identify the router.
Serial number	The CPM's part number. Not user modifiable.
Manufacture date	The chassis manufacture date. Not user modifiable.
Manufacturing string	Factory-inputted manufacturing text string. Not user modifiable.
Administrative state	Up – The card is administratively up. Down – The card is administratively down.
Operational state	Up – The card is operationally up.  Down – The card is operationally down.
Time of last boot	The date and time the most recent boot occurred.
Current alarm state	Displays the alarm conditions for the specific board.
Number of fan trays	The total number of fan trays installed in this chassis.
Number of fans	The total number of fans installed in this chassis.
Operational status	Current status of the fan tray.
Fan speed	Half speed – The fans are operating at half speed. Full speed – The fans are operating at full speed.
Number of power supplies	The number of power supplies installed in the chassis.

Label	Description (Continued)
Power supply number	The ID for each power supply installed in the chassis.
AC power	Within range – AC voltage is within range. Out of range – AC voltage is out of range.
DC power	Within range – DC voltage is within range. Out of range – DC voltage is out of range.
Over temp	Within range – The current temperature is within the acceptable range. Out of range – The current temperature is above the acceptable range.
Status	Up – The specified power supply is up. Down – The specified power supply is down

### Sample Output

Note: This CLI output is obtained only if the hardware supports "DC source failure detection".

```
A:7210-SAS-E> show chassis
=====
Chassis Information
=====
Name                : STU2597
Type                : 7210 SAS-E-1
Location            :
Coordinates         :
CLLI code           :
Number of slots     : 2
Number of ports     : 24
Critical LED state  : Red
Major LED state     : Off
Minor LED state     : Off
Over Temperature state : OK
Base MAC address    : 00:25:ba:04:b9:bc

Hardware Data
Part number         : 3HE04410ABAC01
CLEI code           : IPMK310JRA
Serial number       : NS1026C0341
Manufacture date    : 06292010
Manufacturing string :
Manufacturing deviations :
Time of last boot   : 2010/11/09 16:12:40
Current alarm state : alarm active
-----
```

## Hardware Commands

```
Environment Information
  Number of fan trays      : 1
  Number of fans          : 3

  Fan tray number         : 1
  Status                  : up
  Speed                   : half speed
-----
Power Supply Information

  Number of power supplies : 2

  Power supply number      : 1
  Configured power supply type : dc
  Status                   : failed
  DC power                 : out of range
  Input power              : out of range
  Output power             : within range

  Power supply number      : 2
  Configured power supply type : dc
  Status                   : up
  DC power                 : within range
  Input power              : within range
  Output power             : within range
=====
A:7210-SAS-E>

A:7210-SAS-E> show chassis
=====
Chassis Information
=====
  Name                    : STU2597
  Type                    : 7210 SAS-E-1
  Location                :
  Coordinates             :
  CLLI code               :
  Number of slots         : 2
  Number of ports         : 24
  Critical LED state      : Off
  Major LED state        : Off
  Minor LED state        : Off
  Over Temperature state  : OK
  Base MAC address       : 00:25:ba:04:b9:bc

Hardware Data
  Part number             : 3HE04410ABAC01
  CLEI code               : IPMK310JRA
  Serial number           : NS1026C0341
  Manufacture date        : 06292010
  Manufacturing string     :
  Manufacturing deviations :
  Time of last boot       : 2010/11/09 16:12:40
  Current alarm state     : alarm cleared
-----
Environment Information
  Number of fan trays      : 1
  Number of fans          : 3
```

```

Fan tray number      : 1
Status               : up
Speed                : half speed
-----
Power Supply Information
  Number of power supplies : 2

  Power supply number      : 1
  Configured power supply type : dc
  Status                   : up
  DC power                 : within range
  Input power              : within range
  Output power             : within range

  Power supply number      : 2
  Configured power supply type : dc
  Status                   : up
  DC power                 : within range
  Input power              : within range
  Output power             : within range
=====
A:7210-SAS-E>

*A:SAS-D>show# chassis

=====
Chassis Information
=====
  Name                   : SAS-D
  Type                   : 7210 SAS-D 6F4T-1
  Location                :
  Coordinates             :
  CLLI code              :
  Number of slots        : 2
  Number of ports        : 10
  Critical LED state     : Off
  Major LED state        : Off
  Minor LED state        : Off
  Over Temperature state : OK
  Base MAC address       : 00:3f:11:ab:ca:11

Hardware Data
  Part number            :
  CLEI code              :
  Serial number          : NS1050C0071
  Manufacture date       :
  Manufacturing string   :
  Manufacturing deviations :
  Time of last boot      : 1970/01/01 00:00:03
  Current alarm state    : alarm cleared
-----
Power Supply Information
  Number of power supplies : 1

  Power supply number      : 1
  Configured power supply type : ac single
  Status                   : up
  AC power                 : within range

```

```
=====
*A: SAS-D>show#
```

## card

**Syntax** **card** [*slot-number*] [**detail**]  
**card state**

**Context** show

**Description** This command displays card information.  
If no command line parameters are specified, a card summary for all cards is displayed.

**Parameters** *slot-number* — Displays information for the specified card slot.

**Default** Displays all cards.

**Values** state

Displays provisioned and equipped card and MDA information.

**detail** — Displays detailed card information.

**Default** Displays summary information only.

**Output** **Show Card Output** — The following table describes show card output fields.

Label	Description
Slot	The slot number of the card in the chassis.
Provisioned Card-type	The card type that is configured for the slot.
Equipped Card- type	The card type that is actually populated in the slot.
Admin State	Up — The card is administratively up. Down — The card is administratively down.
Operational State	Up — The card is operationally up. Down — The card is operationally down.

**Show CardState Output** — The following table describes show card state output fields.

Label	Description
Slot/MDA	The slot number of the card in the chassis.
Provisioned Type	The card type that is configured for the slot.
Equipped Type	The card type that is actually populated in the slot.
Admin State	Up — The card is administratively up. Down — The card is administratively down.
Operational State	Up — The card is operationally up.  provisioned — There is no card in the slot but it has been pre-configured.
Num Ports	The number of ports available on the MDA.
Num MDA	The number of MDAs installed.
Comments	Indicates whether the SF/CPM is the active or standby.

### Sample Output

**Show Card Detail Output** — The following table describes detailed card output fields.

Label	Description
Clock source	Source of clock for the IOM. Note: Currently this parameter always displays 'none'
Available MDA slots	The number of MDA slots available on the IOM.
Installed MDAs	The number of MDAs installed on the IOM
Part number	The IOM part number.
CLEI code	The Common Language Location Identifier (CLLI) code string for the router.
Serial number	The serial number. Not user modifiable.
Manufacture date	The chassis manufacture date. Not user modifiable.
Manufacturing string	Factory-inputted manufacturing text string. Not user modifiable.

## Hardware Commands

Label	Description (Continued)
Manufacturing deviations	Displays a record of changes by manufacturing to the hardware or software and which is outside the normal revision control process.
Administrative state	Up – The card is administratively up.  Down – The card is administratively down.
Operational state	Up – The card is operationally up.  Down – The card is operationally down.
Temperature	Internal chassis temperature.
Temperature threshold	The value above which the internal temperature must rise in order to indicate that the temperature is critical.
Software boot version	The version of the boot image.
Software version	The software version number.
Time of last boot	The date and time the most recent boot occurred.
Current alarm state	Displays the alarm conditions for the specific board.
Base MAC address	Displays the base MAC address of the hardware component.
Memory Capacity	Displays the memory capacity of the card.

### Sample Output

**CPM Output** — The following table describes the output fields for a CPM card.

Label	Description
Slot	The slot of the card in the chassis.
Card Provisioned	The SF/CPM type that is configured for the slot.
Card Equipped	The SF/CPM type that is actually populated in the slot.
Admin State	Up – The SF/CPM is administratively up.  Down – The SF/CPM is administratively down.

Label	Description (Continued)
Operational State	Up – The SF/CPM is operationally up.  Down – The SF/CPM is operationally down.
BOF last modified	The date and time of the most recent BOF modification.
Config file version	The configuration file version.
Config file last modified	The date and time of the most recent config file modification.
Config file last modified	The date and time of the most recent config file modification.
Config file last saved	The date and time of the most recent config file save.
CPM card status	active – The card is acting as the primary (active) CPM in a redundant system. standby – The card is acting as the standby (secondary) CPM in a redundant system.
Administrative state	Up – The CPM is administratively up. Down – The CPM is administratively down.
Operational state	Up – The CPM is operationally up. Down – The CPM is operationally down.
Serial number	The compact flash part number. Not user modifiable.
Firmware revision	The firmware version. Not user modifiable.
Model number	The compact flash model number. Not user modifiable.
Size	The amount of space available on the compact flash card.
Free space	The amount of space remaining on the compact flash card.
Part number	The SF/CPM part number.
CLEI code	The code used to identify the router.
Serial number	The SF/CPM part number. Not user modifiable.
Manufacture date	The chassis manufacture date. Not user modifiable.
Manufacturing string	Factory-inputted manufacturing text string. Not user modifiable.

## Hardware Commands

Label	Description (Continued)
Administrative state	Up – The card is administratively up. Down – The card is administratively down.
Operational state	Up – The card is operationally up. Down – The card is operationally down.
Time of last boot	The date and time the most recent boot occurred.
Current alarm state	Displays the alarm conditions for the specific board.
Status	Displays the current status.
Temperature	Internal chassis temperature.
Temperature threshold	The value above which the internal temperature must rise in order to indicate that the temperature is critical.
Software boot version	The version of the boot image.
Memory capacity	The total amount of memory.

### Sample Output

Sample output for 7210 SAS E:

```
*A:SAS-E>bof# /show card
```

```
=====
Card Summary
=====
Slot      Provisioned      Equipped      Admin      Operational
          Card-type       Card-type     State     State
-----
1         iom-sas         iom-sas      up         up
A         sfm-sas         sfm-sas      up         up/active
=====
*A:SAS-E>bof#
```

Sample output for 7210 SAS D:

```
*A:SAS-D>show# card
```

```
=====
Card Summary
=====
Slot      Provisioned      Equipped      Admin      Operational
          Card-type       Card-type     State     State
-----
```

```

1      iom-sas      iom-sas      up      up
A      sfm-sas      sfm-sas      up      up/active
=====

```

```
*A:SAS-D>show#
```

## mda

**Syntax** `mda [slot [/mda]] [detail]`

**Context** show

**Description** This command displays MDA information.

If no command line options are specified, a summary output of all MDAs is displayed in table format.

**Parameters** *slot* — The slot number for which to display MDA information.

*mda* — The MDA number in the slot for which to display MDA information.

**detail** — Displays detailed MDA information.

**Output** **MDA Output** — The following table describes MDA output fields.

Label	Description
Slot	The chassis slot number.
MDA	The MDA slot number.
Provisioned MDA-type	The MDA type provisioned.
Equipped MDA-type	The MDA type actually installed.
Admin State	Up — Administratively up. Down — Administratively down.
Ops State	Up — Operationally up. Down — Operationally down.

**MDA Detailed Output** — The following table describes detailed MDA output fields.

Label	Description
Slot	The chassis slot number.
Slot	The MDA slot number.
Provisioned Provisioned-type	The provisioned MDA type.

## Hardware Commands

Label	Description (Continued)
Equipped Mda-type	The MDA type that is physically inserted into this slot in this chassis.
Admin State	Up – The MDA is administratively up. Down – The MDA is administratively down.
Operational State	Up – The MDA is operationally up. Down – The MDA is operationally down.
Maximum port count	The maximum number of ports that can be equipped on the MDA card.
Number of ports equipped	The number of ports that are actually equipped on the MDA.
Transmit timing selected	Indicates the source for the timing used by the MDA.
Sync interface timing status	Indicates whether the MDA has qualified one of the timing signals from the CPMs.
Network Ingress Queue Policy	Specifies the network queue policy applied to the MDA to define the queueing structure for this object.
Capabilities	Specifies the minimum size of the port that can exist on the MDA.
Part number	The hardware part number.
CLEI code	The code used to identify the MDA.
Serial number	The MDA part number. Not user modifiable.
Manufacture date	The MDA manufacture date. Not user modifiable.
Manufacturing string	Factory-inputted manufacturing text string. Not user modifiable.
Administrative state	Up – The MDA is administratively up. Down – The MDA is administratively down.
Operational state	Up – The MDA is operationally up. Down – The MDA is operationally down.
Time of last boot	The date and time the most recent boot occurred.

<b>Label</b>	<b>Description (Continued)</b>
Current alarm state	Displays the alarm conditions for the specific MDA.
Base MAC address	The base chassis Ethernet MAC address. Special purpose MAC addresses used by the system software are constructed as offsets from this base address.

**Sample Output**

```
B:Dut-D# show mda 1/1 detail
=====
MDA 1/1 detail
=====
Slot  Mda  Provisioned           Equipped           Admin  Operational
      Mda  Mda-type              Mda-type          State  State
-----
1     1     m10-lgb-sfp           m10-lgb-sfp      up     up

MDA Specific Data
  Maximum port count       : 10
  Number of ports equipped : 10
  Network ingress queue policy : default
  Capabilities             : Ethernet

Hardware Data
  Part number              : 3HE00026AAAC01
  CLEI code                :
  Serial number            : NS042800525
  Manufacture date         : 07082004
  Manufacturing string     :
  Manufacturing deviations :
  Administrative state     : up
  Operational state        : up
  Temperature              : 42C
  Temperature threshold    : 75C
  Time of last boot        : 2007/04/11 09:37:52
  Current alarm state      : alarm cleared
  Base MAC address         : 00:03:fa:0e:9e:03
=====
B:Dut-D#
```

**Sample Output (for 7210 SAS D)**

```
*A:SAS-D>show# mda 1 detail
=====
MDA 1/1 detail
=====
Slot  Mda  Provisioned           Equipped           Admin  Operational
      Mda  Mda-type              Mda-type          State  State
-----
1     1     m4-tx+6-sfp          m4-tx+6-sfp      up     up

MDA Specific Data
  Maximum port count       : 10
  Number of ports equipped : 10
  Network ingress queue policy : default
  Capabilities             : Ethernet

Hardware Data
```

```

Part number           :
CLEI code            :
Serial number         : NS1050C0071
Manufacture date     :
Manufacturing string :
Manufacturing deviations :
Administrative state  : up
Operational state    : up
Temperature           : 44C
Temperature threshold : 55C
Software version     : N/A
Time of last boot    : 1970/01/01 00:00:30
Current alarm state   : alarm cleared
Base MAC address     : 00:3f:11:ab:ca:13

```

```

-----
QoS Settings
-----

```

```

Ing. Named Pool Policy      : None
Egr. Named Pool Policy      : None

```

```

=====
*A:SAS-D>show#

```

## pools

**Syntax** **pools** *mda-id* [/port] [<access-app> [<pool-name>]]  
**pools** *mda-id* [/port] [<network-app> [[pool-name]]]

**Context** show

**Description** This command displays pool information.

**Parameters** *mda-id*[/port] — Displays the pool information of the specified MDA.

**access-app** *pool-name* — Displays the pool information of the specified QoS policy.

**Values** access-ingress, access-egress

**network-app** *pool-name* — Displays the pool information of the specified QoS policy.

**Values** network-egress

**Output** **Show Pool Output** — The following table describes show pool output fields.

Label	Description
Type	Specifies the pool type.
ID	Specifies the card/mda or card/MDA/port designation.

## Hardware Commands

Label	Description (Continued)
Application/Type	Specifies the nature of usage the pool would be used for. The pools could be used for access or access uplink at egress.
Pool Name	Specifies the name of the pool being used.
Resv CBS	Specifies the percentage of pool size reserved for CBS.
Utilization	Specifies the type of the slope policy.
State	The administrative status of the port.
Start-Threshold	Specifies the percentage of the buffer utilized after which the drop probability starts to rise above 0.
Actual ResvCBS	Specifies the actual percentage of pool size reserved for CBS.
Admin ResvCBS	Specifies the percentage of pool size reserved for CBS.
Pool Total	Displays the total pool size.
Pool Shared	Displays the amount of the pool which is shared.
Pool Resv	Specifies the percentage of reserved pool size.
Pool Total In Use	Displays the total amount of the pool which is in use.
Pool Shared In Use	Displays the amount of the pool which is shared that is in use.
<b>For 7210 SAS D</b>	
Max-Avg	Specifies the percentage of the buffer utilized after which the drop probability is 100 percent. This implies that all packets beyond this point will be dropped.
Time Avg Factor	Specifies the time average factor the weighting between the previous shared buffer average utilization result and the new shared buffer utilization in determining the new shared buffer average utilization.

Dumping concise pool information for all ports in the MDA:

```
*A:card-1>config# show pools 1/1
=====
Type   Id       App.    Pool Name                Actual ResvCBS  PoolSize
      Admin ResvCBS
-----
Port   1/1/1    Acc-Egr default          0                0
      Sum
Port   1/1/1    AUp-Egr default         50                99
      Sum
Port   1/1/2    Acc-Egr default          26                79
      Sum
Port   1/1/2    AUp-Egr default          0                 0
      Sum
```

## Interface Configuration

```

Port    1/1/3    Acc-Egr default          26          79
                               Sum
Port    1/1/3    AUp-Egr default         0           0
                               Sum
Port    1/1/4    Acc-Egr default          26          79
                               Sum
...
                               Sum
Port    1/1/24   AUp-Egr default         0           0
                               Sum
=====
*A:card-1>config#

```

### Sample Output (for 7210 SAS D)

```

*A:SAS-D>show# pools 1/1
=====
-----
Type   Id       App.   Pool Name                Actual ResvCBS   PoolSize
Admin ResvCBS
-----
Port   1/1/1   Acc-Egr default          68           186
                               Sum
Port   1/1/1   Net-Egr default          0            0
                               Sum
Port   1/1/2   Acc-Egr default          68           186
                               Sum
Port   1/1/2   Net-Egr default          0            0
                               Sum
Port   1/1/3   Acc-Egr default          68           186
                               Sum
Port   1/1/3   Net-Egr default          0            0
                               Sum
Port   1/1/4   Acc-Egr default          68           186
                               Sum
Port   1/1/4   Net-Egr default          0            0
                               Sum
Port   1/1/5   Acc-Egr default          68           186
                               Sum
Port   1/1/5   Net-Egr default          0            0
                               Sum
Port   1/1/6   Acc-Egr default          68           186
                               Sum
Port   1/1/6   Net-Egr default          0            0
                               Sum
Port   1/1/7   Acc-Egr default          68           186
                               Sum
Port   1/1/7   Net-Egr default          0            0
                               Sum
Port   1/1/8   Acc-Egr default          68           186
                               Sum
Port   1/1/8   Net-Egr default          0            0
                               Sum
Port   1/1/9   Acc-Egr default          68           186
                               Sum

```

## Hardware Commands

```

Port    1/1/9      Net-Egr default          0          0
                               Sum
Port    1/1/10     Acc-Egr default         0          0
                               Sum
Port    1/1/10     Net-Egr default         68         186
                               Sum

```

```
=====
*A:SAS-D>show#
```

The following output displays egress pool information for the access port:

```
*A:card-1>config#      show pools 1/1/5 access-egress
```

```
=====
Pool Information
=====
```

```

Port          : 1/1/5
Application   : Acc-Egr          Pool Name      : default
Resv CBS     : Sum

```

```
-----
Utilization          State      Start-Threshold
-----
```

```

High-Slope          Down      75%
Low-Slope           Down      50%

```

```
-----
Queue              High Slope Drop Rate(%)      Low Slope Drop Rate(%)
-----
```

```

Queue 1              6.250000          100.000000
Queue 2              6.250000          100.000000
Queue 3              6.250000          100.000000
Queue 4              6.250000          100.000000
Queue 5              6.250000          100.000000
Queue 6              6.250000          100.000000
Queue 7              6.250000          100.000000
Queue 8              6.250000          100.000000

```

```

Pool Total          : 79 KB
Pool Shared         : 53 KB          Pool Resv       : 26 KB

```

```

Pool Total In Use   : 0 KB
Pool Shared In Use  : 0 KB          Pool Resv In Use : 0 KB

```

```
-----
FC-Maps              ID          CBS          Depth  A.CIR      A.PIR
                               O.CIR      O.PIR
-----
be                   1/1/5      3200         0        0          1000000
                               0          Max
l2                   1/1/5      3200         0        0          1000000
                               0          Max
af                   1/1/5      3200         0        0          1000000
                               0          Max
l1                   1/1/5      3200         0        0          1000000
                               0          Max
h2                   1/1/5      3200         0        0          1000000
                               0          Max
ef                   1/1/5      3200         0        0          1000000
                               0          Max
h1                   1/1/5      3200         0        0          1000000
                               0          Max
nc                   1/1/5      3200         0        0          1000000

```

0 Max

=====  
\*A:card-1>config#

**Sameple Output (for 7210 SAS D)**

\*A:SAS-D>show# pools 1/1/2 access-egress

=====  
Pool Information

=====  
Port : 1/1/2  
Application : Acc-Egr Pool Name : default  
Resv CBS : Sum  
-----

High Slope

-----

QueueId	State	Start-Avg(%)	Max-Avg(%)	Max-Prob(%)
Queue1	Down	70	90	75
Queue2	Down	70	90	75
Queue3	Down	70	90	75
Queue4	Down	70	90	75
Queue5	Down	70	90	75
Queue6	Down	70	90	75
Queue7	Down	70	90	75
Queue8	Down	70	90	75

-----

Low Slope

-----

QueueId	State	Start-Avg(%)	Max-Avg(%)	Max-Prob(%)
Queue1	Down	50	75	75
Queue2	Down	50	75	75
Queue3	Down	50	75	75
Queue4	Down	50	75	75
Queue5	Down	50	75	75
Queue6	Down	50	75	75
Queue7	Down	50	75	75
Queue8	Down	50	75	75

-----

Non Tcp Slope

-----

QueueId	State	Start-Avg(%)	Max-Avg(%)	Max-Prob(%)
Queue1	Down	50	75	75
Queue2	Down	50	75	75
Queue3	Down	50	75	75
Queue4	Down	50	75	75
Queue5	Down	50	75	75
Queue6	Down	50	75	75
Queue7	Down	50	75	75
Queue8	Down	50	75	75

-----



## Interface Configuration

```

Low-Slope                               Down                               50%
-----
Queue                                   High Slope Drop Rate(%)           Low Slope Drop Rate(%)
-----
Queue 1                                 6.250000                          100.000000
Queue 2                                 6.250000                          100.000000
Queue 3                                 6.250000                          100.000000
Queue 4                                 6.250000                          100.000000
Queue 5                                 6.250000                          100.000000
Queue 6                                 6.250000                          100.000000
Queue 7                                 6.250000                          100.000000
Queue 8                                 6.250000                          100.000000

Pool Total                               : 99 KB
Pool Shared                              : 49 KB                Pool Resv                : 50 KB

Pool Total In Use                        : 0 KB
Pool Shared In Use                       : 0 KB                Pool Resv In Use        : 0 KB
-----
FC-Maps                                  ID                               CBS                       Depth  A.CIR  A.PIR
                                           O.CIR                           O.PIR
-----
be                                       1/1/1                          3557                      0      0      1000000
                                           0                               Max
l2                                       1/1/1                          3557                      0      250000 1000000
                                           249984                          Max
af                                       1/1/1                          10671                     0      250000 1000000
                                           249984                          Max
l1                                       1/1/1                          3557                      0      250000 1000000
                                           249984                          Max
h2                                       1/1/1                          10671                     0      1000000 1000000
                                           Max                               Max
ef                                       1/1/1                          10671                     0      1000000 1000000
                                           Max                               Max
h1                                       1/1/1                          3557                      0      100000 1000000
                                           100032                          Max
nc                                       1/1/1                          3557                      0      100000 1000000
                                           100032                          Max
=====
*A:card-1>config#

```

### Sample Output (for 7210 SAS D)

```

*A:SASD>config>port# show pools 1/1/9 access-uplink-egress
=====
Pool Information
=====
Port                : 1/1/9
Application         : Net-Egr           Pool Name           : default
Resv CBS           : Sum

High Slope
-----
-----
QueueId            State      Start-Avg(%)      Max-Avg(%)      Max-Prob(%)
-----

```

## Hardware Commands

Queue1	Down	70	90	75
Queue2	Down	70	90	75
Queue3	Down	70	90	75
Queue4	Down	70	90	75
Queue5	Down	70	90	75
Queue6	Down	70	90	75
Queue7	Down	70	90	75
Queue8	Down	70	90	75

-----  
 Low Slope  
 -----

QueueId	State	Start-Avg(%)	Max-Avg(%)	Max-Prob(%)
Queue1	Down	50	75	75
Queue2	Down	50	75	75
Queue3	Down	50	75	75
Queue4	Down	50	75	75
Queue5	Down	50	75	75
Queue6	Down	50	75	75
Queue7	Down	50	75	75
Queue8	Down	50	75	75

-----  
 Non Tcp Slope  
 -----

QueueId	State	Start-Avg(%)	Max-Avg(%)	Max-Prob(%)
Queue1	Down	50	75	75
Queue2	Down	50	75	75
Queue3	Down	50	75	75
Queue4	Down	50	75	75
Queue5	Down	50	75	75
Queue6	Down	50	75	75
Queue7	Down	50	75	75
Queue8	Down	50	75	75

-----  
 Time Avg Factor  
 -----

Queue Id	Time Avg Factor
Queue1	7
Queue2	7
Queue3	7
Queue4	7
Queue5	7
Queue6	7
Queue7	7
Queue8	7

MMU Pool Total In Use: 0 KB

MMU Pool Shared In\*: 0 KB

Pool Total : 186 KB

Pool Shared : 102 KB

Pool Resv : 68 KB

Pool Total In Use : 0 KB

Pool Shared In Use : 0 KB

Pool Resv In Use : 0 KB

## Interface Configuration

```
-----
```

ID	FC-MAPS	CBS (B)	Depth	A.CIR O.CIR	A.PIR O.PIR
1/1/9	be	8698	0	0 0	40000 Max
1/1/9	l2	8698	0	0 0	40000 Max
1/1/9	af	8698	0	0 0	40000 Max
1/1/9	l1	8698	0	0 0	40000 Max
1/1/9	h2	8698	0	0 0	40000 Max
1/1/9	ef	8698	0	0 0	40000 Max
1/1/9	h1	8698	0	0 0	40000 Max
1/1/9	nc	8698	0	0 0	40000 Max

```
-----
```

\* indicates that the corresponding row element may have been truncated.

\*A:SASD>config>port#

---

## Port Show Commands

### port

**Syntax** **port** *port-id* [**count**] [**detail**]  
**port** *port-id* **description**  
**port** *port-id* **associations**  
**port** *port-id* **ethernet** [**efm-oam** | **detail**]  
**port** *port-id* **dot1x** [**detail**]  
**port** *port-id* **vport** [*vport-name*] **associations**  
**port** [**A1**] [**detail**] [**statistics**] [**description**](Out-of-band Ethernet port is not supported on 7210 SAS D devices)

**Context** show

**Description** This command displays port information.

If no command line options are specified, the command port displays summary information for all ports on provisioned MDAs.

**Parameters** *port-id* — Specifies the physical port ID in the form *slot/mda/port*.

**Syntax** port-id *slot[/mda[/port]]*

**MDA Values** 1

**Port Values** 1 — 60 (depending on the MDA type)

**associations** — Displays a list of current router interfaces to which the port is associated.

**description** — Displays port description strings.

**dot1x** — Displays information about 802.1x status and statistics.

**ethernet** — Displays ethernet port information.

**efm-oam** — Displays EFM OAM information.

**detail** — Displays detailed information about the Ethernet port.

**A1** — Displays the out-of-band Ethernet port information.

**Port Output** — The following tables describe port output fields:

- [General Port Output Fields on page 147](#)
- [Entering port ranges: on page 151](#)
- [Specific Port Output Fields on page 152](#)
- [Detailed Port Output Fields on page 156](#)
- [Ethernet Output Fields on page 166](#)
- [Ethernet-Like Medium Statistics Output Fields on page 172](#)
- [Port Associations Output Fields on page 176](#)

Label	Description
Port ID	The port ID configured or displayed in the <i>slot/mda/port</i> format.
Admin State	Up – The administrative state is up. Down – The administrative state is down.
Phy Link	Yes – A physical link is present. No – A physical link is not present.
Port State	Up – The port is physically present and has physical link present. Down – The port is physically present but does not have a link. Ghost – A port that is not physically present. None – The port is in its initial creation state or about to be deleted. Link Up – A port that is physically present and has physical link present. Link Down – A port that is physically present but does not have a link.
Cfg MTU	The configured MTU.
Oper MTU	The negotiated size of the largest packet which can be sent on the port specified in octets.
LAG ID	The LAG or multi-link trunk (MLT) that the port is assigned to.
Port Mode	network – The port is configured for transport network use. access – The port is configured for service access.
Port Encap	Null – Ingress frames will not use tags or labels to delineate a service. dot1q – Ingress frames carry 802.1Q tags where each tag signifies a different service.
Port Type	The type of port or optics installed.
SFP/MDI MDX	GIGE – Indicates the GigE SFP type. FASTE – Indicates the FastE SFP type. MDI – Indicates that the Ethernet interface is of type MDI (Media Dependent Interface).

Label	Description (Continued)
	MDX – Indicates that the Ethernet interface is of type MDX (Media Dependent Interface with crossovers).
IP MTU	Displays the configured IP MTU value.

**Sample Output**

```
*A:ALU-211# show port 1/1/2
=====
Ethernet Interface
=====
Description      : 10/100 Ethernet TX
Interface        : 1/1/2                Oper Speed      : 100 mbps
Link-level      : Ethernet             Config Speed    : 100 mbps
Admin State     : up                   Oper Duplex     : full
Oper State      : up - Active in LAG 10 Config Duplex   : full
Physical Link   : Yes                  MTU             : 1514
Single Fiber Mode : No                 : Internal
IfIndex         : 35717120              Hold time up    : 0 seconds
Last State Change : 12/16/2008 19:31:40   Hold time down  : 0 seconds
Last Cleared Time : 12/16/2008 19:31:48
IP MTU          : 1000
=====
*A:ALU-211#
```

```
*A:ALU-211# show port 1/1/2
=====
Ethernet Interface
=====
Description      : 10/100 Ethernet TX
Interface        : 1/1/2                Oper Speed      : 100 mbps
Link-level      : Ethernet             Config Speed    : 100 mbps
Admin State     : up                   Oper Duplex     : full
Oper State      : down - Standby in LAG 10 Config Duplex   : full
Physical Link   : Yes                  MTU             : 1514
Single Fiber Mode : No                 : None
IfIndex         : 35717120              Hold time up    : 0 seconds
Last State Change : 12/16/2008 18:28:52   Hold time down  : 0 seconds
Last Cleared Time : 12/16/2008 18:28:51
IP MTU          : 1000
=====
*A:ALU-211#
```

**Sample Output (for 7210 SAS D)**

```
*A:7210SAS>show# port 1/1/2 detail
=====
Ethernet Interface
=====
Description      : 10/100/Gig Ethernet SFP
```

## Interface Configuration

```
Interface          : 1/1/2
Link-level         : Ethernet
Admin State       : up
Oper State        : up
Physical Link     : Yes
Single Fiber Mode : No
IfIndex           : 35717120
Last State Change : 01/01/1970 00:18:10
Last Cleared Time  : N/A

Oper Speed        : 1 Gbps
Config Speed     : 1 Gbps
Oper Duplex      : full
Config Duplex    : full
MTU              : 1518
LoopBack Mode    : Internal
Hold time up     : 0 seconds
Hold time down   : 0 seconds
DDM Events       : Enabled

Configured Mode   : access
Dot1Q Ethertype  : 0x8100
PBB Ethertype    : 0x88e7
Ing. Pool % Rate : 100
Ing. Pool Policy : n/a
Egr. Pool Policy : n/a
Net. Egr. Queue Pol : default
Egr. Sched. Pol  : default

Encap Type       : 802.1q
QinQ Ethertype  : 0x8100
Egr. Pool % Rate : 100
Network Qos Pol : n/a
Access Egr. Qos *: 1

Acc Egr Marking  : Port-Based
Acc Egr Policy ID: 1

Auto-negotiate   : true
Accounting Policy : None
Egress Rate      : Default
LACP Tunnel      : Disabled

MDI/MDX          : MDI
Collect-stats    : Disabled
Max Burst        : Default

Uplink           : No
Split Horizon Group: (Not Specified)
Down-when-looped : Disabled
Loop Detected    : False
Use Broadcast Addr : False

Keep-alive       : 10
Retry            : 120

Sync. Status Msg. : Disabled
Code-Type        : SDH
Tx DUS/DNU       : Disabled

Rx Quality Level : N/A
Tx Quality Level : N/A

Configured Address : 00:12:ab:34:cd:59
Hardware Address   : 00:12:ab:34:cd:59
Cfg Alarm          :
Alarm Status       :

Transceiver Data

Transceiver Type   : SFP
Model Number       : 3HE00027AAAA02 ALA IPUIAELDAB
TX Laser Wavelength: 850 nm
Connector Code     : LC
Manufacture date   : 2010/06/14
Serial Number      : PHR06BD
Part Number        : FTRJ8519P2BNL-A6
Optical Compliance : GIGE-SX
Link Length support: 550m for 50u MMF; 300m for 62.5u MMF

=====
Transceiver Digital Diagnostic Monitoring (DDM), Internally Calibrated
=====
Value High Alarm High Warn Low Warn Low Alarm
-----
Temperature (C) +26.8 +95.0 +90.0 -20.0 -25.0
```

## Port Show Commands

```

Supply Voltage (V)          3.27      3.90      3.70      2.90      2.70
Tx Bias Current (mA)       6.9      17.0     14.0      2.0      1.0
Tx Output Power (dBm)     -4.39    -2.00    -2.00    -11.02   -11.74
Rx Optical Power (avg dBm) -7.24     1.00    -1.00    -18.01   -20.00
=====

=====
Traffic Statistics
=====
                                     Input          Output
-----
Octets                             0              0
Packets                             0              0
Errors                               0              0
=====

=====
Ethernet Statistics
=====

Broadcast Pkts :                0 Drop Events :                0
Multicast Pkts :                0 CRC/Align Errors :            0
Undersize Pkts :                0 Fragments :                0
Oversize Pkts :                0 Jabbers :                0
Collisions :                    0

Octets :                        0
Packets :                        0
Packets of 64 Octets :          0
Packets of 65 to 127 Octets :  0
Packets of 128 to 255 Octets :  0
Packets of 256 to 511 Octets :  0
Packets of 512 to 1023 Octets : 0
Packets of 1024 to 1518 Octets : 0
Packets of 1519 or more Octets : 0
=====
* indicates that the corresponding row element may have been truncated.
=====

Port Statistics
=====
                                     Input          Output
-----
Unicast Packets                  0              0
Multicast Packets                 0              0
Broadcast Packets                 0              0
Discards                         0              0
Unknown Proto Discards            0
=====

=====
Ethernet-like Medium Statistics
=====

Alignment Errors :                0 Sngl Collisions :            0
FCS Errors :                    0 Mult Collisions :            0
SQE Test Errors :                0 Late Collisions :            0
CSE :                            0 Excess Collisns :            0
Too long Frames :                0 Int MAC Tx Errs :            0
Symbol Errors :                  0 Int MAC Rx Errs :            0

```

```

=====
Queue Statistics
=====
-----
Packets                               Octets
-----
Egress Queue 1 (be)
Fwd Stats                             :           0
Drop Stats                             :           0
Egress Queue 2 (l2)
Fwd Stats                             :           0
Drop Stats                             :           0
Egress Queue 3 (af)
Fwd Stats                             :           0
Drop Stats                             :           0
Egress Queue 4 (l1)
Fwd Stats                             :           0
Drop Stats                             :           0
Egress Queue 5 (h2)
Fwd Stats                             :           0
Drop Stats                             :           0
Egress Queue 6 (ef)
Fwd Stats                             :           0
Drop Stats                             :           0
Egress Queue 7 (hl)
Fwd Stats                             :           0
Drop Stats                             :           0
Egress Queue 8 (nc)
Fwd Stats                             :           0
Drop Stats                             :           0
=====

```

\*A:7210SAS>show#

Entering port ranges:

\*A:7210SAS# show port

```

=====
Ports on Slot 1
=====
Port      Admin Link Port  Cfg  Oper  LAG/  Port  Port  Port  SFP/XFP/
Id        State   State MTU  MTU  Bndl  Mode  Encp  Type  MDIMDX
-----
1/1/1     Down  No   Down  1514 1514  -  accs null xcme
1/1/2     Up    Yes  Up    1518 1518  -  accs dotq xcme  MDI GIGE-SX
1/1/3     Up    No   Down  1518 1518  -  accs dotq xcme
1/1/4     Up    No   Down  1514 1514  -  accs null xcme
1/1/5     Up    Yes  Up    1518 1518  -  accs dotq xcme  MDI GIGE-T
1/1/6     Down  No   Down  1514 1514  -  accs null xcme
1/1/7     Down  No   Down  1514 1514  -  accs null xcme
1/1/8     Down  No   Down  1514 1514  -  accs null xcme
1/1/9     Up    Yes  Up    1522 1522  -  l2up qinq xcme  MDX
1/1/10    Up    Yes  Up    1522 1522  -  l2up qinq xcme  MDI
=====

```

\*A:7210SAS#

**Specific Port Output** — The following table describes port output fields for a specific port.

Label	Description
Description	A text description of the port.
Interface	The port ID displayed in the <i>slot/mda/port</i> format.
Speed	The speed of the interface.
Link-level	Ethernet — The port is configured as Ethernet.
MTU	The size of the largest packet which can be sent/received on the Ethernet physical interface, specified in octets.
LoopBack Mode	Indicates if the port is in use by loopback mac-swap application. If 'None' is displayed the port is not enabled for loopback testing. If 'Internal' is displayed, the port is in use by port loopback mac-swap application and no services can be configured on this port. This field is displayed only on the 7210 SAS-D sample output.
Admin State	Up — The port is administratively up. Down — The port is administratively down.
Oper State	Up — The port is operationally up. Down — The port is operationally down.  Additionally, the <i>lag-id</i> of the LAG it belongs to in addition to the status of the LAG member (active or standby) is specified.
Duplex	Full — The link is set to full duplex mode. Half — The link is set to half duplex mode.
Hold time up	The link up dampening time in seconds. The port link dampening timer value which reduces the number of link transitions reported to upper layer protocols.
Hold time down	The link down dampening time in seconds. The <b>down</b> timer controls the dampening timer for link down transitions.
Physical Link	Yes — A physical link is present. No — A physical link is not present.
IfIndex	Displays the interface's index number which reflects its initialization sequence.
Last State chg	Displays the system time moment that the peer is up.
Configured Mode	network — The port is configured for transport network use. access — The port is configured for service access.

Label	Description (Continued)
Dot1Q Ethertype	Indicates the Ethertype expected when the port's encapsulation type is Dot1Q.
QinQ Ethertype	Indicates the Ethertype expected when the port's encapsulation type is QinQ.
Net. Egr. Queue Pol	Specifies the network egress queue policy or that the default policy is used.
Access Egr. Qos	Specifies the access egress policy or that the default policy 1 is in use
Egr. Sched. Pol	Specifies the port scheduler policy or that the default policy default is in use
Encap Type	<p>Null – Ingress frames will not use any tags or labels to delineate a service.</p> <p>dot1q – Ingress frames carry 802.1Q tags where each tag signifies a different service.</p>
Active Alarms	The number of alarms outstanding on this port.
Auto-negotiate	<p>True – The link attempts to automatically negotiate the link speed and duplex parameters.</p> <p>False – The duplex and speed values are used for the link.</p>
Port-clock	Displays the mode of the port-clock. The port-clock can be set either as master or slave (supported only on 7210 SAS-D).
Alarm State	The current alarm state of the port.
Collect Stats	<p>Enabled – The collection of accounting and statistical data for the network Ethernet port is enabled. When applying accounting policies the data by default will be collected in the appropriate records and written to the designated billing file.</p> <p>Disabled – Collection is disabled. Statistics are still accumulated by the IOM cards, however, the CPU will not obtain the results and write them to the billing file.</p>
Configured Address	The base chassis Ethernet MAC address.
Hardware Address	The interface's hardware or system assigned MAC address at its protocol sub-layer.
Transceiver Type	Type of the transceiver.
Model Number	The model number of the transceiver.
Transceiver Code	The code for the transmission media.

## Port Show Commands

Label	Description (Continued)
Laser Wavelength	The light wavelength transmitted by the transceiver's laser.
Connector Code	The vendor organizationally unique identifier field (OUI) contains the IEEE company identifier for the vendor.
Diag Capable	Indicates if the transceiver is capable of doing diagnostics.
Vendor OUI	The vendor-specific identifier field (OUI) contains the IEEE company identifier for the vendor.
Manufacture date	The manufacturing date of the hardware component in the mmddyyyy ASCII format.
Media	The media supported for the SFP.
Serial Number	The vendor serial number of the hardware component.
Part Number	The vendor part number contains ASCII characters, defining the vendor part number or product name.
Input/Output	When the collection of accounting and statistical data is enabled, then octet, packet, and error statistics are displayed.
Errors Input/ Output	For packet-oriented interfaces, the number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol. For character-oriented or fixed-length interfaces, the number of inbound transmission units that contained errors preventing them from being deliverable to a higher-layer protocol. For packet-oriented interfaces, the number of outbound packets that could not be transmitted because of errors. For character-oriented or fixed-length interfaces, the number of outbound transmission units that could not be transmitted because of errors.
Unicast Packets Input/Output	The number of packets, delivered by this sub-layer to a higher (sub-) layer, which were not addressed to a multicast or broadcast address at this sub-layer. The total number of packets that higher-level protocols requested be transmitted, and which were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent.
Multicast Pack- ets Input/Output	The number of packets, delivered by this sub-layer to a higher (sub-) layer, which were addressed to a multicast address at this sub-layer. For a MAC layer protocol, this includes both group and functional addresses. The total number of packets that higher-level protocols requested be transmitted, and which were addressed to a multicast address at this sub-layer, including those that were discarded or not sent. For a MAC layer protocol, this includes both Group and Functional addresses.

Label	Description (Continued)
Broadcast Packets Input/Output	The number of packets, delivered by this sub-layer to a higher (sub-) layer, which were addressed to a broadcast address at this sub-layer. The total number of packets that higher-level protocols requested be transmitted, and which were addressed to a multicast address at this sub-layer, including those that were discarded or not sent. For a MAC layer protocol, this includes both Group and Functional addresses.
Discards Input/Output	The number of inbound packets chosen to be discarded to possibly free up buffer space.
Unknown Protocol Discards Input/Output	For packet-oriented interfaces, the number of packets received through the interface which were discarded because of an unknown or unsupported protocol. For character-oriented or fixed-length interfaces that support protocol multiplexing the number of transmission units received via the interface which were discarded because of an unknown or unsupported protocol. For any interface that does not support protocol multiplexing, this counter will always be 0.
Errors	This field displays the number of cells discarded due to uncorrectable HEC errors. Errors do not show up in the raw cell counts.
Sync. Status Msg	Whether synchronization status messages are enabled or disabled.
Tx DUS/DNU	Whether the QL value is forcibly set to QL-DUS/QL-DNU.
Rx Quality Level	Indicates which QL value has been received from the interface.
Tx Quality Level	Indicates which QL value is being transmitted out of the interface.
SSM Code Type	Indicates the SSM code type in use on the port.

**Detailed Port Output** — The following table describes detailed port output fields.

Label	Description
Description	A text description of the port.
Interface	The port ID displayed in the <i>slot/mda/port</i> format.
Speed	The speed of the interface.
Link-level	Ethernet — The port is configured as Ethernet.
MTU	The size of the largest packet which can be sent/received on the Ethernet physical interface, specified in octets.
Admin State	Up — The port is administratively up. Down — The port is administratively down.
Oper State	Up — The port is operationally up. Down — The port is operationally down.
Duplex	Full — The link is set to full duplex mode. Half — The link is set to half duplex mode.
Hold time up	The link up dampening time in seconds. The port link dampening timer value which reduces the number of link transitions reported to upper layer protocols.
Hold time down	The link down dampening time in seconds. The <b>down</b> timer controls the dampening timer for link down transitions.
IfIndex	Displays the interface's index number which reflects its initialization sequence.
Phy Link	Yes — A physical link is present. No — A physical link is not present.
Configured Mode	network — The port is configured for transport network use. access — The port is configured for service access.
Network Qos Pol	The QoS policy ID applied to the port.
Access Egr. Qos	Specifies the access egress policy or that the default policy 1 is in use.
Egr. Sched. Pol	Specifies the port scheduler policy or that the default policy default is in use.
Encap Type	Null — Ingress frames will not use any tags or labels to delineate a service.

Label	Description (Continued)
	<code>dot1q</code> – Ingress frames carry 802.1Q tags where each tag signifies a different service.
Active Alarms	The number of alarms outstanding on this port.
Auto-negotiate	<p><code>True</code> – The link attempts to automatically negotiate the link speed and duplex parameters.</p> <p><code>False</code> – The duplex and speed values are used for the link.</p>
Alarm State	The current alarm state of the port.
Collect Stats	<p><code>Enabled</code> – The collection of accounting and statistical data for the network Ethernet port is enabled. When applying accounting policies the data by default will be collected in the appropriate records and written to the designated billing file.</p> <p><code>Disabled</code> – Collection is disabled. Statistics are still accumulated by the IOM cards, however, the CPU will not obtain the results and write them to the billing file.</p>
Down-When-Looped	Shows whether the feature is enabled or disabled.
Egress Rate	The maximum amount of egress bandwidth (in kilobits per second) that this Ethernet interface can generate.
Configured Address	The base chassis Ethernet MAC address.
Hardware Address	The interface's hardware or system assigned MAC address at its protocol sub-layer.
Errors Input/Output	<p>For packet-oriented interfaces, the number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol. For character-oriented or fixed-length interfaces, the number of inbound transmission units that contained errors preventing them from being deliverable to a higher-layer protocol.</p> <p>For packet-oriented interfaces, the number of outbound packets that could not be transmitted because of errors. For character-oriented or fixed-length interfaces, the number of outbound transmission units that could not be transmitted because of errors.</p>
Unicast Packets Input/Output	The number of packets, delivered by this sub-layer to a higher (sub-) layer, which were not addressed to a multicast or broadcast address at this sub-layer. The total number of packets that higher-level protocols requested be transmitted, and which were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent.

## Port Show Commands

Label	Description (Continued)
Multicast Packets Input/Output	The number of packets, delivered by this sub-layer to a higher (sub-) layer, which were addressed to a multicast address at this sub-layer. For a MAC layer protocol, this includes both Group and Functional addresses. The total number of packets that higher-level protocols requested be transmitted, and which were addressed to a multicast address at this sub-layer, including those that were discarded or not sent. For a MAC layer protocol, this includes both Group and Functional addresses.
Broadcast Packets Input/Output	The number of packets, delivered by this sub-layer to a higher (sub-) layer, which were addressed to a broadcast address at this sub-layer. The total number of packets that higher-level protocols requested be transmitted, and which were addressed to a multicast address at this sub-layer, including those that were discarded or not sent. For a MAC layer protocol, this includes both Group and Functional addresses.
Discards Input/Output	The number of inbound packets chosen to be discarded to possibly free up buffer space.
Unknown Protocol Discards Input/Output	For packet-oriented interfaces, the number of packets received through the interface which were discarded because of an unknown or unsupported protocol. For character-oriented or fixed-length interfaces that support protocol multiplexing the number of transmission units received via the interface which were discarded because of an unknown or unsupported protocol. For any interface that does not support protocol multiplexing, this counter will always be 0.
LLF Admin State	Displays the Link Loss Forwarding administrative state.
LLF Oper State	Displays the Link Loss Forwarding operational state.
Rx S1 Byte	Displays the received S1 byte and its decoded QL value.
Tx DUS/DNU	Displays whether the QL value is forcibly set to QL-DUS/QL-DNU.
Qinq etype	Displays the ethertype used for qinq packet encapsulation.
Sync. Status Msg.	Enabled- If SSM is enabled. Disabled-If SSM is disabled.
Code-Type	Displays the encoding type of SSM messages as SONET or SDH.
Rx Quality Level	When SSM is enabled on this port, it displays the Clock Quality level for the clock received through that interface. The Clock Quality level is typically sent by the peer in the ESMC/SSM protocol. The quality level shown depends on the quality level mode used (SONET or SDH).

Label	Description (Continued)
Tx Quality Level	When SSM is enabled on this port, it displays the System Clock Quality level that the system advertises to the peer using the ESMC/SSM protocol. The quality level shown depends on the quality level mode used (SONET or SDH).

### Sample Output

```
*A:SN12345678# show port 1/1/15
=====
Ethernet Interface
=====
Description      : 10/100/Gig Ethernet TX
Interface        : 1/1/15                Oper Speed      : 1 Gbps
Link-level      : Ethernet              Config Speed    : 1 Gbps
Admin State     : up                    Oper Duplex     : full
Oper State      : up                    Config Duplex   : full
Physical Link   : Yes                   MTU             : 1522
IfIndex         : 36143104              Hold time up   : 0 seconds
Last State Change : 03/19/2001 21:21:07 Hold time down : 0 seconds
Last Cleared Time : N/A
IP MTU          : 1000

Configured Mode  : access                Encap Type      : QinQ
Dot1Q Ethertype : 0x8100                 QinQ Ethertype  : 0x8100
Net. Egr. Queue Pol: default           Access Egr. Qos *: n/a
Egr. Sched. Pol : default              Network Qos Pol : 1
Auto-negotiate  : limited              MDI/MDX        : MDI
Accounting Policy : None                Collect-stats   : Disabled
Egress Rate     : Default               Ingress Rate    : Default
Uplink          : Yes

Down-when-looped : Disabled              Keep-alive      : 10
Loop Detected    : False                 Retry           : 120

Configured Address : 00:87:98:76:65:0e
Hardware Address   : 00:87:98:76:65:0e
Cfg Alarm          :
Alarm Status       :
=====
Traffic Statistics
=====
                                     Input           Output
-----
Octets                2229540275006      0
Packets               2177285416         0
Errors                 14                 0
=====
* indicates that the corresponding row element may have been truncated.

=====
Port Statistics
=====
                                     Input           Output
-----
```

## Port Show Commands

```

Unicast Packets                2177285416          0
Multicast Packets              0                  0
Broadcast Packets              0                  0
Discards                      0                  0
Unknown Proto Discards        0
=====
Ethernet-like Medium Statistics
=====

Alignment Errors :           0  Sngl Collisions :           0
FCS Errors       :          13  Mult Collisions :           0
SQE Test Errors  :           0  Late Collisions :           0
CSE              :           0  Excess Collisns :           0
Too long Frames  :           0  Int MAC Tx Errs :           0
Symbol Errors    :           0  Int MAC Rx Errs :           0
=====
*A:SN12345678#
*A:SN12345678#  show port 1/1/15 detail
=====
Ethernet Interface
=====
Description       : 10/100/Gig Ethernet TX
Interface         : 1/1/15
Link-level        : Ethernet
Admin State       : up
Oper State        : up
Physical Link     : Yes
IfIndex           : 36143104
Last State Change : 03/19/2001 21:21:07
Last Cleared Time : N/A

Oper Speed        : 1 Gbps
Config Speed     : 1 Gbps
Oper Duplex       : full
Config Duplex    : full
MTU               : 1522
Hold time up     : 0 seconds
Hold time down   : 0 seconds

Configured Mode   : access
Dot1Q Ethertype  : 0x8100
Net. Egr. Queue Pol: default
Egr. Sched. Pol  : default
Auto-negotiate   : limited
Accounting Policy : None
Egress Rate      : Default
Uplink           : Yes

Encap Type       : QinQ
QinQ Ethertype   : 0x8100
Access Egr. Qos *: n/a
Network Qos Pol  : 1
MDI/MDX          : MDI
Collect-stats    : Disabled
Ingress Rate     : Default

Down-when-looped : Disabled
Loop Detected    : False

Keep-alive       : 10
Retry            : 120

Configured Address : 00:87:98:76:65:0e
Hardware Address   : 00:87:98:76:65:0e
Cfg Alarm          :
Alarm Status       :
=====
Traffic Statistics
=====
                                     Input          Output
-----
Octets                2199575527230          0
Packets               2148022967            0
Errors                 14              0
=====
Ethernet Statistics
=====

```

## Interface Configuration

```

Broadcast Pkts : 0 Drop Events : 0
Multicast Pkts : 0 CRC/Align Errors : 13
Undersize Pkts : 0 Fragments : 1
Oversize Pkts : 0 Jabbers : 0
Collisions : 0

```

```

Octets : 2199575527230
Packets : 2148022967
Packets of 64 Octets : 0
Packets of 65 to 127 Octets : 0
Packets of 128 to 255 Octets : 1
Packets of 256 to 511 Octets : 0
Packets of 512 to 1023 Octets : 12
Packets of 1024 to 1518 Octets : 2148022966
Packets of 1519 or more Octets : 0

```

=====  
\* indicates that the corresponding row element may have been truncated.  
=====

### Port Statistics

```

=====
                                     Input          Output
-----
Unicast Packets                    2148272026          0
Multicast Packets                   0                  0
Broadcast Packets                   0                  0
Discards                            0                  0
Unknown Proto Discards              0
=====

```

### Ethernet-like Medium Statistics

```

=====
Alignment Errors : 0 Sngl Collisions : 0
FCS Errors : 13 Mult Collisions : 0
SQE Test Errors : 0 Late Collisions : 0
CSE : 0 Excess Collisns : 0
Too long Frames : 0 Int MAC Tx Errs : 0
Symbol Errors : 0 Int MAC Rx Errs : 0
=====

```

### Meter Statistics

```

=====
                                     Packets          Octets
-----
Ingress Meter 1 (Unicast)
For. InProf : 0 0
For. OutProf : 0 0
Ingress Meter 9 (Multipoint)
For. InProf : 0 0
For. OutProf : 0 0
=====

```

\*A:SN12345678#

## Port Show Commands

### Sample Output (for 7210 SAS D)

```
*A:SAS-D>config# show port 1/1/2
```

```
=====
Ethernet Interface
=====
Description      : 10/100/Gig Ethernet SFP
Interface        : 1/1/2                Oper Speed      : N/A
Link-level       : Ethernet             Config Speed    : 1 Gbps
Admin State      : down                 Oper Duplex     : N/A
Oper State       : down                 Config Duplex   : full
Physical Link    : No                   MTU             : 1514
Single Fiber Mode : No
IfIndex          : 35717120             Hold time up    : 0 seconds
Last State Change : 01/01/1970 00:00:08 Hold time down  : 0 seconds
Last Cleared Time : N/A                 DDM Events     : Enabled

Configured Mode  : access                Encap Type      : null
Dot1Q Ethertype  : 0x8100               QinQ Ethertype  : 0x8100
PBB Ethertype    : 0x88e7
Ing. Pool % Rate : 100                   Egr. Pool % Rate : 100
Ing. Pool Policy : n/a
Egr. Pool Policy : n/a
Net. Egr. Queue Pol: default           Network Qos Pol : n/a
Egr. Sched. Pol  : default              Access Egr. Qos *: 1
Auto-negotiate   : true                 MDI/MDX        : unknown
Port-clock       : master
Accounting Policy : None                 Collect-stats   : Disabled
Egress Rate      : Default              Max Burst      : Default
Load-balance-algo : default             LACP Tunnel    : Disabled
LACP Tunnel      : Disabled

Uplink           : No
Split Horizon Group: (Not Specified)
Down-when-looped : Disabled            Keep-alive     : 10
Loop Detected    : False               Retry          : 120
Use Broadcast Addr : False

Sync. Status Msg. : Disabled           Rx Quality Level : N/A
Code-Type        : SDH                 Tx Quality Level : N/A
Tx DUS/DNU       : Disabled

Configured Address : 00:3f:11:ab:ca:14
Hardware Address   : 00:3f:11:ab:ca:14
Cfg Alarm          :
Alarm Status       :
```

```
=====
Traffic Statistics
=====
-----
Input                               Output
-----
Octets                               0                               0
Packets                              0                               0
Errors                               0                               0
=====
```

## Interface Configuration

\* indicates that the corresponding row element may have been truncated.

### Port Statistics

```

=====
Port Statistics
=====
                                     Input          Output
-----
Unicast Packets                      0             0
Multicast Packets                     0             0
Broadcast Packets                     0             0
Discards                              0             0
Unknown Proto Discards                0
=====

```

### Ethernet-like Medium Statistics

```

=====
Alignment Errors :                0  Sngl Collisions :                0
FCS Errors       :                0  Mult Collisions :                0
SQE Test Errors  :                0  Late Collisions :                0
CSE              :                0  Excess Collisns :                0
Too long Frames  :                0  Int MAC Tx Errs :                0
Symbol Errors    :                0  Int MAC Rx Errs :                0
=====

```

\*A:ALA-A# show port 1/1/1 detail

### Ethernet Interface

```

=====
Description       : 10/100/Gig Ethernet SFP
Interface         : 1/1/1           Oper Speed      : 0 mbps
Link-level       : Ethernet        Config Speed    : 1 Gbps
Admin State      : up              Oper Duplex     : N/A
Oper State       : down            Config Duplex   : full
Reason Down      : linkLossFwd
Physical Link    : No              MTU             : 1514
IfIndex          : 35684352        Hold time up   : 0 seconds
Last State Change : 01/22/2010 23:54:49
Last Cleared Time : 01/21/2010 17:40:16
Hold time down   : 0 seconds

Configured Mode   : access          Encap Type      : null
Dot1Q Ethertype  : 0x8100         QinQ Ethertype  : 0x8100
Net. Egr. Queue Pol: default       Access Egr. Qos *: 1
Egr. Sched. Pol  : default         Network Qos Pol : n/a
Auto-negotiate   : false           MDI/MDX        : unknown
Accounting Policy : None            Collect-stats   : Disabled
Egress Rate      : Default          Max Burst       : Default
Uplink           : No

Down-when-looped : Disabled        Keep-alive     : 10
Loop Detected    : False           Retry          : 120

Configured Address : 28:06:01:01:00:01
Hardware Address   : 28:06:01:01:00:01
Cfg Alarm         :
Alarm Status      :

```

## Port Show Commands

```
=====
Traffic Statistics
=====
                                     Input           Output
-----
Octets                               0             0
Packets                              0             0
Errors                               0             0
=====
```

```
=====
Ethernet Statistics
=====
Broadcast Pkts : 0 Drop Events : 0
   0 Pkts : 0 CRC/Align Errors : 0
Undersize Pkts : 0 Fragments : 0
Oversize Pkts : 0 Jabbers : 0
Collisions : 0

Octets : 0
Packets : 0
Packets of 64 Octets : 0
Packets of 65 to 127 Octets : 0
Packets of 128 to 255 Octets : 0
Packets of 256 to 511 Octets : 0
Packets of 512 to 1023 Octets : 0
Packets of 1024 to 1518 Octets : 0
Packets of 1519 or more Octets : 0
=====
```

\* indicates that the corresponding row element may have been truncated.

\*A:ALA-A#

\*A:SAS-D>config# show port 1/1/2 detail

```
=====
Ethernet Interface
=====
Description      : 10/100/Gig Ethernet SFP
Interface        : 1/1/2           Oper Speed      : N/A
Link-level       : Ethernet         Config Speed    : 1 Gbps
Admin State      : down             Oper Duplex     : N/A
Oper State       : down             Config Duplex   : full
Physical Link    : No               MTU             : 1514
Single Fiber Mode : No
IfIndex          : 35717120         Hold time up   : 0 seconds
Last State Change : 01/01/1970 00:00:08 Hold time down : 0 seconds
Last Cleared Time : N/A             DDM Events     : Enabled

Configured Mode  : access           Encap Type     : null
Dot1Q Ethertype  : 0x8100          QinQ Ethertype : 0x8100
PBB Ethertype    : 0x88e7
Ing. Pool % Rate : 100              Egr. Pool % Rate : 100
Ing. Pool Policy : n/a
Egr. Pool Policy : n/a
Net. Egr. Queue Pol: default       Network Qos Pol : n/a
Egr. Sched. Pol  : default          Access Egr. Qos *: 1
Auto-negotiate   : true             MDI/MDX        : unknown
Accounting Policy : None             Collect-stats   : Disabled
Egress Rate      : Default           Max Burst      : Default
=====
```

## Interface Configuration

```

Load-balance-algo : default
LACP Tunnel       : Disabled

LACP Tunnel       : Disabled

Uplink            : No
Split Horizon Group: (Not Specified)
Down-when-looped  : Disabled
Loop Detected     : False
Use Broadcast Addr : False

Sync. Status Msg. : Disabled
Code-Type         : SDH
Tx DUS/DNU        : Disabled

Rx Quality Level  : N/A
Tx Quality Level  : N/A

Configured Address : 00:3f:11:ab:ca:14
Hardware Address   : 00:3f:11:ab:ca:14
Cfg Alarm          :
Alarm Status       :
  
```

```

=====
Traffic Statistics
=====
                                     Input           Output
-----
Octets                               0             0
Packets                              0             0
Errors                               0             0
  
```

```

=====
Ethernet Statistics
=====
Broadcast Pkts : 0 Drop Events : 0
Multicast Pkts : 0 CRC/Align Errors : 0
Undersize Pkts : 0 Fragments : 0
Oversize Pkts  : 0 Jabbers : 0
Collisions     : 0

Octets : 0
Packets : 0
Packets of 64 Octets : 0
Packets of 65 to 127 Octets : 0
Packets of 128 to 255 Octets : 0
Packets of 256 to 511 Octets : 0
Packets of 512 to 1023 Octets : 0
Packets of 1024 to 1518 Octets : 0
Packets of 1519 or more Octets : 0
  
```

\* indicates that the corresponding row element may have been truncated.

```

=====
Port Statistics
=====
                                     Input           Output
-----
Unicast Packets  0             0
Multicast Packets 0             0
Broadcast Packets 0             0
Discards         0             0
Unknown Proto Discards 0
  
```

## Port Show Commands

```
=====  
=====  
Ethernet-like Medium Statistics  
=====  
Alignment Errors : 0 Sngl Collisions : 0  
FCS Errors : 0 Mult Collisions : 0  
SQE Test Errors : 0 Late Collisions : 0  
CSE : 0 Excess Collisns : 0  
Too long Frames : 0 Int MAC Tx Errs : 0  
Symbol Errors : 0 Int MAC Rx Errs : 0  
=====
```

```
=====  
Queue Statistics  
=====
```

```
-----  
Packets Octets  
-----  
Egress Queue 1 (be)  
Fwd Stats : 0 0  
Drop Stats : 0 0  
Egress Queue 2 (l2)  
Fwd Stats : 0 0  
Drop Stats : 0 0  
Egress Queue 3 (af)  
Fwd Stats : 0 0  
Drop Stats : 0 0  
Egress Queue 4 (l1)  
Fwd Stats : 0 0  
Drop Stats : 0 0  
Egress Queue 5 (h2)  
Fwd Stats : 0 0  
Drop Stats : 0 0  
Egress Queue 6 (ef)  
Fwd Stats : 0 0  
Drop Stats : 0 0  
Egress Queue 7 (h1)  
Fwd Stats : 0 0  
Drop Stats : 0 0  
Egress Queue 8 (nc)  
Fwd Stats : 0 0  
Drop Stats : 0 0  
=====
```

### Ethernet Output Fields

Sample output for 7210 SAS-D:

```
*7210SAS-D># show port 1/1/3 detail
```

```
=====  
Ethernet Interface
```

## Interface Configuration

```

=====
Description          : 10/100/Gig Ethernet SFP
Interface            : 1/1/3
Link-level           : Ethernet
Admin State          : up
Oper State            : up
Physical Link        : Yes
Single Fiber Mode    : No
IfIndex              : 35749888
Last State Change    : 01/01/1970 00:15:29
Last Cleared Time     : N/A

Oper Speed           : 1 Gbps
Config Speed         : 1 Gbps
Oper Duplex          : full
Config Duplex        : full
MTU                  : 1514
LoopBack Mode        : None
Hold time up         : 0 seconds
Hold time down       : 0 seconds
DDM Events           : Enabled

Configured Mode      : access
Dot1Q Ethertype      : 0x8100
PBB Ethertype        : 0x88e7
Ing. Pool % Rate     : 100
Ing. Pool Policy     : n/a
Egr. Pool Policy     : n/a
Net. Egr. Queue Pol : default
Egr. Sched. Pol      : default
Auto-negotiate       : true
Accounting Policy    : None
Egress Rate          : Default
LACP Tunnel          : Disabled

Encap Type           : null
QinQ Ethertype       : 0x8100
Acc Egr Sch Mode     : Fc-Based
Egr. Pool % Rate     : 100

Network Qos Pol      : n/a
Access Egr. Qos     *: 1
MDI/MDX              : MDI
Collect-stats        : Disabled
Max Burst            : Default

Uplink               : No
Split Horizon Group  : (Not Specified)
Down-when-looped     : Disabled
Loop Detected        : False
Use Broadcast Addr   : False

Keep-alive           : 10
Retry                : 120

Sync. Status Msg.    : Enabled
Code-Type            : SDH
Tx DUS/DNU           : Disabled

Rx Quality Level     : 0x2(prc)
Tx Quality Level     : 0xf(dnu)

Configured Address   : 00:32:fb:04:1a:04
Hardware Address     : 00:32:fb:04:1a:04
Cfg Alarm            :
Alarm Status         :

Transceiver Data

Transceiver Type     : SFP
Model Number         : 3HE00027AAAA02 ALA IPUAELDAB
TX Laser Wavelength : 850 nm
Connector Code       : LC
Manufacture date     : 2010/06/02
Serial Number        : PHP2JMJ
Part Number          : FTRJ8519P2BNL-A6
Optical Compliance   : GIGE-SX
Link Length support  : 550m for 50u MMF; 300m for 62.5u MMF

Diag Capable        : yes
Vendor OUI          : 00:90:65
Media               : Ethernet

=====
Transceiver Digital Diagnostic Monitoring (DDM), Internally Calibrated
=====
Value High Alarm  High Warn  Low Warn  Low Alarm
-----
Temperature (C)   +44.9    +95.0    +90.0    -20.0    -25.0
Supply Voltage (V) 3.30     3.90     3.70     2.90     2.70
=====

```

## Port Show Commands

```

Tx Bias Current (mA)          6.8      17.0      14.0      2.0      1.0
Tx Output Power (dBm)        -4.71   -2.00   -2.00   -11.02  -11.74
Rx Optical Power (avg dBm)   -5.18    1.00   -1.00   -18.01  -20.00
=====

=====
Traffic Statistics
=====
-----
                                Input                Output
-----
Octets                          30976                30720
Packets                          308                  304
Errors                            0                    0
=====

=====
Ethernet Statistics
=====

Broadcast Pckts :                0 Drop Events :                0
Multicast Pckts :               612 CRC/Align Errors :            0
Undersize Pckts :                0 Fragments :                0
Oversize Pckts :                0 Jabbers :                0
Collisions :                    0

Octets :                        61696
Packets :                        612
Packets of 64 Octets :           260
Packets of 65 to 127 Octets :    0
Packets of 128 to 255 Octets :   352
Packets of 256 to 511 Octets :   0
Packets of 512 to 1023 Octets :  0
Packets of 1024 to 1518 Octets : 0
Packets of 1519 or more Octets : 0
=====
* indicates that the corresponding row element may have been truncated.
=====

=====
Port Statistics
=====
-----
                                Input                Output
-----
Unicast Packets                  0                    0
Multicast Packets                308                  304
Broadcast Packets                 0                    0
Discards                         0                    0
Unknown Proto Discards           0
=====

=====
Ethernet-like Medium Statistics
=====

Alignment Errors :                0 Sngl Collisions :            0
FCS Errors :                    0 Mult Collisions :            0
SQE Test Errors :                0 Late Collisions :            0
CSE :                            0 Excess Collisns :            0
Too long Frames :                0 Int MAC Tx Errs :            0
Symbol Errors :                  0 Int MAC Rx Errs :            0
=====

```

```

=====
Queue Statistics
=====
-----
                Packets                Octets
-----
Egress Queue 1 (be)
Fwd Stats      :                0                0
Drop Stats     :                0                0
Egress Queue 2 (l2)
Fwd Stats      :                0                0
Drop Stats     :                0                0
Egress Queue 3 (af)
Fwd Stats      :                0                0
Drop Stats     :                0                0
Egress Queue 4 (l1)
Fwd Stats      :                0                0
Drop Stats     :                0                0
Egress Queue 5 (h2)
Fwd Stats      :                0                0
Drop Stats     :                0                0
Egress Queue 6 (ef)
Fwd Stats      :                0                0
Drop Stats     :                0                0
Egress Queue 7 (h1)
Fwd Stats      :                0                0
Drop Stats     :                0                0
Egress Queue 8 (nc)
Fwd Stats      :                0                0
Drop Stats     :                0                0
=====

```

**Ethernet Output** — The following table describes Ethernet output fields.

Label	Description
Broadcast Pckts	The number of packets, delivered by this sub-layer to a higher (sub-) layer, which were addressed to a broadcast address at this sub-layer. The total number of packets that higher-level protocols requested be transmitted, and which were addressed to a multicast address at this sub-layer, including those that were discarded or not sent. For a MAC layer protocol, this includes both Group and Functional addresses.
Multicast Pckets	The number of packets, delivered by this sub-layer to a higher (sub-) layer, which were addressed to a multicast address at this sub-layer. For a MAC layer protocol, this includes both Group and Functional addresses. The total number of packets that higher-level protocols requested be transmitted, and which were addressed to a multicast address at this sub-layer, including those that were discarded or not sent. For a MAC layer protocol, this includes both Group and Functional addresses.

## Port Show Commands

Label	Description (Continued)
Undersize Pckets	The total number of packets received that were less than 64 octets long (excluding framing bits, but including FCS octets) and were otherwise well formed.
Oversize Pckts	The total number of packets received that were longer than can be accepted by the physical layer of that port (9900 octets excluding framing bits, but including FCS octets for GE ports) and were otherwise well formed.
Collisions	The best estimate of the total number of collisions on this Ethernet segment.
Drop Events	The total number of events in which packets were dropped by the probe due to lack of resources. Note that this number is not necessarily the number of packets dropped; it is just the number of times this condition has been detected.
CRC Align Errors	The total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Fragments	The total number of packets received that were less than 64 octets in length (excluding framing bits but including FCS octets) and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Jabbers	The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Octets	The total number of octets received.
Packets	The total number of packets received.
Packets to	The number of packets received that were equal to or less than the displayed octet limit.

### Sample Output (for 7210 SAS E)

```

=====
Ethernet Statistics
=====
Broadcast Pckts :                0 Drop Events      :                0
Multicast Pckts :                0 CRC/Align Errors :                0

```

## Interface Configuration

```
Undersize Pkts : 0 Fragments : 0
Oversize Pkts : 0 Jabbers : 0
Collisions : 0
```

```
Octets : 0
Packets : 0
Packets of 64 Octets : 0
Packets of 65 to 127 Octets : 0
Packets of 128 to 255 Octets : 0
Packets of 256 to 511 Octets : 0
Packets of 512 to 1023 Octets : 0
Packets of 1024 to 1518 Octets : 0
Packets of 1519 or more Octets : 0
```

=====  
 \* indicates that the corresponding row element may have been truncated.

=====  
 Port Statistics  
 =====

	Input	Output
Unicast Packets	0	0
Multicast Packets	0	0
Broadcast Packets	0	0
Discards	0	0
Unknown Proto Discards	0	

=====

=====  
 Ethernet Statistics  
 =====

```
Broadcast Pkts : 42621 Drop Events : 0
Multicast Pkts : 0 CRC/Align Errors : 0
Undersize Pkts : 0 Fragments : 0
Oversize Pkts : 0 Jabbers : 0
Collisions : 0
```

```
Octets : 2727744
Packets : 42621
Packets of 64 Octets : 42621
Packets of 65 to 127 Octets : 0
Packets of 128 to 255 Octets : 0
Packets of 256 to 511 Octets : 0
Packets of 512 to 1023 Octets : 0
Packets of 1024 to 1518 Octets : 0
Packets of 1519 or more Octets : 0
```

=====  
 Port Statistics  
 =====

	Input	Output
Unicast Packets	0	0
Multicast Packets	0	0
Broadcast Packets	42621	0
Discards	0	0
Unknown Proto Discards	0	

=====

...

**Ethernet-like Medium Statistics Output** — The following table describes Ethernet-like medium statistics output fields.

Label	Description
Alignment Errors	The total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets.
FCS Errors	The number of frames received on a particular interface that are an integral number of octets in length but do not pass the FCS check.
SQE Errors	The number of times that the SQE TEST ERROR is received on a particular interface.
CSE	The number of times that the carrier sense condition was lost or never asserted when attempting to transmit a frame on a particular interface.
Too long Frames	The number of frames received on a particular interface that exceed the maximum permitted frame size.
Symbol Errors	For an interface operating at 100 Mb/s, the number of times there was an invalid data symbol when a valid carrier was present.
Sngl Collisions	The number of frames that are involved in a single collision, and are subsequently transmitted successfully.
Mult Collisions	The number of frames that are involved in more than one collision and are subsequently transmitted successfully.
Late Collisions	The number of times that a collision is detected on a particular interface later than one slotTime into the transmission of a packet.
Excess Collisns	The number of frames for which transmission on a particular interface fails due to excessive collisions.
Int MAC Tx Errs	The number of frames for which transmission on a particular interface fails due to an internal MAC sublayer transmit error,
Int MAC Rx Errs	The number of frames for which reception on a particular interface fails due to an internal MAC sublayer receive error.
Ingress Meter	Specifies themeter ID.
For. InProf	The number of in-profile packets and octets (rate below CIR) forwarded by the ingress meter.
For. OutProf	The number of out-of-profile packets and octets (rate below CIR) forwarded by the ingress meter.

**Ethernet-like Medium Statistics** — the following table describe Ethernet-like Medium Statistics field..

<b>Label</b>	<b>Description</b>
Alignment Errors	The total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but that had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets.
FCS Errors	The number of frames received that are an integral number of octets in length but do not pass the FCS check.
SQE Errors	The number of times that the SQE TEST ERROR is received.
CSE	The number of times that the carrier sense condition was lost or never asserted when attempting to transmit a frame.
Too long Frames	The number of frames received that exceed the maximum permitted frame size.
Symbol Errors	For an interface operating at 100 Mb/s, the number of times there was an invalid data symbol when a valid carrier was present
Sngl Collisions	The number of frames that are involved in a single collision, and are subsequently transmitted successfully.
Mult Collisions	The number of frames that are involved in more than one collision and are subsequently transmitted successfully.
Late Collisions	The number of times that a collision is detected later than one slot Time into the transmission of a packet.
Excess Collisions	The number of frames for which a transmission fails due to excessive collisions.
Int MAC Tx Errs	The number of frames for which a transmission fails due to an internal MAC sub-layer transmit error.
Int MAC Rx Errs	The number of frames for which a reception fails due to an internal MAC sub-layer receive error.
Multicast Pckts	The number of packets, delivered by this sub-layer to a higher (sub-) layer, which were not addressed to a unicast or broadcast address at this sub-layer. The total number of packets that higher-level protocols requested be transmitted, and which were not addressed to a unicast or broadcast address at this sub-layer, including those that were discarded or not sent.
Undersize Pckts	The total number of packets received that were shorter than 64 octets (excluding framing bits, but including FCS octets) but were otherwise well formed.

## Port Show Commands

<b>Label</b>	<b>Description</b>
Oversize Pckts	The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets) but were otherwise well formed.
Collisions	The best estimate of the total number of collisions on this Ethernet segment.
Drop Events	The total number of times that packets were detected as being dropped due to a lack of resources (not necessarily the total number of packets dropped).
CRC Align Errors	The total number of packets received that were between 64 and 1518 octets (excluding framing bits but including FCS octets) that had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Fragments	The total number of packets received that were shorter than 64 octets (excluding framing bits but including FCS octets) that had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Jabbers	The total number of packets received that were longer than 1518 octets (excluding framing bits but including FCS octets) that had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Octets	Total number of octets received.
Packets	The number of packets received, broken down by size Port Statistics.
Unicast packets input/output	The number of packets, delivered by this sub-layer to a higher (sub-) layer, which were not addressed to a multicast or broadcast address at this sub-layer. The total number of packets that higher-level protocols requested be transmitted, and which were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent.
Multicast packets input/output	The number of packets, delivered by this sub-layer to a higher (sub-) layer, which were not addressed to a unicast or broadcast address at this sub-layer. The total number of packets that higher-level protocols requested be transmitted, and which were not addressed to a unicast or broadcast address at this sub-layer, including those that were discarded or not sent.

Label	Description
Broadcast packets input/output	The number of packets, delivered by this sub-layer to a higher (sub-) layer, which were not addressed to a unicast or multicast address at this sub-layer. The total number of packets that higher-level protocols requested be transmitted, and which were not addressed to a unicast or multicast address at this sub-layer, including those that were discarded or not sent.
Discards input/output	The number of inbound packets chosen to be discarded to possibly free up buffer space.
Unknown protocols discards input/output	For packet-oriented interfaces, the number of packets received via the interface that were discarded because of an unknown or unsupported protocol. For character-oriented or fixed-length interfaces that support protocol multiplexing, the number of transmission units received via the interface that were discarded because of an unknown or unsupported protocol. For any interface that does not support protocol multiplexing, this counter will always be 0.
Unknown protocols	Discards do not show up in the packet counts.

### Sample Output (for 7210 SAS E)

```

=====
Ethernet-like Medium Statistics
=====
Alignment Errors :                0  Sngl Collisions :                0
FCS Errors       :                0  Mult Collisions :                0
SQE Test Errors  :                0  Late Collisions :                0
CSE              :                0  Excess Collisns :                0
Too long Frames  :                0  Int MAC Tx Errs :                0
Symbol Errors    :                0  Int MAC Rx Errs :                0
=====

.....

A:ALA-48# show port 1/3/1 detail
=====
...
=====
Ethernet-like Medium Statistics
=====
Alignment Errors :                0  Sngl Collisions :                0
FCS Errors       :                0  Mult Collisions :                0
SQE Test Errors  :                0  Late Collisions :                0
CSE              :                0  Excess Collisns :                0
Too long Frames  :                0  Int MAC Tx Errs :                0
Symbol Errors    :                0  Int MAC Rx Errs :                0

```

## Port Show Commands

```
*A:ALU-SAS#
=====
...
Meter Statistics
=====
                Packets                Octets
-----
Ingress Meter  1 (Unicast)
For. InProf    :                0                0
For. OutProf   :                0                0
Ingress Meter  9 (Multipoint)
For. InProf    :                0                0
For. OutProf   :                0                0
...
=====
*A:ALU-SAS#
```

**Port Associations Output** — The following table describes port associations output fields.

Label	Description
Svc ID	The service identifier.
Name	The name of the IP interface.
Encap Value	The dot1q or qinq encapsulation value on the port for this IP interface

### Sample Output

```
A:ALA-1# show port 1/1/6 associations
=====
Interface Table
=====
Router/ServiceId      Name                Encap Val
-----
Router: Base          if1000              1000
Router: Base          if2000              2000
-----
Interfaces
=====
A:ALA-1#
```

**A1 Detailed Output** — The following table describes A1 detailed output fields.(Out of Band Ethernet port is not supported on 7210 SAS D devices)

Label	Description
Description	A text description of the port.
Interface	The port ID displayed in the slot/mda/port format.
Oper Speed	The operating speed of the interface.
Link-level	Ethernet — the port is configured as Ethernet.

Label	Description (Continued)
Config Speed	The configured speed of the interface.
Admin State	up — the port is administratively up. down — the port is administratively down.
Oper Duplex	The operating duplex mode of the interface.
Oper State	up — the port is operationally up. down — the port is operationally down.
Config Duplex	full — the link is configured to full duplex mode. half — the link is configured to half duplex mode.
Physical Link	Yes — a physical link is present. No — a physical link is not present.
MTU	The size of the largest packet that can be sent/received on the Ethernet physical interface, specified in octets.
IfIndex	The interface's index number that reflects its initialization sequence.
Hold time up	The link-up dampening time in seconds. The port link dampening timer value that reduces the number of link transitions reported to upper layer protocols.
Last State Change	The last time that the operational status of the port changed state.
Hold time down	The link-down dampening time in seconds. The down timer controls the dampening timer for link down transitions.
Configured Mode	network — the port is configured for transport. network use access — the port is configured for service access.
Encap Type	null — ingress frames will not use any tags or labels to delineate a service. dot1q — ingress frames carry 802.1Q tags where each tag signifies a different service.
Dot1Q Ethertype	The protocol carried in an Ethernet frame.
Net.Egr. Queue Pol.	The number of the associated network egress queue QoS policy, or default if the default policy is used.
ACFC	Indicates whether Address and Control Field PPP Header Compression is enabled.
PFC	Indicates whether Protocol Field PPP Header Compression is enabled.
Auto-negotiate	true — the link attempts to automatically negotiate the link speed and duplex parameters. false — the duplex and speed values are used for the link.

## Port Show Commands

Label	Description (Continued)
Egress Rate	The maximum amount of egress bandwidth (in kilobits per second) that this Ethernet interface can generate.
Loopback	The type of loopback configured on the port, either line, internal, or none.
Loopback Time Left	The number of seconds left in a timed loopback. If there is no loopback configured or the configured loopback is latched, the value is unspecified.
Configured Address	The base chassis Ethernet MAC address.
Hardware Address	The interface's hardware or system assigned MAC address at its protocol sub-layer.
Traffic Statistics	<p>Octets input/output – the total number of octets received and transmitted on the port. Packets input/output – the number of packets, delivered by this sub-layer to a higher (sub-) layer, which were not addressed to a multicast or broadcast address at this sublayer. The total number of packets that higher-level protocols requested be transmitted, and which were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent.</p> <p>Errors input/output – for packet-oriented interfaces, the number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol. For character-oriented or fixed-length interfaces, the number of inbound transmission units that contained errors preventing them from being deliverable to a higher-layer protocol.</p> <p>For packet-oriented interfaces, the number of outbound packets that could not be transmitted because of errors. For character-oriented or fixed length interfaces, the number of outbound transmission units that could not be transmitted because of errors.</p>
Ethernet Statistics	Broadcast Pkts — the number of packets, delivered by this sub-layer to a higher (sub-) layer, which were not addressed to a unicast or multicast address at this sub-layer. The total number of packets that higher-level protocols requested be transmitted, and which were not addressed to a unicast or multicast address at this sub-layer, including those that were discarded or not sent.

```
A:7210>show# port A/1 detail
```

```

=====
Ethernet Interface
=====
Description          : 10/100 Ethernet TX

```

## Interface Configuration

Interface : A/1  
Link-level : Ethernet  
Admin State : up  
Oper State : up  
Physical Link : Yes  
Single Fiber Mode : No  
IfIndex : 67141632  
Last State Change : 07/09/2010 16:30:04  
Last Cleared Time : N/A

Oper Speed : 10 mbps  
Config Speed : 100 mbps  
Oper Duplex : half  
Config Duplex : full  
MTU : 1514

Hold time up : 0 seconds  
Hold time down : 0 seconds

Configured Mode : network  
Dot1Q Ethertype : 0x8100  
PBB Ethertype : 0x88e7  
Ing. Pool % Rate : 100  
Ing. Pool Policy : n/a  
Egr. Pool Policy : n/a  
Net. Egr. Queue Pol :  
Egr. Sched. Pol : default  
Egr. Sched. Pol : default  
Auto-negotiate : true  
Accounting Policy : None  
Egress Rate : Default

Encap Type : null  
QinQ Ethertype : 0x8100  
Egr. Pool % Rate : 100  
Network Qos Pol : n/a  
Access Egr. Qos \*: n/a  
MDI/MDX : MDI  
Collect-stats : Disabled  
Max Burst : Default

Split Horizon Group: (Not Specified)  
Down-when-looped : N/A  
Loop Detected : N/A  
Use Broadcast Addr : N/A

Keep-alive : N/A  
Retry : N/A

Sync. Status Msg. : Disabled

Rx Quality Level : N/A

Configured Address : 00:aa:01:ab:02:02  
Hardware Address : 00:aa:01:ab:02:02  
Cfg Alarm :  
Alarm Status :

### Traffic Statistics

	Input	Output
Octets	5950409	0
Packets	4274	0
Errors	0	0

### Ethernet Statistics

Broadcast Pckts :	38	Drop Events :	0
Multicast Pckts :	0	CRC/Align Errors :	0
Undersize Pckts :	0	Fragments :	0
Oversize Pckts :	0	Jabbers :	0
Collisions :	0		

Octets :	6102041
Packets :	4382
Packets of 64 Octets :	34
Packets of 65 to 127 Octets :	0
Packets of 128 to 255 Octets :	366

## Port Show Commands

```
Packets of 256 to 511 Octets : 0
Packets of 512 to 1023 Octets : 0
Packets of 1024 to 1518 Octets : 3982
Packets of 1519 or more Octets : 0
=====
* indicates that the corresponding row element may have been truncated.
=====
Port Statistics
=====
-----
Input                                     Output
-----
Unicast Packets                          4416                                0
Multicast Packets                         0                                  0
Broadcast Packets                        38                                 0
Discards                                  0                                  0
Unknown Proto Discards                   0                                  0
=====
Ethernet-like Medium Statistics
=====
Alignment Errors : 0 Sngl Collisions : 0
FCS Errors : 0 Mult Collisions : 0
SQE Test Errors : 0 Late Collisions : 0
CSE : 0 Excess Collisns : 0
Too long Frames : 0 Int MAC Tx Errs : 0
Symbol Errors : 0 Int MAC Rx Errs : 0
=====
```

## lldp

**Syntax** **lldp** [**nearest-bridge**|**nearest-non-tpmr**|**nearest-customer**] [**remote-info**] [**detail**]

**Context** show>port>ethernet

**Description** This command displays Link Layer Discovery Protocol (LLDP) information.

**Parameters** **nearest-bridge** — Displays nearest bridge information.

**nearest-non-tpmr** — Displays nearest Two-Port MAC Relay (TPMR) information.

**nearest-customer** — Displays nearest customer information.

**remote-info** — Displays remote information on the bridge MAC.

**detail** — Shows detailed information.

**Output** **Sample Output**

```
*A:7210-SAS# show port 1/1/3 ethernet lldp
=====
Link Layer Discovery Protocol (LLDP) Port Information
=====
```

```

Port 1/1/3 Bridge nearest-bridge
-----
Admin State          : rxOnly          Notifications      : Disabled
Transmit TLVs       : None

Management Address Transmit Configuration:
Index 1 (system)    : Disabled        Address           : Not Configured
    
```

```

Port 1/1/3 Bridge nearest-non-tpmr
-----
Admin State          : rxOnly          Notifications      : Disabled
Transmit TLVs       : None

Management Address Transmit Configuration:
Index 1 (system)    : Disabled        Address           : Not Configured
    
```

```

Port 1/1/3 Bridge nearest-customer
-----
Admin State          : rxOnly          Notifications      : Disabled
Transmit TLVs       : None

Management Address Transmit Configuration:
Index 1 (system)    : Disabled        Address           : Not Configured
    
```

```

=====
*A:7210-SAS#
    
```

```

*A:7210-SAS# show port 1/1/3 ethernet lldp nearest-bridge detail
=====
Link Layer Discovery Protocol (LLDP) Port Information
=====
    
```

```

Port 1/1/3 Bridge nearest-bridge
-----
Admin State          : rxOnly          Notifications      : Disabled
Transmit TLVs       : None

Management Address Transmit Configuration:
Index 1 (system)    : Disabled        Address           : Not Configured
    
```

```

Port LLDP Stats:
Tx Frames           : 0                Tx Length Err Frames : 0
Rx Frames           : 0                Rx Frame Discard     : 0
Rx Frame Errors     : 0                Rx TLV Discard       : 0
Rx TLV Unknown      : 0                Rx Ageouts           : 0
=====
*A:7210-SAS#
    
```

```

*A:7210-SAS# show port 1/1/3 ethernet lldp remote-info detail
=====
Link Layer Discovery Protocol (LLDP) Port Information
=====
    
```

## Port Show Commands

```
Port 1/1/3 Bridge nearest-bridge Remote Peer Information
```

```
-----  
No remote peers found
```

```
Port 1/1/3 Bridge nearest-non-tpmr Remote Peer Information
```

```
-----  
Remote Peer Index 142 at timestamp 06/10/2010 00:23:22:
```

```
Supported Caps      : bridge router  
Enabled Caps       : bridge router  
Chassis Id Subtype : 4 (macAddress)  
Chassis Id         : 0a:a5:ff:00:00:00  
PortId Subtype     : 7 (local)  
Port Id           : 35749888  
Port Description   : 10/100/Gig Ethernet SFP  
System Name       : Dut-B  
System Description : TiMOS-B-0.0.I927 both/i386 ALCATEL SAS 7210  
                  : Copyright (c) 2000-2010 Alcatel-Lucent.  
                  : All rights reserved. All use subject to applicable  
                  : license agreements.  
                  : Built on Wed Dec 1 22:23:12 IST 2010 by builder in  
                  : /builder/0.0/panos/main
```

```
Remote Peer Index 142 management addresses at time 06/10/2010 00:23:22:
```

```
No remote management addresses found
```

```
Port 1/1/3 Bridge nearest-customer Remote Peer Information
```

```
-----  
Remote Peer Index 143 at timestamp 06/10/2010 00:23:22:
```

```
Supported Caps      : bridge router  
Enabled Caps       : bridge router  
Chassis Id Subtype : 4 (macAddress)  
Chassis Id         : 0a:a7:ff:00:00:00  
PortId Subtype     : 7 (local)  
Port Id           : 35782656  
Port Description   : 10/100 Ethernet TX  
System Name       : Dut-G  
System Description : TiMOS-B-8.0.R5 both/i386 ALCATEL SR 7750 Copyright (c)  
                  : 2000-2010 Alcatel-Lucent.  
                  : All rights reserved. All use subject to applicable  
                  : license agreements.  
                  : Built on Tue Sep 28 18:24:07 PDT 2010 by builder in  
                  : /rel8.0/b1/R5/panos/main
```

```
Remote Peer Index 143 management addresses at time 06/10/2010 00:23:22:
```

## internal-loopback-ports

**Syntax** `internal-loopback-ports [detail]`

**Context** `show>system`

**Description** This command displays information about internal loopback ports and is applicable only to 7210 SAS-D.

**Parameters** *Detail* — keyword - includes application information

**Sample Output**

```
*A:7210SAS>config>port# show system internal-loopback-ports detail
=====
Internal Loopback Port Status
=====
Port          Loopback      Application    Service
Id            Type          Mac-Swap      Enabled
-----
1/1/2         Physical      Mac-Swap      Yes
1/1/11        Virtual       Mac-Swap      No

=====
Mac-swap Application Status
=====
Enabled       : Yes
Test Service Id : 1
Test Sap Id   : 1/1/2:40
Loopback Src Addr : 00:00:01:00:02:00
Loopback Dst Addr : 00:00:01:00:03:00
=====
*A:7210SAS>config>port#
```

**Mac-swap Application Status** — The following table describes Mac-swap Application Status associations output fields.

Label	Description
LoopBack Type	The Loopback type indicates whether the port is in Physical Front panel port or Internal Virtual port.
Application	Application mentions the application in use of the port.
Service enabled	The Service enabled displays, if services can be configured over this port.
Enabled	Displays the current status.
Test Service Id	The service ID that is used in the configuration of Mac-swap test.
Test Sap Id	The SAP ID that is used to configure the loopback SAP for the Mac-swap application.
Loopback Src Addr	The source MAC address that is used in the configuration of port loopback mac-swap test.
Loopback Dst Addr	The destination MAC address that is used in the configuration of port loopback mac-swap test.

---

## LAG Commands

### lag

**Syntax** **lag** [*lag-id*] [**detail**] [**statistics**]  
**lag** *lag-id* **associations**

**Context** show

**Description** This command displays Link Aggregation Group (LAG) information.  
 If no command line options are specified, a summary listing of all LAGs is displayed.

**Parameters** *lag-id* — Displays only information on the specified LAG ID.

**Default** Display information for all LAG IDs.

**detail** — Displays detailed LAG information.

**Default** Displays summary information.

**statistics** — Displays LAG statistics information.

**associations** — Displays a list of current router interfaces to which the LAG is assigned.

**Output** **LAG Output** — The following table describes LAG output fields.

Label	Description
LAG ID	The LAG ID that the port is assigned to.
Adm	Up — The LAG is administratively up. Down — The LAG is administratively down.
Opr	Up — The LAG is operationally up. Down — The LAG is operationally down.
Port-Threshold	The number of operational links for the LAG at or below which the configured action will be invoked.
Up-Link-Count	The number of ports that are physically present and have physical links present.
MC Act/Stdby	Member port is selected as active or standby link.

### Sample Output

```
A:ALA-48>config# show lag
=====
Lag Data
=====
```

```

Lag-id      Adm      Opr      Port-Threshold  Up-Link-Count  MC Act/Stdby
-----
1           up       down    0                0                N/A
2           up       up      0                1                active
3           up       down    0                0                standby
4           up       down    0                0                standby
10          up       down    0                0                N/A

```

```

Total Lag-ids: 5      Single Chassis: 2      MC Act: 1      MC Stdby: 2
=====

```

```

A:ALA-48>config# show lag
*A:stu-1>config>service>epipe# show lag 1 detail
=====

```

```

LAG Details
=====

```

```

Details
-----
Lag-id      : 1                Mode           : access
Adm         : up                Opr            : down
Reason Down : linkLossFwd
Encap Type  : null
Configured Address : 00:0a:ab:b1:c0:1c  Lag-IfIndex    : 1342177281
Hardware Address : 00:0a:ab:b1:c0:1c
Hold-time Down : 0.0 sec          Uplink         : No
LACP        : disabled

```

```

-----
Port-id      Adm      Act/Stdby Opr      Primary  Sub-group  Forced  Prio
-----
1/1/21      up       active   down    yes      1          -       32768
1/1/22      up       active   down    no       1          -       32768
=====

```

```

*A:stu-1>config>service>epipe#

```

```

*A:7210-SAS>show# lag 1

```

```

=====
Lag Data
=====

```

```

Lag-id      Adm      Opr      Port-Threshold  Up-Link-Count  MC Act/Stdby
-----
1           up       down    1                0                N/A

```

```

*A:7210-SAS>show#

```

**Detailed LAG Output** — The following table describes detailed LAG output fields.

Label	Description
LAG ID	The LAG or multi-link trunk (MLT) that the port is assigned to.
Adm	Up — The LAG is administratively up. Down — The LAG is administratively down.

Label	Description (Continued)
Port Threshold	If the number of available links is equal or below this number, the threshold action is executed.
Thres. Last Cleared	The last time that keepalive stats were cleared.
Dynamic Cost	The OSPF costing of a link aggregation group based on the available aggregated, operational bandwidth.
Configured Address	The base chassis Ethernet MAC address.
Hardware Address	The hardware address.
Hold-Time Down	The timer, in tenths of seconds, which controls the delay between detecting that a LAG is down and reporting it to the higher levels.
LACP	Enabled – LACP is enabled. Down – LACP is disabled.
LACP Transmit Intvl	LACP timeout signalled to peer.
Selection Criteria	Configured subgroup selection criteria.
Number of subgroups	Total subgroups in LAG.
System ID	System ID used by actor in LACP messages.
Admin Key	Configured LAG key.
Oper Key	Key used by actor in LACP messages.
System Priority	System priority used by actor in LACP messages.
Prtr System ID	System ID used by partner in LACP messages.
Prtr Oper Key	Key used by partner in LACP messages.
Prtr System Priority	System priority used by partner in LACP messages.
Mode	LAG in access or network mode.
Opr	Up – The LAG is operationally up. Down – The LAG is operationally down.
Port Threshold	Configured port threshold.
Thres. Exceeded Cnt	The number of times that the drop count was reached.

Label	Description (Continued)
Threshold Action	Action to take when the number of available links is equal or below the port threshold.
Encap Type	The encapsulation method used to distinguish customer traffic on a LAG.
Lag-IFIndex	A box-wide unique number assigned to this interface.
Port ID	The specific slot/MDA/port ID.
(LACP) Mode	LACP active or passive mode.
LACP xmit standby	LACP transmits on standby links enabled / disabled.
Slave-to-partner	Configured enabled/disabled.
Port-id	Displays the member port ID.
Adm	Displays the member port administrative state.
Active/stdby	Indicates that the member port is selected as the active or standby link.
Opr	Indicates that the member port operational state.
Primary	Indicates that the member port is the primary port of the LAG.
Sub-group	Displays the member subgroup where the member port belongs to.
Priority	Displays the member port priority.

```
*A:Dut-B# show lag 10 detail
```

```
=====
LAG Details
=====
```

```
Description : N/A
-----
```

```
Details
-----
```

```
Lag-id : 10 Mode : access
Adm : up Opr : up
Thres. Exceeded Cnt : 1 Port Threshold : 0
Thres. Last Cleared : 05/17/2009 19:33:00 Threshold Action : down
Dynamic Cost : false Encap Type : qinq
Configured Address : 00:03:fa:8d:45:d2 Lag-IfIndex : 1342177290
Hardware Address : 00:03:fa:8d:45:d2 Adapt Qos : distribute
Hold-time Down : 0.0 sec Port Type : standard
Per FP Ing Queuing : disabled
LACP : enabled Mode : active
LACP Transmit Intvl : fast LACP xmit stdby : enabled
Selection Criteria : highest-count Slave-to-partner : disabled
Number of sub-groups: 1 Forced : -
System Id : 00:03:fa:8d:44:88 System Priority : 32768
Admin Key : 32777 Oper Key : 40009
Prtr System Id : 00:03:fa:13:6f:a7 Prtr System Priority : 32768
```

## LAG Commands

```

Prtr Oper Key : 32777
MC Peer Address : 10.20.1.2 MC Peer Lag-id : 10
MC System Id : 00:02:80:01:00:0a MC System Priority : 100
MC Admin Key : 40009 MC Active/Standby : active
MC Lacp ID in use : true MC extended timeout : false
MC Selection Logic : peer decided
MC Config Mismatch : no mismatch
Source BMAC LSB : use-lacp-key Oper Src BMAC LSB : 9c:49
-----
Port-id Adm Act/Stdby Opr Primary Sub-group Forced Prio
-----
1/1/10 up active up yes 1 - 32768
-----
Port-id Role Exp Def Dist Col Syn Aggr Timeout Activity
-----
1/1/10 actor No No Yes Yes Yes Yes Yes Yes
1/1/10 partner No No Yes Yes Yes Yes Yes Yes
=====
*A:ALA-48>show# lag 1 detail
=====
LAG Details
=====
Description:
-----
Details
-----
Lag-id          : 1                Mode           : access
Adm             : up                Opr             : down
Thres. Exceeded Cnt : 0            Port Threshold : 3
Thres. Last Cleared : 02/21/2007 12:39:36 Threshold Action : dynamic cost
Dynamic Cost     : false            Encap Type     : null
Configured Address : 04:67:01:01:00:01 Lag-IfIndex    : 1342177281
Hardware Address  : 14:30:ff:00:01:41 Adapt Qos     : distribute
Hold-time Down   : 0.0 sec
LACP             : enabled           Mode           : active
LACP Transmit Intvl : fast                LACP xmit stdby : enabled
Selection Criteria : highest-count       Slave-to-partner : enabled
Number of sub-groups: 0            Forced         : -
System Id        : 14:30:ff:00:00:00 System Priority : 1
Admin Key        : 32768            Oper Key       : 32666
Prtr System Id   :                  Prtr System Priority : 0
Prtr Oper Key    : 0

MC Peer Address : 10.10.10.2        MC Peer Lag-id : 1
MC System Id    : 00:00:00:33:33:33 MC System Priority : 32888
MC Admin Key    : 32666             MC Active/Standby : active
MC Lacp ID in use : true            MC extended timeout : false
MC Selection Logic : peer timed out (no route to peer), selected local
                    subgroup
MC Config Mismatch : no mismatch
-----
Port-id      Adm   Act/Stdby Opr   Primary  Sub-group  Forced  Prio
-----
*A:ALA-48>show#
-----
*A:7210-SAS>show# lag 1 detail
=====

```

```

LAG Details
=====
Description          : N/A
-----
Details
-----
Lag-id              : 1                Mode                : access
Adm                 : up                Opr                 : down
Thres. Exceeded Cnt : 0                Port Threshold      : 1
Thres. Last Cleared : 05/31/2011 11:55:49 Threshold Action    : down
Encap Type          : null
Configured Address  : 00:25:ba:0a:33:cc Lag-IfIndex         : 1342177281
Hardware Address    : 00:25:ba:0a:33:cc
Hold-time Down     : 0.0 sec
LACP                : disabled
Uplink              : No
Split Horizon Group : (Not Specified)

-----
Port-id      Adm      Act/Stdby Opr      Primary  Sub-group  Forced  Prio
-----
*A:7210-SAS>show#

```

**LAG Statistics Output** — The following table describes detailed LAG statistics output fields.

Label	Description
LAG ID	The LAG or multi-link trunk (MLT) that the port is assigned to.
Port ID	The port ID configured or displayed in the <i>slot/mda/port</i> format.
Input Bytes	The number of incoming bytes for the LAG on a per-port basis.
Input Packets	The number of incoming packets for the LAG on a per-port basis.
Output Bytes	The number of outbound bytes for the LAG on a per-port basis.
Output Packets	The number of outbound packets for the LAG on a per-port basis.
Input/Output Errors	For packet-oriented interfaces, the number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol. For character-oriented or fixed-length interfaces, the number of inbound transmission units that contained errors preventing them from being deliverable to a higher-layer protocol. For packet-oriented interfaces, the number of outbound packets that could not be transmitted because of errors. For character-oriented or fixed-length interfaces, the number of outbound transmission units that could not be transmitted because of errors.
Totals	Displays the column totals for bytes, packets, and errors.

**Sample Output**

```
ALA-1# show lag statistics
=====
LAG Statistics
=====
Description:
Lag-id Port-id   Input   Input   Output   Output   Input   Output
          Bytes   Packets Bytes   Packets Errors   Errors
-----
1       1/1/3     0       1006    0        2494     0        0
          1/1/4     0        435    0         401     0        0
          1/1/5     0       9968    0       9833     0        0
-----
Totals           0       11409    0       12728    0        0
=====
ALA-1#
```

**LAG Associations Output** — The following table describes LAG associations output fields.

Label	Description
Service ID	The service associated with the LAG.
Name	The name of the IP interface.
Encap Val	The values of the port for the IP interface.

### Sample Output

```
A:ALA-1# show lag 5 associations
=====
Interface Table
=====
Router/ServiceId          Name          Encap Val
-----
Router: Base              LAG2West     0
-----
Interfaces
=====
A:ALA-1#
```

**LAG Details without MC-LAG Output** — The following example displays LAG output without MC LAG:

```
*A:pc5# show lag 2 detail
=====
LAG Details
=====
Description:
-----
Details
-----
Lag-id          : 2          Mode          : access
Adm             : up         Opr           : up
Thres. Exceeded Cnt : 4          Port Threshold : 0
Thres. Last Cleared : 04/11/2007 02:03:49 Threshold Action : down
Dynamic Cost    : false     Encap Type    : dot1q
Configured Address : 8e:8b:ff:00:01:42 Lag-IfIndex   :
1342177282
Hardware Address : 8e:8b:ff:00:01:42 Adapt Qos    :
distribute
Hold-time Down  : 0.0 sec
LACP           : enabled    Mode          : active
LACP Transmit Intvl : fast    LACP xmit stdby : enabled
Selection Criteria : highest-count Slave-to-partner : disabled
Number of sub-groups: 2      Forced       : -
System Id      : 8e:8b:ff:00:00:00 System Priority : 32768
Admin Key      : 32768      Oper Key      : 32768
Prtr System Id : 8e:89:ff:00:00:00 Prtr System Priority : 32768
Prtr Oper Key  : 32768
-----
Port-id      Adm   Act/Stdby Opr   Primary  Sub-group  Forced
Prio
```

## LAG Commands

```
-----  
1/1/1      up    active  up    yes    7      -      99  
1/1/2      up    standby down   8      -      100  
-----  
Port-id    Role      Exp    Def   Dist  Col   Syn  Aggr  Timeout  
Activity  
-----  
1/1/1      actor    No     No    Yes   Yes   Yes  Yes   Yes    Yes  
1/1/1      partner No     No    Yes   Yes   Yes  Yes   Yes    Yes  
1/1/2      actor    No     No    No    No    No   Yes   Yes    Yes  
1/1/2      partner No     No    No    No    Yes  Yes   Yes   Yes    Yes  
-----  
*A:pc5#
```

## Port Monitor Commands

### port

**Syntax** `port port-id [port-id...(up to 5 max)] [interval seconds] [repeat repeat] [absolute | rate]`

**Context** monitor

**Description** This command enables port traffic monitoring. The specified port(s) statistical information displays at the configured interval until the configured count is reached.

The first screen displays the current statistics related to the specified port(s). The subsequent statistical information listed for each interval is displayed as a delta to the previous display.

When the keyword **rate** is specified, the "rate per second" for each statistic is displayed instead of the delta.

Monitor commands are similar to **show** commands but only statistical information displays. Monitor commands display the selected statistics according to the configured number of times at the interval specified.

**Parameters** `port port-id` — Specify up to 5 port IDs.

**Syntax:** `port-id` slot/mda/port  
interval `seconds`

Configures the interval for each display in seconds.

**Default** 10 seconds

**Values** 3 — 60

`repeat repeat` — Configures how many times the command is repeated.

**Default** 10

**Values** 1 — 999

**absolute** — When the **absolute** keyword is specified, the raw statistics are displayed, without processing. No calculations are performed on the delta or rate statistics.

**rate** — When the **rate** keyword is specified, the rate-per-second for each statistic is displayed instead of the delta.

### Sample Output

```
A:ALA-12>monitor# port 1/4 interval 3 repeat 3 absolute
=====
Monitor statistics for Port 1/4
=====
                                     Input                Output
-----
At time t = 0 sec (Base Statistics)
-----
Octets                               0                    0
Packets                              39                   175
```

## Port Monitor Commands

```

Errors                                0                                0
-----
At time t = 3 sec (Mode: Absolute)
-----
Octets                                0                                0
Packets                               39                               175
Errors                                0                                0
-----
At time t = 6 sec (Mode: Absolute)
-----
Octets                                0                                0
Packets                               39                               175
Errors                                0                                0
-----
At time t = 9 sec (Mode: Absolute)
-----
Octets                                0                                0
Packets                               39                               175
Errors                                0                                0
=====
A:ALA-12>monitor#

A:ALA-12>monitor# port 1/4 interval 3 repeat 3 rate
=====
Monitor statistics for Port 1/4
=====
                                Input                                Output
-----
At time t = 0 sec (Base Statistics)
-----
Octets                                0                                0
Packets                               39                               175
Errors                                0                                0
-----
At time t = 3 sec (Mode: Rate)
-----
Octets                                0                                0
Packets                               0                                0
Errors                                0                                0
-----
At time t = 6 sec (Mode: Rate)
-----
Octets                                0                                0
Packets                               0                                0
Errors                                0                                0
-----
At time t = 9 sec (Mode: Rate)
-----
Octets                                0                                0
Packets                               0                                0
Errors                                0                                0
=====
A:ALA-12>monitor#

```

---

## Clear Commands

### lag

**Syntax** `lag lag-id statistics`

**Context** clear

**Description** This command clears statistics for the specified LAG ID.

**Parameters** *lag-id* — The LAG ID to clear statistics.  
**statistics** — Specifies to clear statistics for the specified LAG ID.

### port

**Syntax** `port port-id statistics`

**Context** clear

**Description** This command clears port statistics for the specified port(s).

**Parameters** *port-id* — The port identifier.

**Values**

**statistics** — Specifies that port statistics will be cleared.

*slot* — The slot number.

**Values** 1

*mda* — The MDA number.

**Default** All MDAs.

**Values** 1, 2

---

## Debug Commands

### lag

**Syntax**    **lag** [**lag-id** *lag-id* [**port** *port-id*]] [**all**]  
**lag** [**lag-id** *lag-id* [**port** *port-id*]] [**sm**] [**pkt**] [**cfg**] [**red**] [**iom-upd**] [**port-state**] [**timers**] [**sel-logic**]  
**no lag** [**lag-id** *lag-id*]

**Context**    debug

**Description**    This command enables debugging for LAG.

**Parameters**    *lag-id* — Specifies the link aggregation group ID.  
*port-id* — Specifies the physical port ID.  
**sm** — Specifies to display trace LACP state machine.  
**pkt** — Specifies to display trace LACP packets.  
**cfg** — Specifies to display trace LAG configuration.  
**red** — Specifies to display trace LAG high availability.  
**iom-upd** — Specifies to display trace LAG IOM updates.  
**port-state** — Specifies to display trace LAG port state transitions.  
**timers** — Specifies to display trace LAG timers.  
**sel-logic** — Specifies to display trace LACP selection logic.

# Standards and Protocol Support (7210 SAS D)

## Standards Compliance

IEEE 802.1ab-REV/D3 Station  
And Media Access Control  
Connectivity Discovery  
IEEE 802.1d Bridging  
IEEE 802.1p/Q VLAN Tagging  
IEEE 802.1w Rapid Spanning Tree  
Protocol  
IEEE 802.1x Port Based Network Access  
Control  
IEEE 802.1ad Provider Bridges  
IEEE 802.1ag Service Layer OAM  
IEEE 802.3ah Ethernet in the  
First Mile  
IEEE 802.3 10BaseT  
IEEE 802.3ad Link Aggregation  
IEEE 802.3ah Ethernet OAM  
IEEE 802.3u 100BaseTX  
IEEE 802.3z 1000BaseSX/LX  
IANA-IFType-MIB  
IEEE8023-LAG-MIB

## Protocol Support

### DIFFERENTIATED SERVICES

RFC 2474 Definition of the DS Field the  
IPv4 and IPv6 Headers (Rev)  
RFC 2597 Assured Forwarding PHB  
Group (rev3260)  
RFC 2598 An Expedited Forwarding  
PHB  
ITU-T X.721: Information technology-  
OSI-Structure of Management  
Information  
ITU-T X.734: Information technology-  
OSI-Systems Management: Event  
Report Management Function  
M.3100/3120 Equipment and Connection  
Models  
TMF 509/613 Network Connectivity  
Model  
RFC 1157 SNMPv1  
RFC 1215 A Convention for Defining  
Traps for use with the SNMP  
RFC 1907 SNMPv2-MIB  
RFC 2011 IP-MIB  
RFC 2012 TCP-MIB  
RFC 2013 UDP-MIB

RFC 2096 IP-FORWARD-MIB  
RFC 2138 RADIUS  
RFC 2571 SNMP-FRAMEWORKMIB  
RFC 2572 SNMP-MPD-MIB  
RFC 2573 SNMP-TARGET-&-  
NOTIFICATION-MIB  
RFC 2574 SNMP-USER-BASED-  
SMMIB  
RFC 2575 SNMP-VIEW-BASED-ACM-  
MIB  
RFC 2576 SNMP-COMMUNITY-MIB  
RFC 2665 EtherLike-MIB  
RFC 2819 RMON-MIB  
RFC 2863 IF-MIB  
RFC 2864 INVERTED-STACK-MIB  
RFC 3014 NOTIFICATION-LOGMIB  
RFC 3164 Syslog  
RFC 3273 HCRMON-MIB  
RFC 3411 An Architecture for  
Describing Simple Network  
Management Protocol (SNMP)  
Management Frameworks  
RFC 3412 Message Processing and  
Dispatching for the Simple Network  
Management Protocol (SNMP)  
RFC 3413 Simple Network Management  
Protocol (SNMP) Applications  
RFC 3414 User-based Security Model  
(USM) for version 3 of the Simple  
Network Management Protocol  
(SNMPv3)  
RFC 3418 SNMP MIB draft-ietf-disman-  
alarm-mib-04.txt  
RFC 3418 SNMP MIB

### TCP/IP

RFC 768 UDP  
RFC 1350 The TFTP Protocol (Rev.  
RFC 791 IP  
RFC 792 ICMP  
RFC 793 TCP  
RFC 826 ARP  
RFC 854 Telnet  
RFC 1519 CIDR  
RFC 1812 Requirements for IPv4  
Routers  
RFC 2347 TFTP option Extension  
RFC 2328 TFTP Blocksize Option

RFC 2349 TFTP Timeout Interval and  
Transfer Size option

### RADIUS

RFC 2865 Remote Authentication Dial In  
User Service  
RFC 2866 RADIUS Accounting

### SSH

draft-ietf-secsh-architecture.txt SSH  
Protocol Architecture  
draft-ietf-secsh-userauth.txt SSH  
Authentication Protocol  
draft-ietf-secsh-transport.txt SSH  
Transport Layer Protocol  
draft-ietf-secsh-connection.txt SSH  
Connection Protocol  
draft-ietf-secsh-newmodes.txt SSH  
Transport Layer Encryption Modes

### TACACS+

draft-grant-tacacs-02.txt

### IPv6

RFC 2460 Internet Protocol, Version 6  
(IPv6) Specification  
RFC 2461 Neighbor Discovery for IPv6  
RFC 2462 IPv6 Stateless Address Auto  
configuration  
RFC 2463 Internet Control Message  
Protocol (ICMPv6) for the Internet  
Protocol Version 6 Specification  
RFC 2464 Transmission of IPv6 Packets  
over Ethernet Networks  
RFC 3587 IPv6 Global Unicast Address  
Format  
RFC 4007 IPv6 Scoped Address  
Architecture  
RFC 4193 Unique Local IPv6 Unicast  
Addresses  
RFC 4291 IPv6 Addressing Architecture  
RFC 5095 Deprecation of Type 0 Routing  
Headers in IPv6

### Timing (Only on 7210 SAS-D ETR)

ITU-T G.781 Telecommunication  
Standardization Section of ITU,

## Standards and Protocols

Synchronization layer functions,  
issued 09/2008

ITU-T G.813 Telecommunication  
Standardization Section of ITU,  
Timing characteristics of SDH  
equipment slave clocks (SEC),  
issued 03/2003.

GR-1244-CORE Clocks for the  
Synchronized Network: Common  
Generic Criteria, Issue 3, May 2005

ITU-T G.8261 Telecommunication  
Standardization Section of ITU,  
Timing and synchronization aspects  
in packet networks, issued 04/2008.

ITU-T G.8262 Telecommunication  
Standardization Section of ITU,  
Timing characteristics of  
synchronous Ethernet equipment  
slave clock (EEC), issued 08/2007.

ITU-T G.8264 Telecommunication  
Standardization Section of ITU,  
Distribution of timing information

### NETWORK MANAGEMENT

ITU-T X.721: Information technology-  
OSI-Structure of Management  
Information

ITU-T X.734: Information technology-  
OSI-Systems Management: Event  
Report Management Function

M.3100/3120 Equipment and Connection  
Models

TMF 509/613 Network Connectivity  
Model

RFC 1157 SNMPv1

RFC 1215 A Convention for Defining  
Traps for use with the SNMP

RFC 1907 SNMPv2-MIB

RFC 2011 IP-MIB

RFC 2012 TCP-MIB

RFC 2013 UDP-MIB

RFC 2096 IP-FORWARD-MIB

RFC 2138 RADIUS

RFC 2571 SNMP-FRAMEWORKMIB

RFC 2572 SNMP-MPD-MIB

RFC 2573 SNMP-TARGET-&-  
NOTIFICATION-MIB

RFC 2574 SNMP-USER-BASED-  
SMMIB

RFC 2575 SNMP-VIEW-BASED-ACM-  
MIB

RFC 2576 SNMP-COMMUNITY-MIB

RFC 2665 EtherLike-MIB

RFC 2819 RMON-MIB

RFC 2863 IF-MIB

RFC 2864 INVERTED-STACK-MIB

RFC 3014 NOTIFICATION-LOGMIB

RFC 3164 Syslog

RFC 3273 HCRMON-MIB

RFC 3411 An Architecture for  
Describing Simple Network  
Management Protocol (SNMP)  
Management Frameworks

RFC 3412 - Message Processing and  
Dispatching for the Simple Network  
Management Protocol (SNMP)

RFC 3413 - Simple Network  
Management Protocol (SNMP)  
Applications

RFC 3414 - User-based Security Model  
(USM) for version 3 of the Simple  
Network Management Protocol  
(SNMPv3)

RFC 3418 - SNMP MIB  
draft-ietf-disman-alarm-mib-04.txt

### PROPRIETARY MIBs

ALCATEL-IGMP-SNOOPING-  
MIB.mib

TIMETRA-CAPABILITY-7210-SAS-D-  
V5v0.mib (Only for 7210 SAS-D)

TIMETRA-CHASSIS-MIB.mib

TIMETRA-CLEAR-MIB.mib

TIMETRA-DOT3-OAM-MIB.mib

TIMETRA-FILTER-MIB.mib

TIMETRA-GLOBAL-MIB.mib

TIMETRA-IEEE8021-CFM-MIB.mib

TIMETRA-LAG-MIB.mib

TIMETRA-LOG-MIB.mib

TIMETRA-MIRROR-MIB.mib

TIMETRA-NTP-MIB.mib

TIMETRA-OAM-TEST-MIB.mib

TIMETRA-PORT-MIB.mib

TIMETRA-QOS-MIB.mib

TIMETRA-SAS-FILTER-MIB.mib

TIMETRA-SAS-IEEE8021-CFM-  
MIB.mib

TIMETRA-SAS-GLOBAL-MIB.mib

TIMETRA-SAS-LOG-MIB.mib.mib

TIMETRA-SAS-MIRROR-MIB.mib

TIMETRA-SAS-PORT-MIB.mib

TIMETRA-SAS-QOS-MIB.mib

TIMETRA-SAS-SYSTEM-MIB.mib

TIMETRA-SCHEDULER-MIB.mib

TIMETRA-SECURITY-MIB.mib

TIMETRA-SERV-MIB.mib

TIMETRA-SYSTEM-MIB.mib

TIMETRA-TC-MIB.mib

TIMETRA-VRTR-MIB.mib

# Standards and Protocol Support (7210 SAS E)

## Standards Compliance

IEEE 802.1ab-REV/D3 Station And Media Access Control Connectivity Discovery  
IEEE 802.1d Bridging  
IEEE 802.1p/Q VLAN Tagging  
IEEE 802.1w Rapid Spanning Tree Protocol  
IEEE 802.1x Port Based Network Access Control  
IEEE 802.1ad Provider Bridges  
IEEE 802.1ag Service Layer OAM  
IEEE 802.3ah Ethernet in the First Mile  
IEEE 802.3 10BaseT  
IEEE 802.3ad Link Aggregation  
IEEE 802.3ah Ethernet OAM  
IEEE 802.3u 100BaseTX  
IEEE 802.3z 1000BaseSX/LX  
ITU-T Y.1731 OAM functions and mechanisms for Ethernet based networks  
IANA-IFType-MIB  
IEEE8023-LAG-MIB  
ITU-T G.8032 Ethernet Ring Protection Switching (version 1)

## Protocol Support

### DIFFERENTIATED SERVICES

RFC 2474 Definition of the DS Field the IPv4 and IPv6 Headers (Rev)  
RFC 2597 Assured Forwarding PHB Group (rev3260)  
RFC 2598 An Expedited Forwarding PHB  
ITU-T X.721: Information technology-OSI-Structure of Management Information  
ITU-T X.734: Information technology-OSI-Systems Management: Event Report Management Function  
M.3100/3120 Equipment and Connection Models  
TMF 509/613 Network Connectivity Model  
RFC 1157 SNMPv1  
RFC 1215 A Convention for Defining Traps for use with the SNMP

RFC 1907 SNMPv2-MIB  
RFC 2011 IP-MIB  
RFC 2012 TCP-MIB  
RFC 2013 UDP-MIB  
RFC 2096 IP-FORWARD-MIB  
RFC 2138 RADIUS  
RFC 2571 SNMP-FRAMEWORKMIB  
RFC 2572 SNMP-MPD-MIB  
RFC 2573 SNMP-TARGET-&-NOTIFICATION-MIB  
RFC 2574 SNMP-USER-BASED-SMMIB  
RFC 2575 SNMP-VIEW-BASED-ACM-MIB  
RFC 2576 SNMP-COMMUNITY-MIB  
RFC 2665 EtherLike-MIB  
RFC 2819 RMON-MIB  
RFC 2863 IF-MIB  
RFC 2864 INVERTED-STACK-MIB  
RFC 3014 NOTIFICATION-LOGMIB  
RFC 3164 Syslog  
RFC 3273 HCRMON-MIB  
RFC 3411 An Architecture for Describing Simple Network Management Protocol (SNMP) Management Frameworks  
RFC 3412 Message Processing and Dispatching for the Simple Network Management Protocol (SNMP)  
RFC 3413 Simple Network Management Protocol (SNMP) Applications  
RFC 3414 User-based Security Model (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)  
RFC 3418 SNMP MIB draft-ietf-disman-alarm-mib-04.txt  
RFC 3418 SNMP MIB

### IPv6

RFC 2460 Internet Protocol, Version 6 (IPv6) Specification  
RFC 2461 Neighbor Discovery for IPv6  
RFC 2462 IPv6 Stateless Address Auto configuration  
RFC 2463 Internet Control Message Protocol (ICMPv6) for the Internet Protocol Version 6 Specification

RFC 2464 Transmission of IPv6 Packets over Ethernet Networks  
RFC 3587 IPv6 Global Unicast Address Format  
RFC 4007 IPv6 Scoped Address Architecture  
RFC 4193 Unique Local IPv6 Unicast Addresses  
RFC 4291 IPv6 Addressing Architecture  
RFC 5095 Deprecation of Type 0 Routing Headers in IPv6

### MULTICAST

RFC 1112 Host Extensions for IP Multicasting (Snooping)  
RFC 2236 Internet Group Management Protocol, (Snooping)  
RFC 3376 Internet Group Management Protocol, Version 3 (Snooping)

### TCP/IP

RFC 768 UDP  
RFC 1350 The TFTP Protocol (Rev.  
RFC 791 IP  
RFC 792 ICMP  
RFC 793 TCP  
RFC 826 ARP  
RFC 854 Telnet  
RFC 1519 CIDR  
RFC 1812 Requirements for IPv4 Routers  
RFC 2347 TFTP option Extension  
RFC 2328 TFTP Blocksize Option  
RFC 2349 TFTP Timeout Interval and Transfer Size option

### RADIUS

RFC 2865 Remote Authentication Dial In User Service  
RFC 2866 RADIUS Accounting

### SSH

draft-ietf-secsh-architecture.txt SSH Protocol Architecture  
draft-ietf-secsh-userauth.txt SSH Authentication Protocol  
draft-ietf-secsh-transport.txt SSH Transport Layer Protocol

## Standards and Protocols

draft-ietf-secsh-connection.txt SSH  
Connection Protocol  
draft-ietf-secsh- newmodes.txt SSH  
Transport Layer Encryption Modes

### TACACS+

draft-grant-tacacs-02.txt

### NETWORK MANAGEMENT

ITU-T X.721: Information technology-  
OSI-Structure of Management  
Information  
ITU-T X.734: Information technology-  
OSI-Systems Management: Event  
Report Management Function  
M.3100/3120 Equipment and Connection  
Models  
TMF 509/613 Network Connectivity  
Model  
RFC 1157 SNMPv1  
RFC 1215 A Convention for Defining  
Traps for use with the SNMP  
RFC 1907 SNMPv2-MIB  
RFC 2011 IP-MIB  
RFC 2012 TCP-MIB  
RFC 2013 UDP-MIB  
RFC 2096 IP-FORWARD-MIB  
RFC 2138 RADIUS  
RFC 2571 SNMP-FRAMEWORKMIB  
RFC 2572 SNMP-MPD-MIB  
RFC 2573 SNMP-TARGET-&-  
NOTIFICATION-MIB  
RFC 2574 SNMP-USER-BASED-  
SMMIB  
RFC 2575 SNMP-VIEW-BASEDACM-  
MIB  
RFC 2576 SNMP-COMMUNITY-MIB  
RFC 2665 EtherLike-MIB  
RFC 2819 RMON-MIB  
RFC 2863 IF-MIB  
RFC 2864 INVERTED-STACK-MIB  
RFC 3014 NOTIFICATION-LOGMIB  
RFC 3164 Syslog  
RFC 3273 HCRMON-MIB  
RFC 3411 An Architecture for  
Describing Simple Network  
Management Protocol (SNMP)  
Management Frameworks  
RFC 3412 - Message Processing and  
Dispatching for the Simple Network  
Management Protocol (SNMP)

RFC 3413 - Simple Network  
Management Protocol (SNMP)  
Applications  
RFC 3414 - User-based Security Model  
(USM) for version 3 of the Simple  
Network Management Protocol  
(SNMPv3)  
RFC 3418 - SNMP MIB  
draft-ietf-disman-alarm-mib-04.txt

### PROPRIETARY MIBs

ALCATEL-IGMP-SNOOPING-  
MIB.mib  
TIMETRA-CAPABILITY-7210-SAS-E-  
V5v0.mib (Only for 7210 SAS-E)  
TIMETRA-CHASSIS-MIB.mib  
TIMETRA-CLEAR-MIB.mib  
TIMETRA-DOT3-OAM-MIB.mib  
TIMETRA-FILTER-MIB.mib  
TIMETRA-GLOBAL-MIB.mib  
TIMETRA-IEEE8021-CFM-MIB.mib  
TIMETRA-LAG-MIB.mib  
TIMETRA-LOG-MIB.mib  
TIMETRA-MIRROR-MIB.mib  
TIMETRA-NTP-MIB.mib  
TIMETRA-OAM-TEST-MIB.mib  
TIMETRA-PORT-MIB.mib  
TIMETRA-QOS-MIB.mib  
TIMETRA-SAS-ALARM-INPUT-  
MIB.mib [Only for 7210 SAS-E]  
TIMETRA-SAS-FILTER-MIB.mib  
TIMETRA-SAS-IEEE8021-CFM-  
MIB.mib  
TIMETRA-SAS-GLOBAL-MIB.mib  
TIMETRA-SAS-LOG-MIB.mib.mib  
TIMETRA-SAS-MIRROR-MIB.mib  
TIMETRA-SAS-PORT-MIB.mib  
TIMETRA-SAS-QOS-MIB.mib  
TIMETRA-SAS-SYSTEM-MIB.mib  
TIMETRA-SCHEDULER-MIB.mib  
TIMETRA-SECURITY-MIB.mib  
TIMETRA-SERV-MIB.mib  
TIMETRA-SYSTEM-MIB.mib  
TIMETRA-TC-MIB.mib  
TIMETRA-VRTR-MIB.mib

# INDEX

## NUMERICS

- [802.1x](#) 37
- [802.3ah OAM](#) 41

## A

- [access uplink](#) 21

## C

### Card, MDA, Port

- [overview](#) 16
  - [chassis slots and cards](#) 16
  - [MTU configuration guidelines](#) 44
  - [preprovisioning](#)
    - [chassis slots and cards](#) 16

### configuring

- [basic](#) 52
- [LAG](#) 58
- [management tasks](#) 59
- [port](#)

- [Ethernet](#) 55
  - [access port](#) 55
  - [network port](#) 55

### command reference

- [card commands](#) 64
- [MDA commands](#) 64
- [port commands](#) 65

- [ports](#) 54

## D

- [DDM](#) 17

## H

- [hashing](#) 31

## L

- [LAG](#) 29

### overview

- [guidelines](#) 30
- [port link damping](#) 36

### configuring

- [command reference](#) 69

### hashing

- [LAG features](#) 22

## M

- [multi-chassis LAG](#) 36

## P

- [port features](#) 22

- [port types](#) 21

- [preprovisioning guidelines](#) 50

