
Triple Play DHCP Configuration Commands

Global Commands

shutdown

Syntax	[no] shutdown
Context	<pre>config>service>ies>if>dhcp config>service>vpls>sap>dhcp config>service>vpls>sap>dhcp>option>vendor config>service>vprn>if>dhcp config>service>vprn>if>dhcp>proxy-server config>subscr-mgmt>loc-user-db config>subscr-mgmt>loc-user-db>dhcp>host config>subscr-mgmt>loc-user-db>dhcp>host>options config>subscr-mgmt>loc-user-db>ppp>host config>router>dhcp6>server>failover config>router>dhcp>server>failover</pre>
Description	<p>This command administratively disables an entity. When disabled, an entity does not change, reset, or remove any configuration settings or statistics.</p> <p>The operational state of the entity is disabled as well as the operational state of any entities contained within. Many objects must be shut down before they may be deleted.</p> <p>The no form of this command places the entity into an administratively enabled state.</p>

description

Syntax	description <i>description-string</i> no description
Context	<pre>config>service>vpls>sap>dhcp config>service>ies>if>dhcp config>service>ies>if>ipv6>dhcp6-relay config>service>vprn>if>dhcp config>router>dhcp>server config>router>dhcp>server>pool config>subscr-mgmt>loc-user-db</pre>
Description	<p>This command creates a text description stored in the configuration file for a configuration context.</p> <p>The description command associates a text string with a configuration context to help identify the content in the configuration file.</p> <p>The no form of this command removes the string from the configuration.</p>
Default	No description associated with the configuration context.

Triple Play DHCP Configuration Commands

Parameters *description-string* — The description character string. Allowed values are any string up to 80 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

Router DHCP Configuration Commands

local-dhcp-server

Syntax	local-dhcp-server <i>server-name</i> [create] no local-dhcp-server <i>server-name</i>
Context	config>router>dhcp config>service>vprn>dhcp
Description	This command instantiates a local DHCP server. A local DHCP server can serve multiple interfaces but is limited to the routing context it was which it was created.
Default	none
Parameters	<i>server-name</i> — Specifies the name of local DHCP server.

delegated-prefix-length

Syntax	delegated-prefix-length <i>bits</i> delegated-prefix-length <i>variable</i> no delegated-prefix-length
Context	configure>router>local-dhcp-server>pool
Description	This command configures the subscriber-interface level setting for delegated prefix length. The delegated prefix length for a subscriber- interface can be either set to a fixed value that is explicitly configured under the subscriber-interface CLI hierarchy or a variable value that can be obtained from various sources. This command can be changed only when no IPv6 prefixes are configured under the subscriber-interface.
Default	no delegated-prefix-length This means that the delegated prefix length is 64.
Parameters	<i>bits</i> — The delegated prefix length in bits. This value will be applicable to the entire subscriber-interface. In case that the delegated prefix length is also supplied via other means (LUDB, RADIUS or DHCP Server), such supplied value must match the value configured under the subscriber-interface. Otherwise the prefix instantiation in 7x50 will fail. Values 48 — 64 <i>variable</i> — The delegated prefix value can be of any length between 48..64. The value itself can vary between the prefixes and it will be provided at the time of prefix instantiation. The order of priority for the source of the delegated prefix length is: <ul style="list-style-type: none"> • LUDB • RADIUS • DHCPv6 server

failover

Syntax	failover
Context	config>router>dhcp>server config>router>dhcp6>server
Description	This command enables the context to configure failover parameters.

maximum-client-lead-time

Syntax	maximum-client-lead-time [hrs <i>hours</i>] [min <i>minutes</i>] [sec <i>seconds</i>] no maximum-client-lead-time
Context	config>router>dhcp>server>failover config>router>dhcp6>server>failover
Context	<p>Maximum-client-lead-time (MCLT) is the maximum time that a DHCP server can extend client lease time beyond the lease time currently known by the DHCP partner node. In dual-homed environment, the initial lease time for all DHCP clients is strictly restricted to MCLT. Consecutive DHCP renewals are allowed to extend the lease time beyond the MCLT.</p> <p>The MCLT is a safeguard against IP address/prefix duplication in cases of a lease synchronization failure.</p> <p>Consider a case whereby the primary DHCP server assign a new lease to the client but it crashes before it sends a sync update to the partner (secondary DHCP server). Because of the primary DHCP server failure, the secondary server (whose partner-down-delay is set to 0) is not aware of the IP address/prefix that has been allocated on the primary server. This condition creates the possibility in which the secondary DHCP server allocates the same address/prefix to another client. This would cause IP address/prefix duplication. MCLT is put in place to prevent this scenario.</p> <p>Lease synchronization failure can be caused either by a node failure, or a failure of the link over which the DHCP leases are synchronized (Multi-Chassis Synchronization (MCS) link). Synchronization failure detection can take up to three seconds. Once the synchronization failure is detected, the minimum time required for a DHCP server to start delegating new addresses/prefixes from the prefix designated as remote is the sum of the maximum-client-lead-time and the partner-down-delay.</p> <p>During the failed state (DHCP peer is unreachable), the DHCP lease time for the new clients will be restricted to MCLT while for the existing clients the lease time will over time (by consecutive DHCP renewals) gradually be reduced to the MCLT.</p>
Default	10 minutes
Parameters	<p>hrs <i>hours</i> — Specifies the maximum amount of time, in hours, that one server can extend a lease for a client's binding beyond the time known by the partner server.</p> <p>Values 1 — 23</p> <p>min <i>minutes</i> — Specifies the maximum amount of time, in minutes, that one server can extend a lease for a client's binding beyond the time known by the partner.</p> <p>Values 1 — 59</p>

sec *seconds* — Specifies the maximum amount of time, in seconds, that one server can extend a lease for a client's binding beyond the time known by the partner.

Values 1 — 59

partner-down-delay

Syntax	partner-down-delay [<i>hrs hours</i>] [<i>min minutes</i>] [<i>sec seconds</i>] no partner-down-delay
Context	config>router>dhcp>server>failover config>router>dhcp6>server>failover
Description	Since the DHCP lease synchronization failure can be caused by the failure of the Multi-Chassis Synchronization (MCS) link (and not necessary the entire node), there is a possibility that both DHCP servers are operational during the failure. The purpose of the partner-down-delay is to allow the operator enough time to remedy the failed situation and to avoid duplication of IP addresses/prefixes during the failure. During the partner-down-delay time, the prefix designated as remote will be eligible only for renewals of the existing DHCP leases that have been synchronized by the peering node. Only after the sum of the partner-down-delay and the maximum-client-lead-time will the prefix designated as remote be eligible for assignment of the new DHCP leases.
Default	23 hours, 59minutes and 59 seconds
Parameters	hrs <i>hours</i> — Specifies the partner-down delay time in hours. Values 1 — 23 min <i>minutes</i> — Specifies the partner-down delay time in minutes. Values 1 — 59 sec <i>seconds</i> — Specifies the partner-down delay time in seconds. Values 1 — 59

peer

Syntax	peer <i>ip-address tag sync-tag-name</i> no peer <i>ip-address</i>
Context	config>router>dhcp6>server>failover config>router>dhcp>server>failover
Description	DHCP leases are synchronized per DHCP server. The pair of synchronizing servers (peers) is identified by a tag. The synchronization information is carried over the Multi-Chassis Synchronization (MCS) link between the two peers. MCS link is a logical link (IP or MPLS). MCS runs over TCP, port 45067 and it is using either data traffic or keepalives to detect failure on the communication link between the two nodes. In the absence of any MCS data traffic for more than 0.5sec, MCS will send its own keepalive to the peer. If a reply is NOT received within 3sec, MCS will declare its operation state as DOWN and the DB Sync state as out-of-sync. MCS will consequently notify its clients (DHCP Server being one of them) of this. It can take up to 3 seconds before the DHCP client realizes that the inter-chassis communication link has failed.

Triple Play DHCP Configuration Commands

Note that the inter-chassis communication link failure does not necessarily assume the same failed fate for the access links.

- Parameters** *ip-address* — Specifies the IPv4 address of the peer.
- sync-tag** *sync-tag* — Specifies a synchronization tag to be used while synchronizing with the multi-chassis peer.

startup-wait-time

- Syntax** **[no] startup-wait-time [min *minutes*] [sec *seconds*]**
- Context** config>router>dhcp6>server>failover
config>router>dhcp>server>failover
- Description** This command enables startup-wait-time during which each peer waits after the initialization process before assuming the active role for the prefix designated as local. This is to avoid transient issues during the initialization process.
- Default** 2 minutes
- Parameters** **min** *minutes* — Specifies the time in minutes that one server attempts to contact the partner server. During this time, the server is unresponsive to DHCP client requests.
- Values** 1 — 10
- sec** *seconds* — Specifies the time in seconds that one server attempts to contact the partner server. During this time, the server is unresponsive to DHCP client requests.
- Values** 1 — 59

force-renews

- Syntax** **[no] force-renews**
- Context** config>router>dhcp>server
- Description** This command enables the sending of sending forcerenew messages.
The **no** form of the command disables the sending of forcerenew messages.
- Default** no force-renews

ignore-rapid-commit

- Syntax** **[no] ignore-rapid-commit**
- Context** config>router>dhcp6>server
- Description** This command enables the Rapid Commit Option.
The **no** form of the command disables the Rapid Commit Option.

interface-id-mapping

Syntax	[no] interface-id-mapping
Context	config>router>dhcp6>server
Description	If enabled, this command enables the behavior where unique /64 prefix is allocated per interface-id, and all clients having the same interface-id get an address allocated out of this /64 prefix. This is relevant for bridged clients behind the same local-loop (and same SAP), where sharing the same prefix allows communication between bridged clients behind the same local-loop to stay local. For SLAAC based assignment, downstream neighbor-discovery is automatically enabled to resolve the assigned address.
Default	no interface-id-mapping

lease-hold-time

Syntax	lease-hold-time [days <i>days</i>] [hrs <i>hours</i>] [min <i>minutes</i>] [sec <i>seconds</i>] no lease-hold-time								
Context	config>router>dhcp6>server								
Description	This command configures the time to remember this lease. This lease-hold-time is for unsolicited release conditions such as lease timeout. This lease-hold-time is not applied when the sever receives normal solicited client release messages. The no form of the command reverts to the default.								
Default	sec 0								
Parameters	[days <i>days</i>][hrs <i>hours</i>] [min <i>minutes</i>] [sec <i>seconds</i>] — Specifies the lease hold time.								
Values	<table> <tr> <td>days:</td> <td>[0..3650]</td> </tr> <tr> <td>hours:</td> <td>[0..23]</td> </tr> <tr> <td>minutes:</td> <td>[0..59]</td> </tr> <tr> <td>seconds:</td> <td>[0..59]</td> </tr> </table>	days:	[0..3650]	hours:	[0..23]	minutes:	[0..59]	seconds:	[0..59]
days:	[0..3650]								
hours:	[0..23]								
minutes:	[0..59]								
seconds:	[0..59]								

pool

Syntax	pool <i>pool-name</i> [create] no pool <i>pool-name</i>
Context	config>router>dhcp>server
Description	This command configures a DHCP address pool on the router.
Default	none
Parameters	<i>pool name</i> — Specifies the name of this IP address pool. Allowed values are any string up to 32 characters long composed of printable, 7-bit ASCII characters.

max-lease-time

Syntax	max-lease-time [<i>days days</i>] [<i>hrs hours</i>] [<i>min minutes</i>] [<i>sec seconds</i>] no max-lease-time								
Context	config>router>dhcp>server>pool								
Description	This command configures the maximum lease time. The no form of the command returns the value to the default.								
Default	10 days								
Parameters	<i>time</i> — Specifies the maximum lease time.								
Values	<table> <tr> <td>days :</td> <td>0 — 3650</td> </tr> <tr> <td>hours</td> <td>0 — 23</td> </tr> <tr> <td>minutes:</td> <td>0 — 59</td> </tr> <tr> <td>seconds</td> <td>0 — 59</td> </tr> </table>	days :	0 — 3650	hours	0 — 23	minutes:	0 — 59	seconds	0 — 59
days :	0 — 3650								
hours	0 — 23								
minutes:	0 — 59								
seconds	0 — 59								

min-lease-time

Syntax	min-lease-time [<i>days days</i>] [<i>hrs hours</i>] [<i>min minutes</i>] [<i>sec seconds</i>] no min-lease-time								
Context	config>router>dhcp>server>pool								
Description	This command configures the minimum lease time. The no form of the command returns the value to the default.								
Default	10 minutes								
Parameters	<i>time</i> — Specifies the minimum lease time.								
Values	<table> <tr> <td>days :</td> <td>0 — 3650</td> </tr> <tr> <td>hours</td> <td>0 — 23</td> </tr> <tr> <td>minutes:</td> <td>0 — 59</td> </tr> <tr> <td>seconds</td> <td>0 — 59</td> </tr> </table>	days :	0 — 3650	hours	0 — 23	minutes:	0 — 59	seconds	0 — 59
days :	0 — 3650								
hours	0 — 23								
minutes:	0 — 59								
seconds	0 — 59								

minimum-free

Syntax	minimum-free <i>minimum-free</i> [percent] [event-when-depleted] no minimum-free
Context	config>router>dhcp>server>pool
Description	This command specifies the desired minimum number of free addresses in this pool. The no form of the command reverts to the default.
Default	1
Parameters	<i>minimum-free</i> — Specifies the minimum number of free addresses. 0 — 255

percent — Specifies that the value indicates a percentage.

event-when-depleted — This parameter enables a system-generate event when all available addresses in the pool/subnet of local DHCP server are depleted.

offer-time

Syntax	offer-time [min <i>minutes</i>] [sec <i>seconds</i>] no offer-time
Context	config>router>dhcp>server>pool
Description	This command configures the offer time. The no form of the command returns the value to the default.
Default	1 minute
Parameters	<i>time</i> — Specifies the offer time.
	Values minutes: 0 — 10 seconds 0 — 59

msap-defaults

Syntax	msap-default
Context	config>sub-mgmt>lu-db>dhcp>hos config>sub-mgmt>lu-db>ppp>host
Description	This command configures MSAP authentication defaults.

group-interface

Syntax	group-interface <i>ip-int-name</i> [prefix { <i>port-id</i> }] group-interface <i>ip-int-name</i> [suffix { <i>port-id</i> }] no group-interface
Context	config>sub-mgmt>lu-db>dhcp>hos config>sub-mgmt>lu-db>ppp>host
Description	This command configures the group interface.
Parameters	<i>ip-int-name</i> — Specifies the IP interface name.
	Values 32 chars max (must start with a letter)
Parameters	prefix { <i>port-id</i> } — Specifies the port ID as the prefix to the specified ip-int-name. suffix { <i>port-id</i> } — Specifies the port ID as the suffix to the specified ip-int-name.

Triple Play DHCP Configuration Commands

service

Syntax	service <i>service-id</i> no service
Context	config>sub-mgmt>lu-db>dhcp>hos config>sub-mgmt>lu-db>ppp>host
Description	This command sets retail-service for a given subscriber host.
Parameters	<i>service-id</i> — Specifies the service ID as an interger. Values 1-2147483648

policy

Syntax	policy <i>msap-policy-name</i> no policy
Context	config>sub-mgmt>lu-db>dhcp>hos config>sub-mgmt>lu-db>ppp>host
Description	This command configures the MSAP policy.
Parameters	<i>msap-policy-name</i> — Specifies the policy name.

retail-service

Syntax	[no] retail-service <i>service-id</i>
Context	config>sub-mgmt>lu-db>dhcp>hos config>sub-mgmt>lu-db>ppp>host
Description	This command sets default service for all subscribers created based on trigger packets received on the given capture SAP in case the corresponding VSA is not included in the RADIUS authentication response. This command is applicable to capture SAP only.
Default	no retail-service

options

Syntax	options
Context	config>router>dhcp>local-dhcp-serve>pool config>router>dhcp>local-dhcp-serve>pool>subnet config>subscr-mgmt>loc-user-db>dhcp>host config>subscr-mgmt>loc-user-db>ppp>host
Description	This command enables the context to configure pool options. The options defined here can be overruled by defining the same option in the local user database.

Default none

custom-option

Syntax **custom-option** *option-number* **address** [*ip-address...*(up to 4 max)]
custom-option *option-number* **hex** *hex-string*
custom-option *option-number* **string** *ascii-string*
no custom-option *option-number*

Context config>router>dhcp>local-dhcp-serve>pool>options
config>router>dhcp>local-dhcp-serve>pool>subnet>options
config>subscr-mgmt>loc-user-db>dhcp>host>options
config>subscr-mgmt>loc-user-db>ppp>host>options

Description This command configures specific DHCP options. The options defined here can overrule options in the local user database.

The **no** form of the removes the option from the configuration.

Default none

Parameters *option-number* — specifies the option number that the DHCP server uses to send the identification strings to the DHCP client.

Values 1 — 254

address *ip-address* — Specifies the IP address of this host.

hex *hex-string* — Specifies the hex value of this option.

Values 0x0..0xFFFFFFFF...(maximum 254 hex nibbles)

string *ascii-string* — Specifies the value of this option.

Values Up to 127 characters maximum.

dns-server

Syntax **dns-server** *address* [*ip-address...*(upto 4 max)]
no dns-server

Context config>router>dhcp>server>pool>options
config>subscr-mgmt>loc-user-db>dhcp>host>options
config>subscr-mgmt>loc-user-db>ppp>host>options

Description This command configures the IP address of the DNS server.

Default none

Parameters *ipv6-address* — The IPv4 address of the DNS server. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets).

Triple Play DHCP Configuration Commands

dns-server

Syntax	dns-server <i>ipv6-address</i> [<i>ipv6-address...</i> (up to 4 max)] no dns-server
Context	config>subscr-mgmt>loc-user-db>ppp>host>options6 config>subscr-mgmt>loc-user-db>dhcp>host>options6
Description	Configure IPv6 DNS server addresses that can be used for name resolution
Default	no dns-server
Parameters	<i>ipv6-address</i> — - IPv6 address of the a DNS server.

domain-name

Syntax	domain-name <i>domain-name</i> no domain-name
Context	config>router>dhcp>server>pool>options config>subscr-mgmt>loc-user-db>dhcp>host>options
Description	This command configures the default domain for a DHCP client that the router uses to complete unqualified hostnames (without a dotted-decimal domain name). The no form of the command removes the name from the configuration.
Default	none
Parameters	<i>domain-name</i> — Specifies the domain name for the client. Values Up to 127 characters

lease-rebind-time

Syntax	lease-rebind-time [days <i>days</i>] [hrs <i>hours</i>] [min <i>minutes</i>] [sec <i>seconds</i>] no lease-rebind-time
Context	config>router>dhcp>server>pool>subnet>options config>subscr-mgmt>loc-user-db>dhcp>host>options
Description	This command configures the time the client transitions to a rebinding state. The no form of the command removes the time from the configuration.
Default	none
Parameters	<i>time</i> — Specifies the lease rebind time.
Values	days: 0 — 3650 hours: 0 — 23 minutes: 0 — 59 seconds: 0 — 59

lease-renew-time

Syntax	lease-renew-time [days <i>days</i>] [hrs <i>hours</i>] [min <i>minutes</i>] [sec <i>seconds</i>] no lease-renew-time								
Context	config>router>dhcp>server>pool>options config>subscr-mgmt>loc-user-db>dhcp>host>options								
Description	This command configures the time the client transitions to a renew state. The no form of the command removes the time from the configuration.								
Default	none								
Parameters	<i>time</i> — Specifies the lease renew time.								
Values	<table> <tr> <td>days:</td> <td>0 — 3650</td> </tr> <tr> <td>hours:</td> <td>0 — 23</td> </tr> <tr> <td>minutes:</td> <td>0 — 59</td> </tr> <tr> <td>seconds</td> <td>0 — 59</td> </tr> </table>	days:	0 — 3650	hours:	0 — 23	minutes:	0 — 59	seconds	0 — 59
days:	0 — 3650								
hours:	0 — 23								
minutes:	0 — 59								
seconds	0 — 59								

lease-time

Syntax	lease-time [days <i>days</i>] [hrs <i>hours</i>] [min <i>minutes</i>] [sec <i>seconds</i>] no lease-time								
Context	config>router>dhcp>server>pool>options config>subscr-mgmt>loc-user-db>dhcp>host>options								
Description	This command configures the amount of time that the DHCP server grants to the DHCP client permission to use a particular IP address. The no form of the command removes the lease time parameters from the configuration.								
Default	none								
Parameters	<i>time</i> — Specifies the lease time.								
Values	<table> <tr> <td>days :</td> <td>0 — 3650</td> </tr> <tr> <td>hours</td> <td>0 — 23</td> </tr> <tr> <td>minutes:</td> <td>0 — 59</td> </tr> <tr> <td>seconds</td> <td>0 — 59</td> </tr> </table>	days :	0 — 3650	hours	0 — 23	minutes:	0 — 59	seconds	0 — 59
days :	0 — 3650								
hours	0 — 23								
minutes:	0 — 59								
seconds	0 — 59								

netbios-name-server

Syntax	netbios-name-server ip-address [<i>ip-address</i> ...(up to 4 max)] no netbios-name-server
Context	config>router>dhcp>server>pool>options config>subscr-mgmt>loc-user-db>dhcp>host>options config>subscr-mgmt>loc-user-db>ppp>host>options

Triple Play DHCP Configuration Commands

Description	This command configures up to four Network Basic Input/Output System (NetBIOS) name server IP addresses.
Default	none
Parameters	<i>ip-address</i> — The IP address of the NetBIOS name server. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets).

netbios-node-type

Syntax	netbios-node-type <i>netbios-node-type</i> no netbios-node-type
Context	config>router>dhcp>server>pool>options config>subscr-mgmt>loc-user-db>dhcp>host>options
Description	This command configures the Network Basic Input/Output System (NetBIOS) node type.
Default	none
Parameters	<i>netbios-node-type</i> — Specifies the netbios node type. Values B — Broadcast node uses broadcasting to query nodes on the network for the owner of a NetBIOS name. P — Peer-to-peer node uses directed calls to communicate with a known NetBIOS name server for the IP address of a NetBIOS machine name. M — Mixed node uses broadcasted queries to find a node, and if that fails, queries a known P-node name server for the address. H — Hybrid node is the opposite of the M-node action so that a directed query is executed first, and if that fails, a broadcast is attempted.

prefix

Syntax	prefix <i>ipv6-addr/prefix-len</i> [failover { local remote }] [pd] [wan-host] [create] no prefix <i>ipv6-addr/prefix-len</i>
Context	configure>router>dhcp6>server>pool configure>service>vpn>dhcp6>server>pool
Description	This is an existing command and we just need to add the failover option.
Default	failover local
Parameters	<i>ipv6-addr/prefix-len</i> — Values <i>ipv6-address</i> x:x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:d.d.d.d x [0..FFFF]H d [0..255]D prefix-length [1..128] failover { local remote } — This command designates a prefix as local or remote . This is used when multi-chassis synchronization is enabled.

Values **local** — A prefix designated as local is always used to renew the existing addresses/ prefixes or to assign a new one.
remote — A prefix designated as remote is used only to renew the existing DHCP leases. The new leases will be assigned from it only after the maximum-client-lead-time + partner-down-delay time elapses.

subnet

Syntax **subnet** {*ip-address/mask*|*ip-address netmask*} [**create**]
no subnet {*ip-address/mask*|*ip-address netmask*}

Context config>router>dhcp>server>pool

Description This command creates a subnet of IP addresses to be served from the pool. The subnet cannot include any addresses that were assigned to subscribers without those addresses specifically excluded. When the subnet is created no IP addresses are made available until a range is defined.

Default none

Parameters *ip-address* — Specifies the base IP address of the subnet. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets).
mask — The subnet mask in dotted decimal notation. Allowed values are dotted decimal addresses in the range 128.0.0.0 – 255.255.255.252. Note that a mask of 255.255.255.255 is reserved for system IP addresses.
netmask — Specifies a string of 0s and 1s that mask or screen out the network part of an IP address so that only the host computer part of the address remains.

address-range

Syntax [**no**] **address-range** *start-ip-address end-ip-address* [**failover** {**local** | **remote**}]

Context config>router>dhcp>server>pool>subnet

Description This command configures a range of IP addresses to be served from the pool. All IP addresses between the start and end IP addresses will be included (other than specific excluded addresses).

Default none

Parameters *start-ip-address* — Specifies the start address of this range to include. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets).
end-ip-address — Specifies the end address of this range to include. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets).
failover local — Specifies that the DHCP server failover control type is in control under normal operation.
failover remote — Specifies that the remote DHCP server failover system is in control under normal operation.

drain

Syntax	[no] drain
Context	config>service>vprn>dhcp>server>pool>subnet
Description	This command subnet draining which means no new leases can be assigned from this subnet and existing leases are cleaned up upon renew/rebind. The no form of the command means the subnet is active and new leases can be assigned from it.

exclude-addresses

Syntax	[no] exclude-addresses <i>start-ip-address</i> [<i>end-ip-address</i>]
Context	config>router>dhcp>server>pool>subnet
Description	This command specifies a range of IP addresses that excluded from the pool of IP addresses in this subnet.
Default	none
Parameters	<i>start-ip-address</i> — Specifies the start address of this range to exclude. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets). <i>end-ip-address</i> — Specifies the end address of this range to exclude. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets).

maximum-declined

Syntax	maximum-declined <i>maximum-declined</i> no maximum-declined
Context	config>router>dhcp>server>pool>subnet
Description	This command configures the maximum number of declined addresses allowed.
Default	64
Parameters	<i>maximum-declined</i> — Specifies the maximum number of declined addresses allowed. Values 0 — 4294967295

minimum-free

Syntax	minimum-free <i>minimum-free</i> [percent] [event-when-depleted] no minimum-free
Context	config>router>dhcp>server>pool>subnet

Description This command configures the minimum number of free addresses in this subnet. If the actual number of free addresses in this subnet falls below this configured minimum, a notification is generated.

Default 1

Parameters *minimum-free* — Specifies the minimum number of free addresses in this subnet.

Values 0 — 255

percent — Specifies that the value indicates a percentage.

event-when-depleted — This parameter enables a system-generate event when all available addresses in the pool/subnet of local DHCP server are depleted.

— default-router

Syntax **default-router** *ip-address* [*ip-address...*(up to 4 max)]
no default-router

Context config>router>dhcp>server>pool>subnet>options

Description This command configures the IP address of the default router for a DHCP client. Up to four IP addresses can be specified.

The **no** form of the command removes the address(es) from the configuration.

Default none

Parameters *ip-address* — Specifies the IP address of the default router. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets).

subnet-mask

Syntax **subnet-mask** *ip-address*
no subnet-mask

Context config>router>dhcp>local-dhcp-serve>pool>subnet>options
config>subscr-mgmt>loc-user-db>dhcp>host>options

Description This command specifies the subnet-mask option to the client. The mask can either be defined (for supernetting) or taken from the pool address.

The **no** form of the command removes the address from the configuration.

Default none

Parameters *ip-address* — Specifies the IP address of the subnet mask. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets).

subnet-binding key

Syntax	subnet-binding key [sys-id-svc-id sys-id string] unbind-delay [hrs <i>hours</i>] [min <i>mins</i>] [sec <i>secs</i>] no subnet-binding key
Context	config>router>dhcp>local-dhcp-server>pool config>service>vprn>dhcp>local-dhcp-server>pool
Description	<p>The command enables the pool to bind three selectable parameters, sys-id-svc-id, sys-id, or a string to a subnet. These parameters are retrieved from DHCP relay Option 82 vendor specific option (VSO). The intent of this feature is to allow multiple BNG to share a DHCP pool. When a subnet is bound to a VSO, only DHCP discoveries with matching VSO are allowed to allocate additional DHCP addresses. For example, if sys-id is the chosen VSO, a DHCP discovery will bind the sys-id to a subnet. Only DHCP discoveries with matching sys-id are allowed to allocate additional addresses from the same subnet. If a DHCP discovery fails to match any bindings, and if a new subnet is still available, it will first bind the VSO to the new subnet and offer the subscriber an IP address.</p> <p>Once all addresses are released back to the pool, the subnet is once again available for binding after the unbind-delay has expired. The unbind-delay expiration is to hold the subnet for a small period of time until the subnet has successful remove itself from the routing table. The delay is configurable to allow enough time for routing update to occur. By default, the delay is 5 minute with a minimal required value of 1 second.</p>
Default	unbind-delay min 5
Parameters	<p><i>key</i> — The desire key to which the subnet to bind: sys-id-svc-id sys-id string</p> <p><i>hours</i> — [0 — 24] the delay for the subnet to unbind in hours.</p> <p><i>minutes</i> — [0 — 59] the delay for the subnet to unbind in minutes.</p> <p><i>seconds</i> — [0 — 59] the delay for the subnet to unbind in seconds.</p>

use-gi-address

Syntax	use-gi-address [scope <i>scope</i>]
Context	config>router>dhcp>server
Description	This command enables the use of gi-address matching. By default, the scope is subnet and addresses are allocated only from the subnet where the gi-address belongs, even if the pool contains multiple other subnets. When the scope is pool, addresses are allocated from any subnet in the pool that contains the subnet where the gi-address belongs.
Default	no use-gi-address
Parameters	<p>scope <i>scope</i> — Specifies if addresses are handed out for a certain subnet where the gi-address belongs to only or for all subnets part of the pool.</p> <p>Values</p> <p>subnet — Addresses are only handed out for the subnet where the gi-address is part of</p> <p>pool — All subnets part of the pool which contain subnet where the gi-address is part of can hand out addresses.</p>

use-pool-from-client

Syntax	use-pool-from-client <i>delimiter delimiter</i> use-pool-from-client no use-pool-from-client
Context	config>router>dhcp>server
Description	This command enables the use of the pool indicated by DHCP client. When enabled, the IP address pool to be used by this server is the pool is indicated by the vendor-specific sub-option 13 of the DHCP option 82. When disabled or if there is no sub-option 13 in the DHCP message, the pool selection falls back to the “use-gi-address” configuration.
Default	no use-pool-from-client
Parameters	delimiter <i>delimiter</i> — A single ASCII character specifies the delimiter of separating primary and secondary pool names in Option82 VSO.

user-ident

Syntax	user-ident <i>user-ident</i> no user-ident
Context	config>router>dhcp6>local-dhcp-server
Description	This command configures the keys for identification of the DHCPv6 lease being held in the lease-database (for configured period after lease timeout). Subscriber requesting a lease via DHCPv6 that matches an existing lease based on this configured key is handed the matched prefix or address. This allows address and prefix “stickiness” for DHCPv6 assigned prefixes (IA_NA or PD).
Default	duid
Parameters	<i>user-ident</i> — Specifies the the user identification method
Values	duid — Specifies the IPv6 DHCP unique identifier from DHCPv6. interface-id — Specifies the IPv6 interface-id option. interface-id-link-local — Specifies the interface-id and link-local address.

use-link-address

Syntax	use-link-address [<i>scope scope</i>] no use-link-address
Context	config>router>dhcp6>local-dhcp-server
Description	If configured, local pool selection for v6 address or prefix assignment will use the configured link-address under relay configuration. The selected pool will contain a prefix covering the link-address. The scope option defines the scope for the match. With scope subnet , the prefix or address selection is limited to the prefix in the pool that covers the link-address. With scope pool , all the prefixes in the selected pool are eligible for assignment.
Default	scope subnet

Triple Play DHCP Configuration Commands

- Parameters** **scope** *scope* — Specifies the scope of the IP address selection.
- Values** **subnet** — Specifies that the prefix or address selection is limited to the prefix in the pool that covers the link address.
- pool** — Specifies that all prefixes in the selected pool are eligible for assignment.

user-db

- Syntax** **user-db** *local-user-db-name*
no user-db
- Context** config>router>dhcp>server
- Description** This command configures a local user database for authentication.
- Default** not enabled
- Parameters** *local-user-db-name* — Specifies the name of a local user database.

Service Commands

dhcp

Syntax	dhcp
Context	<pre>config>service>vpls>sap config>service>vpls>spoke-sdp config>service>vpls>mesh-sdp config>service>ies>interface config>service>vprn config>service>vprn>interface config>service>vprn>sub-if config>service>vprn>sub-if>group-interface config>service>ies>sub-if>group-interface config>service>ies>sub-if config>service>ies>sub-if>grp-if</pre>
Description	This command enables the context to configure DHCP parameters.

dhcp6

Syntax	dhcp6
Context	<pre>config>service>vpls>sap config>service>vpls>spoke-sdp config>service>vpls>mesh-sdp config>service>ies>interface config>service>vprn config>service>vprn>interface config>service>vprn>sub-if config>service>vprn>sub-if>group-interface config>service>ies>sub-if>group-interface config>service>ies>sub-if config>service>ies>sub-if>grp-if</pre>
Description	This command enables the context to configure DHCP6 parameters.

client-applications

Syntax	<pre>client-applications dhcp client-applications pppoe client-applications dhcp pppoe no client-applications</pre>
Context	config>service>vprn>sub-if>dhcp

Triple Play DHCP Configuration Commands

```
config>service>vprn>sub-if>grp-if>dhcp
```

- Description** This command enables the clients that will try to contact the DHCP server(s).
The **no** form of the command removes the server client type from the configuration.
- Parameters** **dhcp** — Specifies that the DHCP relay will forward requests to the DHCP server(s).
pppoe — Specifies that PPPoE will attempt to request an IP address for a PPPoE client from the DHCP server(s)ly assigned to PPPoE node.

lease-populate

- Syntax** **lease-populate** [*nbr-of-leases*]
lease-populate [*nbr-of-leases*] **l2-header** [*mac ieee-address*]
no lease-populate
- Context** config>service>vprn>interface>dhcp
config>service>vprn>sub-if>group-if>dhcp
config>service>vprn>interface>dhcp
- Description** DHCP snooping must be explicitly enabled (using the **snoop** command) at all points where DHCP messages requiring snooping enter the VPLS instance (both from the DHCP server and from the subscribers). Lease state information is extracted from snooped DHCP ACK messages to populate lease state table entries for the SAP.
- The optional number-of-entries parameter is used to define the number lease state table entries allowed for this SAP or IP interface. If number-of-entries is omitted, only a single entry is allowed. Once the maximum number of entries has been reached, subsequent lease state entries are not allowed and subsequent DHCP ACK messages are discarded.
- The retained lease state information representing dynamic hosts may be used to:
- Populate a SAP based anti-spoof filter table to provide dynamic anti-spoof filtering. If the system is unable to populate the dynamic host information in the anti-spoof filter table on the SAP, the DHCP ACK message must be discarded without adding new lease state entry or updating an existing lease state entry.
 - Generate dynamic ARP replies if **arp-reply-agent** is enabled.
- Default** no lease-populate
- Parameters** *nbr-of-leases* — Specifies the number of DHCP leases allowed.
- Values** 1 — 8000
- l2-header** — Indicates a mode of operation where anti-spoof entry associated with the given DHCP state is created based on the MAC address from the Layer 2 header. The Layer 2 header flag is not set by default.
- mac** — Specifies that the provisioned MAC address will be used in the anti-spoofing entries for this SAP. The parameter may be changed mid-session. Existing sessions will not be re-programmed unless a **tools perform** command is issues for the lease.

lease-populate

Syntax	lease-populate [<i>nbr-of-entries</i>] lease-populate [<i>nbr-of-entries</i>] l2-header [<i>mac ieee-address</i>] no lease-populate
Context	config>service>vprn>if>dhcp config>service>vprn>sub-if>dhcp config>service>vprn>sub-if>grp-if>dhcp
Description	<p>This command enables dynamic host lease state management for VPLS SAPs and VPRN or IES IP interfaces. Lease state information is extracted from snooped or relayed DHCP ACK messages to populate lease state table entries for the SAP or IP interface.</p> <p>The optional <i>number-of-entries</i> parameter defines the number lease state table entries allowed for this SAP or IP interface. If <i>number-of-entries</i> is not specified, only a single entry is allowed. Once the maximum number of entries has been reached, subsequent lease state entries are not allowed. If lease state population is enabled and an entry cannot be retained in the table, the DHCP Relay or DHCP snoop function will prevent the far-end host from receiving the DHCP ACK message.</p> <p>The retained lease state information representing dynamic hosts may be used to populate a SAP based anti-spoof filter table to provide dynamic anti-spoof filtering. Anti-spoof filtering is only available on VPLS SAPs, IES IP interfaces terminated on a SAP or VPRN IP interfaces terminated on a SAP.</p> <p>The retained lease state information representing dynamic hosts may be used to populate the system's ARP cache based the arp-populate feature. ARP-populate functionality is only available for static and dynamic hosts associated with IES and VPRN SAP bound IP interfaces.</p> <p>The retained lease state information representing dynamic hosts may be used to populate managed entries into a VPLS forwarding database. VPLS forwarding database population is an implicit feature that automatically places the dynamic host's MAC address into the VPLS FDB. When a dynamic host's MAC address is placed in the lease state table, it will automatically be populated into the VPLS forwarding database associated with the SAP on which the host is learned. The dynamic host MAC address will override any static MAC entries using the same MAC and prevent dynamic learning of the MAC on another interface. Existing static MAC entries with the same MAC address as the dynamic host are marked as inactive but not deleted. If all entries in the lease state table associated with the MAC address are removed, the static MAC may be populated. New static MAC definitions for the VPLS instance may be created while a dynamic host exists associated with the static MAC address.</p>
Default	not enabled
Parameters	<p><i>nbr-of-entries</i> — Defines the number lease state table entries allowed for this interface. If this parameter is omitted, only a single entry is allowed. Once the maximum number of entries has been reached, subsequent lease state entries are not allowed and subsequent DHCP ACK messages are discarded.</p> <p>Values 1 — 8000</p>

lease-populate

Syntax **lease-populate** [*nbr-of-leases*]
no lease-populate

Triple Play DHCP Configuration Commands

Context	config>service>vpls>sap>dhcp config>service>ies>if>sap>dhcp config>service>ies>if>ipv6>dhcp-relay
Description	This command specifies the maximum number of DHCP or DHCP6 lease states allocated by the DHCP relay function, allowed on this interface. The no form of the command disables dynamic host lease state management.
Default	no lease-populate
Parameters	<i>nbr-of-leases</i> — Defines the number lease state table entries allowed for this interface. If this parameter is omitted, only a single entry is allowed. Once the maximum number of entries has been reached, subsequent lease state entries are not allowed and subsequent DHCP6 ACK messages are discarded.
Values	1 — 8000

match-circuit-id

Syntax	[no] match-circuit-id
Context	config>service>ies>sub-if>grp-if>dhcp config>service>vprn>sub-if>dhcp config>service>vprn>sub-if>grp-if>dhcp
Description	This command enables matching Option 82 circuit ID on relayed DHCP packet matching. For Routed CO, the group interface DHCP relay process is stateful. When packets are relayed to the server the virtual router ID, transaction ID, SAP ID, and client hardware MAC address of the relayed packet are tracked. When a response is received from the server the virtual router ID, transaction ID, and client HW MAC address must be matched to determine the SAP on which to send the packet out. In some cases, the virtual router ID, transaction ID, and client HW MAC address are not guaranteed to be unique. When the match-circuit-id command is enabled this part of the key is used to guarantee correctness in the lookup. This is only needed when are dealing with an IP aware DSLAM that proxies the client HW mac address.
Default	no match-circuit-id

option

Syntax	[no] option
Context	config>service>vpls>sap>dhcp config>service>ies>interface>dhcp config>service>vprn>interface>dhcp config>service>vprn>sub-if>dhcp config>service>vprn>sub-if>grp-if>dhcp config>service>ies>sub-if>grp-if>dhcp
Description	This command enables DHCP Option 82 (Relay Agent Information Option) parameters processing and enters the context for configuring Option 82 sub-options.

The **no** form of this command returns the system to the default.

Default no option

action

Syntax **action** {**replace** | **drop** | **keep**}
no action

Context config>service>vpls>sap>dhcp>option
config>service>ies>interface>dhcp>option
config>service>vprn>interface>dhcp>option
config>service>vprn>sub-if>grp-if>dhcp>option
config>service>ies>sub-if>grp-if>dhcp

Description This command configures the Relay Agent Information Option (Option 82) processing.
The **no** form of this command returns the system to the default value.

Default The default is to keep the existing information intact.

Parameters **replace** — In the upstream direction (from the user), the Option 82 field from the router is inserted in the packet (overwriting any existing Option 82 field). In the downstream direction (towards the user) the Option 82 field is stripped (in accordance with RFC 3046).

drop — The DHCP packet is dropped if an Option 82 field is present, and a counter is incremented.

keep — The existing information is kept in the packet and the router does not add any additional information. In the downstream direction the Option 82 field is not stripped and is forwarded towards the client.

In Vendor-Specific Options (VSOs) scenarios, the behavior is slightly different. Even with the **action=keep**, the router will insert his own vso into the Option 82 field. This will only be done when the incoming message has already an Option 82 field.

If no Option 82 field is present, the router will not create the Option 82 field - in that case, no VSO will be added to the message.

circuit-id

Syntax **circuit-id** [**ascii-tuple** | **vlan-ascii-tuple**]
no circuit-id

Context config>service>vpls>sap>dhcp>option

Description When enabled, the router sends an ASCII-encoded tuple in the **circuit-id** sub-option of the DHCP packet. This ASCII-tuple consists of the access-node-identifier, service-id, and SAP-ID, separated by “|”.

In order to send a tuple in the circuit ID, the **action replace** command must be configured in the same context.

If disabled, the **circuit-id** sub-option of the DHCP packet will be left empty.

The **no** form of this command returns the system to the default.

Triple Play DHCP Configuration Commands

Default	circuit-id
Parameters	ascii-tuple — Specifies that the ASCII-encoded concatenated tuple consisting of the access-node-identifier, service-id, and interface-name is used. vlan-ascii-tuple — Specifies that the format will include VLAN-id and dot1p bits in addition to what is included in ascii-tuple already. The format is supported on dot1q and qinq ports only. Thus, when the Option 82 bits are stripped, dot1p bits will be copied to the Ethernet header of an outgoing packet.

circuit-id

Syntax	circuit-id [ascii-tuple ifindex sap-id vlan-ascii-tuple] no circuit-id
Context	config>service>ies>if>dhcp>option config>service>ies>sub-if>grp-if>dhcp>option config>service>vprn>if>dhcp>option config>service>vprn>sub-if>grp-if>dhcp>option
Description	<p>When enabled, the router sends an ASCII-encoded tuple in the circuit-id sub-option of the DHCP packet. This ASCII-tuple consists of the access-node-identifier, service-id, and SAP-ID, separated by “ ”.</p> <p>In order to send a tuple in the circuit ID, the action replace command must be configured in the same context.</p> <p>If disabled, the circuit-id sub-option of the DHCP packet will be left empty.</p> <p>The no form of this command returns the system to the default.</p>
Default	circuit-id ascii-tuple — Specifies that the ASCII-encoded concatenated tuple will be used which consists of the access-node-identifier, service-id, and interface-name, separated by “ ”. ifindex — Specifies that the interface index will be used. (The If Index of a router interface can be displayed using the command <code>show>router>interface>detail</code>) sap-id — Specifies that the SAP identifier will be used. vlan-ascii-tuple — Specifies that the format will include VLAN-id and dot1p bits in addition to what is included in ascii-tuple already. The format is supported on dot1q-encapsulated ports only. Thus, when the option 82 bits are stripped, dot1p bits will be copied to the Ethernet header of an outgoing packet.

remote-id

Syntax	remote-id [mac string <i>string</i>] no remote-id
Context	config>service>vpls>sap>dhcp>option config>service>ies>if>dhcp>option config>service>vprn>if>dhcp>option config>service>ies>sub-if>grp-if>dhcp>option

```
config>service>ies>sub-if>grp-if>dhcp>option
```

- Description** This command specifies what information goes into the remote-id sub-option in the DHCP relay packet.
- If disabled, the **remote-id** sub-option of the DHCP packet will be left empty.
- The **no** form of this command returns the system to the default.
- Default** remote-id
- Parameters** **mac** — This keyword specifies the MAC address of the remote end is encoded in the sub-option.
string string — Specifies the remote-id.

vendor-specific-option

- Syntax** **[no] vendor-specific-option**
- Context** config>service>vpls>sap>dhcp>option
 config>service>ies>if>dhcp>option
 config>service>vprn>if>dhcp>option
 config>service>ies>sub-if>grp-if>dhcp>option
 config>service>vprn>sub-if>grp-if>dhcp>option
- Description** This command configures the Alcatel-Lucent vendor specific sub-option of the DHCP relay packet.

client-mac-address

- Syntax** **[no] client-mac-address**
- Context** config>service> ies>if>dhcp>option>vendor
 config>service>vprn>if>dhcp>option>vendor
 config>service>vprn>sub-if>grp-if>dhcp>option>vendor
 config>service>ies>sub-if>grp-if>dhcp>option>vendor
- Description** This command enables the sending of the MAC address in the Alcatel-Lucent vendor specific sub-option of the DHCP relay packet.
- The **no** form of the command disables the sending of the MAC address in the Alcatel-Lucent vendor specific sub-option of the DHCP relay packet.

pool-name

- Syntax** **[no] pool-name**
- Context** config>service>vprn>if>dhcp>option>vendor
 config>service>vprn>sub-if>grp-if>dhcp>option>vendor
 config>service>ies>if>dhcp>option>vendor
 config>service>ies>sub-if>grp-if>dhcp>option>vendor

Triple Play DHCP Configuration Commands

Description This command sends the pool name in the Alcatel vendor specific suboption of the DHCP relay packet.
The **no** form of the command disables the sending.

sap-id

Syntax **[no] sap-id**

Context config>service>vpls>sap>dhcp>option>vendor
config>service>vprn>if>dhcp>option>vendor
config>service>vprn>sub-if>grp-if>dhcp>option>vendor
config>service>ies>sub-if>grp-if>dhcp>option>vendor

Description This command enables the sending of the SAP ID in the Alcatel-Lucent vendor specific sub-option of the DHCP relay packet.
The **no** form of the command disables the sending of the SAP ID in the Alcatel-Lucent vendor specific sub-option of the DHCP relay packet.

service-id

Syntax **[no] service-id**

Context config>service>vpls>sap>dhcp>option>vendor
config>service>vprn>if>dhcp>option>vendor
config>service>vprn>sub-if>grp-if>dhcp>option>vendor
config>service>ies>sub-if>grp-if>dhcp>option>vendor

Description This command enables the sending of the service ID in the Alcatel-Lucent vendor specific sub-option of the DHCP relay packet.
The **no** form of the command disables the sending of the service ID in the Alcatel-Lucent vendor specific sub-option of the DHCP relay packet.

string

Syntax **[no] string *text***

Context config>service>vpls>sap>dhcp>option>vendor
config>service>vprn>if>dhcp>option>vendor
config>service>vprn>sub-if>grp-if>dhcp>option>vendor
config>service>ies>sub-if>grp-if>dhcp>option>vendor

Description This command specifies the string in the Alcatel-Lucent vendor specific sub-option of the DHCP relay packet.
The **no** form of the command returns the default value.

Parameters *text* — The string can be any combination of ASCII characters up to 32 characters in length. If spaces are used in the string, enclose the entire string in quotation marks (“ ”).

system-id

Syntax	[no] system-id
Context	config>service>vpls>sap>dhcp>option>vendor config>service>vprn>if>dhcp>option>vendor config>service>vprn>sub-if>grp-if>dhcp>option>vendor config>service>ies>sub-if>grp-if>dhcp>option>vendor
Description	This command specifies whether the system-id is encoded in the Alcatel-Lucent vendor specific sub-option of Option 82.

proxy-server

Syntax	proxy-server
Context	config>service>vpls>sap>dhcp config>service>vprn>sub-if>grp-if>dhcp
Description	This command configures the DHCP proxy server.

emulated-server

Syntax	emulated-server <i>ip-address</i> no emulated-server
Context	config>service>ies>if>dhcp>proxy-server config>service>ies>sub-if>grp-if>dhcp>proxy-server config>service>vpls>sap>dhcp>proxy-server config>service>vprn>sub-if>grp-if>dhcp
Description	This command configures the IP address which will be used as the DHCP server address in the context of the SAP. Typically, the configured address should be in the context of the subnet represented by the service. The no form of this command reverts to the default setting. The local proxy server will not become operational without the emulated-server address being specified.
Parameters	<i>ip-address</i> — Specifies the emulated server's IP address. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets).

emulated-server

Syntax	emulated-server <i>ip-address</i> no emulated-server
Context	config>service>vprn>if>dhcp>proxy config>service>vprn>sub-if>grp-if>dhcp>proxy-server

Triple Play DHCP Configuration Commands

Description	This command configures IP address which will be used as DHCP server address in context of the SAP. Typically, configured address should be in context of the subnet represented by VPRN. No version of these commands reverts to default setting. The local proxy server will not become operational without emulated-server address being specified.
Parameters	<i>ip-address</i> — Specifies the emulated server's IP address.

lease-time

Syntax	lease-time [<i>days days</i>] [<i>hrs hours</i>] [<i>min minutes</i>] [<i>sec seconds</i>] [override] no lease-time
Context	config>service>vpls>sap>dhcp>proxy-server config>service>ies>if>dhcp>proxy-server config>service>ies>sub-if>grp-if>dhcp>proxy-server config>service>vprn>if>dhcp>proxy config>service>vprn>sub-if>grp-if>dhcp>proxy-server
Description	This command defines the length of lease-time that will be provided to DHCP clients. By default the local-proxy-server will always make use of the lease-time information provide by either a RADIUS or DHCP server. The no form of this command disables the use of the lease-time command. The local-proxy-server will use the lease-time offered by either a RADIUS or DHCP server.
Default	7 days 0 hours 0 seconds
Parameters	override — Specifies that the local-proxy-server will use the configured lease-time information to provide DHCP clients. radius-override — Supported only in the config>service>vpls>sap>dhcp>proxy-server context, specifies that the local-proxy-server will use the configured lease-time information to provide DHCP clients. <i>days</i> — Specifies the number of days that the given IP address is valid. Values 0 — 3650 <i>hours</i> — Specifies the number of hours that the given IP address is valid. Values 0 — 23 <i>minutes</i> — Specifies the number of minutes that the given IP address is valid. Values 0 — 59 <i>seconds</i> — Specifies the number of seconds that the given IP address is valid. Values 0 — 59

snoop

Syntax	snoop no snoop
Context	config>service>vpls>sap>dhcp

```
config>service>vpls>spoke-sdp>dhcp
config>service>vpls>mesh-sdp>dhcp
config>service>vprn>if>dhcp>option
config>service>vprn>if>dhcp>option
```

Description This command enables DHCP snooping of DHCP messages on the SAP or SDP. Enabling DHCP snooping on interfaces (SAPs and SDP bindings) is required where DHCP messages important to lease state table population are received, or where Option 82 information is to be inserted. This includes interfaces that are in the path to receive messages from either DHCP servers or from subscribers.

Use the **no** form of the command to disable DHCP snooping on the specified SAP or SDP binding.

Default no snoop
dhcp6

dhcp-user-db

Syntax **dhcp-user-db** *local-user-db*
no dhcp-user-db

Context configure>service>vpls>sap

Description This command enabled access to LUDB for DHCPv4 hosts under the capture SAP. The name of this ladb must match the name of ladb configured under the **configure>service>vprn/ies>subscriber-intf>group-intf>dhcp** hierarchy.

Default no dhcp-user-db

Parameters *local-user-db* — Specifies the name of the local-user-database up to 32 characters max.

dhcp6-user-db

Syntax **dhcp6-user-db** *local-user-db*
no dhcp6-user-db

Context configure>service>vpls>sap

Description This command enabled access to LUDB for DHCPv6 hosts under the capture SAP. The name of this ladb must match the name of ladb configured under the **configure>service>vprn/ies>subscriber-intf>group-intf>dhcp** hierarchy.

Default no dhcp6-user-db

Parameters *local-user-db* — Specifies the name of the local-user-database up to 32 characters max.

ppp-user-db

Syntax **ppp-user-db** *local-user-db-name*
no ppp-user-db

Triple Play DHCP Configuration Commands

Context	configure>service>vpls
Description	This command enabled access to LUDB for PPPoE and PPPoEoA v4and v6 hosts under the capture SAP. The name of this luidb must match the name of luidb configured under the configure>service>vprn/ies>subscr-intf>group-intf>pppoe hierarchy.
Default	no pppoe-user-db
Parameters	<i>local-user-db</i> — Specifies the name of the local-user-database up to 256 characters max.

pppoe-user-db

Syntax	pppoe-user-db <i>local-user-db-name</i> no pppoe-user-db
Context	configure>service>vpls
Description	This command enabled access to LUDB for PPPoE and PPPoEoA v4and v6 hosts under the capture SAP. The name of this luidb must match the name of luidb configured under the configure>service>vprn/ies>subscr-intf>group-intf>pppoe hierarchy.
Default	no pppoe-user-db
Parameters	<i>local-user-db</i> — Specifies the name of the local-user-database up to 256 characters max.

filter

Syntax	filter <i>filter-id</i> no filter
Context	config>service>ies>sub-if>grp-if>dhcp
Description	This command configures the DHCP filter for this interface

gi-address

Syntax	gi-address <i>ip-address</i> [<i>src-ip-addr</i>] no gi-address
Context	config>service>ies>if>dhcp config>service>vprn>interface>dhcp config>service>vprn>sub-if>dhcp config>service>ies>sub-if>grp-if>dhcp config>service>ies>sub-if>dhcp
Description	This command configures the gateway interface address for the DHCP relay. A subscriber interface can include multiple group interfaces with multiple SAPs. The GI address is needed, when the router functions as a DHCP relay, to distinguish between the different subscriber interfaces and potentially between the group interfaces defined.

By default, the GI address used in the relayed DHCP packet is the primary IP address of a normal IES interface. Specifying the GI address allows the user to choose a secondary address. For group interfaces a GI address must be specified under the group interface DHCP context or subscriber-interface DHCP context in order for DHCP to function.

Default	no gi-address
Parameters	<i>ip-address</i> — Specifies the host IP address to be used for DHCP relay packets. <i>src-ip-address</i> — Specifies that this GI address is to be the source IP address for DHCP relay packets.

relay-plain-bootp

Syntax	[no] relay-plain-bootp
Context	config>service>ies>if>dhcp
Description	This command enables the relaying of plain BOOTP packets. The no form of the command disables the relaying of plain BOOTP packets.

relay-unicast-msg

Syntax	relay-unicast-msg [release-update-src-ip] no relay-unicast-msg
Context	config>service>ies>if>dhcp config>service>ies>sub-if>dhcp config>service>ies>sub-if>grp-if>dhcp config>service>vprn>if>dhcp config>service>vprn>sub-if>dhcp config>service>vprn>sub-if>grp-if>dhcp
Description	Relay unicast client DHCPv4 request (renew) messages. In the upstream direction: update the source-ip address and add the gateway IP address (gi-address) field before sending the message to the intended DHCP server (the message is not broadcasted to all configured DHCP servers). In the downstream direction: remove the gi-address and update the destination IP address to the value of the yiaddr (your IP address) field. By default, unicast DHCPv4 release messages are forwarded transparently. The optional “release-update-src-ip” flag, updates the source IP address with the value used for relayed DHCPv4 messages. Additionally when the optional flag “relay-unicast-msg” is enabled, then the gi address and source IP address of relayed DHCPv4 messages can be configured to any local configured IP address in the same routing instance.
Default	no relay-unicast-msg
Parameters	release-update-src-ip — Updates the source IP address with the value used for relayed DHCPv4 messages

Triple Play DHCP Configuration Commands

server

Syntax	server <i>server1</i> [<i>server2</i> ...(up to 8 max)]
Context	config>service>ies>if>dhcp config>service>vprn>if>dhcp config>service>ies>sub-if>grp-if>dhcp
Description	This command specifies a list of servers where requests will be forwarded. The list of servers can entered as either IP addresses or fully qualified domain names. There must be at least one server specified for DHCP relay to work. If there are multiple servers then the request is forwarded to all of the servers in the list. There can be a maximum of 8 DHCP servers configured.
Default	no server
Parameters	<i>server</i> — Specify the DHCP server IP address.

relay-plain-bootp

Syntax	[no] relay-plain-bootp
Context	config>service>vprn>if>dhcp
Description	This command enables the relaying of plain BOOTP packets. The no form of the command disables the relaying of plain BOOTP packets.

use-arp

Syntax	[no] use-arp
Context	config>service>vprn>if>dhcp
Description	This command enables the use of ARP to determine the destination hardware address. The no form of the command disables the use of ARP to determine the destination hardware address

trusted

Syntax	[no] trusted
Context	config>service>ies>if>dhcp config>service>vprn>if>dhcp config>service>vprn>sub-if>grp-if>dhcp config>service>ies>sub-if>grp-if>dhcp
Description	This command enables relaying of untrusted packets. The no form of this command disables the relay.

Default not enabled

host-connectivity-verify

Syntax	host-connectivity-verify [interval <i>interval</i>] [action { remove alarm }] [family <i>family</i>]
Context	config>service>vprn>if>sap config>service>vprn>sub-if>grp-if config>service>vprn>sub-if>grp-if>dhcp
Description	This command enables subscriber host connectivity verification on a given SAP within a service. This tool will periodically scan all known hosts (from dhcp-state) and perform a UC ARP request. The subscriber host connectivity verification will maintain state (connected vs. not-connected) for all hosts.
Default	no host-connectivity-verify
Parameters	interval <i>interval</i> — The interval, expressed in minutes, which specifies the time interval which all known sources should be verified. The actual rate is then dependent on number of known hosts and interval. Values 1— 6000) Note that a zero value can be used by the SNMP agent to disable host-connectivity-verify.) action { remove alarm } — Defines the action taken on a subscriber host connectivity verification failure for a given host. The remove keyword raises an alarm and removes dhcp-state and releases all allocated resources (queues, table entries, etc.). DHCP-RELEASE will be signaled to corresponding DHCP server. Static hosts will never be removed. The alarm keyword raises an alarm indicating that the host is disconnected. family <i>family</i> — The family configuration allows the host connectivity checks to be performed for IPv4 endpoint, IPv6 endpoint or both. With family IPv6 configured, host connectivity checks will be performed on the global unicast address (assigned via SLAAC or DHCPv6 IA_NA) and link-local address of a Layer 3 RG or bridged hosts. In case of SLAAC assignment, host connectivity can only be performed if the /128 is known (via downstream ND). DHCPv6 PD assigned prefixes will be removed if link-local address is determined to be unreachable via “host connectivity check”. Reachability checks for GUA and link-local address will be done simultaneously.

dhcp

Syntax	dhcp
Context	config>service>vprn>interface config>service>vprn> config>service>vprn>sub-if>grp-if
Description	This command enables the context to configure DHCP parameters.

action

Syntax	action {replace drop keep} no action
Context	config>service>vprn>if>dhcp>option config>service>vprn>sub-if>grp-if>dhcp>option
Description	This command configures the processing required when the SR-Series receives a DHCP request that already has a Relay Agent Information Option (Option 82) field in the packet. The no form of this command returns the system to the default value.
Default	Per RFC 3046, <i>DHCP Relay Agent Information Option</i> , section 2.1.1, <i>Reforwarded DHCP requests</i> , the default is to keep the existing information intact. The exception to this is if the giaddr of the received packet is the same as the ingress address on the router. In that case the packet is dropped and an error is logged.
Parameters	replace — In the upstream direction (from the user), the existing Option 82 field is replaced with the Option 82 field from the router. In the downstream direction (towards the user) the Option 82 field is stripped (in accordance with RFC 3046). drop — The packet is dropped, and an error is logged. keep — The existing information is kept in the packet and the router does not add any additional information. In the downstream direction the Option 82 field is not stripped and is sent on towards the client. The behavior is slightly different in case of Vendor Specific Options (VSOs). When the keep parameter is specified, the router will insert his own VSO into the Option 82 field. This will only be done when the incoming message has already an Option 82 field. If no Option 82 field is present, the router will not create the Option 82 field. In this in that case, no VSO will be added to the message.

match-circuit-id

Syntax	[no] match-circuit-id
Context	config>service>vprn>sub-if>grp-if>dhcp
Description	This command enables Option 82 circuit ID on relayed DHCP packet matching. For routed CO, the group interface DHCP relay process is stateful. When packets are relayed to the server the virtual router ID, transaction ID, SAP ID, and client hardware MAC address of the relayed packet are tracked. When a response is received from the server the virtual router ID, transaction ID, and client hardware MAC address must be matched to determine the SAP on which to send the packet out. In some cases, the virtual router ID, transaction ID, and client hardware MAC address are not guaranteed to be unique. When the match-circuit-id command is enabled this part of the key is used to guarantee correctness in our lookup. This is really only needed when dealing with an IP aware DSLAM that proxies the client hardware MAC address.
Default	no match-circuit-id

option

Syntax	[no] option
Context	config>service>vprn>if>dhcp config>service>vprn>sub-if>dhcp config>service>vprn>sub-if>grp-if>dhcp
Description	This command enables DHCP Option 82 (Relay Agent Information Option) parameters processing and enters the context for configuring Option 82 sub-options. The no form of this command returns the system to the default.
Default	no option

vendor-specific-option

Syntax	[no] vendor-specific-option
Context	config>service>vprn>if>dhcp>option config>service>vprn>sub-if>grp-if>dhcp>option
Description	This command configures the Alcatel-Lucent vendor specific suboption of the DHCP relay packet.

client-mac-address

Syntax	[no] client-mac-address
Context	config>service>vprn>if>dhcp>option config>service>vprn>if>dhcp>option>vendor config>service>vprn>sub-if>grp-if>dhcp>option>vendor
Description	This command enables the sending of the MAC address in the Alcatel-Lucent vendor specific suboption of the DHCP relay packet. The no form of the command disables the sending of the MAC address in the Alcatel-Lucent vendor specific suboption of the DHCP relay packet.

sap-id

Syntax	[no] sap-id
Context	config>service>vprn>if>dhcp>option>vendor config>service>vprn>sub-if>grp-if>dhcp>option>vendor
Description	This command enables the sending of the SAP ID in the Alcatel-Lucent vendor specific suboption of the DHCP relay packet. The no form of the command disables the sending of the SAP ID in the Alcatel-Lucent vendor specific suboption of the DHCP relay packet.

Triple Play DHCP Configuration Commands

service-id

Syntax	[no] service-id
Context	config>service>vprn>if>dhcp>option>vendor config>service>vprn>sub-if>grp-if>dhcp>option>vendor
Description	This command enables the sending of the service ID in the Alcatel-Lucent vendor specific suboption of the DHCP relay packet. The no form of the command disables the sending of the service ID in the Alcatel-Lucent vendor specific suboption of the DHCP relay packet.

string

Syntax	[no] string text
Context	config>service>vprn>if>dhcp>option>vendor config>service>vprn>sub-if>grp-if>dhcp>option>vendor
Description	This command specifies the vendor specific suboption string of the DHCP relay packet. The no form of the command returns the default value.
Parameters	<i>text</i> — The string can be any combination of ASCII characters up to 32 characters in length. If spaces are used in the string, enclose the entire string in quotation marks (“ ”).

system-id

Syntax	[no] system-id
Context	config>service>vprn>if>dhcp>option>vendor config>service>vprn>sub-if>grp-if>dhcp>option>vendor
Description	This command specifies whether the system-id is encoded in the Alcatel-Lucent vendor specific suboption of Option 82.
Default	None

proxy-server

Syntax	proxy-server
Context	config>service>if>dhcp config>service>vprn>sub-if>grp-if>dhcp
Description	This command configures the DHCP proxy server.

emulated-server

Syntax	emulated-server <i>ip-address</i> no emulated-server
Context	config>service>vprn>if>dhcp>proxy config>service>vprn>sub-if>grp-if>dhcp>proxy-server
Description	This command configures the IP address to be used as the DHCP server address in the context of this service. Typically, the configured address should be in the context of the subnet. The no form of this command reverts to the default setting. The local proxy server will not become operational without a specified emulated server address.
Parameters	<i>ip-address</i> — Specifies the emulated server address. Default Note that for a retail interface, the default is the local interface.

lease-time

Syntax	lease-time [days <i>days</i>] [hrs <i>hours</i>] [min <i>minutes</i>] [sec <i>seconds</i>] [override] no lease-time
Context	config>service>vprn>if>dhcp>proxy config>service>vprn>sub-if>grp-if>dhcp>proxy-server
Description	This command defines the length of lease-time that will be provided to DHCP clients. By default the local-proxy-server will always make use of the lease-time information provide by either a RADIUS or DHCP server. The no form of this command disables the use of the lease-time command. The local-proxy-server will use the lease-time offered by either a RADIUS or DHCP server.
Default	7 days 0 hours 0 seconds
Parameters	override — Specifies that the local-proxy-server will use the configured lease-time information to provide DHCP clients. <i>days</i> — Specifies the number of days that the given IP address is valid. Values 0 — 3650 <i>hours</i> — Specifies the number of hours that the given IP address is valid. Values 0 — 23 <i>minutes</i> — Specifies the number of minutes that the given IP address is valid. Values 0 — 59 <i>seconds</i> — Specifies the number of seconds that the given IP address is valid. Values 0 — 59

server

Syntax **server** *server1* [*server2*...(up to 8 max)]

Triple Play DHCP Configuration Commands

Context	config>service>vprn>if>dhcp config>service>vprn>sub-if>grp-if>dhcp
Description	<p>This command specifies a list of servers where requests will be forwarded. The list of servers can entered as either IP addresses or fully qualified domain names. There must be at least one server specified for DHCP relay to work. If there are multiple servers then the request is forwarded to all of the servers in the list. There can be a maximum of 8 DHCP servers configured.</p> <p>The flood command is applicable only in the VPLS case. There is a scenario with VPLS where the VPLS node only wants to add Option 82 information to the DHCP request to provider per-subscriber information, but it does not do full DHCP relay. In this case, the server is set to "flood". This means the DHCP request is still a broadcast and is sent through the VPLS domain. A node running at L3 further upstream then can perform the full L3 DHCP relay function.</p>
Default	no server
Parameters	<i>server</i> — Specify the DHCP server IP address.

host-connectivity-verify

Syntax	host-connectivity-verify [<i>interval interval</i>] [<i>action {remove alarm}</i>] [<i>family family</i>]
Context	config>service>vprn>if>sap config>service>vprn>sub-if>grp-if config>service>vprn>sub-if>grp-if>dhcp
Description	<p>This command enables enables subscriber host connectivity verification on a given SAP within a service.</p> <p>This tool will periodically scan all known hosts (from dhcp-state) and perform a UC ARP request. The subscriber host connectivity verification will maintain state (connected vs. not-connected) for all hosts.</p>
Default	no host-connectivity-verify
Parameters	<p>interval <i>interval</i> — The interval, expressed in minutes, which specifies the time interval which all known sources should be verified. The actual rate is then dependent on number of known hosts and interval.</p> <p>Values 1— 6000) Note that a zero value can be used by the SNMP agent to disable host-connectivity-verify.)</p> <p>action {remove alarm} — Defines the action taken on a subscriber host connectivity verification failure for a given host. The remove keyword raises an alarm and removes dhcp-state and releases all allocated resources (queues, table entries, etc.). DHCP-RELEASE will be signaled to corresponding DHCP server. Static hosts will never be removed. The alarm keyword raises an alarm indicating that the host is disconnected.</p> <p>family <i>family</i> — The family configuration allows the host connectivity checks to be performed for IPv4 endpoint, IPv6 endpoint or both. With family IPv6 configured, host connectivity checks will be performed on the global unicast address (assigned via SLAAC or DHCPv6 IA_NA) and link-local address of a Layer 3 RG or bridged hosts. In case of SLAAC assignment, host connectivity can only be performed if the /128 is known (via downstream ND). DHCPv6 PD assigned prefixes will be removed if link-local address is determined to be unreachable via “host connectivity check”. Reachability checks for GUA and link-local address will be done simultaneously.</p>

Interface Commands

local-proxy-arp

Syntax	[no] local-proxy-arp
Context	config>service>vprn>interface config>service>vprn>sub-if>grp-if
Description	This command enables local proxy ARP. When local proxy ARP is enabled on an IP interface, the system responds to all ARP requests for IP addresses belonging to the subnet with its own MAC address, and thus will become the forwarding point for all traffic between hosts in that subnet. When local-proxy-arp is enabled, ICMP redirects on the ports associated with the service are automatically blocked.
Default	no local-proxy-arp

mac

Syntax	[no] mac <i>ieee-mac-address</i>
Context	config>service>vprn>interface config>service>vprn>if>vrrp config>service>vprn>sub-if>grp-if
Description	This command assigns a specific MAC address to a VPRN IP interface. The no form of this command returns the MAC address of the IP interface to the default value.
Default	The physical MAC address associated with the Ethernet interface that the SAP is configured on.
Parameters	<i>ieee-mac-address</i> — Specifies the 48-bit MAC address for the static ARP in the form <i>aa:bb:cc:dd:ee:ff</i> or <i>aa-bb-cc-dd-ee-ff</i> where <i>aa</i> , <i>bb</i> , <i>cc</i> , <i>dd</i> , <i>ee</i> and <i>ff</i> are hexadecimal numbers. Allowed values are any non-broadcast, non-multicast MAC and non-IEEE reserved MAC addresses.

proxy-arp-policy

Syntax	[no] proxy-arp <i>policy-name</i> [<i>policy-name...</i>(up to 5 max)]
Context	config>service>vprn>interface config>service>vprn>sub-if>grp-if
Description	This command enables a proxy ARP policy for the interface. The no form of this command disables the proxy ARP capability.
Default	no proxy-arp

Parameters *policy-name* — The export route policy name. Allowed values are any string up to 32 characters long composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

The specified name(s) must already be defined.

redundant-interfacer

Syntax **redundant-interface** *red-ip-int-name*
no redundant-interface

Context config>service>vprn
 config>service>vprn>sub-if>grp-if

Description This command configures a redundant interface used for dual homing.

Parameters *red-ip-int-name* — Specifies the redundant IP interface name.

remote-proxy-arp

Syntax **[no] remote-proxy-arp**

Context config>service>vprn>interface
 config>service>vprn>sub-if>grp-if

Description This command enables remote proxy ARP on the interface.

Remote proxy ARP is similar to proxy ARP. It allows the router to answer an ARP request on an interface for a subnet that is not provisioned on that interface. This allows the router to forward to the other subnet on behalf of the requester. To distinguish remote proxy ARP from local proxy ARP, local proxy ARP performs a similar function but only when the requested IP is on the receiving interface.

Default no remote-proxy-arp

Subscriber Interface Commands

subscriber-interface

Syntax	[no] subscriber-interface <i>ip-int-name</i>
Context	config>service>ies config>service>vprn
Description	This command allows the operator to create special subscriber-based interfaces. It is used to contain multiple group interfaces. Multiple subnets associated with the subscriber interface can be applied to any of the contained group interfaces in any combination. The subscriber interface allows subnet sharing between group interfaces. Use the no form of the command to remove the subscriber interface.
Parameters	<i>ip-int-name</i> — Specifies the name of the IP interface. Interface names can be from 1 to 32 alphanumeric characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

group-interface

Syntax	[no] group-interface <i>ip-int-name</i>
Context	config>service>ies>sub-if
Description	This command enables the context to configure a group interface. A group interface is an interface that may contain one or more SAPs. This interface is used in triple-play services where multiple SAPs are part of the same subnet.
Default	none
Parameters	<i>ip-int-name</i> — Configures the interface group name. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

authentication-policy

Syntax	authentication-policy <i>name</i> no authentication-policy
Context	config>service>ies>sub-if>grp-if
Description	This command assigns a RADIUS authentication policy to the interface. The no form of this command removes the policy name from the group interface configuration.
Default	no authentication-policy
Parameters	<i>name</i> — Specifies the authentication policy name. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

Local User Database Commands

local-user-db

Syntax	local-user-db <i>local-user-db-name</i> [create] no local-user-db <i>local-user-db-name</i>
Context	config>subscr-mgmt
Description	This command enables the context to configure a local user database.
Default	not enabled
Parameters	<i>local-user-db-name</i> — Specifies the name of a local user database.

dhcp

Syntax	dhcp
Context	config>subscr-mgmt>loc-user-db
Description	This command configures DHCP host parameters.

ppp

Syntax	ppp
Context	config>subscr-mgmt>loc-user-db
Description	This command configures PPP hosts.

mask

Syntax	mask type <i>dhcp-match-type</i> {[prefix-string <i>prefix-string</i> prefix-length <i>prefix-length</i>] [suffix-string <i>suffix-string</i> suffix-length <i>suffix-length</i>]} no mask type <i>dhcp-match-type</i>				
Context	config>subscr-mgmt>loc-user-db>dhcp config>subscr-mgmt>loc-user-db>ppp				
Description	This command configures the mask.				
Parameters	<i>dhcp-match-type</i> — Specifies up to four matching types to identify a host. <table> <tr> <td>Values</td> <td>DHCP: circuit-id, option60, remote-id, sap-id, string, system-id PPP: circuit-id, remote-id, service-name, username</td> </tr> <tr> <td>Values</td> <td>prefix-string <i>prefix-string</i></td> </tr> </table>	Values	DHCP: circuit-id, option60, remote-id, sap-id, string, system-id PPP: circuit-id, remote-id, service-name, username	Values	prefix-string <i>prefix-string</i>
Values	DHCP: circuit-id, option60, remote-id, sap-id, string, system-id PPP: circuit-id, remote-id, service-name, username				
Values	prefix-string <i>prefix-string</i>				

Triple Play DHCP Configuration Commands

Specifies a substring that is stripped of the start of the incoming circuit ID before it is matched against the value configured in the DHCP or PPPOE circuit ID.

This string can only contain printable ASCII characters. The "*" character is a wildcard that matches any substring. If a "\" character is masked, use the escape key so it becomes "\\".

Values 127 characters maximum, * is wildcard.

prefix-length *prefix-length* — Specifies the number of characters to remove from the start of the incoming circuitId before it is matched against the value configured in the DHCP circuit ID.

Values 1— 127

suffix-string *suffix-string* — Specifies a substring that is stripped of the end of the incoming circuit ID before it is matched against the value configured in DHCP circuit ID.

This string can only contain printable ASCII characters. The "*" character is a wildcard that matches any substring. If a "\" character is masked, use the escape key so it becomes "\\".

Values 127 characters maximum

suffix-length *suffix-length* — Specifies the number of characters to remove from the end of the incoming circuit ID before it is matched against the value configured in the DHCP circuit ID.

Values 1— 127

host

Syntax	host <i>host-name</i> [create] no host <i>host-name</i>
Context	config>subscr-mgmt>loc-user-db>dhcp config>subscr-mgmt>loc-user-db>ppp
Description	This command defines a DHCP or PPP subscriber.
Parameters	<i>host-name</i> — create — Keyword used to create the host name. The create keyword requirement can be enabled/disabled in the environment>create context.

access-loop-encapsulation

Syntax	[no] access-loop-encapsulation
Context	config>subscr-mgmt>loc-user-db>ppp>host
Description	

encap-offset

Syntax	encap-offset [<i>type type</i>]
---------------	--

no encap-offset**Context** config>subscr-mgmt>loc-user-db>ppp>host>ale**Description**

rate-down

Syntax **rate-down** *rate*
no rate-down**Context** config>subscr-mgmt>loc-user-db>ppp>host>ale**Description**

access-loop-information

Syntax **access-loop-information****Context** config>subscr-mgmt>loc-user-db>ppp>host>ali**Description** This command enables the context to configure access loop information in the local user database

circuit-id

Syntax	circuit-id sap-id circuit-id string <i>ASCII string</i> no circuit-id
Context	config>subscr-mgmt>loc-user-db>ppp>host
Description	This command specifies a circuit-id for PPPoE hosts. A circuit-id received in PPPoE tags has precedence over the ludb specified circuit-id.
Default	no circuit-id
Parameters	sap-id — Specifies to use the SAP ID of the PPPoE session as the circuit ID. <i>string ASCII string</i> Specifies the circuit-id as a string, up to 63 characters. in length.

remote-id

Syntax	remote-id string mac remote-id string <i>ASCII string</i> no remote-id
Context	config>subscr-mgmt>loc-user-db>ppp>host>ali
Description	This command specifies a remote-id for PPPoE hosts. A remote-id received in PPPoE tags has precedence over the ludb specified remote-id.
Default	no remote-id
Parameters	<i>string ASCII string</i> — specifies the circuit-id as a string, up to 63 characters. in length. mac — specifies MAC address of the PPPoE session as the remote ID.

acct-policy

Syntax	acct-policy acct-policy-name [duplicate acct-policy-name] no acct-policy
Context	config>subscr-mgmt>loc-user-db>ppp>host
Description	This command specifies the accounting policy used for sending an Accounting Stop message to report RADIUS authentication failures of PPPoE sessions. A duplicate policy can be specified if a copy of the Accounting Stop message must be sent to another destination. Reporting RADIUS authentication failures with an Accounting Stop message must be enabled in the RADIUS authentication policy (“send-acct-stop-on-fail”) A duplicate RADIUS accounting policy can be specified if the accounting stop resulting from a RADIUS authentication failure must also be sent to a second RADIUS destination.
Default	no acct-policy

Parameters *acct-policy-name* — Specifies the name of a RADIUS accounting policy up to 32 characters in length.

address

Syntax **address gi-address [scope scope]**
address ip-address
address pool pool-name [secondary-pool sec-pool-name] [delimiter delimiter]
address use-pool-from-client [delimiter delimiter]
no address

Context config>subscr-mgmt>loc-user-db>dhcp>host
config>subscr-mgmt>loc-user-db>ppp>host

Description This command configures how the IP address is defined for this host.

When the user-db is used from a local-dhcp-server, then this command defines how to define the IP address the server will “offer” to the DHCP-client.

When the user-db is used for PPPoE authentication, the **gi-address** parameter cannot be used. A fixed IP address will then cause PPPoE to use this IP address. If no IP address is specified, the PPPoE will look for IP address by other means (DHCP). If a pool name is given, this pool will be sent in the DHCP request so that it can be used in by the DHCP server to determine which address to give to the host.

The **no** form of the command causes no IP address to be assigned to this host. In a user-db referred to from a local-dhcp-server, creating a host without address information will cause the matching client never to get an IP address.

Default no address

Parameters **gi-address** — When specified, the gi-address of the DHCP message is taken to look for a subnet in the local DHCP server. The first available free address of the subnet is taken and “offered” to the host. When **local-user-db** is used for PPPoE authentication, this has the same result as **no address**.

ip-address — Specifies the fixed IP address to use for this host.

pool-name/sec-pool-name — Specifies the primary (and secondary) pool (in the local DHCP server) to use to look for an available address. The first available IP address from any subnet in the pool will be used. When local-user-dbis used for PPPoE authentication, this causes the specified pool name to be sent to the DHCP server in a vendor-specific suboption under Option 82

use-pool-from-client — Use the pool-name in the Option 82 vendor-specific sub-option.

delimiter delimiter — A single ascii character specifies the delimiter of separating primary and secondary pool names in option82 VSO

auth-policy

Syntax **auth-policy policy-name**
no auth-policy

Context config>subscr-mgmt>loc-user-db>dhcp>host

Triple Play DHCP Configuration Commands

Description This command configures the authentication policy of this host and PPPoE hosts. This authentication policy is only used if no authentication policy is defined at the interface level. For DHCP hosts, the host entry should not contain any other information needed for setup of the host (IP address, ESM strings, etc.). For PPPoE hosts, the authentication policy configured here must have its pppoe-authentication-method set to **pap-chap**, otherwise the request will be dropped.

Parameters *policy-name* — Specifies the authentication policy name.

auth-domain-name

Syntax **auth-domain-name** *domain-name*
no auth-domain-name

Context config>subscr-mgmt>loc-user-db>dhcp>host

Description This command sets the domain name which can be appended to user-name in RADIUS-authentication-request message for the given host.

Parameters *domain-name* — Specifies the domain name to be appended to user-name in RADIUS-authentication-request message for the given host.

host-identification

Syntax **host-identification**

Context config>subscr-mgmt>loc-user-db>dhcp>host
config>subscr-mgmt>loc-user-db>ppp>host

Description This command enables the context to configure host identification parameters.

server

Syntax **server** *ip-address*
no server

Context config>subscr-mgmt>loc-user-db>dhcp>host

Description This command configures the IP address of the DHCP server in which to relay.
The **no** form of the command removes the value from the configuration.

Default no server

Parameters *ip-address* — Specifies the IP address of the DHCP host server. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets).

circuit-id

Syntax	circuit-id string <i>ascii-string</i> circuit-id hex <i>hex-string</i> no circuit-id
Context	config>subscr-mgmt>loc-user-db>dhcp>host>host-ident config>subscr-mgmt>loc-user-db>ppp>host>host-ident
Description	This command specifies the circuit-id to match.
Parameters	<i>ascii-string</i> — specifies the circuit ID from the Option 82. <i>hex-string</i> — Specifies the circuit ID in hexadecimal format from the Option 82.
Values	0x0..0xFFFFFFFF (maximum 254 hex nibbles)

encap-tag-range

Syntax	encap-tag-range start-tag <i>start-tag</i> end-tag <i>end-tag</i> no encap-tag-range																								
Context	config>subscr-mgmt>loc-user-db>dhcp>host>host-ident config>subscr-mgmt>loc-user-db>ppp>host>host-ident																								
Description	This command specifies a range of encapsulation tag as the host identifications. The encapsulation tag is dot1q or QinQ on Ethernet port; VPI/VCI on ATM port. For dot1q, the start/end-tag is single number, range from 0-4094; for QinQ, the start/end-tag format is x.y, x or y could be “*”, which means ignore inner or outer tag; For ATM the start/end-tag format is vpi/vci, vpi or vci could be “*”, which means ignore VPI or VCI. Note: This command will only be used when “encap-tag-range” is configured as one of the match-list The no form of the command removes the values from the configuration.																								
Default	none																								
Parameters	start-tag <i>start-tag</i> — Specifies the value of the start label in the range of SAP’s allowed on this host.																								
Values	<table> <tr> <td><i>start-tag</i></td> <td>dot1q</td> <td>qtag1</td> </tr> <tr> <td></td> <td>qinq(</td> <td>qtag1.qtag2 qtag1.* *.qtag2)</td> </tr> <tr> <td></td> <td>atm</td> <td>(vpi/vci vpi/* */vci)</td> </tr> <tr> <td></td> <td>qtag1</td> <td>[0..4094]</td> </tr> <tr> <td></td> <td>qtag2</td> <td>[0..4094]</td> </tr> <tr> <td></td> <td>vpi</td> <td>[0..4095] (NNI)</td> </tr> <tr> <td></td> <td></td> <td>[0..255] (UNI)</td> </tr> <tr> <td></td> <td>vci</td> <td>[1..65535]</td> </tr> </table>	<i>start-tag</i>	dot1q	qtag1		qinq(qtag1.qtag2 qtag1.* *.qtag2)		atm	(vpi/vci vpi/* */vci)		qtag1	[0..4094]		qtag2	[0..4094]		vpi	[0..4095] (NNI)			[0..255] (UNI)		vci	[1..65535]
<i>start-tag</i>	dot1q	qtag1																							
	qinq(qtag1.qtag2 qtag1.* *.qtag2)																							
	atm	(vpi/vci vpi/* */vci)																							
	qtag1	[0..4094]																							
	qtag2	[0..4094]																							
	vpi	[0..4095] (NNI)																							
		[0..255] (UNI)																							
	vci	[1..65535]																							
	end-tag <i>end-tag</i> — Specifies the value of the end label in the range of SAP’s allowed on this host.																								
Values	<table> <tr> <td><i>end-tag</i></td> <td>dot1q</td> <td>qtag1</td> </tr> <tr> <td></td> <td>qinq(</td> <td>qtag1.qtag2 qtag1.* *.qtag2)</td> </tr> <tr> <td></td> <td>atm</td> <td>(vpi/vci vpi/* */vci)</td> </tr> <tr> <td></td> <td>qtag1</td> <td>[0..4094]</td> </tr> <tr> <td></td> <td>qtag2</td> <td>[0..4094]</td> </tr> </table>	<i>end-tag</i>	dot1q	qtag1		qinq(qtag1.qtag2 qtag1.* *.qtag2)		atm	(vpi/vci vpi/* */vci)		qtag1	[0..4094]		qtag2	[0..4094]									
<i>end-tag</i>	dot1q	qtag1																							
	qinq(qtag1.qtag2 qtag1.* *.qtag2)																							
	atm	(vpi/vci vpi/* */vci)																							
	qtag1	[0..4094]																							
	qtag2	[0..4094]																							

Triple Play DHCP Configuration Commands

vpi	[0..4095] (NNI) [0..255] (UNI)
vci	[1..65535]

mac

Syntax	mac <i>ieee-address</i> no mac
Context	config>subscr-mgmt>loc-user-db>dhcp>host>host-ident config>subscr-mgmt>loc-user-db>ppp>host>host-ident
Description	This command specifies the MAC address to match.
Parameters	<i>ieee-address</i> — Specifies the 48-bit MAC address in the form aa:bb:cc:dd:ee:ff or aa-bb-cc-dd-ee-ff where aa, bb, cc, dd, ee, and ff are hexadecimal numbers.

options6

Syntax	options6
Context	config>subscr-mgmt>loc-user-db>ppp>host config>subscr-mgmt>loc-user-db>dhcp>host
Description	This command enables the context to configure IPv6 DNS server information in the local user database

option60

Syntax	option60 <i>hex-string</i> no option60
Context	config>subscr-mgmt>loc-user-db>dhcp>host>host-ident
Description	This command specifies the Vendor-Identifying Vendor Option to match. Option 60 is encoded as Type-Length-Value (TLV). The <i>hex-string</i> portion of Option 60 in the received DHCP request is used for matching. Only the first 32 bytes can be defined here. If Option 60 from the message is longer, those bytes are ignored.
Default	no option60
Parameters	<i>hex-string</i> — Specifies the hex value of this option. Values 0x0..0xFFFFFFFF...(maximum 254 hex nibbles)

remote-id

Syntax	remote-id <i>remote-id</i> no remote-id
---------------	--

Context	config>subscr-mgmt>loc-user-db>dhcp>host>host-ident config>subscr-mgmt>loc-user-db>ppp>host>host-ident
Description	This command specifies the remote id of this host. The no form of this command returns the system to the default.
Default	no remote-id
Parameters	<i>remote-id</i> — Specifies the remote-id.

service-name

Syntax	service-name <i>service-name</i> no service-name
Context	config>subscr-mgmt>loc-user-db>ppp>host>host-ident
Description	This command specifies the service-name tag in PADI and/or PADR packets to match for PPPoE hosts.
Parameters	<i>service-name</i> — Specifies a PPPoE service name, up to 255 characters maximum.

sap-id

Syntax	sap-id <i>sap-id</i> no sap-id
Context	config>subscr-mgmt>loc-user-db>dhcp>host>host-ident
Description	This command specifies the SAP ID from the Alcatel Vendor Specific Sub-option in Option 82 to match.
Parameters	<i>sap-id</i> — Specifies a SAP ID, up to 255 characters maximum.

service-id

Syntax	service-id <i>service-id</i> no service-id
Context	config>subscr-mgmt>loc-user-db>dhcp>host>host-ident
Description	This command specifies an existing service ID from the Alcatel Vendor Specific Sub-Option in Option 82 to match.
Parameters	<i>service-id</i> — Specifies an existing service ID.
Values	1 — 2147483647

string

Syntax	string <i>string</i> no string
Context	config>subscr-mgmt>loc-user-db>dhcp>host>host-ident
Description	This command specifies the string from the Alcatel Vendor Specific Sub-Option in Option 82 to match.
Parameters	<i>string</i> — Specifies the string, up to 255 characters maximum.

system-id

Syntax	system-id <i>system-id</i> no system-id
Context	config>subscr-mgmt>loc-user-db>dhcp>host>host-ident
Description	This command specifies the system ID from the Alcatel Vendor Specific Sub-Option in Option 82 to match.
Parameters	<i>system-id</i> — Specifies the system ID, up to 255 characters maximum.

username

Syntax	username <i>user-name</i> [no-domain] username <i>user-name</i> domain-only no username
Context	config>subscr-mgmt>loc-user-db>ppp>host>host-ident
Description	This command specifies how the username is specified.
Parameters	<i>username</i> — Specifies the user name of this host. no-domain — No username is specified. domain-only — Only the domain part of the username is specified, for example, alcatel-lucent.com.

identification-strings

Syntax	identification-strings <i>option-number</i> [create] no identification-strings
Context	config>subscr-mgmt>loc-user-db>dhcp>host config>subscr-mgmt>loc-user-db>ppp>host
Description	This command specifies identification strings for the subscriber. This is useful when the server is centralized with Enhanced Subscriber Management (ESM) in a lower level in the network. These strings will be parsed by a downstream Python script or they can be used literally if the “strings-from-

option” option in the **config>subscriber-mgmt>sub-ident-policy** context is set to this option number. In this case, the option number may be set to any allowed number (between 224 and 254 is suggested, as these are not dedicated to specific purposes). If the option number is not given, a default value of 254 is used. Note, for PPPoE only, if the local user database is attached to the PPPoE node under the group interface and not to a local DHCP server, the strings will be used internally so the option number is not used.

Default 254

Parameters *option-number* — Specifies identification strings for the subscriber

Values 1 — 254

ancp-string

Syntax **ancp-string** *ancp-string*
no ancp-string

Context config>subscr-mgmt>loc-user-db>dhcp>host>ident-strings
config>subscr-mgmt>loc-user-db>ppp>host>ident-strings

Description This command specifies the ANCP string which is encoded in the identification strings.

Parameters *ancp-string* — Specifies the the ANCP string, up to 63 characters, maximum.

app-profile-string

Syntax **app-profile-string** *app-profile-string*
no app-profile-string

Context config>subscr-mgmt>loc-user-db>dhcp>host>ident-strings
config>subscr-mgmt>loc-user-db>ppp>host>ident-strings

Description This command specifies the application profile string which is encoded in the identification strings.

Parameters *app-profile-string* — Specifies the the application profile string, up to 16 characters, maximum.

inter-dest-id

Syntax **inter-dest-id** *intermediate-destination-id*
no inter-dest-id

Context config>subscr-mgmt>loc-user-db>dhcp>host>ident-strings
config>subscr-mgmt>loc-user-db>ppp>host>ident-strings

Description This command specifies the intermediate destination identifier which is encoded in the identification strings.

Parameters *intermediate-destination-id* — Specifies the intermediate destination identifier, up to 32 characters, maximum.

sla-profile-string

Syntax	sla-profile-string <i>sla-profile-string</i> no sla-profile-string
Context	config>subscr-mgmt>loc-user-db>dhcp>host>ident-strings config>subscr-mgmt>loc-user-db>ppp>host>ident-strings
Description	This command specifies the SLA profile string which is encoded in the identification strings.
Parameters	<i>sla-profile-string</i> — Specifies the SLA profile string, up to 16 characters, maximum.

sub-profile-string

Syntax	sub-profile-string <i>sub-profile-string</i> no sub-profile-string
Context	config>subscr-mgmt>loc-user-db>dhcp>host>ident-strings config>subscr-mgmt>loc-user-db>ppp>host>ident-strings
Description	This command specifies the subscriber profile string which is encoded in the identification strings.
Parameters	<i>sub-profile-string</i> — Specifies the subscriber profile string, up to 16 characters, maximum.

subscriber-id

Syntax	subscriber-id <i>sub-ident-string</i> no subscriber-id
Context	config>subscr-mgmt>loc-user-db>dhcp>host>ident-strings config>subscr-mgmt>loc-user-db>ppp>host>ident-strings
Description	This command specifies the subscriber ID which is encoded in the identification strings.
Parameters	<i>sub-ident-string</i> — Specifies the subscriber ID string, up to 32 characters, maximum.

ipv6-address

Syntax	ipv6-address <i>ipv6-address</i> no ipv6-address
Context	config>subscr-mgmt>loc-user-db>dhcp>host config>subscr-mgmt>loc-user-db>ppp>host
Description	This command configures static DHCPv6 IA-NA address for the host. This address is delegated to the client as /128 via DHCPv6 proxy function within the 7x50. This IP address must not be part of any DHCP pool within internal DHCP server. The no form of the command removes the IPv6 address from the host configuration.
Parameters	<i>ipv6-address</i> — Specifies the IPv6 address.

Triple Play DHCP Configuration Commands

The **no** form of the command removes the static IPv6 SLAAC prefix (PIO) for the host from the configuration.

Default	no ipv6-slaac-prefix
Parameters	<i>ipv6-prefix/prefix-length</i> — Specifies the IPv6 address and prefix length.
Values	<ipv6-prefix/prefix*> : ipv6-prefix x:x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:d.d.d.d x [0..FFFF]H d [0..255]D
	prefix-length 64

ipv6-delegated-prefix-length

Syntax	ipv6-delegated-prefix-length <i>bits</i> no ipv6-delegated-prefix-length
Context	configure>subscr-mgmt>local-user-db>dhcp>host configure>subscr-mgmt>local-user-db>ppp>host
Description	This command allows configuration of delegated prefix length via local user database.
Default	no ipv6-delegated-prefix-length
Parameters	<i>bits</i> — Specifies the delegated prefix length in bits.
Values	48..64.

ipv6-prefix

Syntax	ipv6-prefix <i>ipv6-prefix/prefix-length</i> no ipv6-prefix
Context	config>subscr-mgmt>loc-user-db>dhcp>host
Description	This command configures the IPv6 prefix and length of this host. The no form of the command removes the IPv6 prefix and length of this host from the configuration.
Parameters	<i>ipv6-prefix/prefix-length</i> — Specifies the IPv6 prefix of this host.
Values	ipv6-prefix/prefix: ipv6-prefix x:x:x:x:x:x:x (eight 16-bit pieces) x:x:x:x:x:d.d.d.d x [0..FFFF]H d [0..255]D
	prefix-length 48..64

ipv6-wan-address-pool

Syntax	ipv6-wan-address-pool <i>pool-name</i> no ipv6-wan-address-pool
---------------	--

Context	config>subscr-mgmt>loc-user-db>dhcp>host
Description	This command configures the pool name that will be used in DHCPv6 server for DHCPv6 IA-PA address selection. The no form of the command removes the pool name from the configuration.
Default	no ipv6-wan-address-pool
Parameters	<i>pool-name</i> — Specifies the WAN address pool up to 32 characters in length.

l2tp

Syntax	l2tp
Context	config>subscr-mgmt>loc-user-db>ppp>host
Description	This command configures L2TP for the host.

group

Syntax	group <i>tunnel-group-name</i> [service-id <i>service-id</i>] no group
Context	config>subscr-mgmt>loc-user-db>ppp>host>l2tp
Description	This command configures the L2TP tunnel group. The tunnel-group-name is configured in the config>router>l2tp context. Refer to the 7750 SR OS Router Configuration Guide.
Parameters	<i>tunnel-group-name</i> — Specifies an existing tunnel L2TP group up to 63 characters in length. service-id <i>service-id</i> — [Specifies an existing service ID or service name.
Values	service-id: 1 — 214748364 svc-name: A string up to 64 characters in length.

authentication-policy

Syntax	authentication-policy <i>policy-name</i> no authentication-policy
Context	config>subscr-mgmt>loc-user-db>ppp>host
Description	This command configures the authentication policy for the host. A host name with name “default” will be matched when all other hosts do not match.

pado-delay

Syntax	pado-delay <i>deci-seconds</i> no pado-delay
---------------	---

Triple Play DHCP Configuration Commands

Context	config>subscr-mgmt>loc-user-db>ppp>host
Description	This command configures the delay timeout before sending a PPPoE Active Discovery Offer. (PADO)
Parameters	<i>deci-seconds</i> — Specifies the delay timeout before sending a PADO. Values 1 — 30

mask

Syntax	mask type <i>ppp-match-type</i> {[prefix-string <i>prefix-string</i> prefix-length <i>prefix-length</i>] [suffix-string <i>suffix-string</i> suffix-length <i>suffix-length</i>]} no mask type <i>ppp-match-type</i>
Context	config>subscr-mgmt>loc-user-db>ppp
Syntax	mask type <i>dhcp-match-type</i> {[prefix-string <i>prefix-string</i> prefix-length <i>prefix-length</i>] [suffix-string <i>suffix-string</i> suffix-length <i>suffix-length</i>]} no mask type <i>dhcp-match-type</i>
Context	config>subscr-mgmt>loc-user-db>dhcp
Description	This command configures the mask.
Parameters	<i>ppp-match-type</i> — Specifies the sub-option inserted by the PPPoE intermediate agent. Values circuit-id, remote-id, service-name, username <i>dhcp-match-type</i> — The data type represents the type of matching done to identify a DHCP host. Values circuit-id , option60 , remote-id , sap-id , string , system-id prefix-string <i>prefix-string</i> — Specifies a substring that is stripped of the start of the incoming circuit ID before it is matched against the value configured in the DHCP or PPPOE circuit ID. This string can only contain printable ASCII characters. The “*” character is a wildcard that matches any substring. If a “\” character is masked, use the escape key so it becomes “\\”. Values 127 characters maximum , *' is wildcard. prefix-length <i>prefix-length</i> — Specifies the number of characters to remove from the start of the incoming circuitId before it is matched against the value configured in the circuit ID. Values 1— 127 suffix-string <i>suffix-string</i> — Specifies a substring that is stripped of the end of the incoming circuit ID before it is matched against the value configured in circuit ID. This string can only contain printable ASCII characters. The “*” character is a wildcard that matches any substring. If a “\” character is masked, use the escape key so it becomes “\\”. Values 127 characters maximum suffix-length <i>suffix-length</i> — Specifies the number of characters to remove from the end of the incoming circuit ID before it is matched against the value configured in the circuit ID. Values 1— 127

match-list

Syntax	match-list <i>dhcp-match-type-1</i> [<i>dhcp-match-type-2...</i> (up to 4 max)] no match-list
Context	config>subscr-mgmt>loc-user-db>dhcp config>subscr-mgmt>loc-user-db>ppp
Description	This command specifies the type of matching done to identify a host. There are different match-types for PPPoE hosts of which a maximum of 3 can be specified (4 for DHCP)
Default	no match-list
Parameters	<i>dhcp-match-type-x</i> — Specifies up to four matching types to identify a DHCP host. Values circuit-id, mac, remote-id, sap-id, encap-tag-range, service-id, string, system-id, option60

password

Syntax	password { ignore chap <i>string</i> pap <i>string</i> } [hash hash2] no password
Context	config>subscr-mgmt>loc-user-db>ppp>host
Description	This command specifies a password type or configures password string for pap or chap . The pap and chap passwords are stored in a hashed format in the config files. The hash hash2 optional keywords are used for config execution. This command will only be interpreted if the local user database is connected directly to the PPPoE node under the VPRN/IES group interface. It is not used if the local user database is accessed by a local DHCP server.
Parameters	ignore — Specifies that the password will be ignored, in which case authentication will always succeed, independent of the password used by the PPPoE client. The client must still perform authentication. chap <i>string</i> — Specifies that the password for Challenge-Handshake Authentication Protocol (CHAP) is used. Only a password received with the CHAP protocol will be accepted. pap <i>string</i> — Specifies that the Password Authentication Protocol (PAP) is used. Only a password received with the PAP protocol will be accepted, even though the CHAP protocol will be proposed to the client first because it is unknown at the time of the offer which password type will be allowed to the client. hash hash2 — Specifies hashing scheme.

retail-service-id

Syntax	retail-service-id <i>service-id</i> no retail-service-id
Context	config>subscr-mgmt>loc-user-db>ppp>host

Triple Play DHCP Configuration Commands

Description This command indicates the service ID of the retailer VPRN service to which this session belongs. If the value of this object is non-zero, the session belongs to a retailer VPRN.

The **no** form of the command removes the service ID from the configuration.

Default no retail-service-id

Parameters *service-id* — Specifies the the retailer service ID.

Values

service-id:	1 — 2147483647
service-name:	Service name up to 64 characters in length.

MLPPP on LNS Commands

accept-mrru

Syntax	[no] accept-mrru
Context	configure>subscr-mgt>ppp-policy>mlppp
Description	<p>This command is applicable only to LAC. MRRU option is an indication that the session is of MLPPPoX type. The 7750 LAC will never initiate MRRU option in LCP negotiation process. However, it will respond to MRRU negotiation request by the client.</p> <p>This command provides an option to specifically enable or disable negotiation of MLPPPoX on a capture SAP level or on a group-interface level.</p>
Default	no accept-mrru — The MRRU option in LCP will not be negotiated by LAC.

admin-state

Syntax	admin-state {up down} no admin-state
Context	configure>router>l2tp>group>tunnel>mlppp configure>service>vpn>l2tp>group>tunnel>mlppp
Description	<p>This command is applicable only to LNS.</p> <p>The tunnel can be explicitly activated (assuming that the parent group is in a no shutdown state) or deactivated by the up and down keywords.</p> <p>If case that there is no admin-state configured, the tunnel will inherit its administrative state from its parent (group).</p>
Default	<p>no admin-state — Tunnel administrative state is inherited from the group.</p> <p>up — Tunnel is in administratively up.</p> <p>down — Tunnel is administratively down.</p>

encap-offset

Syntax	encap-offset [type <i>encap-type</i>] no encap-offset
Context	configure>subscriber-mgmt>local-user-db>ppp>host>access-loop
Description	<p>This command is applicable within the LAC/LNS context. It provides the last mile link encapsulation information that is needed for proper (shaping) rate calculations and interleaving delay in the last mile.</p> <p>The encapsulation value will be taken from the following sources in the order of priority:</p>

Triple Play DHCP Configuration Commands

- Statically provisioned value in local user database (LUDB).
- RADIUS
- PPPoE tags on LAC or ICRQ message (RFC 5515) on LNS

In case that the encapsulation information is not provided by any of the existing means (LUDB, RADIUS, AVP signaling, PPPoE Tags), then by default pppoea-null encapsulation will be in effect.

The following values are supported encapsulation values on LNS in the 7750.

encap-type:

pppoa-llc LLC (NLPID) PPPoA encapsulation.
pppoa-null VC-MUX PPPoA encapsulation.
pppoeoa-llc LLC/SNAP based bridged Ethernet PPPoEoA encapsulation without FCS.
pppoeoa-llc-fcs LLC/SNAP based bridged Ethernet PPPoEoA encapsulation with FCS.
pppoeoa-null VC-MUX PPPoEoA encapsulation without FCS.
pppoeoa-null-fcs VC-MUX PPPoEoA encapsulation with FCS.
pppoe PPPoE encapsulation.
pppoe-tagged Tagged PPPoE Encapsulation.

The values are not supported encapsulation values on LNS in the 7750.

pppoeoa-llc-tagged
pppoeoa-llc-tagged-fcs
pppoeoa-null-tagged
pppoeoa-null-tagged-fcs
ipoa-llc
ipoa-null
ipoeoa-llc
ipoeoa-llc-fcs
ipoeoa-llc-tagged
ipoeoa-llc-tagged-fcs
ipoeoa-null
ipoeoa-null-fcs
ipoeoa-null-tagged
ipoeoa-null-tagged-fcs
ipoe
ipoe-tagged

Default no encap-offset No offset is configured.

endpoint

Syntax **endpoint ip** *ip-address*
endpoint mac *ieee-address*
endpoint system-ip
endpoint system-mac
no endpoint

Context configure>router>l2tp>group>mlppp
configure>router>l2tp>group>tunnel>mlppp
configure>service>vprn>l2tp>group>mlppp
configure>service>vprn>l2tp>group>tunnel>mlppp
configure>subscr-mgt>ppp-policy>mlppp

Description	<p>When configured under the l2tp hierarchy, this command is applicable to LNS.</p> <p>Within the ppp-policy, this command is applicable only to LAC.</p> <p>The endpoint, according to RFC 1990, represents the system transmitting the packet. It is used during MLPPPoX negotiation phase to distinguish this peer from all others.</p> <p>In the case that the client rejects the endpoint option during LCP negotiation, the LAC and the LNS must be able to negotiate the LCP session without the endpoint option.</p> <p>The no form of this command disables sending endpoint option in LCP negotiation.</p>
Default	no endpoint
Parameters	<p>ip <i>ip-address</i> — Specifies the IPv4 address (class 2)</p> <p>system-ip — Specifies to use the system IPv4 address (class 2)</p> <p>mac <i>ieee-address</i> — Specifies the MAC address of the interface (class 3).</p> <p>system-mac — Specifies to use the MAC address of the system (class 3)</p>

interleave

Syntax	[no] interleave
Context	<pre>configure>router>l2tp>group>mlppp configure>service>vpn>l2tp>group>mlppp</pre>
Description	<p>This command is applicable only to LNS. Interleaving is supported only on MLPPPoX bundles that contain a single member link. If more than one link is present in the MLPPPoX bundle, interleaving will be automatically disabled and a TRAP/log (tmnxMlpppBundleIndicatorsChange) will be generated.</p> <p>The minimum supported rate of the link on which interleaving is performed is 1kbps.</p> <p>If configured at this level, interleaving will be enabled on all tunnels within the group, unless it is explicitly disable per tunnel.</p>
Default	no interleave — Interleaving per group is disabled.

interleave

Syntax	<p>interleave {always never}</p> <p>no interleave</p>
Context	<pre>configure>router>l2tp>group>tunnel>mlppp configure>service>vpn>l2tp>group>tunnel>mlppp</pre>
Description	<p>This command is applicable only to LNS. Interleaving is supported only on MLPPPoX bundles that contain a single member link. If more than one link is present in the MLPPPoX bundle, interleaving will be automatically disabled and a TRAP/log (tmnxMlpppBundleIndicatorsChange) will be generated.</p> <p>The minimum supported rate of the link on which interleaving is performed is 1kbps.</p>

Triple Play DHCP Configuration Commands

Interleaving configured on this level will overwrite the configuration option under the group hierarchy. If the `no` form of the command is configured for interleaving at this level, the interleaving configuration will inherit the configuration option configured under the `l2tp` group.

- Default** no `interleave` — Interleaving configuration is inherited from the group.
- Parameters** **always** — Always perform interleaving on single linked MLPPPoX sessions within this tunnel, regardless of the configuration option for interleaving under the group level.
- never** — Never perform interleaving on single linked MLPPPoX sessions within this tunnel, regardless of the configuration option for interleaving under the group level.

load-balance-method

- Syntax** **load-balance-method** {**session** | **tunnel**}
no load-balance-method
- Context** `configure>router>l2tp>group`
`configure>router>l2tp>group>tunnel`
`configure>service>vprn>l2tp>group`
`configure>service>vprn>l2tp>group>tunnel`
- Description** This command is applicable only to LNS. By default traffic load balancing between the BB-ISAs is based on sessions. Each session is individually assigned to an BB-ISA during session establishment phase.
- By introducing MLPPPoX, all sessions of a bundle must be terminated on the same LNS BB-ISA. This is necessary for two reasons:
- QoS in the carrier IOM has a uniform view of the subscriber
 - a single BB-ISA is responsible for MLPPPoX encapsulation/fragmentation for a given bundle.
- Therefore, if fragmentation is enabled, load-balancing per tunnel must be configured. In the per tunnel load-balancing mode, all sessions within the same tunnel are terminated on the same LNS BB-ISA.
- In the case that we have MLPPPoX sessions with a single member link, both load-balancing methods are valid.
- The **no** form of this command set the per session load balancing.
- Default** `session` — Per session load balancing is enabled by default.
- Parameters** **session** — Traffic load balancing between the LNS BB-ISAs is based on individual PPPoE sessions.
- tunnel** — Traffic load balancing between the LNS BB-ISAs is based on tunnels.

max-fragment-delay

- Syntax** **max-fragment-delay** *mili-seconds*
no max-fragment-delay

Context	configure>router>l2tp>group>mlppp configure>router>l2tp>group>tunnel>mlppp configure>service>vprn>l2tp>group>mlppp configure>service>vprn>l2tp>group>tunnel>mlppp
Description	This command is applicable only to LNS. It determines the maximum fragment delay caused by the transmission that will be imposed on a link. Fragmentation can be used to interleave high priority packet in-between low priority fragments on a MLPPPoX session with a single link or on a MLPPPoX session with multiple links to better load balance traffic over multiple member links.
Default	no max-fragment-delay — Fragmentation is disabled.
Parameters	<i>mili-seconds</i> — Specifies the interval in mili-seconds. Values 5-1000ms

max-link

Syntaxs	max-links <i>max-links</i> no max-links
Context	configure>router>l2tp>group>mlppp configure>router>l2tp>group>tunnel>mlppp configure>service>vprn>l2tp>group>mlppp configure>service>vprn>l2tp>group>tunnel>mlppp
Description	This command is applicable only to LNS. It determines the maximum number of links that can be put in a bundle. Any attempt of a session to join a bundle that is above the max-link limit will be rejected. If interleaving is configured, it is recommended that max-links be set to 1 or a <input type="checkbox"/> <input type="checkbox"/> version of the command is used (no max-links). Both have the same effect. The configuration under the tunnel hierarchy will override the configuration under the group hierarchy. The no form of this command limits the number of links in the bundle to 1.
Default	no max-links — A single link per bundle is allowed.
Parameters	<i>max-links</i> — Specifies the maximum number of links in a bundle. Values 1 — 8

reassemble-timeout

Syntax	reassemble-timeout {{100 1000} milliseconds} no reassemble-timeout
Context	configure>router>l2tp>group>mlppp configure>router>l2tp>group>tunnel>mlppp configure>service>vprn>l2tp>group>mlppp

```
configure>service>vprn>l2tp>group>tunnel>mlppp
```

Description	<p>This command is applicable only to LNS. It determines the time during which the LNS keeps fragments of the same packet in the buffer before it discards them. The assumption is that if the fragments do not arrive within certain time, the chance is that they were lost somewhere in the network. In this case the partial packet cannot be reassembled and all fragments that has arrived up to this point and are stored in the buffer will be discarded in order to free up the buffer. Otherwise, a condition will arise in which partial packets will be held in the buffer until the buffer is exhausted.</p> <p>The configuration under the tunnel hierarchy will override the configuration under the group hierarchy.</p> <p>The no form of this command also sets the time-out to 1000ms.</p>
Default	1000
Parameters	{ {100 1000} milliseconds } — Specifies the reassembly timeout value.

rate-down

Syntax	rate-down rate no rate-down
Context	configure>subscriber-mgmt>local-user-db>ppp>host>access-loop
Description	<p>This command is applicable to LAC and LNS. It provides the last mile link rate in the downstream direction that is needed for proper shaping and calculating the interleaving delay.</p> <p>The rate information in the last mile will be taken from the following sources in the order of priority:</p> <ul style="list-style-type: none">• Statically provisioned value in local user database (LUDB).• RADIUS.• PPPoE tags on LAC or ICRQ message (RFC 5515) /ICCN message (TX Connect Seed) on LNS.
Default	no rate-down
Parameters	<i>rate</i> — Specifies last mile link downstream rate in the access loop
Values	1 — 100000 kbps

short-sequence-numbers

Syntax	[no] short-sequence-numbers
Context	configure>subscr-mgt>ppp-policy>mlppp
Description	<p>This command enables a peer request to send short sequence numbers. This command is applicable to LAC and LNS. By default, MLPPPoX will negotiate 24bit long sequence numbers. This command allows this to be changed to shorter, 12-bit sequence numbers.</p>
Default	short-sequence-numbers

Show Commands

id

Syntax	id <i>service-id</i>
Context	show>service
Description	This command displays information for a particular service-id.
Parameters	<i>service-id</i> — The unique service identification number that identifies the service in the service domain. all — Display detailed information about the service. base — Display basic service information. fdb — Display FDB entries. labels — Display labels being used by this service. sap — Display SAPs associated to the service. sdp — Display SDPs associated with the service. split-horizon-group — Display split horizon group information. stp — Display STP information.

dhcp

Syntax	dhcp
Context	show>router show>service>id
Description	This command enables the context to show DHCP statistics.

dhcp6

Syntax	dhcp6
Context	show>router show>service>id
Description	This command enables the context to show DHCP6 statistics.

lease-state

- Syntax** **lease-state [detail]**
lease-state [detail] interface *interface-name*
lease-state [detail] ipv6-address *ipv6-prefix[/prefix-length]*
lease-state [detail] mac *ieee-address*
- Context** show>service>id>dhcp6
- Description** This command displays DHCP6 lease state related information.

Sample Output

```
*A:Dut-C# show service id 202 dhcp6 lease-state
=====
DHCP lease state table, service 202
=====
IP Address           Mac Address           Sap/Sdp Id           Remaining   Lease   MC
                    LifeTime             Origin              Stdby
-----
1::/120
                    1/1/6                30d33h12m   DHCP
-----
Number of lease states : 1
=====
*A:Dut-C#

*A:Dut-C# show service id 202 dhcp6 lease-state detail
=====
DHCP lease states for service 202
=====
Service ID           : 202
IP Address           : 1::/120
Mac Address          :
Interface            : ip-11.3.202.3
SAP                  : 1/1/6
Remaining Lifetime   : 30d33h12m
Persistence Key      : N/A

Sub-Ident            : ""
Sub-Profile-String   : ""
SLA-Profile-String   : ""
Lease ANCP-String    : ""
Dhcp6 ClientId (DUID): 0101
Dhcp6 IAID           : 1
Dhcp6 IAID Type      : prefix
Dhcp6 Client Ip      : FE80::200:FF:FE00:202

ServerLeaseStart     : 09/01/2002 04:27:00
ServerLastRenew      : 09/01/2002 04:27:00
ServerLeaseEnd       : 10/01/2002 04:27:00
-----
Number of lease states : 1
=====
*A:Dut-C#
```

statistics

Syntax	statistics [sap <i>sap-id</i>] [sdp [<i>sdp-id</i> [: <i>vc-id</i>]]] interface <i>ip-int-name</i>]]
Context	show>service>id>dhcp show>router>dhcp
Description	This command displays statistics for DHCP relay and DHCP snooping. If no IP address or interface name is specified, then all configured interfaces are displayed. If an IP address or interface name is specified, then only data regarding the specified interface is displayed.
Parameters	<i>sap-id</i> — Specifies the physical port identifier portion of the SAP definition. See Common Service Commands on page 1740 for <i>sap-id</i> command syntax. <i>sdp-id</i> — The SDP ID to be shown. Values 1— 17407 <i>vc-id</i> — The virtual circuit ID on the ID to be shown. Values 1 — 4294967295 <i>ip-int-name</i> <i>ip-address</i> — Displays statistics for the specified IP interface.
Output	Show DHCP Statistics Output — The following table describes the output fields for DHCP statistics.

Label	Description
Received Packets	The number of packets received from the DHCP clients.
Transmitted Packets	The number of packets transmitted to the DHCP clients.
Received Malformed Packets	The number of malformed packets received from the DHCP clients.
Received Untrusted Packets	The number of untrusted packets received from the DHCP clients.
Client Packets Discarded	The number of packets received from the DHCP clients that were discarded.
Client Packets Relayed	The number of packets received from the DHCP clients that were forwarded.
Client Packets Snooped	The number of packets received from the DHCP clients that were snooped.
Server Packets Discarded	The number of packets received from the DHCP server that were discarded.
Server Packets Relayed	The number of packets received from the DHCP server that were forwarded.
Server Packets Snooped	The number of packets received from the DHCP server that were snooped.

Sample Output

```
A:ALA-A# show router 1000 dhcp statistics
=====
DHCP Global Statistics (Service: 1000)
=====
Rx Packets                : 16000
Tx Packets                : 15041
Rx Malformed Packets     : 0
Rx Untrusted Packets     : 0
Client Packets Discarded  : 423
Client Packets Relayed    : 0
Client Packets Snooped    : 0
Client Packets Proxied (RADIUS) : 0
Client Packets Proxied (Lease-Split) : 0
Server Packets Discarded  : 0
Server Packets Relayed    : 0
Server Packets Snooped    : 0
DHCP RELEASEs Spoofed    : 0
DHCP FORCERENEWS Spoofed : 0
=====
A:ALA-A#
```

summary

- Syntax** **summary**
- Context** show>router>dhcp
show>service>id>dhcp
- Description** Display the status of the DHCP Relay and DHCP Snooping functions on each interface.
- OutputOutput** **Show DHCP Summary Output** — The following table describes the output fields for DHCP summary.

Label	Description
Interface Name	Name of the router interface.
ARP Populate	Indicates whether ARP populate is enabled.
Used/Provided	Indicates the number of used and provided DHCP leases.
Info Option	Indicates whether Option 82 processing is enabled on the interface.
Admin State	Indicates the administrative state.

Sample Output

```
A:ALA-48>show>router>dhcp# summary
=====
Interface Name            Arp    Used/    Info    Admin
                          Populate Provided    Option    State
-----
ccaiesif                No        0/0        Keep    Down
```

```

ccanet6                No          0/0          Keep        Down
iesBundle              No          0/0          Keep        Up
spokeSDP-test         No          0/0          Keep        Down
test                   No          0/0          Keep        Up
test1                  No          0/0          Keep        Up
test2                  No          0/0          Keep        Up
testA                  No          0/0          Keep        Up
testB                  No          0/0          Keep        Up
testIES                No          0/0          Keep        Up
to-web                 No          0/0          Keep        Up

```

```
-----
Interfaces: 11
=====
```

```
A:ALA-48>show>router>dhcp#
```

statistics

- Syntax** **statistics [interface *ip-int-name*]**
- Context** **show>router>dhcp6**
show>service>id>dhcp6
- Description** This command displays statistics for DHCP relay and DHCP snooping.

Sample Output

```

A:ALA-A# show router 1000 dhcp statistics
=====
DHCP Global Statistics (Service: 1000)
=====
Rx Packets                : 16000
Tx Packets                : 15041
Rx Malformed Packets     : 0
Rx Untrusted Packets     : 0
Client Packets Discarded : 423
Client Packets Relayed   : 0
Client Packets Snooped   : 0
Client Packets Proxied (RADIUS) : 0
Client Packets Proxied (Lease-Split) : 0
Server Packets Discarded : 0
Server Packets Relayed   : 0
Server Packets Snooped   : 0
DHCP RELEASEs Spoofed   : 0
DHCP FORCERENEWs Spoofed : 0
=====
A:ALA-A#

```

summary

- Syntax** **summary**
- Context** **show>router>dhcp6**
show>service>id>dhcp6

Triple Play DHCP Configuration Commands

- Description** Display the status of the DHCP6 relay and DHCP snooping functions on each interface.
- Output** **Show DHC6P Summary Output** — The following table describes the output fields for DHCP6 summary.

Label	Description
Interface Name	Name of the router interface.
Nbr. Resol.	Indicates whether or not neighbor resolution is enabled.
Used/Provided	Indicates the number of used and provided DHCP leases.
Admin State	Indicates the administrative state.
Oper State	Indicates the operational state.

Sample Output

```
*A:Dut-C# show router dhcp6 summary
=====
DHCP6 Summary (Router: Base)
=====
Interface Name          Nbr      Used/Max Relay   Admin  Oper Relay
  SapId                Resol.   Used/Max Server  Admin  Oper Server
-----
ip-1.1.1.10             No        0/0              Down   Down
  sap:1/1/5              0/8000
ip-11.3.202.3           No        0/0              Down   Down
  sap:1/1/6              1/8000
                          Up     Up
-----
Interfaces: 2
=====
*A:Dut-C#
```

local-dhcp-server

- Syntax** **local-dhcp-server** *server-name*
- Context** show>router>dhcp
- Description** This command displays local DHCP server information.
- Parameters** *server-name* — Specifies information about the local DHCP server.

Sample Output

```
*A:ALA-48>show>router>dhcp>local-dhcp-server# declined-addresses pool test
=====
Declined addresses for server test Base
=====
Pool                    Subnet      IP Address
PPPoE User Name/       Time        MAC Address   Type
Option 82 Circuit ID
-----
```

```
No Matching Entries
=====
*A:ALA-48>show>router>dhcp>local-dhcp-server#
```

associations

Syntax	associations
Context	show>router>dhcp>local-dhcp-server show>router>dhcp
Description	This command displays the interfaces associated with this DHCP or DHCP6 server.

Sample Output

```
*A:SUB-Dut-A# show router dhcp local-dhcp-server dhcpS1 associations
=====
DHCP server s1 router 3
=====
Associations                               Admin
-----
tosim5                                     Up
=====
*A:SUB-Dut-A#
```

declined-addresses

Syntax	declined-addresses <i>ip-address[/mask]</i> [detail] declined-addresses pool <i>pool-name</i>
Context	show>router>dhcp>local-dhcp-server
Description	This command display information about declined addresses.
Parameters	pool <i>pool-name</i> — Specifies a DHCP pool name on the router. <i>ip-address</i> — Specifies the IP address of the DNS server. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets). detail — Displays detailed information.

Sample Output

```
*A:ALA-48>show>router>dhcp>local-dhcp-server# declined-addresses pool test
=====
Declined addresses for server test Base
=====
Pool                               Subnet           IP Address
PPPoE User Name/                   Time             MAC Address      Type
Option 82 Circuit ID
-----
No Matching Entries
=====
```

Triple Play DHCP Configuration Commands

```
*A:ALA-48>show>router>dhcp>local-dhcp-server#
```

free-addresses

- Syntax** **free-addresses** *ip-address*[/*mask*]
free-addresses summary [**subnet** *ip-address*[/*mask*]]
free-addresses pool *pool-name*
- Context** show>router>dhcp>local-dhcp-server
- Description** This command displays the free addresses in a subnet.
- Parameters** **pool** *pool-name* — Specifies a DHCP pool name on the router.
subnet *subnet* — Specifies a subnet of IP addresses that are served from the pool.
summary — Displays summary output of the free addresses.

Sample Output

```
*A:ALA-48>show>router>dhcp>local-dhcp-server# free-addresses pool test subnet
1.0.0.0/24
=====
Free addresses in subnet 1.0.0.0/24
=====
IP Address
-----
No. of free addresses: 0
=====
*A:ALA-48>show>router>dhcp>local-dhcp-server#
```

interface-id-mapping

- Syntax** **interface-id-mapping**
- Context** show>router>dhcp6>local-dhcp-server
- Description** This command displays the DHCP6 interface-id mappings.

Sample Output

```
show router 600 dhcp6 local-dhcp-server "d6" interface-id-mapping
=====
Interface-ID Mappings for DHCPv6 server d6
=====
Mapped Prefix      : 2001:AAAA::/64
Relay Interface ID : 1/1/10
LDRA Interface ID  : (Not Specified)
Active Leases      : 2001:AAAA::1 (stable)
=====
1 prefix found
=====
```

leases

Syntax	leases leases <i>ip-address[/mask]</i> address-from-user-db [detail] leases <i>ip-address[/mask]</i> dhcp-host <i>dhcp-host-name</i> [detail] leases <i>ip-address[/mask]</i> ppp-host <i>ppp-host-name</i> [detail] leases <i>ip-address[/mask]</i> [detail]
Context	show>router>dhcp>local-dhcp-server
Description	This command displays the DHCP leases.
Parameters	<i>ip-address</i> — Specifies the base IP address of the subnet. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets). <i>mask</i> — The subnet mask in dotted decimal notation. Values 0 — 32 address-from-user-db [detail] — Displays only leases that have ip-addresses from the local-user-db. dhcp-host <i>dhcp-host-name</i> [detail] — Shows all leases that match a certain DHCP host from the local-user-db. ppp-host <i>ppp-host-name</i> [detail] — Displays all leases that match a certain PPPoE host from the local-user-db. detail — Displays detailed information of all leases that fall into the indicated subnet. The command with no parameters will show all leases from the local-user-db.

Sample Output

```
*A:ALA-48>show>router>dhcp>local-dhcp-server# leases ip-address 1.0.0.4
=====
Leases for DHCP server test router Base
=====
IP Address      Lease State      Mac Address      Remaining Clnt
  PPPoE user name/Opt82 Circuit Id      LifeTime  Type
-----
No leases found
*A:ALA-48>show>router>dhcp>local-dhcp-server#
```

leases

Syntax	leases [<i>ipv6-address/prefix-length</i>] [<i>type</i>] [<i>state</i>] [detail]
Context	show>router>dhcp6>local-dhcp-server
Description	This command displays the DHCP6 leases.
Parameters	<i>ipv6-address</i> — Specifies the base IP address of the subnet. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets).

Triple Play DHCP Configuration Commands

mask — The subnet mask in dotted decimal notation.

Values 0 — 32

type — Displays the lease type.

Values pd, wan-host

state — Displays the state of the lease.

Values advertised, remove-pending, held

detail — Displays detailed information of all leases that fall into the indicated subnet.

The command with no parameters will show all leases from the local-user-db.

Sample Output

```
show router 600 dhcp6 local-dhcp-server "d6" leases
=====
Leases for DHCPv6 server d6
=====
IP Address/Prefix                               Lease State      Remaining      Fail
  Link-local Address                             LifeTime         Ctrl
-----
2001:AAAA::1/128
  FE80::220:FCFF:FE1E:CD52                       stable           23h58m52s     local
-----
1 leases found
=====
```

pool-ext-stats

Syntax **pool-ext-stats** [*pool-name*]

Context show>router>dhcp>server

Description This command displays extended statistics per DHCPv4 pool in local DHCPv4 server.

The following statistics are included in output:

- The number of stable leases in the pool
- The number of provisioned address in the pool
- The number of used address in the pool
- The number of free address in the pool
- The percentage of used address
- The percentage of free address

For each statistic (except for Provisioned Addresses), there is current value and peak value, peak value is the highest value since pool creation or last reset via the **clear router *rt-id* dhcp local-dhcp-server *svr-name* pool-ext-stats** command.

Parameters *pool-name* — Specify the name of DHCPv4 local server pool.

Sample Output

```

show router 500 dhcp local-dhcp-server "d4" pool-ext-stats "pool-1"
=====
Extended pool statistics for server "d4"
=====
-----
Current          Peak          TimeStamp
-----
Pool              pool-1
Local:
  Stable Leases   0             0             01/07/2013 19:07:11
  Provisioned Addresses 101
  Used Addresses  0             0             01/07/2013 19:07:11
  Free Addresses  101           101           01/07/2013 19:07:11
  Used Pct        0             0             01/07/2013 19:07:11
  Free Pct        100           100           01/07/2013 19:07:11
Last Reset Time  01/07/2013 19:07:11
-----
Number of entries      1
=====

```

pool-ext-stats

Syntax `pool-ext-stats [pool-name]`

Context `show>router>dhcp6>server`

Description This command displays extended statistics per DHCPv6 pool in local DHCPv6 server.

The following statistics are included in output:

- The number of stable leases in the pool
- The number of provisioned /64 address block in the pool
- The number of used /64 address block in the pool
- The number of free /64 address block in the pool
- The percentage of used address (with /64 address block)
- The percentage of free address (with /64 address block)

For each statistic (except for Provisioned Addresses), there is current value and peak value, peak value is the highest value since pool creation or last reset via command “clear router <rt-id> dhcp6 local-dhcp-server <svr-name> pool-ext-stats”.

Parameters *pool-name* — Specify the name of DHCPv6 local server pool.

Sample Output

```

show router 500 dhcp6 local-dhcp-server "d6" pool-ext-stats "pool-v6"
=====
Extended pool statistics for server "d6"
=====
-----
Current          Peak          TimeStamp
-----
Pool              pool-v6
Local:
  Stable Leases   0             0             01/07/2013 19:54:52
  Provisioned Blks 4
  Used Blks       0             0             01/07/2013 19:54:52

```

Triple Play DHCP Configuration Commands

```
Free Blks          4          4          01/07/2013 19:54:52
Used Pct           0          0          01/07/2013 19:54:52
Free Pct           100        100        01/07/2013 19:54:52
Last Reset Time    01/07/2013 19:54:52
-----
Number of entries  1
=====
```

prefix-ext-stats

Syntax **prefix-ext-stats** *ipv6-address/prefix-length*
prefix-ext-stats **pool** *pool-name*

Context show>router>dhcp6>server

Description This command displays extended statistics per DHCPv6 prefix in local DHCPv6 server.

The following statistics are included in output:

- The number of stable leases in the prefix
- The number of provisioned /64 address block in the prefix
- The number of used /64 address block in the prefix
- The number of free /64 address block in the prefix
- The percentage of used address (with /64 address block)
- The percentage of free address (with /64 address block)

For each statistic (except for “Provisioned Addresses”), there is current value and peak value, peak value is the highest value since prefix creation or last reset via command “clear router <rt-id> dhcp6 local-dhcp-server <svr-name> prefix-ext-stats”.

When parameter “pool” is used, the statistics of each prefix in the pool will be displayed.

Parameters *ipv6-address/prefix-length* — Specifies the IPv6 prefix

pool-name — The name of DHCPv6 local server pool

Sample Output

```
show router 500 dhcp6 local-dhcp-server "d6" prefix-ext-stats 2001:ABCD::/62
=====
Extended statistics for prefix 2001:ABCD::/62
=====
                Current          Peak          TimeStamp
-----
Local:
  Failover Oper State    Active
  Stable Leases          0          0          01/07/2013 19:54:52
  Provisioned Blks       4
  Used Blks              0          0          01/07/2013 19:54:52
  Free Blks              4          4          01/07/2013 19:54:52
  Used Pct               0          0          01/07/2013 19:54:52
  Free Pct               100        100        01/07/2013 19:54:52
  Last Reset Time        01/07/2013 19:54:52
-----
Number of entries      1
```

subnet-ext-stats

Syntax **subnet-ext-stats** *ip-address[/mask]*
subnet-ext-stats pool *pool-name*

Context show>router>dhcp>server

Description This command displays extended statistics per DHCPv4 subnet in local DHCPv4 server.

The following statistics are included in output:

- The number of stable leases in the subnet
- The number of provisioned address in the subnet
- The number of used address in the subnet
- The number of free address in the subnet
- The percentage of used address
- The percentage of free address

For each statistic (except for Provisioned Addresses), there is current value and peak value, peak value is the highest value since subnet creation or last reset via the **clear router *rt-id* dhcp local-dhcp-server *svr-name* subnet-ext-stats** command.

When parameter pool is used, the statistics of each subnet in the pool will be displayed.

Parameters *ip-address[/mask]* — Specifies the subnet

pool-name — The name of local DHCPv4 server pool

Sample Output

```
show router 500 dhcp local-dhcp-server "d4" subnet-ext-stats 220.10.10.0/24
=====
Extended statistics for subnet 220.10.10.0/24
=====

```

	Current	Peak	TimeStamp

Local:			
Stable Leases	1	1	01/07/2013 19:38:36
Provisioned Addresses	101		
Used Addresses	1	1	01/07/2013 19:38:36
Free Addresses	100	100	01/07/2013 19:38:36
Used Pct	1	1	01/07/2013 19:38:36
Free Pct	99	99	01/07/2013 19:38:36
Last Reset Time			01/07/2013 19:07:11

Number of entries	1		
=====			

Triple Play DHCP Configuration Commands

server-stats

Syntax	server-stats
Context	show>router>dhcp>server
Description	This command displays server statistics.

Sample Output

```
*A:SUB-Dut-A# show router dhcp local-dhcp-server dhcpS1 server-stats
=====
Statistics for DHCP Server dhcpS1 router Base
=====
Rx Discover Packets           : 0
Rx Request Packets           : 0
Rx Release Packets           : 0
Rx Decline Packets           : 0
Rx Inform Packets            : 0

Tx Offer Packets              : 0
Tx Ack Packets                : 0
Tx Nak Packets                : 0
Tx Forcerenew Packets        : 0

Client Ignored Offers        : 0
Leases Timed Out             : 0

Dropped Bad Packet           : 0
Dropped Invalid Type         : 0
Dropped No User Database     : 0
Dropped Unknown Host         : 0
Dropped User Not Allowed     : 0
Dropped Lease Not Ready      : 0
Dropped Lease Not Found      : 0
Dropped Not Serving Pool     : 0
Dropped Invalid User         : 0
Dropped Overload             : 0
Dropped Persistence Overload : 0
Dropped Generic Error        : 0
Dropped Destined To Other    : 0
Dropped Address Unavailable  : 0
Dropped Max Leases Reached   : 0
Dropped Server Shutdown      : 0
Dropped No Subnet For Fixed IP: 0

=====
*A:SUB-Dut-A#
```

subnet-stats

Syntax	subnet-stats ip-address[/mask] subnet-stats pool pool-name
Context	show>router>dhcp>server
Description	This command displays subnet statistics.

Sample Output

```
*A:SUB-Dut-A# show router dhcp local-dhcp-server dhcpS2 subnet-stats pool POOL2
=====
Statistics for pool POOL2
=====
Subnet                Free          Offered       Stable
                      FRPending    RemPending   Declined
-----
2.0.0.0/8             16384         0             0
                      0             0             0
-----
No. of entries: 1
=====
*A:SUB-Dut-A#
```

summary

Syntax	summary
Context	show>router>dhcp>server
Description	This command displays DHCP summary information.

Sample Output

```
*A:SUB-Dut-A# show router dhcp local-dhcp-server dhcpS2 summary
=====
DHCP server dhcpS2  router Base
=====
dhcpS2-POOL2
Admin State          : inService
Persistency State   : ok
User Data Base       : N/A
Use gateway IP address : disabled
Send force-renewals  : disabled
-----
Pool name : POOL2
-----
Subnet                Free          Stable        Declined     Offered       Remove-pending
-----
2.0.0.0/8             16384         0             0            0             0
-----
Totals for pool       16384         0             0            0             0
-----
Totals for server     16384         0             0            0             0
-----
Associations                               Admin
-----
No associations found
=====
*A:SUB-Dut-A#
```

Triple Play DHCP Configuration Commands

servers

Syntax	servers
Context	show>router>dhcp
Description	This command lists the local DHCP servers.

Sample Output

```
*A:ALA-49>show>router>dhcp# servers
=====
Overview of DHCP Servers
=====
Active Leases:      0
Maximum Leases:    159744

Router              Server                               Admin State
-----
Router: Base        base_router_dhcp_server          outOfService
Service: 3          s1                                inService
=====
*A:ALA-49>show>router>dhcp#
```

servers

Syntax	servers
Context	show>router>dhcp>local-dhcp-server>statistics
Description	This command displays server statistics.

Sample Output

```
*A:ALA-48>show>router>dhcp>local-dhcp-server>statistics# servers
=====
Statistics for DHCP Server test router Base
=====
Rx Discover Packets      : 0
Rx Request Packets      : 0
Rx Release Packets      : 0
Rx Decline Packets      : 0
Rx Inform Packets       : 0

Tx Offer Packets        : 0
Tx Ack Packets          : 0
Tx Nack Packets         : 0
Tx Forcerenew Packets   : 0

Client ignored offers   : 0

Dropped Bad Packet      : 0
Dropped Invalid Type    : 0
Dropped Unknown Host    : 0
Dropped User Not Allowed: 0
Dropped Lease Not Ready : 0
```

```

Dropped Lease Not Found : 0
Dropped Not Serving Pool: 0
Dropped Invalid User    : 0
Dropped Generic Error   : 0
=====
*A:ALA-48>show>router>dhcp>local-dhcp-server>statistics#

```

subnet

- Syntax** `subnet pool pool-name [subnet subnet]`
- Context** `show>router>dhcp>local-dhcp-server>statistics`
- Description** This command displays subnet statistics.
- Parameters** `pool pool-name` — Specifies the pool name on the router.
`subnet subnet` — Specifies a subnet of IP addresses that are served from the pool.

Sample Output

```

*A:ALA-48>show>router>dhcp>local-dhcp-server>statistics# subnet pool test
=====
Statistics for pool test
=====
Subnet                Free      Offered      Stable
                    FRPending  RemPending  Declined
-----
1.0.0.0/24            0          0            0
                    0          0            0
-----
No. of entries: 1
=====
*A:ALA-48>show>router>dhcp>local-dhcp-server>statistics#

```

lease-state

- Syntax** `lease-state [[sap sap-id] | [sdp dp-id:vc-id] | [interface interface-name] | [ip-address ip-address[/mask]>] | [mac ieee-address]] [detail]`
- Context** `show>service>id>dhcp`
- Description** This command displays DHCP lease state related information.
- Parameters** `sap-id` — Specifies the physical port identifier portion of the SAP definition. See [Common Service Commands on page 1740](#) for `sap-id` command syntax.
- `sdp-id` — The SDP ID to be shown.
- Values** 1 — 17407
- `vc-id` — The virtual circuit ID on the SDP ID to be shown.
- Values** 1 — 4294967295

Triple Play DHCP Configuration Commands

servers

Syntax	servers
Context	show>router>dhcp
Description	This command lists the local DHCP servers.

Sample Output

```
*A:SUB-Dut-A# show router dhcp servers
=====
Overview of DHCP Servers
=====
Active Leases:      0
Maximum Leases:    159744

Router              Server              Admin State
-----
Router: Base        dhcpS1              inService
Router: Base        dhcpS10             inService
Router: Base        dhcpS100            inService
Router: Base        dhcpS101            inService
Router: Base        dhcpS102            inService
Router: Base        dhcpS103            inService
Router: Base        dhcpS104            inService
Router: Base        dhcpS105            inService
Router: Base        dhcpS106            inService
Router: Base        dhcpS107            inService
Router: Base        dhcpS108            inService
Router: Base        dhcpS109            inService
Router: Base        dhcpS11             inService
Router: Base        dhcpS110            inService
Router: Base        dhcpS111            inService
Router: Base        dhcpS112            inService
Router: Base        dhcpS113            inService
Router: Base        dhcpS114            inService
Router: Base        dhcpS115            inService
Router: Base        dhcpS116            inService
Router: Base        dhcpS117            inService
Router: Base        dhcpS118            inService
Router: Base        dhcpS119            inService
...
Service: 1022       dhcpS1022           inService
Service: 1023       dhcpS1023           inService
Service: 1024       dhcpS1024           inService
=====
*A:SUB-Dut-A#

*A:SUB-Dut-A#
=====
Overview of DHCP Servers
=====
Active Leases: 0
Maximum Leases: 159744

Router Server Admin State
-----
Router: Base base_router_dhcp_server outOfService
```

```
Service: 3 s1 inService
```

=====

remap-lease-state

Syntax	remap-lease-state old-mac <i>ieee-address</i> mac <i>ieee-address</i> remap-lease-state sap <i>sap-id</i> [<i>mac ieee-address</i>]
Context	tools>perform>subscr-mgmt
Description	<p>This command allows the remapping of all existing hosts if network card on CMTS/WAC side is changed is required.</p> <p>When this command is executed, the following restrictions apply</p> <ul style="list-style-type: none"> • When sap is taken, all leases associated with the SAP are re-written. <ul style="list-style-type: none"> → For a SAP with a configured MAC in lease-populate command, this MAC will be taken. → For a SAP without a configured MAC the MAC from tools command will be taken. → For a SAP without a configured MAC and no MAC in tools command no action will be perform. • When using the old-mac option, providing a new MAC <i>ieee-address</i> is mandatory. <p>This command is applicable only when dealing with DHCP lease states which were instantiated using l2header mode of DHCP operation.</p>
Parameters	<p>old-mac <i>ieee-address</i></p> <p>old-mac <i>ieee-address</i> — specifies the old MAC address to remap.</p> <p>mac <i>ieee-address</i> — Specifies that the provisioned MAC address will be used in the anti-spoofing entries for this SAP when l2-header is enabled. The parameter may be changed mid-session. Existing sessions will not be re-programmed unless a tools perform command is issued for the lease.</p> <p>sap <i>sap-id</i> — Specifies the physical port identifier portion of the SAP definition. See Common Service Commands on page 1740 for <i>sap-id</i> command syntax.</p> <p>When configured, the SAP parameter will remap all MAC addresses of DHCP lease states on the specified SAP. When no optional MAC parameter is specified, the sap sap-id command remaps all MAC addresses of lease states towards the MAC address specified in the l2-header configuration.</p>

Clear Commands

dhcp

Syntax	dhcp
Context	clear>router
Description	This command enables the context to clear and reset DHCP entities.

dhcp6

Syntax	dhcp6
Context	clear>router
Description	This command enables the context to clear and reset DHCP6 entities.

lease-state

Syntax	lease-state [no-dhcp-release] lease-state [port port-id] [inter-dest-id intermediate-destination-id] [no-dhcp-release] lease-state [port port-id] no-inter-dest-id [no-dhcp-release] lease-state ip-address ip-address [no-dhcp-release] lease-state mac ieee-address no-dhcp-release lease-state sap sap-id [no-dhcp-release] lease-state sdp sdp-id:vc-id [no-dhcp-release]
Context	clear>service>id>dhcp
Description	This command clears DHCP lease state information.
Parameters	<p>no-dhcp-release — Clears the state without sending the DHCP release message.</p> <p>ip-address ip-address — Clears the DHCP IP address lease state information. The <i>ip-address</i> portion of the address command specifies the IP host address that will be used by the IP interface within the subnet. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets).</p> <p>mac ieee-address — Clears DHCP MAC address lease state information. The 48-bit MAC address for the static ARP in the form aa:bb:cc:dd:ee:ff or aa-bb-cc-dd-ee-ff where aa, bb, cc, dd, ee, and ff are hexadecimal numbers. Allowed values are any non-broadcast, non-multicast MAC and non-IEEE reserved MAC addresses.</p> <p>sap sap-id — clears DHCP SAP lease state information. See Common Service Commands on page 1740 for <i>sap-id</i> command syntax.</p>

sdp-id — Clears DHCP SDP lease state information.

Values 1 — 17407

port-id — Clears DHCP port lease state information. [Common Service Commands on page 1740](#)

intermediate-destination-id — Specifies the intermediate destination identifier which is encoded in the identification strings.

vc-id — Clears virtual circuit ID information on the specified SDP.

Values 1 — 4294967295

local-dhcp-server

Syntax	local-dhcp-server <i>server-name</i>
Context	clear>router>dhcp
Description	This command clears DHCP server data.
Parameters	<i>server-name</i> — Clears data for the specified local DHCP server.

declined-addresses

Syntax	declined-addresses <i>ip-address[/mask]</i> declined-addresses pool <i>pool-name</i>
Context	clear>router>dhcp>local-dhcp-server
Description	This command clears declined DHCP addresses.
Parameters	<i>pool-name</i> — Specifies the declined pool name. <i>ip-address[/mask]</i> — Specifies the declined IP address and mask.

leases

Syntax	leases <i>ip-address[/mask]</i> [offered]
Context	clear>router>dhcp>local-dhcp-server
Description	This command clears DHCP leases.
Parameters	<i>ip-address[/mask]</i> — Clears the specified IP address and mask. offered — Clears leases in offered state only.

pool-ext-stats

Syntax	pool-ext-stats [<i>pool-name</i>]
---------------	--

Triple Play DHCP Configuration Commands

Context	clear>router>dhcp>local-dhcp-server
Description	This command clears extended pool statistics.
Parameters	<i>pool-name</i> — Specifies the pool name.

server-stats

Syntax	server-stats
Context	clear>router>dhcp>local-dhcp-server
Description	This command clears all server statistics.

subnet-ext-stats

Syntax	subnet-ext-stats <i>ip-address[/mask]</i> subnet-ext-stats pool <i>pool-name</i>
Context	clear>router>dhcp>local-dhcp-server
Description	This command clears extended subnet statistics.

lease-state

Syntax	lease-state [ip-address <i>ipv6-address/prefix-length</i>] [mac <i>ieee-address</i>]
Context	clear>service>id>dhcp6
Description	This command clears DHCP6 lease state information.
Parameters	ip-address <i>ipv6-address</i> — Clears the DHCP6 IP address lease state information. The <i>ipv6-address</i> portion of the address command specifies the IP host address that will be used by the IP interface within the subnet. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IPv6 addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets). mac <i>ieee-address</i> — Clears DHCP6 MAC address lease state information. The 48-bit MAC address for the static ARP in the form aa:bb:cc:dd:ee:ff or aa-bb-cc-dd-ee-ff where aa, bb, cc, dd, ee, and ff are hexadecimal numbers. Allowed values are any non-broadcast, non-multicast MAC and non-IEEE reserved MAC addresses.

statistics

Syntax	statistics [sap <i>sap-id</i> sdp [<i>sdp-id</i> [: <i>vc-id</i>]] interface <i>ip-int-name</i> <i>ip-address</i>]
Context	clear>router>dhcp
Description	This command clears DHCP statistics.

- Parameters** *sap sap-id* — clears DHCP statistics. See [Common Service Commands on page 1740](#) for *sap-id* command syntax.
- sdp-id* — Clears DHCP SDP statistics.
- Values** 1 — 17407
- vc-id* — Clears DHCP the SDP VC ID statistics.
- Values** 1 — 4294967295
- ip-int-name* — Clears DHCP statistics for the specified interface name.
- ip-address* — Clears DHCP statistics for the specified IP address.

local-dhcp-server

- Syntax** **local-dhcp-server** *server-name*
- Context** clear>router>dhcp6
- Description** This command enables the context to clear local DHCP server data.

leases

- Syntax** **leases** [*ipv6-address/prefix-length*] [*type*] [*state*]
leases all [*type*] [*state*]
- Context** clear>router>dhcp6>server
- Description** This command removes the specified leases in the specified local DHCPv6 server.
- Parameters** *ipv6-address/prefix-length* — The prefix of the leases to be removed.
- type* — The type of the lease to be remove.
- Values** pd, wan-host
- state* — The state of the lease to be removed.
- Values** advertised, remove-pending, held
- all** — Remove all leases of specified type and(or) state.

pool-ext-stats

- Syntax** **pool-ext-stats** [*pool-name*]
- Context** clear>router>dhcp6>server
- Description** This command reset the begin time of peak values in output of the **show router *rt-id* dhcp6 local-dhcp-server *svr-name* pool-ext-stats** command.
- Parameters** *pool-name* — The name of the local DHCPv6 server pool,

prefix-ext-stats

Syntax	prefix-ext-stats <i>ipv6-address/prefix-length</i> prefix-ext-stats pool <i>pool-name</i>
Context	clear>router>dhcp6>server
Description	This command reset the begin time of peak values in output of the show router <i>rt-id</i> dhcp6 local-dhcp-server <i>svr-name</i> prefix-ext-stats command/
Parameters	<i>ipv6-address/prefix-length</i> — Specify the IPv6 prefix. <i>pool-name</i> — The name of the local DHCPv6 server pool

server-stats

Syntax	server-stats
Context	clear>router>dhcp6>server
Description	This command reset all stats of the specified local DHCPv6 server

statistics

Syntax	statistics
Context	clear>router>dhcp6
Description	This command clears DHCP6 statistics.

Debug Commands

dhcp

Syntax	[no] dhcp [<i>ip-int-name</i>]
Context	debug>router>ip
Description	This command enables DHCP debugging. The no form of the command disables debugging.
Parameters	<i>ip-int-name</i> — Specifies the name of the IP interface. Interface names can be from 1 to 32 alphanumeric characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

dhcp6

Syntax	dhcp6 [<i>ip-int-name</i>] no dhcp6
Context	debug>router>ip
Description	This command enables DHCP debugging. The no form of the command disables debugging.
Parameters	<i>ip-int-name</i> — Specifies the name of the IP interface. Interface names can be from 1 to 32 alphanumeric characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

detail-level

Syntax	detail-level { low medium high } no detail-level
Context	debug>router>ip>dhcp debug>router>local-dhcp-server debug>router>ip>dhcp6
Description	This command debugs the DHCP tracing detail level.

local-dhcp-server

Syntax	[no] local-dhcp-server <i>server-name</i> [lease-address <i>ip-address</i>] [no] local-dhcp-server <i>server-name</i> [mac <i>ieee-address</i>]
---------------	--

Triple Play DHCP Configuration Commands

Context	debug>router
Description	This command enables, disables or configures debugging for a local DHCP server.
Parameters	<i>server-name</i> — [32 chars max] <i>ip-address</i> — a.b.c.d <i>ieee-address</i> — xx:xx:xx:xx:xx:xx or xx-xx-xx-xx-xx-xx (cannot be all zeroes)

mode

Syntax	mode {dropped-only ingr-and-dropped egr-ingr-and-dropped} no mode
Context	debug>router>ip>dhcp debug>router>local-dhcp-server debug>router>ip>dhcp6
Description	This command debugs the DHCP tracing detail level.

Tools Commands

tools

Syntax	tools
Context	<root>
Description	This command enables the context to enable useful tools for debugging purposes.
Default	none
Parameters	dump — Enables dump tools for the various protocols. perform — Enables tools to perform specific tasks.

perform

Syntax	perform
Context	tools
Description	This command enables the context to enable tools to perform specific tasks.
Default	none

subscriber-mgmt

Syntax	subscriber-mgmt
Context	tools>perform
Description	This command enables tools to control subscriber management.

edit-ppp-session

Syntax	edit-ppp-session sap <i>sap-id</i> ip <i>ip-address</i> [subscriber <i>sub-ident-string</i>] [sub-profile-string <i>sub-profile-string</i>] [sla-profile-string <i>sla-profile-string</i>] [inter-dest-id <i>intermediate-destination-id</i>] [ancp-string <i>ancp-string</i>] [app-profile-string <i>app-profile-string</i>] edit-ppp-session svc-id <i>service-id</i> ip <i>ip-address</i> [subscriber <i>sub-ident-string</i>] [sub-profile-string <i>sub-profile-string</i>] [sla-profile-string <i>sla-profile-string</i>] [app-profile-string <i>app-profile-string</i>] [inter-dest-id <i>intermediate-destination-id</i>] [ancp-string <i>ancp-string</i>]
Context	tools>perform>subscriber-mgmt
Description	This command modifies PPP session information.

Triple Play DHCP Configuration Commands

- Parameters**
- sap-id* — Specifies the physical port identifier portion of the SAP definition. See [Common Service Commands on page 1740](#) for *sap-id* command syntax.
 - ip-address* — Specifies the IP address.
 - sub-ident-string* — Specifies a subscriber identification profile.
 - sub-profile-string* — Specifies the subscriber profile string, up to 16 characters, maximum.
 - service-id* — The service identification number that identifies the service in the domain.
 - intermediate-destination-id* — Specifies the intermediate destination identifier which is encoded in the identification strings.
 - ancp-string** *ancp-string* — Specifies the ASCII string of the DSLAM circuit ID name.
 - app-profile-string* — Specifies an application profile string.

eval-lease-state

- Syntax** **eval-lease-state** [**svc-id** *service-id*] [**sap** *sap-id*] [**subscriber** *sub-ident-string*] [**ip** *ip-address*]
- Context** tools>perform>subscriber-mgmt
- Description** This command evaluates lease state.
- Parameters**
- sap-id* — Specifies the physical port identifier portion of the SAP definition. See [Common Service Commands on page 1740](#) for *sap-id* command syntax.
 - ip-address* — Specifies the a server's IP address. This address must be unique within the subnet and specified in dotted decimal notation. Allowed values are IP addresses in the range 1.0.0.0 – 223.255.255.255 (with support of /31 subnets).
 - sub-ident-string* — Specifies the subscriber ID string, up to 32 characters, maximum.
 - service-id* — Specifies an existing service ID.
- Values** 1 — 2147483647

local-user-db

- Syntax** **local-user-db** *local-user-db-name*
- Context** tools>perform>subscriber-mgmt
- Description** This command enables tools for controlling the local user database.
- Parameters** *local-user-db-name* — Specifies the name of a local user database.

dhcp

Syntax	dhcp
Context	tools>perform>subscriber-mgmt>local-user-db
Description	This command contains the tools used for controlling DHCP entries in the local user database.

host-lookup

Syntax	host-lookup [mac <i>ieee-address</i>] [remote-id <i>remote-id</i>] [sap-id <i>sap-id</i>] [service-id <i>service-id</i>] [string <i>vso-string</i>] [system-id <i>system-id</i>] [option60 <i>hex-string</i>] [circuit-id <i>circuit-id</i> circuit-id-hex <i>circuit-id-hex</i>]
Context	tools>perform>subscriber-mgmt>local-user-db>dhcp
Description	This command performs a lookup in the local user database. This command looks up the host with the match-list configured in the local user database.
Parameters	<p>mac <i>ieee-address</i> — Specifies the 48-bit MAC address for the static ARP in the form aa:bb:cc:dd:ee:ff or aa-bb-cc-dd-ee-ff where aa, bb, cc, dd, ee, and ff are hexadecimal numbers. Allowed values are any non-broadcast, non-multicast MAC and non-IEEE reserved MAC addresses.</p> <p><i>remote-id</i> — specifies what information goes into the remote-id sub-option in the DHCP relay packet.</p> <p>Values Up to 255 characters maximum</p> <p>sap-id — Specifies a SAP identifier to be used. See Common Service Commands on page 1740 for <i>sap-id</i> command syntax.</p> <p><i>service-id</i> — Specifies an existing subscriber service ID.</p> <p>Values 1 — 2147483647</p> <p><i>vso-string</i> — Specifies a Vendor Specific Option (VSO) string.</p> <p><i>system-id</i> — Specifies the system ID.</p> <p>Values up to 255 characters maximum.</p> <p>option60 <i>hex-string</i> — Specifies the content of option 60 for this lookup.</p> <p>Values 0x0..0xFFFFFFFF (maximum 64 hex nibbles)</p> <p>circuit-id <i>circuit-id</i> — specifies the circuit ID from the Option 82.</p> <p>circuit-id-hex <i>circuit-id-hex</i> — Specifies the circuit ID in hexadecimal format from the Option 82.</p> <p>Values 0x0..0xFFFFFFFF (maximum 254 hex nibbles)</p>

ppp

Syntax	ppp
Context	tools>perform>subscriber-mgmt>local-user-db
Description	This command contains the tools used to control PPP entries in the local user database.

authentication

Syntax	authentication password <i>password</i> [mac <i>ieee-address</i>] [remote-id <i>remote-id</i>] [circuit-id <i>circuit-id</i>] user-name <i>user-name</i> [service-name <i>service-name</i>] authentication password <i>password</i> [mac <i>ieee-address</i>] [remote-id <i>remote-id</i>] [circuit-id-hex <i>circuit-id-hex</i>] user-name <i>user-name</i> [service-name <i>service-name</i>]
Context	tools>perform>subscriber-mgmt>local-user-db>ppp
Description	This command authenticates PPP user name. As local user database PAP/CHAP authentication can only be used when the local user database is connected to the PPP node under the group interface, the user lookup will be performed with match-list username.
Parameters	password <i>password</i> — specifies the password of this host up to 32 characters in length. mac <i>ieee-address</i> — Specifies information about the MAC address of the PPP session. <i>remote-id</i> — specifies what information goes into the remote-id sub-option in the DHCP relay packet. Values Up to 255 characters maximum circuit-id <i>circuit-id</i> — specifies the circuit ID from the Option 82. circuit-id-hex <i>circuit-id-hex</i> — Specifies the circuit ID in hexadecimal format from the Option 82. Values 0x0..0xFFFFFFFF (maximum 254 hex nibbles) user-name <i>user-name</i> — Specifies the PPP user name. service-name <i>service-name</i> —

host-lookup

Syntax	host-lookup [mac <i>ieee-address</i>] [remote-id <i>remote-id</i>] [user-name <i>user-name</i>] [service-name <i>service-name</i>] [circuit-id <i>circuit-id</i> circuit-id-hex <i>circuit-id-hex</i>]
Context	tools>perform>subscr-mgmt>loc-user-db>ppp
Description	This command performs a lookup in the local user database. mac <i>ieee-address</i> — Specifies the 48-bit MAC address for the static ARP in the form aa:bb:cc:dd:ee:ff or aa-bb-cc-dd-ee-ff where aa, bb, cc, dd, ee, and ff are hexadecimal numbers. Allowed values are any non-broadcast, non-multicast MAC and non-IEEE reserved MAC addresses. remote-id <i>remote-id</i> — specifies what information goes into the remote-id sub-option in the DHCP relay packet.

Values Up to 255 characters maximum

user-name *user-name* — Specifies a user name up to 128 characters in length.

service-name *service-name* — Specifies a PPP service name, up to 255 characters maximum.

circuit-id *circuit-id* — specifies the circuit ID from the Option 82.

circuit-id-hex *circuit-id-hex* — Specifies the circuit ID in hexadecimal format from the Option 82.

Values 0x0..0xFFFFFFFF (maximum 254 hex nibbles)

