
Application Assurance Commands

- [Application Assurance Commands on page 167](#)
 - [Generic Commands on page 168](#)
 - [Hardware Commands on page 170](#)
 - [Application Assurance Commands on page 172](#)
 - [Group Commands on page 186](#)
 - [Policer Commands on page 187](#)
 - [Policy Commands on page 192](#)
 - [Application Filter Commands on page 198](#)
 - [Application Profile Commands on page 208](#)
 - [Application QoS Policy Commands on page 209](#)
 - [Application Service Options Commands on page 222](#)
 - [Statistics Commands on page 228](#)
- [ISA Commands on page 250](#)

Application Assurance uses system components for some of its functionality. Refer to the following for details on:

- Configuration of Application Assurance Accounting policy including per accounting type record selection and customization of AA subscriber records.
- Configuration of AA ISA IOM QoS.

Generic Commands

description

Syntax	description <i>description-string</i> no description
Context	config>isa>aa-group config>app-assure>protocol config>app-assure>group>policer config>app-assure>group>policy>app-filter>entry config>app-assure>group>policy>app-group config>app-assure>group>policy>app-profile config>app-assure>group>policy>aqp>entry config>app-assure>group>policy>application config>app-assure>group>cflowd>collector config>app-assure>group>cflowd>group>cflowd config>app-assure>group>cflowd>group>cflowd>collector config>app-assure>group>cflowd>group>cflowd>volume config>app-assure>group>policy>custom-protocol config>app-assure>group>policy>transit-ip-policy config>app-assure>group>http-err-redir config>app-assure>group>http-redir config>app-assure>rad-acct-plcy config>app-assure>group>tod-override config>app-assure>group>policy>aqp>entry>action>url-filter config>app-assure>group>url-filter config>app-assure>group>url-filter>icap-server
Description	This command creates a text description which is stored in the configuration file to help identify the content of the entity. The no form of the command removes the string from the configuration.
Default	none
Parameters	<i>string</i> — The description character string. Allowed values are any string composed of printable, 7-bit ASCII characters. If the string contains special characters (#, \$, spaces, etc.), the entire string must be enclosed within double quotes.

shutdown

Syntax	[no] shutdown
Context	config>app-assure>aa-grpconfig>isa>aa-group config>app-assure>group config>app-assure>group>wap1x config>app-assure>group>policy>app-filter>entry

```
config>app-assure>group>policy>aqp>entry
config>app-assure>group>cflowd>collector
config>app-assure>group>cflowd>group>cflowd>performance
config>isa>Ins-group
config>app-assure>group>policy>transit-ip-policy>dhcp
config>app-assure>group>policy>transit-ip-policy>radius
config>app-assure>group>cflowd>tcp-performance
config>app-assure>group>policy>transit-ip-policy>transit-auto-create
config>app-assure>group>tod-override
config>app-assure>group>url-filter
config>app-assure>group>url-filter>icap-server
```

Description

This command administratively disables the entity. When disabled, an entity does not change, reset, or remove any configuration settings or statistics. Many entities must be explicitly enabled using the **no shutdown** command.

The **shutdown** command administratively disables an entity. The operational state of the entity is disabled as well as the operational state of any entities contained within. Many objects must be shut down before they may be deleted.

Hardware Commands

isa-aa (mda-type)

Syntax	mda-type <i>isa-aa</i> no mda-type
Context	config>card>mda
Description	<p>This command provisions an adaptor into an MDA position on an IOM slot. The AA ISA is provisioned into the system in the same manner as all other MDA type. Once an AA ISA is provisioned, independent of it actually existing in the system or the specified slot and MDA position, the AA ISA can be defined as a member of an application assurance group.</p> <p>The no form of this command removes the module from the configuration. The module must be administratively shut down before it can be deleted from the configuration.</p> <p>Refer to the 7750 SR OS Interface Guide or 7450 ESS OS Interface Guide for further information on command usage and syntax for the AA ISA and other MDA and ISA types.</p>
Default	No ISA types are configured for any slots by default.
Parameters	<i>isa-aa</i> — Specifies the Application Assurance Integrated Services Adapter for the slot position.

Admin Commands

application-assurance

Syntax	application-assurance
Context	admin
Description	This command enables the context to perform Application Assurance (AA) configuration operations.

upgrade

Syntax	upgrade
Context	admin>app-assure
Description	Use this command to load a new isa-aa.tim file as part of a router-independent signature upgrade. An AA ISA reboot is required.

Application Assurance Commands

aarp

Syntax	aarp <i>aarpId</i> [create] no aarp <i>aarpId</i>
Context	config>application-assurance
Description	This command defines an Application Assurance Redundancy Protocol (AARP) instance. This instance is paired with the same <i>aarpId</i> in a peer node as part of a configuration to provide flow and packet asymmetry removal for traffic for a multi-homed SAP or spoke SDP. The no form of the command removes the instance from the configuration.
Default	no aarp
Parameters	<i>aarpId</i> — An integer that identifies an AARP instance. Values 1 — 65535 create — Keyword used to create the AARP instance.

master-selection-mode

Syntax	master-selection-mode <i>mode</i>
Context	config>app-assure>aarp
Description	This command configures the AARP mode of operation with the peer instance. The modes affect the AARP state machine behavior according to the desired behavior. Minimize-switchover will change AARP state based on Master ISA failure, and be non-revertive in that when the priority ISA returns a switch does not occur, which is optimal for AA flow identification. Inter-chassis efficiency mode considers both priority (revertive) and the endpoint status of the AARP instance and will switch activity in case of EP failure in order to avoid sending all the traffic over the ICL. The priority-based-balance mode will be revertive after a priority master returns to service, but excludes EP status. The master-selection-mode configuration must match on both peer AARP instances, or the AARP operational status will stay down.
Default	minimize-switchovers
Parameters	<i>mode</i> — Specifies the the AARP master selection mode. Values minimize-switchovers — Optimal AA flow detection continuity by minimizing AARP switchovers. inter-chassis-efficiency — minimizes inter-chassis traffic. priority-based-balance — AA load balance between AARP peers based on configured priority.

peer

Syntax	peer <i>ip-address</i> no peer
Context	config>app-assure>aarp
Description	This command defines the IP address of the peer router which must be a routable system IP address. If no peer is configured and the AARP is no shutdown , it is configured as a single node AARP instance. The no form of the command removes the IP address from the AARP instance.
Default	no peer
Parameters	<i>ip-address</i> — Specifies the IP address in the a.b.c.d format.

peer-endpoint

Syntax	peer-endpoint sap <i>sap-id</i> encap-type {dot1q null qinq} peer-endpoint spoke-sdp <i>sdp-id:vc-id</i> no peer-endpoint
Context	config>app-assure>aarp#
Description	This command defines the peer endpoint ID of the SAP or spoke-SDP parent-aa-sub of the AARP peer. The no form of the command removes the peer endpoint from the AARP instance.
Default	no peer-endpoint
Parameters	sap <i>sap-id</i> — Specifies the physical port identifier portion of the SAP definition. <i>sdp-id:vc-id</i> — Specifies the spoke SDP ID and VC ID.
Values	1 — 17407 1 — 4294967295
	encap-type {dot1q null qinq} — Specifies the encapsulation type.

priority

Syntax	priority [0..255] no priority
Context	config>app-assure>aarp
Description	This command defines the priority for the AARP instance. The priority value is used to determine the master/backup upon initialization or re-balance. The no form of the command removes the priority.

Application Assurance Commands

Default	priority 100
Parameters	[0 — 255] — Specifies an integer that defines the priority of an AARP instance.
Values	0 — 255

bit-rate-high-wmark

Syntax	bit-rate-high-wmark <i>high-watermark</i>
Context	config>application-assurance
Description	This command configures the high watermark for bit rate alarms.
Context	max (disabled)
Parameters	<i>high-watermark</i> — pecifies the high watermark for bit rate alarms. The value must be larger than or equal to the low-watermark value.
Values	1 — 10000, max megabits/sec

bit-rate-low-wmark

Syntax	bit-rate-low-wmark <i>low-watermark</i> no bit-rate-low-wmark
Context	config>application-assurance
Description	This command configures the utilization of the flow records on the ISA-AA Group when the full alarm will be cleared by the agent.
Default	0
Parameters	<i>low-watermark</i> — Specifies the low watermark for bit rate alarms. The value must be lower than or equal to the high-watermark value.
Values	0 — 10000 megabits/sec

packet-rate-high-wmark

Syntax	packet-rate-high-wmark <i>high-watermark</i>
Context	config>app-assure
Description	This command configures the packet rate on the ISA-AA when a packet rate alarm will be raised by the agent.
Default	max = disabled
Parameters	<i>high-watermark</i> — Specifies the high watermark for packet rate alarms. The value must be larger than or equal to the packet-rate-low-wmark value.

Values 1 — 14880952 , **max** packets/sec

packet-rate-low-wmark

Syntax	packet-rate-low-wmark <i>low-watermark</i> no packet-rate-low-wmark
Context	config>app-assure
Description	This command configures the system wide low watermark threshold for per-ISA throughput in packets/second when an high packet rate alarm will be cleared by the agent.. The value must be less than or equal to the packet-rate-high-wmark parameter. The no form of the command sets the parameter to minimum (watermark disabled).
Default	0
Parameters	<i>low-watermark</i> — Specifies the low watermark for packet rate alarms. T he value must be lower than or equal to the packet-rate-low-wmark value. Values 0— 14880952 packets/sec

flow-setup-high-wmark

Syntax	flow-setup-high-wmark <i>high-watermark</i>
Context	config>application-assurance
Description	This command configures the system wide high watermark threshold for per-ISA throughput in packets/second when an alarm will be raised by the agent. The value must be larger than or equal to the packet-rate-low-wmark parameter. The no form of the command sets the parameter to maximum (watermark disabled).
Default	0
Parameters	<i>high-watermark</i> — Specifies the high watermark for flow setup rate alarms. The value must be larger than or equal to the flow-setup-low-wmark value. Values 1 — 200000, max flows/sec

flow-setup-low-wmark

Syntax	flow-setup-low-wmark <i>low-watermark</i> no flow-setup-low-wmark
Context	config>application-assurance
Description	This command configures the flow setup rate on the ISA-AA when a flow setup alarm will be raised by the agent.

Application Assurance Commands

Default	0
Parameters	<i>low-watermark</i> — Specifies the low watermark for flow setup rate alarms. The value must be larger than or equal to the flow-setup-high-wmark value.
Values	1 — 200000, max flows/sec

application-assurance

Syntax	application-assurance
Context	config
Description	This command enables the context to perform Application Assurance (AA) configuration operations.

flow-table-high-wmark

Syntax	flow-table-high-wmark <i>high-watermark</i> no flow-table-high-wmark
Context	config>app-assure
Description	The command configures the system-wide high watermark threshold as a percentage of the flow table size for the per-ISA utilization of the flow records when a full alarm will be raised by the agent.
Parameters	<i>high-watermark</i> — Specifies the high watermark for flow table full alarms.
Values	0 — 100
Default	95%

flow-table-low-wmark

Syntax	flow-table-low-wmark <i>low-watermark</i> no flow-table-low-wmark
Context	config>app-assure
Description	This command configures the system-wide low watermark threshold as a percentage of the flow table size for per-ISA. The value must be lower than or equal to the flow-table-high-wmark <i>high-watermark</i> parameter.
Parameters	<i>low-watermark</i> — Specifies the low watermark for flow table full alarms.
Values	0 — 100
Default	90%

protocol

Syntax	protocol <i>protocol-name</i>
Context	config>app-assure
Description	This command configures the shutdown of protocols system-wide.
Parameters	<i>protocol-name</i> — A string of up to 32 characters identifying a predefined protocol.

group

Syntax	group <i>aa-group-id</i> [: <i>partition-id</i>] [create] no group <i>aa-group-id</i> [: <i>partition-id</i>]
Context	config>app-assure
Description	This command configures and enables the context to configure an application assurance group and partition parameters.
Parameters	<i>aa-group-id</i> — Represents a group of ISA MDAs. Values 1 — 255 <i>partition-id</i> — Specifies a partition within a group. Values 1 — 65535 create — Keyword used to create the partition in the group.

aa-sub-remote

Syntax	[no] aa-sub-remote
Context	config>app-assure
Description	This command specifies whether or not the from subscriber and to subscriber traffic direction is reversed for this group-partition.
Default	no aa-sub-remote

cflowd

Syntax	cflowd
Context	config>app-assure>group
Description	This command enables the context to configure cflowd parameters for the application assurance group.

collector

Application Assurance Commands

Syntax	collector <i>ip-address[:port]</i> [create] no collector <i>ip-address[:port]</i>
Context	config>app-assure>group>cflowd
Description	This command defines a flow data collector for cflowd data. The IP address of the flow collector must be specified. The UDP port number is an optional parameter. If it is not set, the default of 2055 is used.
Parameters	<i>ip-address</i> — The IP address of the flow data collector in dotted decimal notation. <i>:port</i> — The UDP port of flow data collector. Default 2055 Values 1— 65535

comprehensive

Syntax	comprehensive
Context	config>app-assure>group>cflowd
Description	This command enables the context to configure cflowd comprehensive statistics output parameters.

rtp-performance

Syntax	performance
Context	config>app-assure>group>cflowd
Description	This command configures the cflowd RTP performance export.

app-group

Syntax	[no] app-group <i>app-group-name</i> [<i>rate</i>]
Context	config>app-assure>group>cflowd>rtp-performance config>app-assure>group>cflowd>tcp-performance config>app-assure>group>cflowd>comprehensive
Description	Description This command configures application groups to export performance records with cflowd. The no form of the command removes the parameters from the configuration.
Parameters	<i>app-group-name</i> — Specifies the application group name. <i>rate</i> — Specifies which sampling flow rate to use; flow-rate or flow-rate2. Values flow-rate, flow-rate2 Default flow-rate

application

Syntax	[no] application <i>application-name</i> [<i>rate</i>]
Context	config>app-assure>group>cflowd>rtp-performance config>app-assure>group>cflowd>tcp-performance config>app-assure>group>cflowd>comprehensive
Description	This command configures applications to export performance records with cflowd. The no form of the command removes the parameters from the configuration.
Parameters	<i>application-name</i> — Specifies the name defined for the application. <i>rate</i> — Specifies which sampling flow rate to use; flow-rate or flow-rate2.
	Values flow-rate, flow-rate2
	Default flow-rate

flow-rate

Syntax	flow-rate <i>sample-rate</i> no flow-rat
Context	config>app-assure>group>cflowd>rtp-performance config>app-assure>group>cflowd>tcp-performance config>app-assure>group>cflowd>comprehensive
Description	This command configures specifies the per-flow sampling rate for the cflowd export of Application Assurance performance statistics. The no form of the command reverts to the default.
Default	no flow-rate
Parameters	<i>sample-rate</i> — This is the rate at which to sample flows that are eligible for TCP performance measurement.
	Values 1 — 1000

flow-rate2

Syntax	flow-rate2 <i>sample-rate</i> no flow-rate2
Context	config>app-assure>group>cflowd>rtp-performance config>app-assure>group>cflowd>tcpperformance config>app-assure>group>cflowd>comprehensive
Description	This command configures specifies the per-flow second sampling rate for the cflowd export of Application Assurance performance statistics. The no form of the command reverts to the default.

Application Assurance Commands

Default	no flow-rate
Parameters	<i>sample-rate</i> — This is the rate at which to sample flows that are eligible for TCP and/or RTP performance measurement.
Values	1 — 1000

template-retransmit

Syntax	template-retransmit <i>seconds</i> no template-retransmit
Context	config>app-assure>group>cflowd
Description	This command configures the period of time, in seconds, for the template to be retransmitted.
Parameters	<i>seconds</i> — Specifies the time period for the template to be retransmitted.
Values	10 — 600
Default	600

tcp-performance

Syntax	tcp-performance
Context	config>app-assure>group>cflowd
Description	This command enables the context to configure Cflowd TCP performance export parameters.

volume

Syntax	volume
Context	config>app-assure>group>cflowd
Description	This command configures the cflowd volume export.

rate

Syntax	rate <i>sample-rate</i> no rate
Context	config>app-assure>group>cflowd>volume
Description	This command configures the sampling rate of packets for the cflowd export of application assurance volume statistics. The no form of the command reverts to the default value.

Parameters *sample-rate* — This is the rate at which to sample packets for the cflowd export of application assurance volume statistics.

Values 1 — 10000

http-error-redirect

Syntax **http-error-redirect** *redirect-name* [**create**]
no http-error-redirect *redirect-name*

Context config>app-assure>group

Description This command configures an HTTP error redirect policy. The policy contains important information relevant to the redirect server.

The **no** form of the command removes the redirect name from the group configuration.

Default none

Parameters *redirect-name* — A string of up to 32 characters that identifies the HTTP error redirect policy.

error-code

Syntax **error-code** *error-code* [**custom-msg-size** *custom-msg-size*]
no error-code *error-code*

Context config>app-assure>group>http-error-redirect

Description This command refers to which HTTP status codes a redirect action is applied. Currently, only 404 http error code is supported. Only messages with sizes less than that configured here (*custom-msg-size*) are eligible for redirect action.

The no form of the command removes the parameters from the configuration.

Default Error code: none

Parameters *error-code* — Specifies the error code for a HTTP Error Redirect.

Values 0 — 4294967295

custom-msg-size — Specifies the maximum message size above which redirect will not be done.

Values 0 — 4294967295

http-host

Syntax **http-host** *http-host*
no http-host

Context config>app-assure>group>http-error-redirect

Application Assurance Commands

Description	This is a string that refers to the http host name of the landing server (barefruit or xerocole). It is used in the HTTP GET operation from the client (which is being redirected) to the redirect search landing server. It must contain a valid IP address or HTTP host name / URI for the HTTP GET from the client to the landing server to work. The no form of the command removes the HTTP host string from the configuration.
Default	none
Parameters	<i>http-host</i> — Specifies a string of 255 chars max length, that refers to the HTTP host name of the landing server (barefruit or xerocole).

participant-id

Syntax	participant-id <i>participant-id</i> no participant-id
Context	config>app-assure>group>http-error-redirect
Description	This command specifies a 32-character string assigned to the operator by Barefruit. It is used by barefruit landing servers (applies to template # 1 only).
Default	None
Parameters	<i>participant-id</i> — 32-char string supplied by the Barefruit

template

Syntax	template <i>template-id</i> no template
Context	config>app-assure>group config>app-assure>group>http-redirect
Description	The redirect template refers to the template of parameters passed from the AA-ISA to the redirect server via JavaScript in the redirect packet. The template is specific to the redirect server being used in the network. Currently, two partners are used and tested with AA-ISA redirect solution, Barefruit and Xerocole. The no form of the command reverts to the default.
Default	1 = referring to redirect format for Barefruit landing server.
Parameters	<i>template-id</i> — Specifies an HTTP error redirect template. 1 = Barefruit specific template 2 = xerocole.specific template.
Values	0 — 4294967295

http-match-all-requests

Syntax	[no] http-match-all-requests
Context	config>app-assure>group
Description	This command enables constant monitoring performed for HTTP request strings for application changes in regular HTTP flows. The no form of the command disables the monitoring.

http-notification

Syntax	http-notification <i>http-notification-name</i> [create] no http-notification <i>http-notification-name</i>
Context	config>app-assure>group
Description	This command configures an http-notification object for subscriber in browser notification. The no form of the command removes the http notification policy from the configuration.
Parameters	<i>http-notification-name</i> — Specifies the name of the HTTP Notification policy. create — Specifies the mandatory keyword to create the policy.

interval

Syntax	interval { one-time <i>minimum-interval</i> }
Context	config>app-assure>group>http-notif#
Description	This command configures the minimum interval in between notification messages. It can be set to one-time or a value in minutes from 1 to 1440. The no form of the command removes the interval from the http-notification policy.
Parameters	<i>minimum-interval</i> — Represents the minimum interval value in minutes in between two http notifications. Values 1 — 1440.

template

Syntax	template <i>value</i> no template
Context	config>app-assure>group>http-notif#
Description	This command configures the template which defines the format and parameters included in the http notification message. The no form of the command removes the template from the configuration.
Parameters	<i>value</i> —

Values 1 — The only acceptable value.

script-url

Syntax	script-url <i>script-url-name</i> [create] no script-url
Context	config>app-assure>group>http-notif#
Description	This command configures the url of the script used by the http notification policy. The no form of the command removes the script-url from the http-notification policy.
Parameters	<i>script-url-name</i> — Specifies the 255 characters long string representing the url of the script used in the http notification policy.

http-redirect

Syntax	http-redirect <i>redirect-name</i> [create] no http-redirect <i>redirect-name</i>
Context	config>app-assure>group
Description	This command configures an HTTP redirect. The no form of the command removes the http redirect policy from the configuration.
Parameters	<i>redirect-name</i> — Specifies the HTTP redirect that will be applied. If no redirect name is specified then HTTP redirect is not enabled.

http-host

Syntax	http-host <i>http-host</i> no http-host
Context	config>app-assure>group>http-redirect
Description	This command configures the http redirect URL. This is the URL (page) that the user is redirected to when an HTTP redirect takes effect. The no form of the command removes the http host field from the configuration
Default	none
Parameters	<i>http-host</i> — Specifies the URL of the redirect landing page.s

template

Syntax **template** *template-id*

no template

Context	config>app-assure>group>http-redirect
Description	<p>This command configures the template that defines which parameters are appended to the HTTP host redirect field in the redirect message.</p> <p>The HTTP redirect template provides HTTP 302 redirect containing only the URL specified in the redirect policy, with no other parameters.</p> <p>The no form of the command removes the template from the configuration.</p>
Default	none
Parameters	<p><i>template-id</i> — Specifies the HTTP Policy Redirect template.</p> <p>Values</p> <ul style="list-style-type: none"> 1 = Javascript based redirect embedded in HTTP 200 OK response with a predefined number of arguments automatically appended to the redirect URL 2 = HTTP 302 Redirect with a predefined number of arguments automatically appended to the redirect URL. 3=HTTP 302 Redirect with no parameters appended to the URL

http-x-online-host

Syntax	[no] http-x-online-host
Context	config>app-assure>group
Description	<p>This command specifies whether X-Online-Host header field is used as a replacement for the HTTP Host header field.</p> <p>The no form of the command disables the use of X-Online-Host header field used as a replacement.</p>

Group Commands

Transit Subscriber Commands

transit-ip-policy

Syntax	transit-ip-policy <i>ip-policy-id</i> [create] no transit-ip-policy <i>ip-policy-id</i>
Context	config>application-assurance>group
Description	<p>This command defines a transit AA subscriber IP policy. Transit AA subscribers are managed by the system through the use of this policy assigned to services, which determines how transit subs are created and removed for that service.</p> <p>The no form of the command deletes the policy from the configuration. All associations must be removed in order to delete a policy.</p>
Default	no transit-ip-policy
Parameters	<i>ip-policy-id</i> — An integer that identifies a transit IP profile entry.
	Values 1 — 65535
	create — Keyword used to create the entry.

Policer Commands

policer

Syntax	policer <i>policer-name</i> type <i>type</i> granularity <i>granularity</i> [create] police <i>policer-name</i> no policer <i>policer-name</i>
Context	config>app-assure>group
Description	<p>This command creates application assurance policer profile of a specified type. Policers can be bandwidth or flow limiting and can have a system scope (limits traffic entering AA ISA for all or a subset of AA subscribers), subscriber scope or granularity (limits apply to each AA subscriber traffic).</p> <p>The policer type and granularity can only be configured during creation. They cannot be modified. The policer profile must be removed from all AQPs in order to be removed. Changes to policer profile parameters take effect immediately for policers instantiated as result of AQP actions using this profile..</p> <p>The no form of the command deletes the specified policer from the configuration.</p>
Parameters	<p><i>type</i> — Specifies the policer type.</p> <p>Values</p> <ul style="list-style-type: none"> single-bucket-bandwidth — Creates a profile for a single bucket (PIR) bandwidth limiting policer. dual-bucket-bandwidth — Creates profile for a dual bucket (PIR, CIR) bandwidth limiting policer. flow-rate-limit — Creates profile for a policer limiting rate of flow set-ups. flow-count-limit — Creates profile for a policer limiting total flow count. <p><i>granularity</i> — Specifies the granularity type.</p> <p>Values</p> <ul style="list-style-type: none"> system — Creates a system policer profile for a policer that limits the traffic in the scope of all or a subset of AA subscribers on a given AA ISA. subscriber — Creates a policer profile for a policer for each AA subscriber that limits the traffic in the scope of that subscriber. <p>create — Keyword used to create the policer name and parameters.</p>
Default	none
Parameters	<i>policer-name</i> — A string of up to 32 characters that identifies policer.

action

Syntax	action { priority-mark permit-deny }
Context	config>app-assure>group>policer
Description	This command configures the action to be performed by single-bucket bandwidth policers for non-conformant traffic.

Group Commands

Dual bucket bandwidth policers cannot have their action configured and always mark traffic below CIR in profile, between CIR and PIR out of profile, and drop traffic above PIR.

Flow policers always discard non-conformant traffic.

When multiple application assurance policers are configured against a single flow (including policers at both subscriber and system), the final action done to the flow/packet will be a logical OR of all policers actions. For example, if only of the policers requires the packet to be discarded, the packet will be dropped regardless of the action of the other policers.

Default permit-deny

Parameters **priority-mark** — Non-conformant traffic will be marked out of profile and the conformant traffic will be marked in profile. The new marking will overwrite any previous IOM QoS marking done to a packet.

permit-deny — Non-conformant traffic will be dropped.

adaptation-rule

Syntax **adaptation-rule pir {max | min | closest} [cir {max | min | closest}]**
no adaptation-rule

Context config>app-assure>group>policer

Description This command defines the method used by the system to derive the operational CIR and PIR settings when the queue is provisioned in hardware. For the CIR and PIR parameters individually, the system attempts to find the best operational rate depending on the defined option. To change the CIR adaptation rule only, the current PIR rule must be part of the command executed.

The **no** form of the command removes any explicitly defined constraints used to derive the operational CIR and PIR created by the application of the policy. When a specific adaptation-rule is removed, the default constraints for rate and cir apply.

Default closest

Parameters **max** — The operational PIR or CIR for the queue will be equal to or less than the administrative rate specified using the **rate** command.

min — The operational PIR or CIR for the queue will be equal to or greater than the administrative rate specified using the **rate** command.

closest — The operational PIR or CIR for the queue will be the rate closest to the rate specified using the **rate** command.

flow-count

Syntax **flow-count flow-count**
no flow-count

Context config>app-assure>group>policer

Description This command configures the flow count for the flow-count-limit policer. It is recommended to configure flow count subscriber-level policer for AA subscribers to ensure fair usage of flow resources between AA subscribers.

Parameters *flow-count* — Specifies the flow count for the flow-count-limit policer.

cbs

Syntax **cbs** *committed-burst-size*
no cbs

Context config>app-assure>group>policer

Description This command provides a mechanism to configure the committed burst size for the policer. It is recommended that CBS is configured larger than twice the maximum MTU for the traffic handled by the policer to allow for some burstiness of the traffic. CBS is configurable for dual-bucket bandwidth policers only.

The **no** form of the command resets the cbs value to its default.

Default 0

Parameters *committed-burst-size* — An integer value defining size, in kbytes, for the CBS of the policer.

Values 0 — 131071

mbs

Syntax **mbs** *maximum-burst-size*
no mbs

Context config>app-assure>group>policer
config>app-assure>group>tod-override

Description This command provides a mechanism to configure the maximum burst size for the policer. It is recommended that MBS is configured larger than twice the MTU for the traffic handled by the policer to allow for some burstiness of the traffic. MBS is configurable for single-bucket, dual-bucket bandwidth and flow setup rate policers only.

The **no** form of the command resets the MBS value to its default.

Default 0

Parameters *maximum-burst-size* — An integer value defining either size, in kbytes, for the MBS of the bandwidth policer, or flow count for the MBS of the flow setup rate policers.

Values 0 — 131071

rate

Syntax **rate** *pir-rate* [*cir cir-rate*]

no rate

Context	config>app-assure>group>policer config>app-assure>group>tod-override
Description	This command configures the administrative PIR and CIR for bandwidth policers and flow setup rate limits for flow policers. The actual rate sustained by the flow can be limited by other policers that may be applied to that flow's traffic. This command does not apply to flow-count-limit policers. The cir option is applicable only to dual-bucket bandwidth policers. It is recommended to configure flow setup rate subscriber-level policer for AA subscribers to ensure fair usage of flow resources between AA subscribers. The no form of the command resets the values to defaults.
Default	0
Parameters	<i>pir-rate</i> — An integer specifying either the PIR rate in Kbps for bandwidth policers. Values 1 — 100000000, max or flows <i>cir-rate</i> — An integer specifying the CIR rate in Kbps. Values 0 — 100000000, max

tod-override

Syntax	tod-override <i>tod-override-id</i> [create] no tod-override <i>tod-override-id</i>
Context	config>app-assure>group>policer
Description	This commands creates a time of day override policy for a given policer. Up to 8 overrides can be configured per policer. Rate/mbs/cbs/flow-rate/flow-count configured in each override-id will override the default policer values at the specified time of day configured in the override.
Default	none
Parameters	<i>tod-override-id</i> — Specify the time of day override ID. Values 1 — 255

time-range

Syntax	time-range daily start <i>start-time</i> end <i>end-time</i> [on day [<i>day...</i> (upto 7 max)]] time-range weekly start <i>start-time</i> end <i>end-time</i> no time-range
Context	config>app-assure>group>tod-override
Description	This command configures the time-range applicable to a particular override-id. The time-range can be configured as daily or weekly policies. When using a daily override the operator can select which day(s) during the week from Sunday to Saturday it is applicable along with the start/end hour/min time range repeated over the(se) day(s).

When using a weekly override the operator can select between which days in the week the policy start up to the hours/min for both start day and end day.

Default	no time-range		
Parameters	daily — Schedule the override as a daily occurrence.		
	weekly — Schedule the override as a daily occurrence.		
	Values		
	start-time	daily	<hh>:<mm>
		weekly	<day>,<hh>:<mm> <hh> : 0..23 <mm> : 0 15 30 45
	end-time	daily	<hh>:<mm>
		weekly	<day>,<hh>:<mm> <hh> 0..23 <mm> 0 15 30 45
	<day>		sunday monday tuesday wednesday thursday friday saturday

Policy Commands

policy

Syntax	policy
Context	config>app-assure>group>policy
Description	This command enables the context to configure parameters for application assurance policy. To edit any policy content begin command must be executed first to enter editing mode. The editing mode is left when the abort or commit commands are issued.

abort

Syntax	abort
Context	config>app-assure>group>policy
Description	This command ends the current editing session and aborts any changes entered during this policy editing session.

begin

Syntax	begin
Context	config>app-assure>group>policy
Description	<p>This command begins a policy editing session.</p> <p>The editing session continues until one of the following conditions takes place:</p> <ul style="list-style-type: none">• Abort or commit is issued.• Control complex resets. <p>The editing session is not interrupted by:</p> <ul style="list-style-type: none">• HA activity switch.• CLI session termination (for example, as result of closing a Telnet session).

commit

Syntax	commit
Context	config>app-assure>group>policy
Description	This command commits changes made during the current editing session. None of the policy changes done will take effect until commit command is issued. If the changes can be successfully committed,

no errors detected during the commit during cross-reference verification against existing application assurance configuration, the editing session will also be closed.

The newly committed policy takes affect immediately for all new flows, existing flows will transition onto the new policy shortly after the commit.

app-group

Syntax	app-group <i>application-group-name</i> [create] no app-group <i>application-group-name</i>
Context	config>app-assure>group>policy
Description	This command creates an application group for an application assurance policy. The no form of the command deletes the application group from the configuration. All associations must be removed in order to delete a group.
Default	no app-group
Parameters	<i>application-group-name</i> — A string of up to 32 characters uniquely identifying this application group in the system. create — Mandatory keyword used when creating an application group. The create keyword requirement can be enabled/disabled in the environment>create context.

charging-group

Syntax	charging-group <i>charging-group-name</i> [create] no charging-group
Context	config>app-assure>group>policy config>app-assure>group>policy>app-group
Description	This command creates a charging group for an application assurance policy. The no form of the command deletes the charging group from the configuration. All associations must be removed in order to delete a group.
Default	no charging-group
Parameters	<i>charging-group-name</i> — A string of up to 32 characters uniquely identifying this charging group in the system. create — Mandatory keyword used when creating a charging group group. The create keyword requirement can be enabled/disabled in the environment>create context.

charging-group

Syntax	charging-group { eq neq } <i>charging-group-name</i> no charging-group
---------------	---

Group Commands

Context	config>app-assure>group>policy>application config>app-assure>group>policy>app-group
Description	This command associates an application or app-group to an application assurance charging group. The no form of the command deletes the charging group association.
Default	no charging-group
Parameters	<i>charging-group-name</i> — Specifies a string of up to 32 characters uniquely identifying an existing charging group in the system.

export-id

Syntax	export-id <i>export-id</i> no export-id
Context	config>app-assure>group>policy>application config>app-assure>group>policy>application>charging-group config>app-assure>group>policy>app-group
Description	This command assigns an export-id value to a charging group to be used for accounting export identification of the charging group. This ID is encoded in the top 2 bytes of the RADIUS accounting VSA to identify which charging group the counter value represents. If no export-id is assigned, that charging group cannot be added to the aa-sub stats RADIUS export-type. Once a charging group index is referenced, it cannot be deleted without removing the reference. The no form of the command removes the export-id from the configuration.
Default	no export-id
Parameters	<i>export-id</i> — An integer that identifies an export-id. Values 1 — 65535

app-filter

Syntax	app-filter
Context	config>app-assure>group>policy
Description	This command enables the context to configure an application filter for application assurance.

app-profile

Syntax	app-profile <i>app-profile-name</i> [create] no app-profile <i>app-profile-name</i>
Context	config>app-assure>group>policy

- Description** This command creates an application profile and enables the context to configure the profile parameters.
The **no** form of the command removes the application profile from the configuration.
- Default** none
- Parameters** *app-profile-name* — Specifies the name of the application profile up to 32 characters in length.
create — Mandatory keyword used when creating an application profile. The **create** keyword requirement can be enabled/disabled in the **environment>create** context.

app-qos-policy

- Syntax** **app-qos-policy**
- Context** config>app-assure>group>policy
- Description** This command enables the context to configure an application QoS policy.

app-service-options

- Syntax** **app-service-options**
- Context** config>app-assure>group>policy
- Description** This command enables the context to configure application service option characteristics.

default-charging-group

- Syntax** **default-charging-group** *charging-group-name*
no default-charging-group
- Context** config>app-assure>group>policy
- Description** This command associates a charging group to any applications or app-groups that are not explicitly assigned to a charging group, for an application assurance policy.
The **no** form of the command deletes the default charging group from the configuration.
- Default** no default-charging-group
- Parameters** *charging-group-name* — A string of up to 32 characters uniquely identifying an existing charging group in the system

diff

- Syntax** **diff**

Group Commands

Context config>app-assure>group>policy

Description This command compares the newly configured policy against the operational policy.

application

Syntax **application** *application-name* [**create**]
no application *application-name*

Context config>app-assure>group>policy

Description This command creates an application of an application assurance policy.
The **no** form of the command deletes the application. To delete an application, all associations to the application must be removed.

Default none

Parameters *application-name* — Specifies a string of up to 32 characters uniquely identifying this application in the system.
create — Mandatory keyword used when creating an application. The **create** keyword requirement can be enabled/disabled in the **environment>create** context.

policy-override

Syntax **policy-override**

Context config>app-assure>group>policy

Description This command enables the context to configure policy override parameters.

policy aa-sub

Syntax **policy aa-sub** {**sap** *sap-id* | **spoke-sdp** *sdp-id:vc-id*} [**create**]
no policy aa-sub {**sap** *sap-id* | **spoke-sdp** *sdp-id:vc-id*}

Context config>app-assure>group>policy>policy-override

Description This command specifies the SAP or SDP
The **no** form of the command removes the SAP or ESM matching criteria.

Parameters **sap** *sap-id* — Specifies the physical port identifier portion of the SAP definition.
sdp-id:vc-id — Specifies the spoke SDP ID and VC ID.

Values 1 — 17407
1 — 4294967295

characteristic

Syntax	characteristic <i>characteristic-name</i> value <i>value-name</i> no characteristic <i>characteristic-name</i>
Context	config>app-assure>group>policy>policy-override
Description	This command configure an override characteristic and value.
Parameters	<i>characteristic-name</i> — Specifies the characteristic name up to 32 characters in length. value <i>value-name</i> — Specifies the override characteristic value for the application profile characteristic used by the Application assurance subscriber.

app-group

Syntax	app-group <i>application-group-name</i>
Context	config>app-assure>group>policy>application
Description	This command associates an application with an application group of an application assurance policy.
Default	none
Parameters	<i>application-name</i> — A string of up to 32 characters uniquely identifying an existing application in the system.

APPLICATION FILTER COMMANDS

entry

Syntax	entry <i>entry-id</i> [create] no entry <i>entry-id</i>
Context	config>app-assure>group>policy>app-filter
Description	This command creates an application filter entry. App filter entries are an ordered list, the lowest numerical entry that matches the flow defines the application for that flow. An application filter entry or entries configures match attributes of an application. The no form of this command deletes the specified application filter entry.
Default	none
Parameters	<i>entry-id</i> — An integer that identifies an app-filter entry. Values 1 — 65535 create — Keyword used to create the entry.

application

Syntax	application <i>application-name</i>
Context	config>app-assure>group>policy>application config>app-assure>group>policy>app-filter>entry
Description	This command assigns this application filter entry to an existing application. Assigning the entry to Unknown application restores the default configuration.
Default	unknown application
Parameters	<i>application-name</i> — Specifies an existing application name.

expression

Syntax	expression <i>expr-index</i> <i>expr-type</i> { eq neq } <i>expr-string</i> no expression <i>expr-index</i>
Context	config>app-assure>group>policy>app-filter>entry
Description	This command configures string values to use in the application definition.
Parameters	<i>expr-index</i> — Specifies an index value which represents .expression substrings.

Values 1 — 4

expr-type — Represents a type (and thereby the expression substring).

http-host|http-uri|http-referer|http-user-agent|
sip-ua|sip-uri|sip-mt|citrix-app|h323-product-id|tls-cert-subj-org-name|tls-cert-subj-common-name| rtsp-host|rtsp-uri|rtsp-ua

http-host — Matches the string against the HTTP Host field or TLS Server Name Indicator (SNI).

http-uri — Matches the string against the HTTP URI field.

http-referer — Matches the string against the HTTP Referer field.

http-user-agent — Matches the string against the HTTP User Agent field.

sip-ua — Matches the string against the SIP UA field.

sip-uri — Matches the string against the SIP URI field.

sip-mt — Matches the string against the SIP MT field.

citrix-app — Matches the string against the Citrix app field.

h323-product-id — Matches the string against the h323-product-id field.

tls-cert-subj-org-name — Matches the TLS Certificate Subject Organization Name substring.

tls-cert-subj-common-name — Matches the TLS Certificate Subject Common Name substring.

rtsp-host — Matches the Real Time Streaming Protocol (RTSP) substring host.

rtsp-uri — Matches the RTSP URI substring.

rtsp-ua — Matches the RTSP UA substring.

eq — Specifies the equal to comparison operator to match the specified HTTP string.

neq — Specifies the not equal to comparison operator to match the specified HTTP string.

expr-string — Specifies an expression string, up to 64 characters, used to define a pattern match.

Denotes a printable ASCII substring used as input to an application assurance filter match criteria object.

- The following syntax is permitted within the substring to define the pattern match criteria:
 - ^<substring>* - matches when <substring> is at the beginning of the object.
 - *<substring>* - matches when <substring> is at any place within the object.
 - *<substring>\$ - matches when <substring> is at the end of the object.
 - ^<substring>\$ - matches when <substring> is the entire object.
 - * - matches zero to many of any character. Note that a single wildcard as infix in the expression is allowed.
 - \. - matches any single character
 - \d - matches any single decimal digit [0-9]
 - \I - forces case sensitivity (by default, the expression match are case insensitive), the \I can be specified anywhere between the leading [^*] and trailing [\$*]
 - * - matches the asterisk character
- Rules for <substring> characters:
 - <substring> must contain printable ASCII characters.
 - <substring> must not contain the “double quote” character or the “ ” (space) character on its own.

<substring> match is case in sensitive by default.

<substring> must not include any regular expression meta-characters other than "*", "\I", "\.", "*" and "\d".

- The “\” (slash) character is used as an ESCAPE sequence. The following ESCAPE sequences are permitted within the <substring>:

Character to match	<substring> input
Hexidecimal Octet YY	\xYY

Note: A <substring> that uses the '\ (backslash) ESCAPE character which is not followed by a “\” or “\x” and a 2-digit hex octet is not valid.

Operational notes:

1. When matching a TCP flow against HTTP-string based applications, the HTTP header fields are collected from the first HTTP request (for example a GET or a POST) for a given TCP flow. The collected strings are then evaluated against each HTTP flow created within the given TCP flow to determine whether a given HTTP flow matches the application. By not specifying a protocol, the HTTP expressions are matched against all protocols in the HTTP family. By specifying a specific HTTP protocol (for example, http_video) the expression match can be constrained to a subset of the HTTP protocols.
2. To uniquely identify a SIP-based application a protocol match is not required in the app-filter entry with the SIP expression. The SIP expression match is performed against any protocol in the SIP family (such as sip and rtp_sip). By specifying a specific SIP protocol (like rtp_sip) the expression match can be constrained to a subset of the SIP protocols.

flow-setup-direction

Syntax	flow-setup-direction {subscriber-to-network network-to-subscriber both}
Context	config>app-assure>group>policy>app-filter>entry
Description	This command configures the direction of flow setup to which the application filter entry is to be applied.
Parameters	subscriber-to-network — Specifies that the app-filter entry will be applied to flows initiated by a local subscriber. network-to-subscriber — Specifies that the app-filter entry will be applied to flows initiated from a remote destination towards a local subscriber. both — Specifies that the app filter entry will be applied for subscriber-to-network and network-to-subscriber traffic.
Default	both

ip-protocol-num

Syntax	ip-protocol-num {eq neq} protocol-id no ip-protocol-num
---------------	--

Context	config>app-assure>group>policy>app-filter>entry
Description	This command configures the IP protocol to use in the application definition. The no form of the command restores the default (removes IP protocol number from application criteria defined by this app-filter entry).
Default	none
Parameters	<p>eq — Specifies that the value configured and the value in the flow must be equal.</p> <p>neq — Specifies that the value configured differs from the value in the flow.</p> <p><i>protocol-id</i> — Specifies the decimal value representing the IP protocol to be used as an IP filter match criterion. Well known protocol numbers include ICMP (1), TCP (6), UDP (17). The no form the command removes the protocol from the match criteria.</p> <p>Values 1 — 255 (Decimal, Hexadecimal, or Binary representation). Supported IANA IP protocol names: crtp, crudp, egp, eigrp, encap, ether-ip, gre, icmp, idrp, igmp, igp, ip, ipv6, ipv6-frag, ipv6-icmp, ipv6-no-nxt, ipv6-opts, ipv6-route, isis, iso-ip, l2tp, ospf-igp, pim, pnni, ptp, rdp, rsvp, sctp, stp, tcp, udp, vrrp * - udp/tcp wildcard</p>

server-address

Syntax	server-address { eq neq } <i>ip-address</i> no server-address				
Context	config>app-assure>group>policy>app-filter>entry				
Description	This command configures the server address to use in application definition. The server IP address may be the source or destination, network or subscriber IP address. The no form of the command restores the default (removes the server address from application criteria defined by this entry).				
Default	no net-address				
Parameters	<p>eq — Specifies a comparison operator that the value configured and the value in the flow are equal.</p> <p>neq — Specifies a comparison operator that the value configured differs from the value in the flow.</p> <p><i>ip-address</i> — Specifies a valid unicast address.</p> <p>Values</p> <table> <tr> <td>ipv4-address</td> <td>a.b.c.d[/mask] mask - [1..32]</td> </tr> <tr> <td>ipv6-address</td> <td>x:x:x:x:x:x/prefix-length x:x:x:x:x:d.d.d.d x - [0..FFFF]H d - [0..255]D prefix-length [1..128]</td> </tr> </table>	ipv4-address	a.b.c.d[/mask] mask - [1..32]	ipv6-address	x:x:x:x:x:x/prefix-length x:x:x:x:x:d.d.d.d x - [0..FFFF]H d - [0..255]D prefix-length [1..128]
ipv4-address	a.b.c.d[/mask] mask - [1..32]				
ipv6-address	x:x:x:x:x:x/prefix-length x:x:x:x:x:d.d.d.d x - [0..FFFF]H d - [0..255]D prefix-length [1..128]				

server-port

Syntax	server-port { eq neq gt lt } <i>server-port-number</i> server-port { eq neq } range <i>start-port-num end-port-num</i> server-port { eq } { <i>port-num</i> range <i>start-port-num end-port-num</i> } { first-packet-trusted first-packet-validate } no server-port
Context	config>app-assure>group>policy>app-filter>entry
Description	<p>This command specifies the server TCP or UDP port number to use in the application definition. The no form of the command restores the default (removes server port number from application criteria defined by this app-filter entry).</p>
Default	no server-port (the server port is not used in the application definition)
Parameters	<p>eq — Specifies that the value configured and the value in the flow are equal.</p> <p>neq — Specifies that the value configured differs from the value in the flow.</p> <p>gt — Specifies all port numbers greater than server-port-number match.</p> <p>lt — Specifies all port numbers less than server-port-number match.</p> <p><i>server-port-num</i> — Specifies a valid server port number.</p> <p>Values 0 — 65535</p> <p><i>start-port-num, end-port-num</i> — Specifies the starting or ending port number.</p> <p>Values 0 — 65535</p> <p>Server Port Options:</p> <ul style="list-style-type: none"> • No option specified: TCP/UDP port applications with full signature verification: <ul style="list-style-type: none"> – AA ensures that other applications that can be identified do not run over a well-known port. – Application-aware policy applied once signature-based identification completes (likely requiring several packets). • first-packet-validate: TCP/UDP trusted port applications with signature verification: <ul style="list-style-type: none"> – Application identified using well known TCP/UDP port based filters and re-identified once signature identification completes. – AA policy applied from the first packet of a flow while continuing signature-based application identification. Policy re-evaluated once the signature identification completes, allowing to detect improper/unexpected applications on a well-known port. • first-packet-trusted: TCP/UDP trusted port applications - no signature verification: <ul style="list-style-type: none"> – Application identified using well known TCP/UDP port based filters only. – Application Aware policy applied from the first packet of a flow. – No signature processing assumes operator/customer trusts that no other applications can run on the well-known TCP/UDP port (statistics collected against trusted_tcp or trusted_udp protocol).

protocol

Syntax	protocol { eq neq } <i>protocol-name</i> no protocol
Context	config>app-assure>group>policy>app-filter>entry
Description	This command configures protocol signature in the application definition. The no form of the command restores the default (removes protocol from match application defined by this app-filter entry).
Default	no protocol
Parameters	eq — Specifies that the value configured and the value in the flow are equal. neq — Specifies that the value configured differs from the value in the flow. <i>protocol-name</i> — A string of up to 32 characters identifying a predefined protocol.

Sample Output

```
*A:7x50-E11# show application-assurance protocol
=====
Application Assurance Protocols
=====
                Protocol : Description
-----
                aim_oscar : America Online Oscar Instant Messaging.
                aim_oscar_file_xfer : America Online Oscar File Transfer.
                aim_oscar_video_voice : America Online Oscar Video and Voice
                                     Traffic.
                aim_toc : America Online Talk to Oscar Instant
                          Messaging.
                ares : Ares P2P File Sharing Protocol
                betamax_voip : Betamax VoIP Protocol traffic.
                bgp : IETF RFC 4271: Border Gateway Protocol
                bittorrent : BitTorrent peer to peer protocol.
                citrix_ica : Citrix ICA protocol.
                citrix_ima : Citrix IMA protocol.
                cnnlive : CNN Live Streaming Video
                cups : Common Unix Printing Service.
                cut_through : Traffic that cannot be categorized. Only
                              default subscriber policy is applied.
                cut_through_by_default_policy : Traffic that has been cut-through due to a
                                                subscriber default policy.
                cvs : Concurrent Versions System.
                daap : iTunes Digital Audio Access Protocol media
                       sharing protocol.
                dcerpc : DCERPC Remote Procedure Call.
                denied_by_default_policy : Traffic that was denied by a default
                                           subscriber flow policer.
                dhcp : Dynamic Host Configuration Protocol
                       traffic.
                dht : Peer to Peer Distributed Hash Table
                       exchange.
                direct_connect : Direct Connect peer to peer protocol
                dns : IETF RFC 1035: Domain Name System.
                domino : IBM Domino-Notes.
```

Group Commands

empty_tcp : TCP flows that close without ever having exchanged any data.

emule : eMule/eDonkey peer to peer protocol.

existing : Traffic that was in progress or with no start of flow.

fasttrack : FastTrack peer to peer protocol.

fix : FIX (Financial Information eXchange) protocol.

fring : Fring Mobile traffic.

ftp_control : IETF RFC 959: File Transfer Protocol control traffic.

ftp_data : IETF RFC 959: File Transfer Protocol data traffic.

funshion : Funshion Streaming Video

gamecenter : Apple Game Center

gnutella : Gnutella/Gnutella2 peer to peer protocol.

google_talk_file_xfer : Google Talk Instant Messaging file transfer.

google_talk_im : Google Talk Instant Messaging.

google_talk_voicemail : Google Talk Instant Messaging voice mail.

gtp : GTP (GPRS Tunneling Protocol).

h225 : ITU H.225 Multimedia Call Signalling Protocol

h245 : ITU H.245 Control Protocol for MultiMedia Communication

headcall : Headcall Protocol traffic.

hotline : Hotline Communications: A client-server protocol for file sharing and chatting.

http : IETF RFC 2616: Hypertext transfer protocol.

http_audio : HTTP transported Audio content.

http_shockwaveflash : HTTP transported Shockwave Flash content.

http_video : HTTP transported Video content.

http_webfeed : RSS or ATOM Web Feed

hulu : HULU media traffic.

iax2 : InterAsterisk Exchange Protocol.

ibmdb2 : IBM DB2 Database Server.

icq : ICQ protocol traffic.

ident : IETF RFC 1413 Identification Protocol

iiop : CORBA IIOP Network Protocol.

imap4 : IETF RFC 3501: Internet Message Access Protocol V.4.

iplayer : BBC iPlayer media traffic.

ipp : Internet Printing Protocol.

ipsec_nat_t : IETF RFC 3948: UDP Encapsulated IPsec ESP.

irc : RFC 1459 Internet Relay Chat

isakmp : IETF RFC 2408 4306: Internet Security Association and Key Management Protocol.

iscsi : iSCSI Protocol.

jolt : Oracle JOLT (Java OnLine Transactions) Protocol.

justintv : Justin.tv media traffic.

kerberos : Kerberos Version 5 Network Authentication

kontiki : Kontiki Distribution Protocol

ldap : IETF RFC 4510: Lightweight Directory Access Protocol.

llmnr : LLMNR Protocol.

mail_ru : mail.ru messaging protocol

manolito : Manolito P2P File Sharing Protocol

megaco : Media Gateway Control Protocol.

mgcp : Media Gateway Control Protocol.

mms : Multimedia Messaging Service over HTTP.

```

ms_communicator : Microsoft Communicator Client.
  msexchange : MS Exchange MAPI Interface.
  msn_msgr : MSN Messenger client/server protocol.
msn_msgr_file_xfer : MSN Messenger initiated P2P file transfer.
  msn_msgr_video : MSN Messenger Video Chat.
  mssql_smb : MS SQL Server Named Pipe traffic.
  mssql_tcp : MS SQL Server over TCP.
  mssql_udp : MS SQL Server Monitoring Service.
  mysql : MySQL Network Protocol.
net2phone : Net2Phone protocol.
net2phone_voip : Net2Phone VOIP
  netbios : IETF RFC 1001: Network Basic Input Output
  System.
  nimbuzz : Nimbuzz Protocol.
  nntp : IETF RFC 3977: Network News Transfer
  Protocol.
non_tcp_udp : Non TCP or UDP traffic.
  ntp : IETF RFC1305 RFC2030: Network Time
  Protocol.
  octoshape : Octoshape Streaming Video
  onlive : OnLive Cloud Streaming Services
  oovoo : ooVoo Protocol.
  openft : openft peer to peer protocol.
  openvpn : OpenVPN: open source virtual private
  network protocol.
opera_mini : Opera Mini mobile web browser.
oracle_net : Oracle TNS (Transparent Network Substrate)
  Protocol.
pcanywhere : Symantec PcAnywhere.
  pop3 : IETF RFC 1939: Post Office Protocol V.3.
postgresql : PostgreSQL Network Protocol.
  pplive : PPLive Peer to Peer Video Streaming
  Protocol
  ppstream : PPStream Chinese P2P streaming video.
  pptp : Point-to-Point Tunneling Protocol.
  q931 : ITU Q.931 Call Signalling Protocol
  qq : QQ Instant Messaging Protocol
  qvod : QVOD: Streaming media on demand.
  rdp : Remote Desktop Protocol.
  rdt : Realnetworks Data Transport protocol.
  rfb : Remote Framebuffer protocol.
rlogin : IETF RFC 1258 rlogin virtual terminal
  protocol widely used between Unix hosts
  rsh : Unix remote shell command
rsync : Open source file transfer protocol
rtmp : RTMP: Adobe Real Time Messaging Protocol.
rtmpe : RTMPE: Encrypted Adobe Real Time Messaging
  Protocol.
rtmpt : RTMPT: HTTP Tunneled Adobe Real Time
  Messaging Protocol.
  rtp : IETF RFC 3550: Real-time Transport
  Protocol.
  rtp_aim : America Online RTP Video/Voice.
  rtp_h323 : H323 RTP Voice.
rtp_msn_msgr : MSN Messenger RTP Voice.
  rtp_rtsp : RTSP RTP Data
  rtp_sip : SIP RTP Data
  rtp_skinny : Skinny RTP Data
rtp_yahoo_im : Yahoo Instant Messenger RTP Voice.
  rtsp : IETF RFC 2326: Real Time Streaming
  Protocol.

```

Group Commands

```
sap : SAP Protocol.
shoutcast : SHOUTcast audio streaming protocol.
siebel : Siebel Suite.
sip : IETF RFC 3261: Session Initiation Protocol.
skinny : Skinny Call Control Protocol.
skype : Skype
slingbox : SlingBox: TV video streaming and remote
control
smb : Server Message Block protocol over TCP.
smb_netbios : Server Message Block protocol over NetBIOS.
smtp : IETF RFC 2821: Simple Mail Transfer
Protocol.
snmp : Simple Network Management Protocol traffic.
socks : SOCKS Proxy.
soulseek : SoulSeek P2P File Sharing Protocol
spotify : Spotify Protocol.
ssh : IETF RFC 4251: Secure shell protocol.
starcraft2 : Starcraft II Protocol
steam : Steam Gaming Protocol.
steam_gaming : Steam Online Gaming Protocol.
stun : IETF RFC 3489: Simple Traversal of UDP
through NATs.
sunrpc : SUNRPC Remote Procedure Call.
svn : Subversion Version Control System.
sybase_db : SYBASE Database Network Protocol.
syslog : IETF RFC 3164: syslog protocol.
t125 : ITU T.125 Multipoint communication service
protocol
teamspeak : TeamSpeak Protocol traffic.
telnet : IETF RFC 854: Telnet Network Virtual
Terminal protocol.
teredo : Teredo: IPv6 packets in IPv4 UDP datagrams
tunneling protocol.
tftp : IETF RFC 1350: Trivial File Transfer
Protocol.
tivo : TiVo Service
tls : IETF RFC 4346: Transport Layer Security
protocol.
tn3270 : IETF RFC1576 RFC2355: TN3270 terminal
emulation via telnet.
tor : Tor internet anonymity protocol.
trusted_tcp : Traffic identified using a trusted TCP
port number.
trusted_udp : Traffic identified using a trusted UDP
port number.
tuxedo : Oracle TUXEDO Protocol.
tvu : TVU Networks media traffic.
ultravox : Ultravox streaming media protocol.
unknown_tcp : Unknown or unidentified TCP traffic.
unknown_udp : Unknown or unidentified UDP traffic.
ustream : Ustream media traffic.
utp : uTP: Micro Transport Protocol.
ventrilo : Ventrilo Protocol traffic.
viber : Viber Mobile traffic.
vmware : VMware Traffic.
vudu : VUDU on-demand video distribution
webex : Cisco Webex web conferencing
weixin : Weixin Instant Messaging Protocol
whatsapp : WhatsApp Protocol.
winmx : WinMX P2P File Sharing Protocol
wow : World of Warcraft Protocol
```


Application Assurance Commands

```
wsp_http : WSP transported HTTP traffic.
xboxlive : Xbox Live: Microsoft online game and media
           delivery service.
          xmpp : IETF RFC 3920: Extensible Messaging and
           Presence Protocol.
xmpp_facebook : Facebook XMPP traffic.
          xunlei : Xunlei Client.
          xwindows : X Window System: A graphical user
           interface for networked computers
yahoo_file_xfer : Yahoo Instant Messaging Protocol File
           Transfer.
          yahoo_im : Yahoo Instant Messaging Protocol.
          yahoo_video : Yahoo Instant Messaging Protocol Webcam
           Video.
          youtube : YouTube RTMP/RTMPE traffic.
```

```
=====
Number of protocols      : 181
*A:7x50-E11#
```

APPLICATION PROFILE COMMANDS

capacity-cost

Syntax	capacity-cost <i>cost</i> nocapacity-cost
Context	config>app-assure>group>policy>app-profile
Description	This command configures an application profile capacity cost. Capacity-Cost based load balancing allows a cost to be assigned to diverted SAPs (with the app-profile) and this is then used for load-balancing SAPs between ISAs as well as for a threshold that notifies the operator if/when capacity planning has been exceeded.
Parameters	<i>cost</i> — Specifies the profile capacity cost. Values 1 — 65535

characteristic

Syntax	characteristic <i>characteristic-name value value-name</i> no characteristic <i>characteristic-name</i>
Context	config>app-assure>group>policy>app-profile
Description	This command assigns one of the existing values of an existing application service option characteristic to the application profile. The no form of the command removes the characteristic from the application profile.
Default	none
Parameters	<i>characteristic-name</i> — Specifies the name of an existing ASO characteristic. value <i>value-name</i> — Specifies the name for the application profile characteristic up to 32 characters.

divert

Syntax	[no] divert
Context	config>app-assure>group>policy>app-profile
Description	This command enables the redirection of traffic to AA ISA for the system-wide forwarding classes diverted to application assurance (divert-fe) for AA subscribers using this application profile. The no form of the command stops redirect of traffic to AA ISAs for the AA subscribers using this application profile.
Default	no divert

APPLICATION QoS POLICY COMMANDS

entry

Syntax	[no] entry <i>entry-id</i> [create]
Context	config>app-assure>group>policy>aqp
Description	This command creates an application QoS policy entry. A flow that matches multiple Application QoS policies (AQP) entries will have multiple AQP entries actions applied. When a conflict occurs for two or more actions, the action from the AQP entry with the lowest numerical value takes precedence. The no form of this command deletes the specified application QoS policy entry.
Default	none
Parameters	<i>entry-id</i> — An integer identifying the AQP entry. Values 1 — 65535 create — Mandatory keyword creates the entry. The create keyword requirement can be enabled/disabled in the environment>create context.

action

Syntax	action
Context	config>app-assure>group>policy>aqp>entry
Description	This command enables the context to configure AQP actions to be performed on flows that match the AQP entry's match criteria.

bandwidth-policer

Syntax	bandwidth-policer <i>policer-name</i> no bandwidth-policer
Context	config>app-assure>group>policy>aqp>entry>action
Description	This command assigns an existing bandwidth policer as an action on flows matching this AQP entry. The match criteria for the AQP entry must specify a uni-directional traffic direction before a policer action can be configured. If a policer is used in one direction in an AQP match entry the same policer name cannot be used by another AQP entry which uses a different traffic direction match criteria. When multiple policers apply to a single flow, the final action on a packet is the worse case of all policer outcome (for example, if one of the policers marks packet out of profile, the final marking will reflect that).

Group Commands

The **no** form of the command removes bandwidth policer from actions on flows matching this AQP entry.

Default no bandwidth-policer

Parameters *policer-name* — The name of the existing flow setup rate policer for this application assurance profile. The *policer-name* is configured in the **config>app-assure>group>policer** context.

cut-through-drop

Syntax [**no**] **cut-through-drop**

Context config>app-assure>group>policy>aqp>entry>action

Description This command specifies the action that will be applied to traffic which is cut-through in one or both directions of traffic flow based on the match criteria.

Default allow

drop

Syntax [**no**] **drop**

Context config>app-assure>group>policy>aqp>entry>action

Description This command configures the drop action on flows matching this AQP entry. When enabled, all flow traffic matching this AQP entry will be dropped. When drop action is part of a set of multiple actions to be applied to a single flow as result of one or more AQP entry match, drop action will be performed first and no other action will be invoked on that flow.

The **no** form of the command disables the drop action on flows matching this AQP entry.

Default no drop

flow-count-limit

Syntax **flow-count-limit** *policer-name*
no flow-count-limit

Context config>app-assure>group>policy>aqp>entry>action

Description This command assigns an existing flow count limit policer as an action on flows matching this AQP entry.

The match criteria for the AQP entry must specify a uni-directional traffic direction before a policer action can be configured. If a policer is used in one direction in an AQP match entry the same policer name cannot be used by another AQP entry which uses a different traffic direction match criteria.

When multiple policers apply to a single flow, the final action on a packet is the worse case of all policer outcome (for example, if one of the policers marks packet out of profile, the final marking will reflect that).

The **no** form of the command removes this flow policer from actions on flows matching this AQP entry.

Default no flow-count-limit

Parameters *policer-name* — The name of the existing flow setup rate policer for this application assurance profile. The *policer-name* is configured in the **config>app-assure>group>policer** context.

flow-rate-limit

Syntax **flow-rate-limit** *policer-name*
no flow-rate-limit

Context config>app-assure>group>policy>aqp>entry>action

Description This command assigns an existing flow setup rate limit policer as an action on flows matching this AQP entry.

The match criteria for the AQP entry must specify a uni-directional traffic direction before a policer action can be configured. If a policer is used in one direction in an AQP match entry the same policer name cannot be used by another AQP entry which uses a different traffic direction match criteria.

When multiple policers apply to a single flow, the final action on a packet is the worse case of all policer outcome (for example, if one of the policers marks packet out of profile, the final marking will reflect that).

The **no** form of the command removes this flow policer from actions on flows matching this AQP entry.

Default no flow-rate-limit

Parameters *policer-name* — The name of the existing flow setup rate policer for this application assurance profile. The *policer-name* is configured in the **config>app-assure>group>policer** context.

fragment-drop

Syntax **fragment-drop** {**all** | **out-of-order**} [**event-log** *event-log-name*]
no fragment-drop

Context config>app-assure>group>policy>aqp>entry>action

Description This command specifies the action to apply to fragments.

Parameters **all** — All the fragments will be dropped.

out-of-order — All out of order fragments will be dropped.

event-log *event-log-name* — specifies if the dropping of fragments should be logged to the specified event log name.

http-enrich

Syntax	http-enrich <i>http-enrich-name</i> no http-enrich
Context	config>app-assure>group>policy>aqp>entry>action
Description	This command configures a the HTTP header enrichment template name that will be applied as defined in the tmnxBsxHttpEnrichTable. An empty value specifies no HTTP header enrichment template.
Parameters	<i>http-enrich-name</i> — Specifies the HTTP header enrichment template name up to 32 characters inlength.

http-redirect

Syntax	http-redirect <i>http-redirect-name</i> flow-type <i>flow-type</i> no http-redirect
Context	config>app-assure>group>policy>aqp>entry>action
Description	<p>This command assigns an existing http redirect policy as an action on flows matching this AQP entry. The redirect only takes effect if the matching flows are HTTP and the condition specified after the http-redirect command, admitted flows or dropped-flows, is met. The condition specified by “dropped-flows” means the flow is dropped due to an AQP actions such as “flow rate/count policers” or “drop” actions. HTTP Policy Redirect on admitted-flows allows the operator to redirect HTTP traffic to a web portal while allowing non-HTTP matching the same AQP rule to be forwarded.</p> <p>Note: No HTTP redirect will take place if HTTP redirect action and a “drop/flow-police” action are part of the default AQP policy, because in this case, any flow drop actions will take place before identification of the application/application-group.</p> <p>The no form of the command removes http redirect from actions on flows matching this AQP entry.</p>
Default	no http-redirect
Parameters	<p><i>http-redirect-name</i> — Specifies the name of the existing http policy redirect for this application assurance profile. The HTTP redirect name is configured in the config>appassure>group>http-redirect context.</p> <p>flow-type <i>flow-type</i> —</p> <p>Values</p> <ul style="list-style-type: none"> admitted-flows — Redirect HTTP flows matching the AQP criteria. dropped-flows — Redirects those HTTP flows that are dropped due to an AQP action.

http-error-redirect

Syntax	http-error-redirect <i>redirect-name</i> no http-error-redirect
---------------	--

Context	config>app-assure>group>policy>aqp>entry>action
Description	This command specifies the HTTP error redirect that will be applied as defined in the redirect table. An empty value specifies no HTTP error redirect.
Parameters	<i>redirect-name</i> — Specifies an http-error redirect action, up to 32 characters in length, for flows matching this entry.

http-redirect

Syntax	http-redirect <i>redirect-name</i> flow-type <i>flow-type</i> no http-redirect
Context	config>app-assure>group>policy>aqp>entry>action
Description	This command configures an HTTP redirect action for flows of a specific type matching this entry
Default	no http-redirect
Parameters	<i>redirect-name</i> — Specifies the HTTP error redirect that will be applied as defined in the tmnxBsxHttpRedirErrTable. An empty value specifies no HTTP error redirect. flow-type <i>flow-type</i> — Specifies the type of flow that will be redirected.
Values	admitted-flows — This allows HTTP redirect for selective traffic steering of HTTP traffic while not affecting other traffic. dropped-flows — This allows HTTP redirect on blocked traffic.

http-notification

Syntax	http-notification <i>http-notification</i> no http-notification
Context	config>app-assure>group>policy>aqp>entry>action
Description	This command configures an HTTP notification action for flows matching this entry.
Parameters	<i>http-notification</i> — specifies the Application-Assurance HTTP Notification that will be applied as defined in the tmnxBsxHttpNotifTable. If no string is configured then no HTTP notification will occur.

mirror-source

Syntax	mirror-source [all-inclusive] <i>mirror-service-id</i> no mirror-source
Context	config>app-assure>group>policy>aqp>entry>action
Description	This command configures an application-based policy mirroring service that uses this AA ISA group's AQP entry as a mirror source. When configured, AQP entry becomes a mirror source for IP

Group Commands

packets seen by the AA (note that the mirrored packet is an IP packet analyzed by AA and does not include encapsulations present on the incoming interfaces).

Default no mirror-source

Parameters **all-inclusive** — Specifies that all packets during identification phase that could match a given AQP rule are mirrored in addition to packets after an application identification completes that match the AQP rule. This ensures all packets of a given flow are mirrored at a cost of sending unidentified packets that once the application is identified will no longer match this AQP entry.

mirror-service-id — Specifies the mirror source service ID to use for flows that match this policy.

Values 1 — 214748364
svc-name: 64 char max

remark

Syntax **remark**

Context config>app-assure>group>policy>aqp>entry>action

Description This command configures remark action on flows matching this AQP entry.

dscp

Syntax **dscp in-profile dscp-name out-profile dscp-name**
no dscp

Context config>app-assure>group>policy>aqp>entry>action>remark

Description This command enables the context to configure DSCP remark action or actions on flows matching this AQP entry. When enabled, all packets for all flows matching this AQP entry will be remarked to the configured DSCP name.

DSCP remark can only be applied when the entry remarks forwarding class or forwarding class and priority. In-profile and out-of profile of a given packet for DSCP remark is assessed after all AQP policing and priority remarking actions took place.

The **no** form of the command stops DSCP remarking action on flows matching this AQP entry.

Parameters **in-profile dscp-name** — Specifies the DSCP name to use to remark in-profile flows that match this policy.

out-profile dscp-name — Specifies the DSCP name to use to remark out-of-profile flows that match this policy.

Values be, cp1, cp2, cp3, cp4, cp5, cp6, cp7, cs1, cp9, af11, cp11, af12, cp13, af13, cp15, cs2, cp17, af21, cp19, af22, cp21, af23, cp23, cs3, cp25, af31, cp27, af32, cp29, af33, cp31, cs4, cp33, af41, cp35, af42, cp37, af43, cp39, cs5, cp41, cp42, cp43, cp44, cp45, ef, cp47, nc1, cp49, cp50, cp51, cp52, cp53, cp54, cp55, nc2, cp57, cp58, cp59, cp60, cp61, cp62, cp63

fc

Syntax	fc <i>fc-name</i> no fc
Context	config>app-assure>group>policy>aqp>entry>action>remark
Description	This command configures remark FC action on flows matching this AQP entry. When enabled, all packets for all flows matching this AQP entry will be remarked to the configured forwarding class. The no form of the command stops FC remarking action on packets belonging to flows matching this AQP entry
Parameters	<i>fc-name</i> — Configure the FC remark action for flows matching this entry. Values be, l2, af, l1, h2, ef, h1, nc

priority

Syntax	priority <i>priority-level</i> no priority
Context	config>app-assure>group>policy>aqp>entry>action>remark
Description	This command configures remark discard priority action on flows matching this AQP entry. When enabled, all packets for all flows matching this AQP entry will be remarked to the configured discard priority.
Default	no priority
Parameters	<i>priority-level</i> — Specifies the priority to apply to a packet. Values high, low

session-filter

Syntax	session-filter <i>session-filter-name</i> no session-filter
Context	config>app-assure>group>policy>aqp>entry>action
Description	This command specifies the Application-Assurance session filter that will be evaluated. If no session filters are specified then no session filters will be evaluated.
Default	none
Parameters	<i>session-filter-name</i> — Specifies the session filter to be applied.

url-filter

Syntax **url-filter** *url-filter-name* [**create**]

Group Commands

no url-filter *url-filter-name*

- Context** config>app-assure>group>policy>aqp>entry>action
- Description** This command configures a url-filter policy used for icap url filtering.
The **no** form of the command removes the url filter policy from the configuration.
- Parameters** *url-filter-name* — Specifies the Name of the URL Filter policy
create — - Mandatory keyword to create the policy.

match

- Syntax** **match**
- Context** config>app-assure>group>policy>aqp>entry
- Description** This command enables the context to configure flow match rules for this AQP entry. A flow matches this AQP entry only if it matches all the match rules defined (logical and of all rules). If no match rule is specified, the entry will match all flows.

aa-sub

- Syntax** **aa-sub esm {eq | neq} sub-ident-string**
aa-sub sap {eq | neq} sap-id
aa-sub spoke-sdp {eq | neq} sdp-id:vc-id
aa-sub transit {eq | neq} transit-aasub-name
no aa-sub
- Context** config>app-assure>group>policy>aqp>entry>match
- Description** This command specifies a Service Access Point (SAP) or an ESM subscriber as matching criteria.
The **no** form of the command removes the SAP or ESM matching criteria.
- Parameters** **eq** — Specifies that the value configured and the value in the flow are equal.
neq — Specifies that the value configured differs from the value in the flow.
sub-ident-string — Specifies the name of an existing application assurance subscriber.
sap-id — Specifies the SAP ID.
sap *sap-id* — Specifies the physical port identifier portion of the SAP definition.
sdp-id:vc-id — Specifies the spoke SDP ID and VC ID.
- Values** 1 — 17407
1 — 4294967295
- transit-aa-sub-name* — Specifies the name of a transit AA subscriber.

app-group

Syntax	app-group { eq neq } <i>application-group-name</i> no app-group
Context	config>app-assure>group>policy>aqp>entry>match
Description	This command adds app-group to match criteria used by this AQP entry. The no form of the command removes the app-group from match criteria for this AQP entry.
Default	no app-group
Parameters	eq — Specifies that the value configured and the value in the flow are equal. neq — Specifies that the value configured differs from the value in the flow. <i>application-group-name</i> — The name of the existing application group entry. The application-group-name is configured in the config>app-assure>group>policy>aqp>entry>match context.

application

Syntax	application { eq neq } <i>application-name</i> no application
Context	config>app-assure>group>policy>aqp>entry>match
Description	This command adds an application to match criteria used by this AQP entry. The no form of the command removes the application from match criteria for this AQP entry.
Default	no application
Parameters	eq — Specifies that the value configured and the value in the flow are equal. neq — Specifies that the value configured differs from the value in the flow. <i>application-name</i> — The name of name existing application name. The application-group-name is configured in the config>app-assure>group>policy>aqp>entry>match context.

characteristic

Syntax	characteristic <i>characteristic-name</i> eq <i>value-name</i> no characteristic
Context	config>app-assure>group>policy>aqp>entry>match
Description	This command adds an existing characteristic and its value to the match criteria used by this AQP entry. The no form of the command removes the characteristic from match criteria for this AQP entry.
Default	no characteristic
Parameters	eq — Specifies that the value configured and the value in the flow are equal.

Group Commands

characteristic-name — The name of the existing ASO characteristic up to 32 characters in length.

value-name — The name of an existing value for the characteristic up to 32 characters in length.

charging-group

Syntax	charging-group { eq neq } <i>charging-group-name</i> no charging-group
Context	config>app-assure>group>policy>aqp>entry>match
Description	This command adds charging-group to match criteria used by this AQP entry. The no form of the command removes the charging-group from match criteria for this AQP entry.
Default	no charging-group
Parameters	eq — Specifies that the value configured and the value in the flow are equal. neq — Specifies that the value configured differs from the value in the flow. <i>charging-group-name</i> — The name of the existing application group entry. The application-group name is configured in the config>app-assure>group>policy>aqp>entry>match context.

dscp

Syntax	dscp { eq neq } dscp-name no dscp
Context	config>app-assure>group>policy>aqp>entry>match config>app-assure>group>sess-fltr>entry>match
Description	This command adds a DSCP name to the match criteria used by this entry. The no form of the command removes dscp from match criteria for this entry.
Default	no dscp
Parameters	eq — Specifies that the value configured and the value in the flow are equal. neq — Specifies that the value configured differs from the value in the flow. <i>dscp-name</i> — The DSCP name to be used in match. Values be, cp1, cp2, cp3, cp4, cp5, cp6, cp7, cs1, cp9, af11, cp11, af12, cp13, af13, cp15, cs2, cp17, af21, cp19, af22, cp21, af23, cp23, cs3, cp25, af31, cp27, af32, cp29, af33, cp31, cs4, cp33, af41, cp35, af42, cp37, af43, cp39, cs5, cp41, cp42, cp43, cp44, cp45, ef, cp47, nc1, cp49, cp50, cp51, cp52, cp53, cp54, cp55, nc2, cp57, cp58, cp59, cp60, cp61, cp62, cp63

dst-ip

Syntax	dst-ip { eq neq } <i>ip-address</i>
---------------	--

Group Commands

Description	This command configures the IP protocol to use to use as match criteria. The no form the command removes the protocol from the match criteria.
Default	none
Parameters	eq — Specifies that the value configured and the value in the flow must be equal. neq — Specifies that the value configured differs from the value in the flow. protocol-id — Specifies the decimal value representing the IP protocol to be used as an IP filter match criterion. Well known protocol numbers include ICMP (1), TCP (6), UDP (17). Values 1 — 255 (Decimal, Hexadecimal, or Binary representation). Supported IANA IP protocol names: crtp, crudp, egg, eigrp, encap, ether-ip, gre, icmp, idrp, igmp, igp, ip, ipv6, ipv6-frag, ipv6-icmp, ipv6-no-nxt, ipv6-opts, ipv6-route, isis, iso-ip, l2tp, ospf-igp, pim, pnni, ptp, rdp, rsvp, sctp, stp

src-ip

Syntax	src-ip { eq neq } <i>ip-address</i> no src-ip
Context	config>app-assure>group>policy>aqp>entry>match config>app-assure>group>sess-fltr>entry>match
Description	This command specifies a source TCP/UDP address to use as match criteria.
Parameters	eq — Specifies that a successful match occurs when the flow matches the specified address or prefix. neq — Specifies that a successful match occurs when the flow does not match the specified address or prefix. <i>ip-address</i> — Specifies a valid IPv4 unicast address. <i>ip-address</i> — Specifies a valid unicast address. Values ipv4-address a.b.c.d[/mask] mask - [1..32] ipv6-address x:x:x:x:x:x/x/prefix-length x:x:x:x:x:d.d.d.d x - [0..FFFF]H d - [0..255]D prefix-length [1..128]

src-port

Syntax	src-port { eq neq } <i>port-num</i> src-port { eq neq } range <i>start-port-num end-port-num</i> no src-port
Context	config>app-assure>group>policy>aqp>entry>match

```
config>app-assure>group>sess-fltr>entry>match
```

- Description** This command specifies a source IP port or source range to use as match criteria. The **no** form of the command removes the parameters from the configuration.
- Parameters**
- eq** — Specifies that a successful match occurs when the flow matches the specified port.
 - neq** — Specifies that a successful match occurs when the flow does not match the specified port.
 - port-num* — Specifies the source port number.
 - Values** 0 — 65535
 - start-port-num end-port-num* — Specifies the start or end source port number.
 - Values** 0 — 65535

traffic-direction

- Syntax** **traffic-direction {subscriber-to-network | network-to-subscriber | both}**
- Context** config>app-assure>group>policy>aqp>entry>match
- Description** This command specifies the direction of traffic where the AQP match entry will be applied. To use a policer action with the AQP entry the match criteria must specify a traffic-direction of either subscriber-to-network or network-to-subscriber.
- Default** both
- Parameters**
- subscriber-to-network** — Traffic from a local subscriber will match this AQP entry.
 - network-to-subscriber** — Traffic to a local subscriber will match this AQP entry.
 - both** — Combines subscriber-to-network and network-to-subscriber.

APPLICATION SERVICE OPTIONS COMMANDS

characteristic

Syntax	characteristic <i>characteristic-name</i> [create] no characteristic <i>characteristic-name</i>
Context	config>app-assure>group>policy>aso
Description	This command creates the characteristic of the application service options. The no form of the command deletes characteristic option. To delete a characteristic, it must not be referenced by other components of application assurance.
Default	none
Parameters	<i>characteristic-name</i> — Specifies a string of up to 32 characters uniquely identifying this characteristic. create — Mandatory keyword used to create when creating a characteristic. The create keyword requirement can be enabled/disabled in the environment>create context.

default-value

Syntax	default-value <i>value-name</i> no default-value
Context	config>app-assure>group>policy>aso>char
Description	This command assigns one of the characteristic values as default. When a default value is specified, app-profile entries that do not explicitly include this characteristic inherit the default value and use it as part of the AQP match criteria based on that app-profile. A default-value is required for each characteristic. This is evaluated at commit time. The no form of the command removes the default value for the characteristic.
Default	none
Parameters	<i>value-name</i> — Specifies the name of an existing characteristic value.

value

Syntax	[no] value <i>value-name</i>
Context	config>app-assure>group>policy>aso>char
Description	This command configures a characteristic value. The no form of the command removes the value for the characteristic.

Default none

Parameters *value-name* — Specifies a string of up to 32 characters uniquely identifying this characteristic value.

CUSTOM PROTOCOL COMMANDS

custom-protocol

Syntax	custom-protocol <i>custom-protocol-id</i> ip-protocol-num <i>protocol-id</i> [create] custom-protocol <i>custom-protocol-id</i> no custom-protocol <i>custom-protocol-id</i>
Context	config>app-assure>group>policy
Description	<p>This command creates and enters configuration context for custom protocols. Custom protocols allow the creation of TCP and UDP-based custom protocols (based on the <i>ip-protocol-num</i> option) that employ pattern-match at offset in protocol signature definition.</p> <p>Operator-configurable custom-protocols are evaluated ahead of any Alcatel-Lucent provided protocol signature in order of custom-protocol-id (the lower ID is matched first in case of flow matching multiple custom-protocols) within the context the protocol is defined.</p> <p>Custom protocols must be created before they can be used in application definition but do not have to be enabled. To reference a custom protocol in application definition, or any other CLI configuration one must use protocol name that is a concatenation of “custom_” and <custom-protocol-id>, (for example custom_01, custom_02 ... custom_10, etc.). This concatenation is also used when reporting custom protocol statistics.</p>
Parameters	<p><i>custom-protocol-id</i> — Specifies the index into the protocol list that defines a custom protocol for application assurance.</p> <p>Values 1 — 10</p> <p><i>protocol-id</i> — Specifies the IP protocol to match against for the custom protocol.</p> <p>Values 0 — 255, Protocol numbers accepted in DHB, keywords: udp, tcp</p> <p>create — Mandatory keyword used when creating custom protocol. The create keyword requirement can be enabled/disabled in the environment>create context.</p>

expression

Syntax	expression <i>expr-index</i> eq <i>expr-string</i> offset <i>payload-octet-offset</i> direction <i>direction</i> no expression <i>expr-index</i>
Context	config>app-assure>group>policy>custom-protocol
Description	<p>This command configures an expression string value for pattern-based custom protocols match. A flow matches a custom protocol if the specified string is found at an offset of a TCP/UDP of the first payload packet.</p> <p>Options:</p> <ul style="list-style-type: none"> client-to-server — A pattern will be matched against a flow from a TCP client. server-to-client — A pattern will be matched against a flow from a TCP server.

any – A pattern will be matched against a TCP/UDP flow in any direction (towards or from AA subscriber)

The **no** form of this command deletes a specified string expression from the definition.

Parameters

expr-index — Specifies the expression substring index.

Values 1

expr-string — Denotes a printable ASCII string, up to 16 characters, used to define a custom protocol match. Rules for *expr-string* characters:

- Must contain printable ASCII characters.
- Must not contain the “double quote” character or the “ ” (space) character on its own.
- Match is case sensitive.
- Must not include any regular expression meta-characters.

The “\” (slash) character is used as an ESCAPE sequence. The following ESCAPE sequences are permitted within the *expr-string*:

Character to match	<i>expr-string</i> input
--------------------	--------------------------

Hexidecimal Octet YY	\xYY
----------------------	------

Note: An *expr-string* that uses the “\” (backslash) ESCAPE character which is not followed by a “\” or “\x” and a 2-digit hex octet is not valid.

offset *payload-octet-offset* — specifies the offset (in octets) into the protocol payload, where the *expr-string* match criteria will start.

Values 0 — 127

direction *direction* — Specifies the protocol direction to match against to resolve to a custom protocol.

Values client-to-server, server-to-client, any

Session Filter Commands

session-filter

Syntax	session-filter <i>session-filter-name</i> [create] no session-filter <i>session-filter-name</i>
Context	config>app-assure>group
Description	This command creates a session filter.
Parameters	<i>session-filter-name</i> — Creates a session filter name up to 32 characters in length.

match

Syntax	match
Context	config>app-assure>group>sess-fltr>entry
Description	This command enables the context to configure session conditions for this entry.

default-action

Syntax	default-action { permit deny } no default-action
Context	config>app-assure>group>sess-fltr
Description	This command specifies the default action to take for packets that do not match any filter entries. The no form of the command reverts the default action to the default value (forward).
Default	deny
Parameters	deny — Packets matching the criteria are denied permit — Packets matching the criteria are permitted.

entry

Syntax	entry <i>entry-id</i> [create] no entry <i>entry-id</i>
Context	config>app-assure>group>policy>sess-fltr
Description	This command configures a particular Application-Assurance session filter match entry. Every session filter can have zero or more session filter match entries. An application filter entry or entries configures match attributes of an application.

The **no** form of this command deletes the specified entry.

Default none

Parameters *entry-id* — An integer that identifies the entry.

Values 1 — 65535

create — Keyword used to create the entry.

action

Syntax **action** {**permit**|**deny**}

Context config>app-assure>group>sess-fltr>entry

Description This command configures the action for this entry.

deny — Packets matching the criteria are denied

permit — Packets matching the criteria are permitted.

Statistics Commands

statistics

Syntax	statistics
Context	config>app-assure>group
Description	This command enables the context to configure accounting and billing statistics for this AA ISA group.

app-group

Syntax	app-group <i>app-group-name</i> export-using <i>export-method</i> [<i>export-method...</i> (up to 2 max)] no app-group <i>app-group-name</i>
Context	config>app-assure>group>statistics>aa-sub
Description	This command enables the context to configure accounting and statistics collection parameters per system for application groups of application assurance for a given AA ISA group/partition. The no form of the command removes the application group name.
Default	none
Parameters	<i>app-group-name</i> — Specifies an existing application group name up to 32 characters in length. export-using <i>accounting-policy</i> — Specifies that the method of stats export to be used.

aa-sub

Syntax	aa-sub
Context	config>app-assure>group>statistics
Description	This command enables the context to configure accounting and statistics collection parameters per application assurance subscribers.

aa-sub-study

Syntax	aa-sub-study <i>study-type</i>
Context	config>app-assure>group>statistics
Description	This command enables the context to configure accounting and statistics collection parameters per application assurance special study subscribers.
Parameters	<i>study-type</i> — Specifies special study protocol subscriber stats.

Values application, protocol

application

Syntax	[no] application <i>application-name</i>
Context	config>app-assure>group>statistics
Description	This command configures aa-sub accounting statistics for export of applications of a given AA ISA group/partition. The no form of the command removes the application name.
Default	none
Parameters	<i>applicaiton-name</i> — Specifies an existing application name up to 32 characters in length.

application

Syntax	application <i>application-name</i> export-using { <i>accounting-policy</i> } no application <i>application-name</i>
Context	config>app-assure>group>statistics>aa-sub
Description	This command configures aa-sub accounting statistics for export of applications of a given AA ISA group/partition. The no form of the command removes the application name.
Default	none
Parameters	<i>application-name</i> — Specifies an existing application name up to 32 characters in length. export-using <i>accounting-policy</i> — Specifies that the method of stats export to be used. Accounting-policy is the only option for application statistics.

charging-group

Syntax	charging-group <i>charging-group-name</i> export-using <i>export-method</i> no charging-group <i>charging-group-name</i>
Context	config>aa>group>statistics>aa-sub
Description	This command configures aa-sub accounting statistics for export of charging groups of a given AA ISA group/partition. The no form of the command removes the parameters from the configuration.
Default	none
Parameters	<i>charging-group-name</i> — The name of the charging group. The string is case sensitive and limited to 32 ASCII 7-bit printable characters with no spaces.

Group Commands

export-using *export-method* — Specifies that the method of stats export to be used.

Values accounting, policy, radius-accounting-policy

accounting-policy

Syntax **accounting-policy** *acct-policy-id*

Context config>app-assure>group>statistics>app-grp
config>app-assure>group>statistics>app
config>app-assure>group>statistics>protocol
config>app-assure>group>statistics>aa-sub
config>app-assure>group>statistics>aa-sub-study
config>isa>aa-grp>statistics

Description This command specifies the existing accounting policy to use for AA. Accounting policies are configured in the **config>log>accounting-policy** context.

Parameters *acct-policy-id* — Specifies the existing accounting policy to use for applications.

Values 1 — 99

aggregate-stats

Syntax [**no**] **aggregate-stats**

Context config>app-assure>group>statistics>app-grp

Description This command enables aggregate statistics collection.
The **no** form of the command disables the collection.

protocol

Syntax **protocol**

Context config>app-assure>group>statistics

Description This command enables the context to configure accounting and statistics collection parameters per-system for protocols of application assurance for a given AA ISA group/partition.

aa-sub

Syntax [**no**] **aa-sub** {**esm** *sub-ident-string* | **sap** *sap-id*} | **spoke-sdp** *sdp-id:vc-id* | **transit** *transit-aasub-name*}

Context config>app-assure>group>statistics>aa-sub-study

Description	<p>This command adds an existing subscriber identification to a group of special study subscribers (for example, subscribers for which per subscriber statistics and accounting records can be collected for protocols and applications of application assurance).</p> <p>The no form of the command removes the subscriber from the special study subscribers.</p> <p>Up to 100 subscribers can be configured into the special study group for protocols and up to a 100 potentially different subscribers can be configured into the special study group for applications.</p> <p>When adding a subscriber to the special study group, accounting records and statistics generation will commence immediately. When removing a subscriber from the group, special study statistics and accounting records for that subscriber in the current interval will be lost.</p>
Default	none
Parameters	<p><i>sub-ident-string</i> — The name of a subscriber ID. Note that the subscriber does not need to be currently active. Any sub-ident-string will be accepted. When the subscriber becomes active, statistics generation will start automatically at that time.</p> <p>esm <i>sub-ident-string</i> — Specifies an existing subscriber identification policy name.</p> <p>sap <i>sap-id</i> — Specifies the physical port identifier portion of the SAP definition.</p> <p>spoke-id <i>sdp-id:vc-id</i> — Specifies the spoke SDP ID and VC ID.</p> <p>Values</p> <p>1 — 17407</p> <p>1 — 4294967295</p> <p>transit <i>transit-aasub-name</i> — Specifies an existing transit subscriber name string up to 32 characters in length.</p>

collect-stats

Syntax	[no] collect-stats
Context	<pre>config>app-assure>group>statistics>app-grp config>app-assure>group>statistics>application config>app-assure>group>statistics>protocol config>app-assure>group>statistics>aa-sub config>app-assure>group>statistics>aa-sub-study config>isa>aa-grp>statistics</pre>
Description	This command enables statistic collection within the applicable context.
Default	disabled

exclude-tcp-retrans

Syntax	[no] exclude-tcp-retrans
Context	config>app-assure>group>statistics>aa-sub
Description	This command is to only to EPC. When enabled, TCP errors and retransmission packets are not counted for the purpose of CBC. This setting has no impact on app/app-group aggregate AA stats.

max-throughput-stats

Syntax	[no] max-throughput-stats
Context	config>app-assure>group>statistics>app-sub
Description	This command enables the collection of max-throughput statistics. The no form of the command disables the collection.

protocol

Syntax	protocol protocol-name export-using export-method no protocol
Context	config>app-assure>group>statistics>app-sub
Description	This command configures aa-sub accounting statistics for export of protocols of a given AA ISA group/partition. The no form of the command removes the protocol name.
Default	none
Parameters	<i>protocol-name</i> — Specifies an existing protocol name up to 32 characters in length. export-using <i>export-method</i> — Specifies that the method of stats export to be used. Accounting-policy is the only option for protocol statistics.

radius-accounting-policy

Syntax	radius-accounting-policy rad-acct-plcy-name no radius-accounting-policy
Context	config>aa>group>statistics>aa-sub
Description	This command specifies an existing subscriber RADIUS based accounting policy to use for AA. RADIUS Accounting policies are configured in the config>application-assurance>radius-accounting-policy context.
Parameters	<i>rad-acct-plcy-name</i> — The name of the policy. The string is case sensitive and limited to 32 ASCII 7-bit printable characters with no spaces.

Policy Commands

transit-ip-policy

Syntax	transit-ip-policy ip-policy-id [create] no transit-ip-policy ip-policy-id
---------------	--

Context	config>application-assurance>group>policy
Description	This command defines a transit AA subscriber IP policy. Transit AA subscribers are managed by the system through the use of this policy assigned to services, which determines how transit subs are created and removed for that service. The no form of the command deletes the policy from the configuration. All associations must be removed in order to delete a policy.
Default	no transit-ip-policy
Parameters	<i>ip-policy-id</i> — An integer that identifies a transit IP profile entry. Values 1 — 65535 create — Keyword used to create the entry.

def-app-profile

Syntax	def-app-profile <i>app-profile-name</i> no def-app-profile
Context	config>app-assure>group>policy>transit-ip-policy
Description	This command defines a default app-profile to be associated to dynamically created transit aa-sub created using this profile, when no app-profile is explicitly assigned. The no form of the command removes the default app-profile from the policy.
Parameters	<i>app-profile-name</i> — Specifies the name of the application profile up to 32 characters in length.

detect-seen-ip

Syntax	[no] detect-seen-ip
Context	config>app-assure>group>policy>transit-ip-policy
Description	This command enables seen-IP notification of transit subscriber traffic on the parent transit aa-sub that are referncing this transit-ip-policy. The no form of the command disables seen-IP notification.
Default	no detect-seen-ip

dhcp

Syntax	dhcp
Context	config>app-assure>group>policy>transit-ip-policy
Context	This command enables dynamic DHCP-based management of transit aa-sub for the transit-ip-policy. This is mutually exclusive to other types management of transit subs for a given transit-ip-policy.

ipv6-address-prefix-length

Syntax	ipv6-address-prefix-length <i>IPv6 prefix length</i> no ipv6-address-prefix-length
Context	config>app-assure>group>policy>transit-ip-policy
Description	This command configures a transit IP policy IPv6 address prefix length.
Default	0
Parameters	<i>IPv6 prefix length</i> — Specifies the prefix length of IPv6 addresses in this policy for both static and dynamic transits.
Values	32 — 64

radius

Syntax	radius
Context	config>app-assure>group>policy>transit-ip-policy
Description	This command enables dynamic radius based management of transit aa-subnets for the transit-ip-policy. This is mutually exclusive to other types management of transit subnets for a given transit-ip-policy.

authentication-policy

Syntax	authentication-policy <i>name</i> no authentication-policy
Context	config>app-assure>group>policy>transit-ip-policy>radius
Description	This command configures the RADIUS authentication-policy for the IP transit policy.

seen-ip-radius-acct-policy

Syntax	seen-ip-radius-acct-policy <i>rad-acct-plcy-name</i> no seen-ip-radius-acct-policy
Context	config>app-assure>group>policy>transit-ip-policy>radius
Description	This command refers to a RADIUS accounting-policy to enable seen-IP notification. The no form of the command removes the policy.
Default	no seen-ip-radius-acct-policy

static-aa-sub

Group Commands

Subscribers are managed by the system through the use of subscriber identification strings. A subscriber identification string uniquely identifies a subscriber. For static hosts, the subscriber identification string is explicitly defined with each static subscriber host.

For dynamic hosts, the subscriber identification string must be derived from the DHCP ACK message sent to the subscriber host. The default value for the string is the content of Option 82 CIRCUIT-ID and REMOTE-ID fields interpreted as an octet string. As an option, the DHCP ACK message may be processed by a subscriber identification policy which has the capability to parse the message into an alternative ASCII or octet string value.

When multiple hosts on the same port are associated with the same subscriber identification string they are considered to be host members of the same subscriber.

A sub-ident-policy can also be used for identifying dynamic transit subscriber names.

The **no** form of the command removes the default subscriber identification policy from the SAP configuration.

Default no sub-ident-policy

transit-auto-create

Syntax transit-auto-create

Context config>app-assure>group>transit-ip

Description This command enables seen-IP auto creation of transit subscribers using the transit-IP-policy name and subscriber IP address as the AA-sub name. The default app-profile configured against the transit-ip-policy is applied to these subscribers.

Default disabled

transit-prefix-ipv4-entries

Syntax transit-prefix-ipv4-entries *entries*
no transit-prefix-ipv4-entries

Context config>isa>aa-grp

Description This command defines the number of transit-prefix IPv4 entries for an ISA.
The **no** form of the command removes the assignment of entries space from the configuration. All entries must be removed in order to delete the configuration.

Parameters *entries* — Specifies an integer that determines the number of transit-prefix-ipv4 entries.

Values 0 — 16383

transit-prefix-ipv6-entries

Syntax transit-prefix-ipv6-entries *entries*

no transit-prefix-ipv6-entries

Context	config>isa>aa-grp
Description	<p>This command configures the ISA-AA-group transit prefix IPv6 entry limit for each ISA in the group. This entry space is allocated on the IOM within a common area with the second MDA / ISA position of the IOM and also used for ipv6-filter entries for system SDPs. The per-ISA size allocated for transit-prefix-ipv6 entries should be set to allow sufficient space on the IOM for SDP ipv6-filters.</p> <p>The no form of the command removes the assignment of entries space from the configuration. All entries must be removed in order to delete the configuration.</p>
Parameters	<p><i>entries</i> — Specifies the ISA-AA-Group transit prefix IPv6 entry limit.</p> <p>Values 0 — 8191</p>

transit-prefix-ipv6-remote-entries

Syntax	transit-prefix-ipv6-remote-entries <i>entries</i> no transit-prefix-ipv6-remote-entries
Context	config>isa>aa-grp
Description	<p>This command configures the ISA-AA-group transit prefix IPv6 remote entry limit. This entry space is allocated on the IOM within a common area with the second MDA/ISA position of the IOM and also used for IPv6filter entries for system SDPs. The per-ISA size allocated for transit-prefix-ipv6 entries should be set to allow sufficient space on the IOM for SDP IPv6 filters.</p> <p>The no form of the command removes the assignment of entries space from the configuration. All entries must be removed in order to delete the configuration.</p>
Parameters	<p><i>entries</i> — Specifies the ISA-AA-Group transit prefix IPv6 remote entry limit.</p> <p>Values 0 — 1023</p>

transit-prefix-policy

Syntax	transit-prefix-policy <i>prefix-policy-id</i> [create] no transit-prefix-policy <i>prefix-policy-id</i>
Context	config>service>ies>if>sap config>service>ies>if>spoke-sdp config>service>vprn>if>sap config>service>vprn>if>spoke-sdp config>service>epipe>sap config>service>epipe>spoke-sdp config>service>ipipe>sap config>service>ipipe>spoke-sdp config>service>vpls>sap config>service>vpls>spoke-sdp

Group Commands

Description This command associates a transit aa subscriber prefix policy to the service. The transit prefix policy must be defined prior to associating the policy with a SAP in the `config>application assurance>group>policy>transit-prefix-policy` context.

The **no** form of the command removes the association of the policy to the service.

Parameters *prefix-policy-id* — Specifies an integer that identifies a transit ip profile entry.

Values 1 — 65535

create — Mandatory keyword used when creating transit prefix policy. The **create** keyword requirement can be enabled/disabled in the `environment>create` context.

transit-prefix-policy

Syntax **transit-prefix-policy** *prefix-policy-id* [**create**]
no transit-prefix-policy *prefix-policy-id*

Context `config>app-assure>group`

Description This command defines a transit aa subscriber prefix policy. Transit AA subscribers are managed by the system through the use of this policy assigned to services, which determines how transit subs are created and removed for that service.

The **no** form of the command deletes the policy from the configuration. All associations must be removed in order to delete a policy.

Parameters *prefix-policy-id* — Indicates the transit prefix policy to which this subscriber belongs.

Values 1 — 65535

create — Mandatory keyword used when creating transit prefix policy. The **create** keyword requirement can be enabled/disabled in the `environment>create` context.

entry

Syntax **entry** *entry-id* [**create**]
entry *entry-id*
no entry *entry-id*

Context `config>app-assure>group>transit-prefix-policy`

Description This command configures the index to a specific entry of a transit prefix policy.
The **no** form of the command removes the entry ID from the transit prefix policy configuration.

Default none

Parameters *entry-id* — Specifies a transit prefix policy entry.

Values 1 — 4294967295

aa-sub

Syntax	aa-sub <i>transit-aasub-name</i> no aa-sub
Context	config>app-assure>group>transit-prefix-policy>entry
Description	This command configures a transit prefix policy entry subscriber. The no form of the command removes the transit subscriber name from the transit prefix policy configuration.
Default	none
Parameters	<i>transit-aasub-name</i> — specifies the name of the transit prefix AA subscriber up to 32 characters in length.

match

Syntax	match
Context	config>app-assure>group>transit-prefix-policy>entry
Description	This command enables the context to configure transit prefix policy entry match criteria.

aa-sub-ip

Syntax	aa-sub-ip <i>ip-address[/mask]</i> no aa-sub-ip
Context	config>app-assure>group>transit-prefix-policy>entry>match
Description	This command configures a transit prefix subscriber ip address prefix. It is used when the site is on the local side, being the same side of the system as the parent SAP. The local aa-sub-ip addresses represent the src-IP in the from-SAP direction and dest-IP in the to-SAP direction. The no form of the command deletes the aa-sub-ip address assigned from the entry configuration.
Default	no aa-sub-ip
Parameters	<i>ip-address[/mask]</i> — Specifies the address type of the subscriber address prefix associated with this transit prefix policy entry.
Values	<ip-address[/mask]>: ipv4-address - a.b.c.d[/mask] mask - [1..32] ipv6-address - x:x:x:x:x:x/x/prefix-length x:x:x:x:x:d.d.d.d x - [0..FFFF]H d - [0..255]D prefix-length [1..128]

network-ip

Syntax	network-ip <i>ip-address</i> [/mask] no network-ip
Context	config>app-assure>group>transit-prefix-policy>entry>match
Description	This command configures an entry for an address of prefix transit aa-sub and is used when the site is a remote site on the same opposite side of the system as the parent SAP. The network IP addresses represents the dest-IP in the from-SAP direction and src-IP in the to-SAP direction. The no form of the command removes the network IP address/mask from the match criteria.
Parameters	<i>ip-address</i> [/mask] — specifies the network address prefix and length associated with this transit prefix policy entry.
Values	<ip-address[/mask]>: <ul style="list-style-type: none"> ipv4-address - a.b.c.d[/mask] mask - [1..32] ipv6-address - x:x:x:x:x:x/x/prefix-length x:x:x:x:x:d.d.d.d x - [0..FFFF]H d - [0..255]D prefix-length [1..128]

static-aa-sub

Syntax	static-aa-sub <i>transit-aasub-name</i> static-aa-sub <i>transit-aasub-name</i> app-profile <i>app-profile-name</i> [create] no static-aa-sub <i>transit-aasub-name</i>
Context	config>app-assure>group>transit-prefix-policy config>app-assure>group>transit-ip-policy>static
Description	This command configures a static transit aa-sub with a name and an app-profile. A new transit sub with both a name and an app-profile is configured with the create command. Static transit aa-sub must have an explicitly assigned app-profile. An existing transit sub can optionally be assigned a different app-profile, or this command can be used to enter the static-aa-sub context. The no form of the command deletes the named static transit aa-sub from the configuration.
Parameters	<i>transit-aasub-name</i> — Specifies a transit aasub-name up to 32 characters in length. <i>app-profile-name</i> — Specifies the name of an existing application profile up to 32 characters in length. create — Keyword used to create a new app-profile entry

static-remote-aa-sub

Syntax	static-remote-aa-sub <i>transit-aasub-name</i> static-remote-aa-sub <i>transit-aasub-name</i> app-profile <i>app-profile-name</i> [create] no static-remote-aa-sub <i>transit-aasub-name</i>
---------------	---

Context	config>app-assure>group>transit-prefix-policy
Description	This command configures static remote transit aa-subscribers with a name and an app-profile. Remote transit subscribers are configured for sites on the opposite side of the system as the parent SAP/spoke-SDP. A new remote transit sub with both a name and an app-profile is configured with the create command. Static remote transit aa-subscribers must have an explicitly assigned app-profile. An existing remote transit sub can optionally be assigned a different app-profile. The no form of the command removes the name from the transit prefix policy.
Parameters	<i>transit-aasub-name</i> — Specifies a transit aasub-name up to 32 characters in length. <i>app-profile-name</i> — Specifies the name of an existing application profile up to 32 characters in length. create — Keyword used to create a new app-profile entry

url-filter

Syntax	url-filter <i>url-filter-name</i> [create] no url-filter
Context	config>app-assure>group
Description	This command configures a URL filter action for flows of a specific type matching this entry. If no URL filters are specified then no URL filters will be evaluated.
Parameters	<i>url-filter-name</i> — Specifies the Application-Assurance URL filter that will be evaluated.

default-action

Syntax	default-action allow default-action block-all default-action block-http-redirect <i>http-redirect-name</i> no default-action
Context	config>app-assure>group>policy>aqp>entry>action>url-filter
Description	This command configures the default action to take when the ICAP server is unreachable.
Parameters	allow — Allows all requests. block-all — Blocks all requests. block-http-redirect <i>http-redirect-name</i> — Blocks and redirects requests.

icap-http-redirect

Syntax	icap-http-redirect <i>http-redirect-name</i> no icap-http-redirect
---------------	---

Group Commands

Context	config>app-assure>group>url-filter
Description	This command specifies the HTTP redirect that will be applied when the Internet Content Adaptation Protocol (ICAP) server blocks an HTTP request. This HTTP redirect must exist in the <code>tmnxBsxHttpRedirTable</code> .
Default	none
Parameters	<i>http-redirect-name</i> — Specifies the ICAP HTTP redirect name up to 32 characters in length.

icap-server

Syntax	icap-server <i>ip-address[:port]</i> [create] no icap-server <i>ip-address[:port]</i>
Context	config>app-assure>group>url-filter>icap-server
Description	This command configures the IP address Internet Content Adaptation Protocol (ICAP) server port of the ICAP server.
Default	none
Parameters	<i>ip-address[:port]</i> — the ICAP server IP address and port.

vlan-id

Syntax	vlan-id <i>service-port-vlan-id</i> no vlan-id
Context	config>app-assure>group>url-filter
Description	This command configures the VLAN ID on which the ISA-AA is expected to be emitting traffic.

wap1x

Syntax	wap1x
Context	config>app-assure>group
Description	This command configures the Wireless Application Protocol (WAP) 1.X.

packet-rate-high-wmark

Syntax	packet-rate-high-wmark <i>high-watermark</i>
Context	config>app-assure

Description	This command configures the packet rate on the ISA-AA when a packet rate alarm will be raised by the agent.
Default	max = disabled
Parameters	<i>high-watermark</i> — Specifies the high watermark for packet rate alarms. The value must be larger than or equal to the packet-rate-low-wmark value. Values 1 — 14880952 , max packets/sec
Syntax	packet-rate-low-wmark <i>low-watermark</i> no packet-rate-low-wmark
Context	config>app-assure
Description	This command configures the the packet rate on the ISA-AA when a packet rate alarm will be cleared by the agent. The no form of the command reverts to the default.
Default	0
Parameters	<i>low-watermark</i> — Specifies the low watermark for packet rate alarms. T he value must be lower than or equal to the packet-rate-low-wmark value. Values 0— 14880952 packets/sec

wa-shared-high-wmark

Syntax	wa-shared-high-wmark <i>percent</i> no wa-shared-high-wmark
Context	config>isa>aa-grp>qos>egress>from-sub config>isa>aa-grp>qos>egress>to-sub
Description	This command configures the high watermark for the weighted average utilization of the shared buffer space in the from-subscriber buffer pool for each ISA. When a buffer pool is not in the overload state and the wa-shared buffer utilization for an ISA crosses above the high watermark value in the ISA from-subscriber buffer pool enters an overload state and an overload notification is raised.
Default	100
Parameters	<i>percent</i> — Specifies the weighted average shared buffer utilization high watermark Values 0 — 100

wa-shared-low-wmark

Syntax	wa-shared-low-wmark <i>percent</i> no wa-shared-low-wmark
Context	config>isa>aa-grp>qos>egress>from-sub config>isa>aa-grp>qos>egress>to-sub

Group Commands

Description	This command configures the low watermark for the weighted average utilization of the shared buffer space in the from-subscriber buffer pool. When a buffer pool is in an overloaded state and the weighted average shared buffer utilization for an ISA drops below low watermark value ISA from-subscriber buffer pool leaves the overload state and a is sent to indicate the overload state has cleared.
Default	0
Parameters	<i>percent</i> — Specifies the weighted average shared buffer utilization low watermark
Values	0 — 100

protocol

Syntax	protocol <i>protocol-name</i>
Context	config>app-assure
Description	This command configures the shutdown of protocols system-wide
Parameters	<i>protocol-name</i> — Specifies a shutable (disable) protocol name.

shutdown

Syntax	[no] shutdown
Context	config>app-assure>protocol
Description	This command administratively disables the protocol specified in protocol <i>protocol-name</i> . The no form of the command enables the protocol.

radius-accounting-policy

Syntax	radius-accounting-policy <i>rad-acct-plcy-name</i> [create] no radius-accounting-policy <i>rad-acct-plcy-name</i>
Context	config>app-assure config>aa>group>statistics>aa-sub
Description	This command specifies an existing subscriber RADIUS-based accounting policy to use for AA. RADIUS accounting policies are configured in the config>application-assurance>radius-accounting-policy context.
Default	none
Parameters	<i>name</i> — Specifies the policy name. The string is case sensitive and limited to 32 ASCII 7-bit printable characters with no spaces.

interim-update-interval

Syntax	interim-update-interval <i>minutes</i> no interim-update-interval
Context	config>app-assure>rad-acct-plcy
Description	This command configures the interim update interval. The no form of the command reverts to the default.
Default	no interim-update-interval
Parameters	<i>minutes</i> — Specifies the interval at which subscriber accounting data will be updated. If set no value is specified then no interim updates will be sent. Values 5 — 1080

radius-accounting-server

Syntax	radius-accounting-server
Context	config>app-assure>rad-acct-plcy
Description	This command creates the context for defining RADIUS accounting server attributes under a given session authentication policy.

access-algorithm

Syntax	access-algorithm { direct round-robin } no access-algorithm
Context	config>app-assure>rad-acct-plcy>server
Description	This command configures the algorithm used to access the list of configured RADIUS servers.
Default	direct
Parameters	direct — Specifies that the first server will be used as primary server for all requests, the second as secondary and so on. round-robin — Specifies that the first server will be used as primary server for the first request, the second server as primary for the second request, and so on. If the router gets to the end of the list, it starts again with the first server.

retry

Syntax	retry <i>count</i>
Context	config>app-assure>rad-acct-plcy>server
Description	This command configures the number of times the router attempts to contact the RADIUS server for authentication, if not successful the first time.

Group Commands

The **no** form of the command reverts to the default value.

Default 3

Parameters *count* — Specifies the retry count.

Values 1 — 10

router

Syntax **router** *router-instance*
router *service-name* *service-name*
no router

Context config>app-assure>rad-acct-plcy>server

Description This command specifies the number of times the router attempts to contact the RADIUS server for authentication, if not successful the first time.

The **no** form of the command reverts to the default value.

server

Syntax **server** *server-index* **address** *ip-address* **secret** *key* [**hash** | **hash2**] [**port** *port*] [**create**]
no server *server-index*

Context config>app-assure>rad-acct-plcy>server

Description This command adds a RADIUS server and configures the RADIUS server IP address, index, and key values.

Up to five RADIUS servers can be configured at any one time. RADIUS servers are accessed in order from lowest to highest index for authentication requests until a response from a server is received. A higher indexed server is only queried if no response is received from a lower indexed server (which implies that the server is not available). If a response from a server is received, no other RADIUS servers are queried.

The **no** form of the command removes the server from the configuration.

Default none

Parameters *server-index* — The index for the RADIUS server. The index determines the sequence in which the servers are queried for authentication requests. Servers are queried in order from lowest to highest index.

Values 1 — 16 (a maximum of 5 accounting servers)

address ip-address — The IP address of the RADIUS server. Two RADIUS servers cannot have the same IP address. An error message is generated if the server address is a duplicate.

secret key — **Values** The secret key to access the RADIUS server. This secret key must match the password on the RADIUS server.

secret-key — A string up to 20 characters in length.

hash-key — A string up to 33 characters in length.

hash2-key — A string up to 55 characters in length.

hash — Specifies the key is entered in an encrypted form. If the hash parameter is not used, the key is assumed to be in a non-encrypted, clear text form. For security, all keys are stored in encrypted form in the configuration file with the hash parameter specified.

hash2 — Specifies the key is entered in a more complex encrypted form. If the hash2 parameter is not used, the less encrypted hash form is assumed.

port — Specifies the UDP port number on which to contact the RADIUS server for authentication.

Values 1 — 65535

source-address

Syntax **source-address** *ip-address*
no source-address

Context config>app-assure>rad-acct-plcy>server

Description This command configures the source address of the RADIUS packet. The system IP address must be configured in order for the RADIUS client to work. See Configuring a System Interface in the 7750 SR OS Router Configuration Guide. Note that the system IP address must only be configured if the source-address is not specified. When the no source-address command is executed, the source address is determined at the moment the request is sent. This address is also used in the nas-ip-address attribute: over there it is set to the system IP address if no sourceaddress was given.

The **no** form of the command reverts to the default value.

Default systemIP address

Parameters *ip-address* — The IP prefix for the IP match criterion in dotted decimal notation.

Values 0.0.0.0 - 255.255.255.255

timeout

Syntax **timeout** *seconds*

Context config>app-assure>rad-acct-plcy>server

Description This command configures the number of seconds the router waits for a response from a RADIUS server.

The **no** form of the command reverts to the default value.

Default 5

Parameters *seconds* — Specifies the time the router waits for a response from a RADIUS server.

Values 1 — 90

significant-change

Syntax	significant-change delta no significant-change
Context	config>app-assure>rad-acct-plcy
Description	This command configures the significant change required to generate the record. The no form of the command reverts to the default.
Default	no significant-change
Parameters	delta — Specifies the delta change (significant change) that is required for the charging-group counts to be included in the RADIUS Accounting VSA(s) . Values 0 — 4294967295

System Persistence Commands

persistence

Syntax	persistence
Context	config>system
Description	<p>This command enables the context to configure persistence parameters on the system.</p> <p>The persistence feature enables state on information learned through DHCP snooping across reboots to be retained. This information includes data such as the IP address and MAC binding information, lease-length information, and ingress SAP information (required for VPLS snooping to identify the ingress interface).</p> <p>If persistence is enabled when there are no DHCP relay or snooping commands enabled, it will simply create an empty file.</p>
Default	no persistence

application-assurance

Syntax	application-assurance
Context	config>system>persistence
Description	This command enables the context to configure application assurance persistence parameters.

location

Syntax	location <i>cflash-id</i> no location
Context	config>system>persistence>subscriber-mgmt
Description	<p>This command instructs the system where to write the file. The name of the file is: dhcp-persistence.db. On boot the system scans the file systems looking for dhcp-persistence.db, if it finds it it starts to load it.</p> <p>In the subscriber management context, the location specifies the flash device on a CPM card where the data for handling subscriber management persistency is stored.</p> <p>The no form of this command returns the system to the default. If there is a change in file location while persistence is running, a new file will be written on the new flash, and then the old file will be removed.</p>
Default	no location

ISA Commands

Application Assurance Group Commands

application-assurance-group

Syntax	application-assurance-group <i>application-assurance-group-index</i> [create] [aa-sub-scale <i>sub-scale</i>] no application-assurance-group <i>application-assurance-group-index</i>
Context	config>isa
Description	This command enables the context to create an application assurance group with the specified system-unique index and enables the context to configure that group's parameters. The no form of the command deletes the specified application assurance group from the system. The group must be shutdown first.
Default	none
Parameters	<i>application-assurance-group-index</i> — Specifies an integer to identify the AA group Values 1 create — Mandatory keyword used when creating an application assurance group in the ISA context. The create keyword requirement can be enabled/disabled in the environment>create context. aa-sub-scale <i>sub-scale</i> — Specifies the set of scaling limits that are supported with regards to the maximum number of AA subscribers per ISA and the corresponding policies that can be specified. Values residential: Scaling limits for residential operation. vpn: Scaling limits for VPNs. mobile-gateway: Scaling limits for operation as a mobile gateway. Default residential

backup

Syntax	[no] backup <i>mda-id</i>
Context	config>isa>aa-grp
Description	This command assigns an AA ISA configured in the specified slot to this application assurance group. The backup module provides the application assurance group with warm redundancy when the primary module in the group is configured. Primary and backup modules have equal operational status and when both module are coming up, the ones that becomes operational first becomes the

active module. A module can serve as a backup for multiple AA ISA cards but only one can fail to it at one time.

On an activity switch from the primary module, configurations are already on the backup MDA but flow state information must be re-learned. Any statistics not yet spooled will be lost. Auto-switching from the backup to primary, once the primary becomes available again, is not supported.

Operator is notified through SNMP events when:

- When the AA service goes down (all modules in the group are down) or comes back up (a module in the group becomes active).
- When AA redundancy fails (one of the modules in the group is down) or recovers (the failed module comes back up).
- When an AA activity switch occurred.

The **no** form of the command removes the specified module from the application assurance group.

Default no backup

Parameters *mda-id* — Specifies the card/slot identifying a provisioned module to be used as a backup module.

Values	mda-id:	<i>slot/mda</i>
	slot	1 — up to 10 depending on chassis model
	mda	1 — 2

divert-fc

Syntax **[no] divert-fc** *fc-name*

Context config>isa>aa-grp

Description This command selects a forwarding class in the system to be diverted to an application assurance engine for this application assurance group. Only traffic to/from subscribers with application assurance enabled is diverted.

To divert multiple forwarding classes, the command needs to be executed multiple times specifying each forwarding class to be diverted at a time.

The **no** form of the command stops diverting of the traffic to an application assurance engine for this application assurance group.

Default no divert-fc

Parameters *fc-name* — Creates a class instance of the forwarding class *fc-name*.

Values be, l2, af, l1, h2, ef, h1, nc

fail-to-open

Syntax **[no] fail-to-open**

Context config>isa>aa-grp

Group Commands

Description	This command configures mode of operation during an operational failure of this application assurance group when no application assurance engines are available to service traffic. When enabled, all traffic that was to be inspected will be dropped. When disabled, all traffic that was to be inspected will be forwarded without any inspection as if the group was not configured at all.
Default	no fail-to-open

isa-capacity-cost-high-threshold

Syntax	isa-capacity-cost-high-threshold <i>threshold</i> no isa-capacity-cost-high-threshold
Context	config>isa>aa-grp
Description	This command configures the ISA-AA capacity cost high threshold. The no form of the command reverts the threshold to the default value.
Default	4294967295
Parameters	<i>threshold</i> — Specifies the capacity cost high threshold for the ISA-AA group. Values 0 — 4294967295

isa-capacity-cost-low-threshold

Syntax	isa-capacity-cost-low-threshold <i>threshold</i> no isa-capacity-cost-low-threshold
Context	config>isa>aa-grp
Description	This command configures the ISA-AA capacity cost low threshold. The no form of the command reverts the threshold to the default value.
Default	0
Parameters	<i>threshold</i> — Specifies the capacity cost low threshold for the ISA-AA group. Values 0 — 4294967295

isa-overload-cut-through

Syntax	[no] isa-overload-cut-through
Context	config>isa>aa-grp
Description	This command configures the ISA group to enable cut-through of traffic if an overload event occurs, triggered when the IOM weighted average queues depth exceeds the wa-shared-high-wmark. In this ISA state, packets are cut-through from application analysis but retain subscriber context with default subscriber policy applied.

The **no** form of the command disables cut-through processing on overload.

Default isa-overload-cut-through

partitions

Syntax **[no] partitions**

Context config>isa>aa-grp

Description This command enables partitions within an ISA-AA group. When enabled, partitions can be created. The **no** form of the command disables partitions within an ISA-AA group.

Default disabled

primary

Syntax **[no] primary mda-id**

Context config>isa>aa-grp

Description This command assigns an AA ISA module configured in the specified slot to this application assurance group. Primary and backup ISAs have equal operational status and when both ISAs are coming up, the one that becomes operational first becomes the active ISA.

On an activity switch from the primary ISA, all configurations are already on the backup ISA but flow state information must be re-learned. Any statistics not yet spooled will be lost. Auto-switching from the backup to primary, once the primary becomes available again, is not supported.

Operator is notified through SNMP events when:

- When AA service goes down (all ISAs in the group are down) or comes back up (an ISA in the group becomes active)
- When AA redundancy fails (one of the ISAs in the group is down) or recovers (the failed MDA comes back up)
- When an AA activity switch occurred.

The **no** form of the command removes the specified ISA from the application assurance group.

Default no primary

Parameters *mda-id* — Specifies the slot/mda identifying a provisioned AA ISA.

Values	mda-id:	<i>slot/mda</i>
	slot	1 — up to 10 depending on chassis model
	mda	1 — 2

qos

Syntax **qos**

Group Commands

Context config>isa>aa-grp

Description This command enables the context for Quality of Service configuration for this application assurance group.

statistics

Syntax **statistics**

Context config>isa>aa-grp

Description This command enables the context to configure statistics generation.

performance

Syntax **performance**

Context config>isa>aa-grp>statistics

Description This command configures the ISA group to enable the aa-performance statistic record. This record contains information on the traffic load and resource consumption for each ISA in the group, to allow tracking of ISA load for long term capacity planning and short term anomalies. The user can configure the accounting policy to be used, and enables the record using the [no]collect-stats command

egress

Syntax **egress**

Context config>isa>aa-grp>qos

Description This command enables the context for IOM port-level Quality of Service configuration for this application assurance group in the egress direction (traffic entering an application assurance engine).

from-subscriber

Syntax **from-subscriber**

Context config>isa>aa-grp>qos>egress

Description This command enables the context for Quality of Service configuration for this application assurance group form-subscriber logical port, traffic entering the system from AA subscribers and entering an application assurance engine.

pool

Syntax	pool [<i>pool-name</i>] no pool
Context	config>isa>aa-grp>qos>egress>from-subscriber config>isa>aa-grp>qos>egress>to-subscriber config>isa>aa-grp>qos>ingress
Description	This command enables the context to configure an IOM pool as applicable to the specific application assurance group traffic. The user can configure resv-cbs (as percentage) values and slope-policy similarly to other IOM pool commands.
Default	default
Parameters	<i>pool-name</i> — The name of the pool.
	Values default

resv-cbs

Syntax	resv-cbs <i>percent-or-default</i> no resv-cbs
Context	config>isa>aa-grp>qos>egress>from-subscriber>pool config>isa>aa-grp>qos>egress>to-subscriber>pool config>isa>aa-grp>qos>ingress>pool
Description	<p>This command defines the percentage or specifies the sum of the pool buffers that are used as a guideline for CBS calculations for access and network ingress and egress queues. Two actions are accomplished by this command.</p> <ul style="list-style-type: none"> • A reference point is established to compare the currently assigned (provisioned) total CBS with the amount the buffer pool considers to be reserved. Based on the percentage of the pool reserved that has been provisioned, the over provisioning factor can be calculated. • The size of the shared portion of the buffer pool is indirectly established. The shared size is important to the calculation of the instantaneous-shared-buffer-utilization and the average-shared-buffer-utilization variables used in Random Early Detection (RED) per packet slope plotting. <p>Note that this command does not actually set aside buffers within the buffer pool for CBS reservation. The CBS value per queue only determines the point at which enqueueing packets are subject to a RED slope. Oversubscription of CBS could result in a queue operating within its CBS size and still not able to enqueue a packet due to unavailable buffers. The resv-cbs parameter can be changed at any time.</p> <p>If the total pool size is 10 MB and the resv-cbs set to 5, the ‘reserved size’ is 500 KB.</p> <p>The no form of this command restores the default value.</p>
Default	default (30%)
Parameters	<i>percent-or-default</i> — Specifies the pool buffer size percentage.
	Values 0 — 100, default

Group Commands

slope-policy

Syntax	slope-policy <i>name</i> no slope-policy
Context	config>isa>aa-grp>qos>egress>from-subscriber>pool config>isa>aa-grp>qos>egress>to-subscriber>pool config>isa>aa-grp>qos>ingress>pool
Description	This command specifies an existing slope policy which defines high and low priority RED slope parameters and the time average factor. The slope policy is defined in the config>qos>slope-policy context.

queue-policy

Syntax	queue-policy <i>network-queue-policy-name</i> no queue-policy
Context	config>isa>aa-grp>qos>egress>from-subscriber config>isa>aa-grp>qos>egress>to-subscriber config>isa>aa-grp>qos>ingress
Description	This command assigns an IOM network queue policy as applicable to specific application assurance group traffic.
Default	default
Parameters	<i>network-queue-policy-name</i> — The name of the network queue policy defined in the system.

wa-shared-high-wmark

Syntax	wa-shared-high-wmark <i>percent</i> no wa-shared-high-wmark
Context	config>isa>aa-grp>qos>egress>from-sub config>isa>aa-grp>qos>egress>to-sub
Description	This command configures the high watermark for the weighted average utilization of the shared buffer space in the from-subscriber buffer pool for each ISA. When a buffer pool is not in the overload state and the wa-shared buffer utilization for an ISA crosses above the high watermark value in the ISA from-subscriber buffer pool enters an overload state and an overload notification is raised.
Default	100
Parameters	<i>percent</i> — Specifies the weighted average shared buffer utilization high watermark Values 0 — 100

wa-shared-low-wmark

Syntax	wa-shared-low-wmark <i>percent</i> no wa-shared-low-wmark
Context	config>isa>aa-grp>qos>egress>from-sub config>isa>aa-grp>qos>egress>to-sub
Description	This command configures the low watermark for the weighted average utilization of the shared buffer space in the from-subscriber buffer pool. When a buffer pool is in an overloaded state and the wa-shared buffer utilization for an ISA drops below low watermark value ISA from-subscriber buffer pool leaves the overload state and a is sent to indicate the overload state has cleared.
Default	
Default	0
Parameters	<i>percent</i> — Specifies the weighted average shared buffer utilization low watermark Values 0 — 100

port-scheduler-policy

Syntax	port-scheduler-policy <i>port-scheduler-policy-name</i> no port-scheduler-policy
Context	config>isa>aa-grp>qos>egress>from-subscriber config>isa>aa-grp>qos>egress>to-subscriber
Description	This command assigns an existing port scheduler policy as applicable to the specific application assurance group traffic.
Default	default
Parameters	<i>port-scheduler-policy-name</i> — specifies the name of an existing port scheduler policy.

to-subscriber

Syntax	to-subscriber
Context	config>isa>aa-grp>qos>egress
Description	This command enables the context for Quality of Service configuration for this application assurance group to-subscriber logical port, traffic destined to AA subscribers and entering an application assurance engine.

ingress

Syntax	ingress
Context	config>card>mda>network>ingress
Description	This command enables the context for MDA-level IOM Quality of Service configuration.

